


R-Value Zones within the US



The Department of Energy recommends using different insulation levels based on regional climate zones to increase energy efficiency.

Locate your zone on the map and cross check it with the chart below to determine the correct R-Value for your project.

Zone #	Attic	Wall	Floor	Crawlspaces
7	R49 to R60	R13 to R21	R25 to R30	R25 to R30
6	R49 to R60	R13 to R21	R25 to R30	R25 to R30
5	R38 to R60	R13 to R21	R25 to R30	R25 to R30
4	R38 to R60	R13 to R21	R25 to R30	R25 to R30
3	R30 to R60	R13 to R21	R25	R19 to R25
2	R30 to R49	R13 to R21	R13	R13 to R19
1	R30 to R49	R13 to R21	R13	R13