
CORDLESS TIRE INFLATOR USER MANUAL



CZK-3671

Contents

AFETY INSTRUCTIONS	2
RODUCT DESCRIPTION	2
PERATING INSTRUCTIONS	3
PECIFICATIONS	5
EATURES	6
SING TIPS	6
USTOMER SERVICE	6

SAFETY INSTRUCTIONS

- Read and follow all instructions before use.
- Keep the product out of reach of children.
- 3. Do not expose the air inflator to rain or water of any kind.
- 4. Do not use the product for applications outside of its intended use.
- 5. Do not disassemble and assemble this product without permission. 6. Do not store the air inflator in high temperature or humid environments.
- 7. Do not place the air inflator near hot sources, such as your vehicle's exhaust
- 8. Do not use the air inflator near flammable liquids or in gaseous or explosive
- 9. Check inflation tube for weak and worn conditions before each use, make sure all connections are secure. Don't use if the defect is found.
- 10. Do not use the air inflator if the power button doesn't power it on or off. An inflator can't be controlled by power button is dangerous.
- 11. Keep the air inflator dry, clean, and free from oil and grease. Please use dry cloth to clean it.

PRODUCT DESCRIPTION

Product details

- 3 Display screen 4 Power button
- USB output 6 Unit switch/LED flashlight switch

 $0 \ 0 \ 0 \ 0 \ 0$

Hole for lanyard

Inflation tube port

LED flashlight

Nozzles storage area








button for about 3s to inflator with the tire valve. power on the air inflator.

Accessories



OPERATIING INSTRUCTIONS

1. Battery status and charge



When turn on the inflator:

1. If the battery indicator is always blue. 1.If the battery indicator is red the battery it indicates that the battery is high.

When charge the inflator:


Battery charge

2.If the battery indicator is blue, the battery 2. If the battery indicator flashes, it indicates that the battery is low. is fully charged.

2. Instructions for use



the air inflator





Press the "U" button to choose the correct unit then press "+" or "-" button to preset the desired tire pressure




inflating when it reaches

the preset pressure.

Single-click the power button to start the air inflator to inflate.

3. Lighting instructions




⚠ Attention: Need to press the button **v** first to power on the air inflator

4. Preset tire pressure

Press the "U" button to choose the correct unit, then press "+" or "-" button to preset the tire pressure value. Wait for a few seconds until the number stops flashing. Then press the power button to start the tire inflator to inflate. The air inflator will automatically stop inflating when it reaches the preset pressure.

Tire pressure	2.50 BAR	(a) (b)	Battery status Power on/start button Unit switch button
			Unit display

5. Nozzles storage area



SPECIFICATIONS

Product name	Cordless Tire Inflator
Model No.	CZK-3671
Voltage	12.6V
Inflation tube length	10.81 IN
USB type	Type-C

FEATURES

- 1. Fast inflating, low noise.
- Built-in extra-large capacity lithium battery.
- 3. Small, compact, portable and easy to store.
 - 4. Preset tire pressure, automatically inflate and stop.
 - 5. Cordless air compressor to pump items, safe and convenient
 - 6. Super bright LED flashlight and 4 optional units, PSI, bar, kPa, kg/cm². 7. Our pump is suitable for bicycles, motorcycles, Lawn mower tires, small and
- medium cars including SUV but do not support big truck tires, Van, bus, RV.

USING TIPS

- Please fully charge it before using it for the first time. 2. The product will auto shut off in 40s if you don't use it for a long time.
- 3. Avoid extended and continuous use. The max time for continuous use is
- 4. After extended use, let the inflator to rest for 10 minutes to continue to use it.
- 5. The inflation tube may heat up during continuous use, please don't touch it while inflating or after use. Let it cool down for a few minutes.

CUSTOMER SERVICE

service@nulksen.com





CE ROHS FC