

How to use the Lindr Cooler

Step 1 – Power


Simply plug the unit into the nearest power source in clean and dry area.



Step 2 – Keg connection

- Locate securely
- Push handle down firmly until you hear/feel a click

Don't be too cautious. Once connected do not remove until keg is empty.



Step 3 – Turn the Compressor on

- Switch to the on position


Machine will start. Pressure is pre-set – it will start/stop automatically.



How to use the Lindr Cooler

Step 4 – Temperature control

- Turn clockwise to '3' when starting the cooler
- Adjust depending on how cold you like your product



Step 5 – Flow Control

- Down = Fast, Up = Slow
- Once set to a comfortable level you can leave this in place.



Step 6 – Pour (and enjoy!)

- Use cool, clean glass
- Hold under tap at 45 degrees
- Pull handle (decisively)

The first couple of pours will be frothy, but this will go away quickly as the cooler chills the product.

