

PLATFORM	SYSTEM	NHA Noun	PART NUMBER	Alt PN	NOMENCLATURE	NSN
A-10	Displays	--	93-2010	93-1040	HUD CCTVS Camera	5821-01-468-6516
A-10	Gun System, GAU-8A	--	205F426	MC5879-2	HYDRAULIC DRIVE	1005-01-042-9710
A-10	Gun System, GAU-8A	--	205F138	MC5879-1	HYDRAULIC DRIVE	1005-01-046-3540
A-10	Gun System, GAU-8A	--	209F149	MC5879-3	HYDRAULIC DRIVE	1005-01-059-1394
A-10	Gun System, GAU-8A	--	217F456	--	HYDRAULIC DRIVE ASSEMBLY (OVERHAUL)	1005-01-180-9674
A-10	Gun System, GAU-8A	--	217F455	--	HYDRAULIC DRIVE ASSEMBLY (OVERHAUL)	1005-01-183-9088
A-10	VARIOUS		704100-2	160C145902-3	DUAL MODE AMPLIFIER	5826-01-011-8514
A-10 E-3 F-5 F-15 F-16	AN/APX-101	RECEIVER- TRANSMITTER,RADIO IDENTIFICATION	139658	--	CIRCUIT CARD ASSEMBLY	5998-00-339-7006
A-2	Survival Systems	--	129547-1	--	RADIO BEACON	5826-01-278-9791
A-2	Survival Systems	--	125370-1	--	RADIO BEACON AIRFOIL	5826-01-279-1332
A-6 F-111	AN/ALQ-99		120535-11	--	POWER SUPPLY	6130-01-077-3582
A-7	AN/APQ-122	Radar Reciever	658020-1	--	OSCILLATOR (SSLO)	5841-00-411-3473
A-7	Displays	--	102894G1	--	T.V. MONITOR	5821-01-102-2277
AC-130	AVQ-17		1213-0600	--	TRACKING MOUNT	6230-00-231-2530
AH-64	Displays	IHADSS	BG1165AB01		Display Electronic Unit (DEU)	1240-01-478-8928
AH-64	Displays	IHADSS	7-319420001-3	--	Sensor Surveying Unit (SSU)	1270-01-159-7994
AH-64	Displays	IHADSS	LG1127AB01	LG1127AB01-2	Sensor Surveying Unit (SSU)	1270-01-159-7994
AH-64	Displays	IHADSS	10090939-102	10090939-101	Tube & Cable Assembly (T&C) w/o CRT	1270-01-181-2108
AH-64	Displays	IHADSS	10090939-102	10090939-101	Tube & Cable Assembly (T&C) w/ CRT	1270-01-181-2108
AH-64	Displays	IHADSS	7-319440010-3	LG1120AB	INTEGRATED HELMET UNIT (IHU) ) (LG)	1270-01-181-3314
AH-64	Displays	IHADSS	LG1120AB04	LG1120AB	INTEGRATED HELMET UNIT (IHU) (LG)	1270-01-181-3314
AH-64	Displays	IHADSS	LG1122AB05	7-319440000-3	INTEGRATED HELMET UNIT (IHU) (MED)	1270-01-182-3719
AH-64	Displays	IHADSS	7-319430041-3	BG1113AB01	Display Electronic Unit (DEU)	1270-01-183-0518
AH-64	Displays	IHADSS	BG1114AB02	--	Sight Electronic Unit (SEU)	1270-01-183-0519
AH-64	Displays	IHADSS	7-319430002-5	CG1082AB01	Display Adjust Panel (DAP)	1270-01-211-6346
AH-64	Displays	IHADSS	CG1082AB01	7-319430002-3	Display Adjust Panel (DAP)	1270-01-211-6346
AH-64	Displays	IHADSS	7-319430031-7	BG1114AB03	Sight Electronic Unit (SEU)	1270-01-232-4442
AH-64	Displays	IHADSS	LG1205AB01	LG1205AA01	INTEGRATED HELMET UNIT (IHU) (XLG)	1270-01-263-2545
AH-64	Displays	IHADSS	7-319410001-3	HG1063AB01	Replacement	1270-01-291-9334
AH-64	Displays	IHADSS	7-319410001-3	HG1063AB01	Replacement	1270-01-291-9334
AH-64	Displays	IHADSS	HG1063AB02	7-319410001	Replacement	1270-01-291-9334
AH-64	Displays	IHADSS	HG1063AB02	7-319410001	Replacement	1270-01-291-9334
AH-64	Displays	IHADSS	LG1122AB05	7-319440000-5	INTEGRATED HELMET UNIT (IHU) (MED)	1270-01-295-6255
AH-64	Displays	IHADSS	LG1120AB05	7-319440010-5	INTEGRATED HELMET UNIT (IHU) (LG)	1270-01-298-3544
AH-64	Displays	IHADSS	10130279-101	--	Tube & Cable Assembly (T&C) w/o CRT	1270-01-331-0174
AH-64	Displays	IHADSS	10130279-101	--	Tube & Cable Assembly (T&C) w/ CRT	1270-01-331-0174
AH-64	Displays	IHADSS	LG1157AB01	--	INTEGRATED HELMET UNIT (IHU)	1270-01-461-5273
AH-64	Displays	IHADSS	LG1156AB01	--	INTEGRATED HELMET UNIT (IHU)	1270-01-461-5274
AH-64	Displays	IHADSS	LG1206AA01	--	INTEGRATED HELMET UNIT (IHU)	1270-01-461-5277
AH-64	Displays	IHADSS	10130279-102	--	Tube & Cable Assembly (T&C) w/o CRT	1270-01-473-7713
AH-64	Displays	IHADSS	10130279-102	--	Tube & Cable Assembly (T&C) w/ CRT	1270-01-473-7713
AH-64	Displays	IHADSS	LG1284AB01	--	INTEGRATED HELMET UNIT (IHU)	1270-01-518-6058

AH-64	Displays	IHADSS	IH-003A-00		Tube & Cable Assembly (T&C) w/o CRT	1270-01-539-2638
AH-64	Displays	IHADSS	IH-003A-00		Tube & Cable Assembly (T&C) w/ CRT	1270-01-539-2638
AH-64	Displays	IHADSS	7-519430002-003	95500A-00	DISPLAY DRIVER UNIT (DDU)	1270-01-553-1145
AH-64	Displays	IHADSS	95750A-00	7-519410001-003	w/o CRT	1270-01-553-1146
AH-64	Displays	IHADSS	95750A-00	7-519410001-003	w/ CRT	1270-01-553-1146
AH-64	Displays	IHADSS	7-519430041-003		ENHANCED DISPLAY UNIT	1270-01-553-1147
AH-64	Displays	IHADSS	IH-017A-01	--	Enhanced Display Electronics Unit (EDEU)	1270-01-553-1147
AH-64	Displays	IHADSS	7-319430031-9	--	Sight Electronic Unit (SEU)	1270-01-557-4596
AH-64	Displays	IHADSS	BG1114AB04	--	Sight Electronic Unit (SEU)	1270-01-557-4596
AH-64	Displays	IHADSS	95752A-00		Tube & Cable Assembly (T&C) w/o CRT	1270-01-564-6012
AH-64	Displays	IHADSS	95752A-00		Tube & Cable Assembly (T&C) w/ CRT	1270-01-564-6012
AH-64	Displays	IHADSS	95752A-02		Tube & Cable Assembly (T&C) w/o CRT	1270-01-582-4184
AH-64	Displays	IHADSS	95752A-02		Tube & Cable Assembly (T&C) w/ CRT	1270-01-582-4184
AH-64	Displays	IHADSS	IH-024A-01	32-01109-01	HELMET TEST SET (HOLT)	4931-01-534-1228
AH-64	Displays	IHADSS	CG1274AB01	--	Display Adjust Panel (DAP) NVG w/o HVPS	5850-01-530-1818
AH-64	Displays	IHADSS	CG1274AB01	--	Display Adjust Panel (DAP) NVG w/ HVPS	5850-01-530-1818
AH-64	Displays	IHADSS	CG1134AB01	--	Display Adjust Panel (DAP) w/o HVPS	5850-01-530-1822
AH-64	Displays	IHADSS	CG1134AB01	--	Display Adjust Panel (DAP) w/ HVPS	5850-01-530-1822
AH-64	Displays	IHADSS	CG1134AB01	--	Display Adjust Panel (DAP) w/ Retrofit	5850-01-530-1822
AH-64	Displays	IHADSS	HG1074AB01		Replacement	5855-01-558-9357
AH-64	Displays	IHADSS	HG1074AB01		Replacement	5855-01-558-9357
AH-64	Displays	IHADSS	10078758-101	--	WIRING HARNESS w/o Harness Cable	5995-01-186-8601
AH-64	Displays	IHADSS	10078758-101	--	WIRING HARNESS w/ Harness Cable	5995-01-186-8601
AH-64	Displays	IHADSS	10097699-102		Tube & Cable Assembly (T&C) w/o CRT with Upgrade	6150-01-394-3076
AH-64	Displays	IHADSS	10097699-102		Tube & Cable Assembly (T&C) w/CRT with Upgrade	6150-01-394-3076
AH-64	Displays	IHADSS	10146612-101		Tube & Cable Assembly (T&C) w/o CRT	6150-01-442-8868
AH-64	Displays	IHADSS	10146612-101		Tube & Cable Assembly (T&C) w/ CRT	6150-01-442-8868
AH-64	Displays	IHADSS	IH-92900A-00	--	WIRING HARNESS w/o Harness Cable	6150-01-534-0552
AH-64	Displays	IHADSS	IH-92900A-00	--	WIRING HARNESS w/ Harness Cable	6150-01-534-0552
AH-64	Displays	IHADSS	BG1164AB02	BG1164AB01	Sight Electronic Unit (SEU)	NSL
AH-64	Displays	IHADSS	LG1155AB01	--	Sensor Surveying Unit (SSU)	NSL
AH-64			MB574E-04	--	MISSION PROCESSOR	
B-52	AN/ALQ-155 AN/ALT-28		10-30496-1	--	WAVEGUIDE SWITCH	5985-00-098-7346
B-52	AN/ASK-7		675-11300-605	980-1050-004	CONTROLLER, TRANSMITTER	1280-01-116-3832
B-52	AN/ASK-7		980-1050-004	--	CONTROLLER, TRANSMITTER	1280-01-116-3832
B-52	AN/ASK-7		675-11300-603	980-1052-001	DATA TRAN.CART.MOUNT	7025-01-104-2962
B-52	AN/ASK-7		980-1052-001	--	DATA TRANSFER UNIT	7025-01-104-2962
B-52			1221R2	--	MOTIONAL TRANSDUCER	6695-01-249-6166
Bradley	Stores Management	--	12470930	--	TURRENT PROCESSING UNIT	5895-01-485-3489
Bradley	Stores Management	--	12470930-1	70930A-00	TURRENT PROCESSING UNIT II	5895-01-570-0283
Bradley	Stores Management	TURRENT PROCESSING UNIT	12470923	--	CCA CARD ASSY	5998-01-485-3464
Bradley	Stores Management	TURRENT PROCESSING UNIT	12479314	--	GPP CCA	5998-01-496-0374
Bradley	Stores Management	TURRENT PROCESSING UNIT	12479315	--	FCP CCA	5998-01-496-0375
Bradley	Stores Management	TURRENT PROCESSING UNIT	12479314-01	479314-01	GPP CCA	5998-01-569-3043
Bradley	Stores Management	TURRENT PROCESSING UNIT	12479315-01	479315-01	FCP CCA	5998-01-570-0286

Bradley	Stores Management	TURRENT PROCESSING UNIT	12470923-10	--	CCA CARD ASSY	NSL
Bradley			12976176-20	--	GUNNER'S HAND STATION	1290-01-465-8591
C-130	AAQ/MC130E		708398-1	--	LENS INFRARED	5855-01-073-7232
C-130	AN/AAQ-17	PIPE TO TUBE ADAPTER	2962938-1	--	BACKPLANE ASSEMBLY	5998-01-265-8564
C-130	AN/AJQ-24		1214-0600-3	--	TRACKING MOUNT	1270-00-090-6778
C-130	AN/AJQ-24		1214-0600-2M	--	TRACKING MOUNT	1270-01-235-9961
C-130	AN/AJQ-24		1214-0600-3M	--	TRACKING MOUNT	1270-01-235-9962
C-130	AN/APN-169		8318-0610-1	--	SWITCH ASSY C-130	5930-01-216-3233
C-130	AN/ASD-5		6790703-502	--	CONTROL DSP UNIT	5826-00-172-7787
C-130	AN/ASD-5		7036790-501	--	CIRCUIT CARD ASSEMBLY	5998-01-338-7108
C-130	AN/ASD-5		7036800-501	--	CIRCUIT CARD ASSEMBLY	5998-01-338-7109
C-130	AN/ASD-5		7036810-501	--	CIRCUIT CARD ASSEMBLY	5998-01-338-7117
C-130	AN/ASD-5 DIRECTION FINDER		6790918-501	--	SIGNAL SOURCE	4920-00-469-8488
C-130	AN/AVQ-19	LASER TARGET/DESIGNATOR	3278840	--	CONTROL, INDICATOR	1270-00-138-3077
C-130	AN/AVQ-19		3278800	--	POWER SUPPLY	6130-00-138-3073
C-130	AVQ-19A	LASER TARGET/DESIGNATOR	3278705	--	RECEIVER	1270-00-138-3069
C-130	BEACON SET,RADIO,AN/URT 26		102052	--	AIRFOIL, CRASH POSITION BEACON	5826-00-947-2525
C-130	BENCH SET,ANURT26	SEMICONDUCTOR DEVICES,UNITIZED	109043	MT3712AURT26	MOUNT RELEASE UNIT (MRU)	5826-00-250-0077
C-130	BENCH SET,ANURT26		109044	MT3765AURT26	MOUNT ASSEMBLY	5826-00-250-0080
C-130	BENCH SET,ANURT26		103265	111714	INDICATOR AIRFOIL	5826-00-948-1992
C-130	Communications	ENAMEL	8465	3-43512-3	PRESSURE TRANSMITTER	6685-00-526-7864
C-130	CONTROL DISLPAY UNIT		7036686-501	--	REG ASSEMBLY	6110-01-354-8430
C-130	CONTROL DISPLAY UNIT		7036700-501	--	PC BOARD	5998-01-319-3894
C-130	CONTROL DISPLAY UNIT		7036710-503	7036710-501	PC BOARD	5998-01-319-3895
C-130	CONTROL DISPLAY UNIT		7036720-503	7036720-501	PC BOARD	5998-01-320-2180
C-130	Electronic Warfare (EW)	--	1D8830G2	--	INTERFERENCE BLANKER	5895-01-373-6667
C-130	MX-9411/AAQ-7		20030-2	--	LASERHEAD	5860-01-230-2990
C-130	NIGHT VISION EQPT		342619-1	--	EMIT BOARD	5998-01-067-4182
C-130	PANEL,INDICATOR	TAPE,IDENTIFICATION	518-28007-923	28007-923	ENCODING ALTIMETER	6610-01-358-7582
C-130	TEST KIT,TARGET POD		518-28007-921	--	ENCODING ALTIMETER	6610-01-212-6464
C-130	TEST SET,LASER	LAMP,INCANDESCENT	3282500	--	TEST SET	4920-00-145-5159
C-130	TRAINABLE GUN MOUNT		9282412-10	7881896-011	MANIFOLD ASSY, GUN MOUNT	4730-00-127-6308
C-130	VARIOUS	CODER,COMMAND SIGNALS	8008-2021-1	--	OSCILLATING GROUP	5955-01-158-1249
C-130	VARIOUS	LASER R/T	3278780	--	POWER SUPPLY	1270-00-138-3070

C-130	VARIOUS		3278783	--	CRYSTAL ASSEMBLY	1270-00-138-3071
C-130	VARIOUS		6791000-502	--	ANTENNA PREAMP	1270-00-172-7784
C-130	VARIOUS		6790735-502	--	DATA PROCESSOR	1270-00-238-4773
C-130	VARIOUS		6790811-501	--	MODULE PROCESSOR	1270-00-480-6822
C-130	VARIOUS		6791198-501	--	READOUT ASSEMBLY	1270-00-483-8190
C-130	VARIOUS		7036754-501	--	DATA PROCESSOR	1270-01-313-5307
C-130	VARIOUS		7881896-011	--	MANIFOLD ASSY, GUN MOUNT	4730-00-127-6308
C-130	VARIOUS		7882007-011	--	MANIFOLD ASSY, GUN MOUNT	4730-00-148-8530
C-130	VARIOUS		9282412-30	7882007-011	MANIFOLD ASSY, GUN MOUNT	4730-00-148-8530
C-130	VARIOUS		342611-1	--	PROCESSOR	5855-01-067-4090
C-130	VARIOUS		342615-1	--	GATED LEVEL	5855-01-067-4091
C-130	VARIOUS		342622-1	--	ANALOG ASSEMBLY	5855-01-067-4092
C-130	VARIOUS		342626-1	--	ANALOG ASSEMBLY	5855-01-067-4093
C-130	VARIOUS		342630-1	--	CONTROL	5855-01-067-4094
C-130	VARIOUS		342638-1	--	HEATSINK ASSEMBLY	5855-01-067-4095
C-130	VARIOUS		342650-1	--	CONTROL	5855-01-067-4096
C-130	VARIOUS		342661-1	--	CONTROL	5855-01-067-4097
C-130	VARIOUS		342669-1	--	CIRCUIT CARD ASSEMBLY	5855-01-073-2355
C-130	VARIOUS		7036853-501	--	PEDESTAL	5985-01-313-3451
C-130	VARIOUS		20590	--	STAB AMPLIFIER	5996-01-361-4421
C-130	VARIOUS		3278680	--	CIRCUIT CARD ASSEMBLY	5998-00-138-0969
C-130	VARIOUS		3278760	--	CIRCUIT CARD ASSEMBLY	5998-00-138-0975
C-130	VARIOUS		3278770	--	CIRCUIT CARD ASSEMBLY	5998-00-138-0976
C-130	VARIOUS		3278810	--	CIRCUIT CARD ASSEMBLY	5998-00-138-0977
C-130	VARIOUS		3278820	--	CIRCUIT CARD ASSEMBLY	5998-00-138-0978
C-130	VARIOUS		3278830	--	CIRCUIT CARD ASSEMBLY	5998-00-138-0979
C-130	VARIOUS		3278850	--	ELECTRONIC COMPONENT	5998-00-138-0980
C-130	VARIOUS		3278979	--	COMPONENT ASSEMBLY	5998-00-139-9374
C-130	VARIOUS		3282520	--	CIRCUIT CARD ASSEMBLY	5998-00-140-8422
C-130	VARIOUS		6791189-501	--	PC BOARD	5998-00-432-5989
C-130	VARIOUS		2439815-1	--	BACKPLANE ASSEMBLY	5998-01-253-7916
C-130	VARIOUS		7036730-501	--	PC BOARD	5998-01-320-2181
C-130	VARIOUS		6790786-501	SG959ASD5	GENERATOR	6625-00-497-3066
C-130	VARIOUS		982412-10	--	MANIFOLD ASSY AC-130	NSL
C-130			540-25100-004	--	ALTITUDE ALTERER	1680-01-201-5691
C-130			915-38106-001	--	POWER SUPPLY	6130-01-217-5880
C-130			915-25100-005	--	ALTITUDE ALTERER	6340-01-394-9780
C-130			4932-052	570-2392-012	ALTIMETER	6610-01-074-2819
C-130			570-2392-012	43932-052	ALTIMETER	6610-01-074-2819
C-130			630-37070-235	--	SAT/TAS COMPUTER	6610-01-101-1905
C-130			518-28007-204	--	ENCODING ALTIMETER	6610-01-259-0251
C-130			532-38105-202	--	AIRSPEED	6610-01-263-1400
C-130	AN/ALQ-117 JAMMING POD	STARTER,MOTOR	2612599G002	--	POWER SUPPLY	6130-00-254-0149
C-130	AN/ALQ-117 JAMMING POD	STARTER,MOTOR	72D0330-1	2612599G002	POWER SUPPLY	6130-00-254-0149
C-130	VARIOUS	FAIRING,AIRCRAFT	886160-1	--	DRIVE	5855-01-067-4103
C-130	VARIOUS		814808-1	--	DEMOM ASSEMBLY	5855-01-067-4184
C-130						
C-141B	AN/APN-169		421480	8008-0020	OSCILLATOR SUBASSEMBLY	5841-01-159-6052
C-130						
C-141B	AN/APN-169		8008-0020-1	8008-0020	OSCILLATOR SUBASSEMBLY	5841-01-159-6052

C-130 C-141B	AN/APN-169		8008-0020-2	8008-0020	OSCILLATOR SUBASSEMBLY	5841-01-159-6052
C-130 KC-135	AN/APN-59E(V) RADAR RECEIVER TRANSMITTER	BOLT,MACHINE	1887904	--	CIRCUIT CARD ASSEMBLY	5998-01-054-2841
C-130 KC-135	VARIOUS		1886752	--	LIGHTNING ARRESTOR	5920-01-011-2639
C-130 NVGs	Displays	AN/AVS-7(V)	MA834A-01	--	SIGNAL DATA CONVERTER	1680-01-535-3418
C-130 NVGs	Displays	AN/AVS-7(V)	125200-003	SU-5043/AVS-503	DISPLAY UNIT (DU) W/O OPTICAL UNIT or CRT REPLACEMENT	5855-01-478-6583
C-130 NVGs	Displays	AN/AVS-7(V)	125200-003	SU-5043/AVS-503	DISPLAY UNIT (DU) W/ OPTICAL UNIT or CRT REPLACEMENT	5855-01-478-6583
C-130 NVGs	Displays	AN/AVS-7(V)	125200-003	SU-5043/AVS-503	DISPLAY UNIT (DU) W/OPTICAL UNIT & CRT REPLACEMENT	5855-01-478-6583
C-130 NVGs	Displays	AN/AVS-7(V)	125110-001	ECMK738A01M	SDC V1	5895-01-361-8986
C-130 NVGs	Displays	AN/AVS-7(V)	125110-001	CV-4229(V)1/AVS-7	SDC V1	5895-01-424-2280
C-130 NVGs	Displays	AN/AVS-7(V)	ECMK735A03M	CV-4229(V)1/AVS-7	SDC V1	5895-01-424-2280
C-130 NVGs	Displays	AN/AVS-7(V)	125110-004	CV-4229(V)2/AVS-7	SDC V2	5895-01-424-2281
C-130 NVGs	Displays	AN/AVS-7(V)	ECMK735C01M	CV-4229(V)2/AVS-7	SDC V2	5895-01-424-2281
C-130 NVGs	Displays	AN/AVS-7(V)	125110-002	CV-4229(V)4/AVS-7	SDC V4	5895-01-424-2283
C-130 NVGs	Displays	AN/AVS-7(V)	ECMK598A01M	CV-4229(V)4/AVS-7	SDC V4	5895-01-424-2283
C-130 NVGs	Displays	AN/AVS-7(V)	125110-006	CV-4229(V)6/AVS7	SDC V6	5895-01-446-8594
C-130 NVGs	Displays	AN/AVS-7(V)	ECMK735D01M	CV-4229(V)6/AVS7	SDC V6	5895-01-446-8594
C-130 NVGs	Displays	AN/AVS-7(V)	125110-003	CV-4229(V)5/AVS7	SDC V5	5895-01-447-3999
C-130 NVGs	Displays	AN/AVS-7(V)	ECMK598A-00	CV-4229(V)5/AVS7	SDC V5	5895-01-447-3999
C-130 NVGs	Displays	AN/AVS-7(V)	125110-007	CV-4229(V)7/AVS7	ADV SDC NON BUSSED	5895-01-459-3050
C-130 NVGs	Displays	AN/AVS-7(V)	ECMA834B-00	CV-4229(V)7/AVS7	ADV SDC NON BUSSED	5895-01-459-3050
C-130 NVGs	Displays	AN/AVS-7(V)	MA834B-01	CV-4229(V)7/AVS7	ADV SDC NON BUSSED	5895-01-459-3050
C-130 NVGs	Displays	AN/AVS-7(V)	125110-008	CV-4229(V)8/AVS7	ADV SDC BUSSED	5895-01-459-3051
C-130 NVGs	Displays	AN/AVS-7(V)	ECMA834A-00	CV-4229(V)8/AVS7	ADV SDC BUSSED	5895-01-459-3051
C-130 NVGs	Displays	AN/AVS-7(V)	125118-001	A040567100M	POWER SUPPLY CCA	5950-01-370-4022
C-130 NVGs	Displays	AN/AVS-7(V)	A040567102	A040567100M	POWER SUPPLY CCA	5950-01-370-4022
C-130 NVGs	Displays	AN/AVS-7(V)	125114-001	--	AVS-7, SDC, CPM CCA	5998-01-370-8273

C-130 NVGs	Displays	AN/AVS-7(V)	125112-001	A040567000M	SDA CCA	5998-01-370-8274
C-130 NVGs	Displays	AN/AVS-7(V)	A041785002M	A040567000M	SDA CCA	5998-01-370-8274
C-130 NVGs	Displays	AN/AVS-7(V)	125116-007	A015640B-00	SDR CCA	5998-01-470-7465
C-130 NVGs	Displays	AN/AVS-7(V)	125114-004	--	AVS-7, SDC, CPM CCA	5998-01-470-7467
C-130 NVGs	Displays	AN/AVS-7(V)	125116-004	--	AVS-7, SDC CCA	5998-01-470-7468
C-130 NVGs	Displays	AN/AVS-7(V)	125114-008	A015297A-00	CPM CCA	5998-01-470-7470
C-130 NVGs	Displays	AN/AVS-7(V)	125112-002	--	SDA CCA	5998-01-470-7473
C-130 NVGs	Displays	AN/AVS-7(V)	125114-006	--	AVS-7, SDC, CPM CCA	5998-01-470-7477
C-130 NVGs	Displays	AN/AVS-7(V)	125116-006	--	AVS-7, SDC CCA	5998-01-470-7478
C-130 NVGs	Displays	AN/AVS-7(V)	125114-002	--	AVS-7, SDC, CPM CCA	5998-01-470-7479
C-130 NVGs	Displays	AN/AVS-7(V)	125114-007	A015297B-00	CPM CCA	5998-01-470-7481
C-130 NVGs	Displays	AN/AVS-7(V)	125200-001	ECMK765A01M	DISPLAY UNIT (DU) W/O OPTICAL UNIT or CRT REPLACEMENT	7025-01-362-0980
C-130 NVGs	Displays	AN/AVS-7(V)	125200-001	ECMK765A01M	DISPLAY UNIT (DU) W/ OPTICAL UNIT or CRT REPLACEMENT	7025-01-362-0980
C-130 NVGs	Displays	AN/AVS-7(V)	125200-001	ECMK765A01M	DISPLAY UNIT (DU) W/OPTICAL UNIT & CRT REPLACEMENT	7025-01-362-0980
C-130 NVGs	Displays	AN/AVS-7(V)	ECMK765A01M	--	DISPLAY UNIT (DU) W/O OPTICAL UNIT or CRT REPLACEMENT	7025-01-362-0980
C-130 NVGs	Displays	AN/AVS-7(V)	ECMK765A01M	--	DISPLAY UNIT (DU) W/ OPTICAL UNIT or CRT REPLACEMENT	7025-01-362-0980
C-130 NVGs	Displays	AN/AVS-7(V)	ECMK765A01M	--	DISPLAY UNIT (DU) W/OPTICAL UNIT & CRT REPLACEMENT	7025-01-362-0980
C-130 NVGs	Displays	AN/AVS-7(V)	SU-180/AVS-7	ECMK765A01M	DISPLAY UNIT (DU) W/O OPTICAL UNIT or CRT REPLACEMENT	7025-01-362-0980
C-130 NVGs	Displays	AN/AVS-7(V)	SU-180/AVS-7	ECMK765A01M	DISPLAY UNIT (DU) W/ OPTICAL UNIT or CRT REPLACEMENT	7025-01-362-0980
C-130 NVGs	Displays	AN/AVS-7(V)	SU-180/AVS-7	ECMK765A01M	DISPLAY UNIT (DU) W/OPTICAL UNIT & CRT REPLACEMENT	7025-01-362-0980
C-130 NVGs	Displays	AN/AVS-7(V)	125110-010	CV-5193/AVS-503	SIGNAL PROCESSOR	7025-01-478-6730
C-130 NVGs	Displays	AN/AVS-7(V) SDC	125150-001	ECMK736A01M	CONVERTER CONTROL UNIT	5895-01-361-9003
C-130 NVGs	Displays	AN/AVS-7(V) SDC	125150-001	C-12293/AVS-7	CONVERTER CONTROL UNIT	5895-01-361-9003
C-130 NVGs	Displays	AN/AVS-7(V) SDC	125150-003	ECMK736A01M	CONVERTER CONTROL UNIT	5895-01-470-7475
C-17	AN/FRC-178(V)	ELBOW,PIPE	193506	--	SYNCHRO, TRANSMITTER	5990-01-227-0660
E-3	AN/APY-1		647R751G01	647R751G02	RADAR SET SUBASSEMBLY	5841-01-066-3140
E-3	AN/APY-1		647R751G02	--	AN/APY-1	5841-01-066-3140
E-3	AN/APY-1		684R936G01	--	RADAR SET SUBASSEMBLY	5841-01-106-9769
E-3	RECEIVER,RADIO		2039143-0504	--	CIRCUIT CARD ASSEMBLY	5998-01-242-6654
E-3	RECEIVER,RADIO		2039144-0519	--	CPU BOARD	5998-01-242-6657

E-3	RECEIVER,RADIO		2039134-0503	--	POWER SUPPLY	5998-01-243-8715
E-3	RECEIVER,RADIO		2039138-0505	--	CIRCUIT CARD ASSEMBLY	5998-01-243-8745
E-3	RECEIVER,RADIO		2039145-0503	--	INTERFACE UNIT	5998-01-243-8748
E-3	RECEIVER,RADIO		2039148-0503	--	SYNCHRONIZER ASSEMBLY	5998-01-243-8751
E-3	RECEIVER,RADIO		2039147-0505	--	CIRCUIT CARD ASSEMBLY	5998-01-244-6146
E-3	VARIOUS		522-4280-01	522-4280-101	RECEIVER, RADIO	5826-01-017-0367
E-3	VARIOUS		2041234-3418	--	RADIO RECEIVER	5826-01-187-4387
E-8	JOINT STARS TARGET RADAR SYSTEM		F5014-01	--	LIGHTNING ARRESTOR	5920-01-365-5151
EC-135	PACER LINK	--	441-10040-502	441-10040-501	ELECTRONIC CONTOL PANEL	5895-01-196-4361
EC-135	PACER LINK	--	702309-1	441-10041-1	KEYER CONTROL	5895-01-197-8770
EC-135	PACER LINK	--	441-10014-505	--	ELECTRONIC CONTOL PANEL	5895-01-310-7485
EC-135	PACER LINK	--	441-10013-504	--	COMMUNICATION MODEM	5895-01-311-1185
EC-135	PACER LINK	C-11504/ARC-171X(V)	441-10040-501	--	ELECTRONIC CONTOL PANEL	5895-01-196-4361
EC-135	PACER LINK	RT-1270(V)3/ARC-171X(V)	441-10041-1	--	KEYER CONTROL	5895-01-197-8770
EC-135	PACER LINK	RT-1270(V)3/ARC-171X(V)	441-10041-501	441-10041-1	KEYER CONTROL	5895-01-197-8770
EC-135	PACER LINK	UHF LINE OF SIGHT	441-10022-506	--	MODULATOR	5998-01-291-9965
EC-135	PACER LINK		441-10040-1	441-10040-501	ELECTRONIC CONTOL PANEL	5895-01-196-4361
EC-135	PACER LINK		441-10031-504	441-10031-501	CCA	5998-01-236-6358
EC-135	PACER LINK		441-10022-505	--	CCA MODULATOR (PACER LINK)	5998-01-250-9814
EC-135	PACER LINK		441-10064-501	--	CCA MODULATOR (PACER LINK)	5998-01-310-7481
EC-135	PACER LINK		441-10025-510	441-10025	MODULATOR CCA	5998-01-310-7482
EC-135	PACER LINK		441-10025-512	441-10025	MODULATOR CCA	5998-01-310-7482
EC-135	PACER LINK		441-10025-513	441-10025	MODULATOR CCA	5998-01-310-7482
EC-135	PACER LINK		441-10028-509	--	CIRCUIT CARD ASSEMBLY	5998-01-311-2858
EC-135	PACER LINK		441-10054-505	--	CCA	5998-01-311-3771
EC-135	PACER LINK		441-10067-510	--	CCA	5998-01-311-5134
EC-135	PACER LINK		441-10022-504	--	PACER LINK CCA	NSL
EC-135	PACER LINK		441-10031-503	--	CCA	NSL
EC-135 E-6	GLOBAL POSITIONING SYSTEM		218-0057-030	218-0057-031	RUBIDIUM OSCILLATOR	6625-01-343-3026
F/A-18	Displays		MB560C-02	--	UFCDR	1260-01-548-0780
F/A-18	Displays		MB560C-02	--	UFCDR w/Glass Replacement	1260-01-548-0780
F/A-18	Displays		MB561C-02	--	CONTROL-DISPLAY UNIT	1680-01-548-0779
F/A-18	Displays		MB561C-02	--	CONTROL-DISPLAY UNIT w/ Glass Repair	1680-01-548-0779
F-111	AN/ALQ-137 V		5919159G1	5919159 G1	POWER SUPPLY	6130-01-073-2381
F-15	AN/GSM-397		A31U29819-1	--	ELECTRONIC PLUG-IN-UNIT	6625-01-432-6713
F-15	AN/GSM-397		A31U29684-4	--	SIGNAL GENERATOR	6625-01-432-7288
F-15	AN/GSM-397		A31U29705-1	5410C-55-3	ELECTRONIC PLUG-IN-UNIT	6625-01-432-8461
F-15	AN/ALQ-135 JAMMING POD	CABLE ASSEMBLY	150-019709-003	--	POWER SUPPLY	6130-00-603-5366
F-15	AN/ALQ-135 JAMMING POD	INSERT,CUTTING TOOL	150-019997-003	150-019997-005	POWER SUPPLY	6120-01-032-1232

F-15	AN/ALQ-135 JAMMING POD	RESISTOR, FIXED, FILM	150-019966-003	150-019966-002	POWER SUPPLY	6130-00-603-5392
F-15	AN/ALQ-135 JAMMING POD		150-021045-003	--	MODULATOR, TWT (2U1)	5865-00-607-8147
F-15	AN/ALQ-135 JAMMING POD		057-000637-003	--	ANTENNA BAND 2	5985-01-030-4159
F-15	AN/APG-63	Antenna	5124962	--	ANTENNA ARRAY	5985-01-407-6148
F-15	AN/APG-63		3402065-1	--	AZ READOUT	5985-01-171-3031
F-15	AN/APG-63		3402065-2	--	CONTROL ANTENNA	5985-01-279-4742
F-15	AN/APG-63 Fire Control Radar		MPS538-1	MPS538	MIXER, STAGE FREQUENCY	5895-01-159-6859
F-15	AN/APG-63 RADAR	BUSHING, SLEEVE	3527655-5	3527655	RF LOGIC/RELAY SW ASSEMBLY	5895-01-120-2188
F-15	AN/APG-63 RADAR	BUSHING, PIPE	MPS384	--	MIXER, STAGE FREQUENCY	5895-00-613-2145
F-15	AN/APG-63 RADAR	COVER, ANTI-ICING OA	3464700	--	RF Generator	5895-01-015-4312
F-15	AN/APG-63 RADAR	GENERATOR, ALTERN ATI/ RAMP 4R1	3523112	--	BULK MEMORY CCA	5998-01-058-8792
F-15	AN/APG-63 RADAR	MICROCIRCUIT, DIGITA L	3334270-2	--	SOLENOID POWER SUPPLY ASSEMBLY	5841-01-047-5880
F-15	AN/APG-63 RADAR	RAMP4R1/LATCH	3523104	--	DATA MEMORY CCA	5998-01-058-9033
F-15	AN/APG-63 RADAR		3514100	--	RADAR SET SUBASSEMBLY	5841-01-047-5879
F-15	AN/APG-63 RADAR		3334045-3	--	MODULATOR ASSEMBLY	5841-01-062-3047
F-15	AN/APG-63 RADAR		3334045-5	--	MODULATOR ASSEMBLY	5841-01-067-9265
F-15	AN/APG-63 RADAR		3334045-10	--	MODULATOR ASSEMBLY	5841-01-224-7835
F-15	AN/APG-63 RADAR		259128-1	MPS538-2	MIXER STAGE, FREQ APG-63	5895-01-158-5979
F-15	AN/APG-63 RADAR		290-01-06900	MPS538-2	MIXER STAGE, FREQ APG-63	5895-01-158-5979
F-15	AN/APG-63 RADAR		MPS538-2	--	MIXER, STAGE FREQUENCY	5895-01-158-5979
F-15	AN/APG-63 RADAR		182300	MPS538	MIXER, STAGE FREQUENCY	5895-01-159-6859
F-15	AN/APG-63 RADAR		259128	MPS538	MIXER, STAGE FREQUENCY	5895-01-159-6859
F-15	AN/APG-63 RADAR		MPS538	MPS538	MIXER, STAGE FREQUENCY	5895-01-159-6859
F-15	AN/APG-63 RADAR		3377300-1	--	TWO BAND ANTENNA ARRAY	5985-01-063-0856
F-15	AN/APG-63 RADAR		3514150	--	RADIO FREQUENCY AMPLIFIER	5996-01-047-5953
F-15	AN/APG-63 RADAR		3267128	--	RADAR DATA PROCESSOR CCA	5998-01-003-2062
F-15	AN/APG-63 RADAR		3334210-5	--	TWT POWER SUPPLY	6130-01-072-5622
F-15	AN/APG-63 RADAR		3334210-7	--	TWT POWER SUPPLY	6130-01-217-6657
F-15	AN/APG-63 RADAR		3334210-6	--	RADAR POWER SUPPLY	6130-01-241-5796
F-15	AN/APM-349		14200000	--	TEST SET INTERROGATOR	6625-00-169-1698
F-15	AN/APX-76	CAM, GEARBOX	119416	--	REPLACEMENT	5895-00-117-4115
F-15	AN/APX-76		119415-4	--	RECEIVER TRANSMITTER	5895-01-272-8047
F-15	DISPLAY		659-101000-71	--	PANEL, INDICATOR	1680-01-157-2424
F-15	Gun System, M61A1	--	201F685	--	HYDRAULIC DRIVE ASSEMBLY	1005-01-003-3371
F-15	Gun System, M61A1		209F204	MC13852	GUN DRUM DRIVE	1005-01-052-2784
F-15	TEST SET, CATHODE RAY TUBE	BEARING, WASHER, TH RUST	8002265-902	--	ELECTRONIC CONTROL PANEL	1290-01-215-3269
F-15			707-7005	--	Grip Assy	1290-01-231-4653
F-15			707-7008	--	GRIP ASSEMBLY, CONTROLLER	1290-01-345-9798
F-15			707-7009	--	GRIP ASSEMBLY, CONTROLLER	1290-01-345-9799
F-15			707-7011	--	CONTROLLER GRIP ASSY.	1290-01-407-3205
F-15			707-7010	--	CONTROLLER GRIP ASSY.	1290-01-407-5343
F-15			730-2013	--	GRIP THROTTLE	1680-01-118-5194
F-15			730-2014	--	CONTROL ASSEMBLY, QU	1680-01-225-7244
F-15			A31U29500-1	--	SIGNAL GENERATOR	6625-01-408-5615



F-16	AN/AAQ-13 LANTIRN	SPACER,SPECIAL SHAPED	717513600	K600A240-01	DEROLL ACTUATOR	1270-01-391-4749
F-16	AN/AAQ-13 LANTIRN	SPACER,SPECIAL SHAPED	717513600-001	K600A240-01	DEROLL ACTUATOR	1270-01-391-4749
F-16	AN/ALQ-155	PAD,PACKAGING	058-001717	ICL-4-32634	LOG VIDEO AMP	5865-01-080-4028
F-16	AN/ALQ-155		30D00500-1	10-30496-1	WAVEGUIDE SWITCH	5985-00-098-7346
F-16	AN/ALQ-155		30D02300	--	WAVEGUIDE SWITCH ALQ-155	NSL
F-16	AN/ALQ-155; AN/ALT-28		431232	10-30496-1	WAVEGUIDE SWITCH	5985-00-098-7346
F-16	AN/ALQ-155; AN/ALT-28		7938408-01	--	WAVEGUIDE SWITCH	5985-01-156-6558
F-16	AN/ALQ-184 JAMMING POD	CABLE ASSEMBLY, SPECIAL PURPOSE, ELECTRICAL	G254008-1	2445-2	ROTARY PUMP	4320-01-206-6333
F-16	AN/ALQ-184 JAMMING POD	CABLE ASSEMBLY, SPECIAL PURPOSE, ELECTRICAL	G254008-1V1	2445-2	ROTARY PUMP	4320-01-206-6333
F-16	AN/ALQ-184 JAMMING POD		350005-1	--	ROTARY PUMP	4320-01-375-9939
F-16	AN/ALQ-184 JAMMING POD		G254008-1V2	350005-1	ROTARY PUMP	4320-01-375-9939
F-16	AN/ALR-69 & 46 RADAR WARNING RECEIVER	Control, Receiver, Countermeasures	77D0069-1	82-052795-01	POWER SUPPLY	6130-01-058-5927
F-16	AN/ALR-69 RADAR WARNING RECEIVER	PACKING WITH RETAINER	32-054576-01	--	POWER SUPPLY	6130-01-059-1470
F-16	AN/APG-66 Fire Control Radar	--	682R669G01	16VE009002-6	Radar Transmitter w/o TWT Replacement	1270-01-093-2256
F-16	AN/APG-66 Fire Control Radar	--	682R669G01	16VE009002-6	Radar Transmitter w/ TWT Replacement	1270-01-093-2256
F-16	AN/APG-66 Fire Control Radar	--	681R622G02	--	LPRF	1270-01-102-2962
F-16	AN/APG-66 Fire Control Radar	--	681R622G04	--	LPRF	1270-01-102-2963
F-16	AN/APG-66 Fire Control Radar	--	681R622G01	--	LPRF	1270-01-102-2965
F-16	AN/APG-66 Fire Control Radar	--	681R622G03	--	LPRF	1270-01-102-2966
F-16	AN/APG-66 Fire Control Radar	--	783R240G01	--	PROGRAMMABLE SIGNAL PROCESSOR (PSP)	1270-01-399-8233
F-16	AN/APG-66 Fire Control Radar	--	781R130G01	781R130	LPRF (V)2	1270-01-410-9915
F-16	AN/APG-66 Fire Control Radar	--	781R130G02	781R130	LPRF (V)2	1270-01-416-0083
F-16	AN/APG-66 Fire Control Radar	--	781R130G04	781R130	LPRF (V)2	1270-01-416-0085
F-16	AN/APG-66 Fire Control Radar	--	781R130G03	781R130	LPRF (V)2	1270-01-416-0086
F-16	AN/APG-66 Fire Control Radar	--	783R217G03	783R217	LPRF (V)3	5481-01-412-9543
F-16	AN/APG-66 Fire Control Radar	--	29200-99	16VE039001-9	INDICATOR UNIT-RADAR (REO)	5841-01-096-3945

F-16	AN/APG-66 Fire Control Radar	--	783R217G01	783R217	LPRF (V)3	5841-01-393-3631
F-16	AN/APG-66 Fire Control Radar	--	781R129G01	781R129	Radar Transmitter (V)2 w/o TWT Replacement	5841-01-398-7211
F-16	AN/APG-66 Fire Control Radar	--	781R129G01	781R129	Radar Transmitter (V)2 w/ TWT Replacement	5841-01-398-7211
F-16	AN/APG-66 Fire Control Radar	--	783R217G04	783R217	LPRF (V)3	5841-01-413-1419
F-16	AN/APG-66 Fire Control Radar	--	783R217G02	783R217	LPRF (V)3	5841-01-415-6066
F-16	AN/APG-66 Fire Control Radar	--	682R707G01	--	ANTENNA	5985-01-093-2174
F-16	AN/APG-66 Fire Control Radar	--	750R400G01	--	ANTENNA	5985-01-146-4630
F-16	AN/APG-66 Fire Control Radar	--	768R063G01	--	ANTENNA (V)1	5985-01-293-5451
F-16	AN/APG-66 Fire Control Radar	--	768R109G01	--	ANTENNA (V)	5985-01-308-3647
F-16	AN/APG-66 Fire Control Radar	--	780R440G01	--	ANTENNA (V)3	5985-01-398-7383
F-16	AN/APG-66 Fire Control Radar	--	780R823G01	--	ANTENNA (V)2	5985-01-410-9914
F-16	AN/APG-66 Fire Control Radar	(V)2 Antenna	589R337H01	589R337H02	PHASE SHIFT DRIVE ASSEMBLY	5915-01-422-7391
F-16	AN/APG-66 Fire Control Radar	(V)2 Antenna	803R599G01	--	POWER SUPPLY	6130-01-451-9498
F-16	AN/APG-66 Fire Control Radar	Antenna	646R499G01	--	RESOLVER BUFFER	1270-01-061-5082
F-16	AN/APG-66 Fire Control Radar	Antenna	681R290G01	--	AZ/EL COMPENSATION POWER AMPLIFIER	5996-01-077-8077
F-16	AN/APG-66 Fire Control Radar	Antenna	750R469G01	--	POWER SUPPLY	6130-01-146-4687
F-16	AN/APG-66 Fire Control Radar	CIRCUIT CARD ASSEMBLY	29245-79	29245-69	ELECTRON TUBE	5960-01-084-4987
F-16	AN/APG-66 Fire Control Radar	CIRCUIT CARD ASSEMBLY	29245-79A	29245-69	ELECTRON TUBE	5960-01-084-4987
F-16	AN/APG-66 Fire Control Radar	COVER ASSMEBLY	1040-110	586R667H01	POWER SUPPLY ION PUMP	6130-01-211-4193
F-16	AN/APG-66 Fire Control Radar	COVER ASSMEBLY	1040-119	586R667H01	POWER SUPPLY ION PUMP	6130-01-211-4193
F-16	AN/APG-66 Fire Control Radar	COVER ASSMEBLY	1140-119	586R667H01	POWER SUPPLY ION PUMP	6130-01-211-4193
F-16	AN/APG-66 Fire Control Radar	CWI	587R663H01	587R663	MICROWAVE EXCITER	5841-01-287-6108
F-16	AN/APG-66 Fire Control Radar	CWI	587R663H02	--	MICROWAVE EXCITER	5841-01-287-6109
F-16	AN/APG-66 Fire Control Radar	CWI	587R663H03	--	MICROWAVE EXCITER	5841-01-287-6110
F-16	AN/APG-66 Fire Control Radar	CWI	587R663H04	--	MICROWAVE EXCITER	5841-01-287-6111
F-16	AN/APG-66 Fire Control Radar	CWI	774R008G01	766R333G01	RADAR SET SUBASSEMBLY	5841-01-287-9848
F-16	AN/APG-66 Fire Control Radar	CWI	774R008G02	766R333	RADAR SET SUBASSEMBLY	5841-01-287-9849

F-16	AN/APG-66 Fire Control Radar	CWI	774R008G03	--	RADAR SET SUBASSEMBLY	5841-01-287-9850
F-16	AN/APG-66 Fire Control Radar	CWI	774R008G04	766R333	RADAR SET SUBASSEMBLY	5841-01-287-9851
F-16	AN/APG-66 Fire Control Radar	DMT	785R262G01	--	RF MONITOR BOARD ASSEMBLY	5998-01-220-4050
F-16	AN/APG-66 Fire Control Radar	FCP	16C0612-803	--	PROG SEQUENCER CCA	5998-01-398-8928
F-16	AN/APG-66 Fire Control Radar	FCP	16C0612-801	--	PROG SEQUENCER CCA	6615-01-072-0096
F-16	AN/APG-66 Fire Control Radar	Fire Control Computer	682R535G01	--	MOTHER BOARD	1270-01-101-3600
F-16	AN/APG-66 Fire Control Radar	LPRF	681R317G03	--	REFERENCE SOURCE ASSEMBLY	1270-01-075-9674
F-16	AN/APG-66 Fire Control Radar	LPRF	646R861G01	--	Radar Receiver	1270-01-077-0710
F-16	AN/APG-66 Fire Control Radar	LPRF	583R292H02	--	OSCILLATOR	1270-01-077-0714
F-16	AN/APG-66 Fire Control Radar	LPRF	583R290H01	583R290H02	OSCILLATOR	1270-01-077-0718
F-16	AN/APG-66 Fire Control Radar	LPRF	583R290H02	--	OSCILLATOR	1270-01-077-0718
F-16	AN/APG-66 Fire Control Radar	LPRF	681R317G04	--	REFERENCE SOURCE ASSEMBLY	1270-01-077-0724
F-16	AN/APG-66 Fire Control Radar	LPRF	681R317G02	--	REFERENCE SOURCE ASSEMBLY	1270-01-085-4653
F-16	AN/APG-66 Fire Control Radar	LPRF	681R317G01	--	REFERENCE SOURCE ASSEMBLY	1270-01-086-0716
F-16	AN/APG-66 Fire Control Radar	LPRF	583R936H01	583R936H04	FREQUENCY MULTIPLIER	1270-01-096-7120
F-16	AN/APG-66 Fire Control Radar	LPRF	583R936H02	583R936H04	FREQUENCY MULTIPLIER	1270-01-096-7120
F-16	AN/APG-66 Fire Control Radar	LPRF	583R936H04	MO2X222B	FREQUENCY MULTIPLIER	1270-01-096-7120
F-16	AN/APG-66 Fire Control Radar	LPRF	682R732G01	--	PHASE LOCK LOOP	1270-01-099-3205
F-16	AN/APG-66 Fire Control Radar	LPRF	682R727G01	--	LOW NOISE ASSEMBLY	1270-01-099-3206
F-16	AN/APG-66 Fire Control Radar	LPRF	583R936H03	FS-9082	FREQUENCY MULTIPLIER	1270-01-222-3541
F-16	AN/APG-66 Fire Control Radar	LPRF	583R936H05	--	FREQUENCY MULTIPLIER	1270-01-343-8506
F-16	AN/APG-66 Fire Control Radar	LPRF	775R733G01	--	LOW NOISE ASSEMBLY	1270-01-406-8455
F-16	AN/APG-66 Fire Control Radar	LPRF	583R534H08	--	RECEIVER PROTECTOR	5895-01-086-8056
F-16	AN/APG-66 Fire Control Radar	LPRF	583R290H03	583R292H03	OSCILLATOR	5955-01-393-9603
F-16	AN/APG-66 Fire Control Radar	LPRF	682R720G01	--	SAMPLE DATA BOARD	5998-01-097-2459
F-16	AN/APG-66 Fire Control Radar	LPRF	682R717G01	--	CONTROLLER 2 BOARD ASSEMBLY	5998-01-101-5290
F-16	AN/APG-66 Fire Control Radar	LPRF	688R012G01	--	SAMPLE DATA BOARD	5998-01-107-0140

F-16	AN/APG-66 Fire Control Radar	LPRF	765R581G01	--	CONTROLLER BOARD #1	5998-01-280-8685
F-16	AN/APG-66 Fire Control Radar	LPRF	785R145G01	--	LPRF CONTROLLER #2 CCA	5998-01-407-8999
F-16	AN/APG-66 Fire Control Radar	LPRF	681R112G01	--	POWER SUPPLY	6130-01-077-0836
F-16	AN/APG-66 Fire Control Radar	LPRF	589R014H01	--	POWER SUPPLY	6130-01-443-1216
F-16	AN/APG-66 Fire Control Radar	MLPRF	586R212H06	586R212	RECEIVER/TRANSMITTER	5841-01-353-9263
F-16	AN/APG-66 Fire Control Radar	NUT,SELF-LOCKING, ROUND	756R545G01	756R967G01	ELECTRONIC COMPONENTS ASSEMBLY	5998-01-132-5749
F-16	AN/APG-66 Fire Control Radar	NUT,SELF-LOCKING, ROUND	688R639G01	--	MICM/MICC DIGITAL MODULE	5998-01-132-6877
F-16	AN/APG-66 Fire Control Radar	PSP	688R648G01	--	CIRCUIT CARD ASSEMBLY	5998-01-132-6880
F-16	AN/APG-66 Fire Control Radar	RADAR ELECTRO-OPTICAL UNIT (REO)	10068961-102	--	RADAR RECEIVER	5841-01-100-0080
F-16	AN/APG-66 Fire Control Radar	RADAR ELECTRO-OPTICAL UNIT (REO)	10068951-103	10068951	RADAR TRANSMITTER	5841-01-125-1598
F-16	AN/APG-66 Fire Control Radar	RADAR ELECTRO-OPTICAL UNIT (REO)	29650-19	29650	E.U. PSI POWER SUPPLY	6130-01-114-6824
F-16	AN/APG-66 Fire Control Radar	RC Computer	681R621G01	--	CONTROLLER 1 BOARD ASSEMBLY	5998-01-099-3253
F-16	AN/APG-66 Fire Control Radar	RC Computer	681R608G01	--	ARITHMETIC UNIT BOARD ASSEMBLY	5998-01-099-5200
F-16	AN/APG-66 Fire Control Radar	RC Computer	682R885G01	--	AIRCRAFT SERIAL INTERFACE 1 BOARD ASSEMBLY	5998-01-101-3774
F-16	AN/APG-66 Fire Control Radar	RC Computer	682R917G01	--	RADAR SERIAL INTERFACE BOARD ASSEMBLY	5998-01-101-3776
F-16	AN/APG-66 Fire Control Radar	RC Computer	681R606G01	--	CONTROL UNIT BOARD ASSEMBLY	5998-01-103-0374
F-16	AN/APG-66 Fire Control Radar	RC Computer	682R459G01	--	CIRCUIT CARD ASSEMBLY	5998-01-103-5943
F-16	AN/APG-66 Fire Control Radar	RC Computer	682R973G01	--	ANALOG CONVERSION AND CONTROL ASSEMBLY	5998-01-104-5867
F-16	AN/APG-66 Fire Control Radar	RC Computer	759R963G01	--	AIRCRAFT SERIAL INTERFACE 2 BOARD ASSEMBLY	5998-01-297-7733
F-16	AN/APG-66 Fire Control Radar	RC Computer	682R975G01	--	POWER SUPPLY ASSEMBLY	6130-01-103-4551
F-16	AN/APG-66 Fire Control Radar	REO	29215-89	--	FRONT PANEL ASSEMBLY	5841-01-124-7414
F-16	AN/APG-66 Fire Control Radar	RETAINER, BATTERY	688R642G01	750R505G01	IXRM/IXRG DIGITAL MODULE	5998-01-132-6878
F-16	AN/APG-66 Fire Control Radar	SDP	681R341G01	--	ELECTRONIC COMPONENT	5998-01-079-5393
F-16	AN/APG-66 Fire Control Radar	SDP	785R130G01	785R130	CIRCUIT CARD ASSEMBLY	5998-01-406-2944
F-16	AN/APG-66 Fire Control Radar	SDP	781R913G01	781R913	CIRCUIT CARD ASSEMBLY	5998-01-406-2945
F-16	AN/APG-66 Fire Control Radar	SDP	781R905G01	781R905	CIRCUIT CARD ASSEMBLY	5998-01-406-4223
F-16	AN/APG-66 Fire Control Radar	SDP	785R450G01	--	AUX CCA	5998-01-406-6815

F-16	AN/APG-66 Fire Control Radar	SDP	681R267G01	--	POWER SUPPLY	6130-01-080-1216
F-16	AN/APG-66 Fire Control Radar	SDP	750R085G01	--	CIRCUIT CARD ASSEMBLY	6130-01-133-6495
F-16	AN/APG-66 Fire Control Radar	SDP	588R824H01	--	POWER SUPPLY	6130-01-406-2946
F-16	AN/APG-66 Fire Control Radar	SDP	781R917G01	--	DATA PROCESSOR	NSL
F-16	AN/APG-66 Fire Control Radar	SEMICONDUCTOR DEVICE, DIODE	688R654G01	750R502G01	ROUTER/PBM MEMORY DIGITAL MODULE	5998-01-132-6882
F-16	AN/APG-66 Fire Control Radar	Transmitter	681R366G01	--	Pressure Vessel Assembly (PVA) w/o TWT or T1 Replacement	1270-01-083-0398
F-16	AN/APG-66 Fire Control Radar	Transmitter	681R366G01	--	Pressure Vessel Assembly (PVA) w/ TWT or T1 Replacement	1270-01-083-0398
F-16	AN/APG-66 Fire Control Radar	Transmitter	646R666G01	--	GROUND DECK PULSER	1270-01-083-5926
F-16	AN/APG-66 Fire Control Radar	Transmitter	682R668G01	--	PEAK POWER DETECTOR	1270-01-097-6096
F-16	AN/APG-66 Fire Control Radar	Transmitter	783R056G01	--	Pressure Vessel w/o TWT or T1 Replacement	1270-01-407-6550
F-16	AN/APG-66 Fire Control Radar	Transmitter	783R056G01	--	Pressure Vessel Assembly (PVA) w/ TWT or T1 Replacement	1270-01-407-6550
F-16	AN/APG-66 Fire Control Radar	Transmitter	772R025G01	690R964G01	RF CONTROLLER BOARD ASSEMBLY	5998-01-203-1936
F-16	AN/APG-66 Fire Control Radar	Transmitter	762R010G01	--	PROTECTION & CONTROL BOARD ASSEMBLY	5998-01-226-1196
F-16	AN/APG-66 Fire Control Radar		682R742G01	--	RADAR CONTROL PANEL	1270-01-094-6872
F-16	AN/APG-66 Fire Control Radar		765R598G01	--	CHASSIS ASSEMBLY	1270-01-511-2900
F-16	AN/APG-66 Fire Control Radar		682R559G01	--	RACK EL EQ	5975-01-102-4084
F-16	AN/APG-66 Fire Control Radar		758R594G01	--	MOUNTING BASE,ELECTRICAL EQUIPMENT	5975-01-236-8158
F-16	AN/APG-66 Fire Control Radar		682R798G01	--	BM-F/BM DIGITAL MODULE	5998-01-132-5746
F-16	AN/APG-66 Fire Control Radar		750R491G01	682R798G01	BM-F/BM DIGITAL MODULE	5998-01-132-5746
F-16	AN/APG-66 Fire Control Radar		750R530G01	688R606G01	SUBASSEMBLY MODULE	5998-01-132-6871
F-16	AN/APG-66 Fire Control Radar		750R415G01	688R636G01	SPC CPU/SPC OV DIGITAL MODULE	5998-01-132-6875
F-16	AN/APG-66 Fire Control Radar		750R418G01	688R599G01	SPC INT/SPC MEMORY DIGITAL MODULE	5998-01-132-6885
F-16	AN/APG-66 Fire Control Radar		691R742G01	690R984G01	CIRCUIT CARD ASSEMBLY	5998-01-132-7025
F-16	AN/APG-66 Fire Control Radar		688R672G01	750R940G01	CIRCUIT CARD ASSEMBLY	5998-01-133-6109
F-16	AN/APG-66 Fire Control Radar		758R450G01	--	SAMPLE DATA BOARD ASSEMBLY	5998-01-194-5625
F-16	AN/APG-66 Fire Control Radar		762R012G01	--	REGULATOR BOARD ASSEMBLY	5998-01-209-0128
F-16	AN/APG-66 Fire Control Radar		785R829G01	758R196G01	RF MONITOR BOARD ASSEMBLY	5998-01-220-4050

F-16	AN/APG-66 Fire Control Radar		762R017G01	--	RF MONITOR BOARD ASSEMBLY	5998-01-220-5856
F-16	AN/APG-66 Fire Control Radar		688R720G01	--	SAMPLE DATA BOARD	NSL
F-16	AN/APG-66(V)	TRANSMITTER SUBASSEMBLY, RADA R	774R133G01	--	POWER SUPPLY	6130-01-326-4122
F-16	AN/APG-68 Fire Control Radar	--	750R900G01	688R700G01	ANTENNA	1270-01-132-2437
F-16	AN/APG-68 Fire Control Radar	--	750R820G01	--	MLPRF RECEIVER/GENERATOR w/o Power Supply Transformer, Receiver Protector and/or Chasis Failure	1270-01-169-6289
F-16	AN/APG-68 Fire Control Radar	--	750R820G01	--	MLPRF RECEIVER/GENERATOR w/ Power Supply Transformer, Receiver Protector and/or Chasis Failure	1270-01-169-6289
F-16	AN/APG-68 Fire Control Radar	--	690R999G01	--	ANTENNA	1270-01-193-1609
F-16	AN/APG-68 Fire Control Radar	--	758R560G01	--	ANTENNA	1270-01-201-6507
F-16	AN/APG-68 Fire Control Radar	--	758R900G01	--	Dual Mode Transmitter (DMT) w/o TWT or T1 Replacement	1270-01-201-6638
F-16	AN/APG-68 Fire Control Radar	--	758R900G01	--	Dual Mode Transmitter (DMT) w/ TWT or T1 Replacement	1270-01-201-6638
F-16	AN/APG-68 Fire Control Radar	--	758R950G01	--	Dual Mode Transmitter (DMT) w/o TWT or T1 Replacement	1270-01-220-9095
F-16	AN/APG-68 Fire Control Radar	--	758R950G01	--	Dual Mode Transmitter (DMT) w/ TWT or T1 Replacement	1270-01-220-9095
F-16	AN/APG-68 Fire Control Radar	--	758R990G01	--	Dual Mode Transmitter (DMT) w/o TWT or T1 Replacement	1270-01-238-3662
F-16	AN/APG-68 Fire Control Radar	--	758R990G01	--	Dual Mode Transmitter (DMT) w/ TWT or T1 Replacement	1270-01-238-3662
F-16	AN/APG-68 Fire Control Radar	--	765R010G01	--	Programmable Signal Processor (PSP)	1270-01-256-6538
F-16	AN/APG-68 Fire Control Radar	--	783R230G01	--	PROGRAMMABLE SIGNAL PROCESSOR (PSP)	1270-01-396-6750
F-16	AN/APG-68 Fire Control Radar	--	765R610G01	--	Programmable Signal Processor (PSP)	1270-01-413-5648
F-16	AN/APG-68 Fire Control Radar	--	775R178G01	16VZ001-17	MLPRF RECEIVER/GENERATOR w/o Power Supply Transformer, Receiver Protector and/or Chasis Failure	1270-01-418-1960
F-16	AN/APG-68 Fire Control Radar	--	775R178G01	16VZ001-17	MLPRF RECEIVER/GENERATOR w/ Power Supply Transformer, Receiver Protector and/or Chasis Failure	1270-01-418-1960
F-16	AN/APG-68 Fire Control Radar	--	811R940G01	--	Programmable Signal Processor (PSP)	1270-01-466-5918
F-16	AN/APG-68 Fire Control Radar	--	811R930G01	--	Programmable Signal Processor (PSP)	1270-01-466-7426
F-16	AN/APG-68 Fire Control Radar	--	758R888G01	--	MLPRF RECEIVER/GENERATOR	5841-01-233-0011
F-16	AN/APG-68 Fire Control Radar	--	768R214G01	--	ANTENNA	5985-01-310-7366

F-16	AN/APG-68 Fire Control Radar	--	765R143G01	--	Dual Mode Transmitter (DMT) w/o TWT or T1 Replacement	5998-01-310-8718
F-16	AN/APG-68 Fire Control Radar	--	765R143G01	--	Dual Mode Transmitter (DMT) w/ TWT or T1 Replacement	5998-01-310-8718
F-16	AN/APG-68 Fire Control Radar	--	765R620G01	765R620	Programmable Signal Processor (PSP)	5998-01-323-0623
F-16	AN/APG-68 Fire Control Radar	Antenna	688R683G01	753R086G01	PHASE SHIFT DRIVE ASSEMBLY	1270-01-132-2440
F-16	AN/APG-68 Fire Control Radar	Antenna	758R139G01	783R086G01	PHASE SHIFT DRIVE ASSEMBLY	1270-01-132-2440
F-16	AN/APG-68 Fire Control Radar	Antenna	750R857G01	750R355G01	POWER SUPPLY, ANTENNA	1270-01-132-2709
F-16	AN/APG-68 Fire Control Radar	Antenna	782R602G01	688R675G01	POWER SUPPLY, ANTENNA	1270-01-132-2709
F-16	AN/APG-68 Fire Control Radar	Antenna	758R758G01	819R616G01	AZ/EL COMPENSATION POWER AMPLIFIER	1270-01-195-7397
F-16	AN/APG-68 Fire Control Radar	Antenna, FMS & PDILL	758R432G01	--	POWER SUPPLY	1270-01-211-9681
F-16	AN/APG-68 Fire Control Radar	CABLE,MODEM,COMM UNI	758R804G01	758R805G01	POWER SUPPLY	6130-01-243-3059
F-16	AN/APG-68 Fire Control Radar	DMT	536R477G01	--	ARC DETECTOR ASSEMBLY	1270-01-132-2438
F-16	AN/APG-68 Fire Control Radar	DMT	758R058G01	--	PHASE COMPENSATION ASSEMBLY	1270-01-201-6641
F-16	AN/APG-68 Fire Control Radar	DMT	758R839G01	--	PHASE COMPENSATION ASSEMBLY	1270-01-220-8983
F-16	AN/APG-68 Fire Control Radar	DMT	758R872G01	--	PHASE COMPENSATION ASSEMBLY	1270-01-239-4527
F-16	AN/APG-68 Fire Control Radar	DMT	765R067G01	--	Pressure Vessel Assembly (PVA) w/o TWT or T1 Replacement	1270-01-246-7042
F-16	AN/APG-68 Fire Control Radar	DMT	765R067G01	--	Pressure Vessel Assembly (PVA) w/ TWT or T1 Replacement	1270-01-246-7042
F-16	AN/APG-68 Fire Control Radar	DMT	765R398G01	--	PRESSURIZING SET	1270-01-274-0548
F-16	AN/APG-68 Fire Control Radar	DMT	765R487G01	--	PRESSURIZING SET	1270-01-274-0548
F-16	AN/APG-68 Fire Control Radar	DMT	756R555G01	--	PROTECTION & CONTROL BOARD ASSEMBLY	5998-01-201-6852
F-16	AN/APG-68 Fire Control Radar	DMT	756R556G01	--	REGULATOR BOARD ASSEMBLY	5998-01-201-6854
F-16	AN/APG-68 Fire Control Radar	DMT	690R964G01	--	RF CONTROLLER BOARD ASSEMBLY	5998-01-203-1936
F-16	AN/APG-68 Fire Control Radar	DMT	756R484G01	762R012G01	REGULATOR BOARD ASSEMBLY	5998-01-209-0128
F-16	AN/APG-68 Fire Control Radar	DMT	785R537G01	758R196G01	RF MONITOR BOARD ASSEMBLY	5998-01-220-4050
F-16	AN/APG-68 Fire Control Radar	DMT	762R128G01	762R126G01	PROTECTION & CONTROL BOARD ASSEMBLY	5998-01-242-8034
F-16	AN/APG-68 Fire Control Radar	DMT	762R117G01	--	DIGIBUS BOARD ASSEMBLY	5998-01-242-8035
F-16	AN/APG-68 Fire Control Radar	DMT	762R051G01	--	REGULATOR BOARD ASSEMBLY	5998-01-247-8169
F-16	AN/APG-68 Fire Control Radar	DMT	762R173G01	762R051G01	REGULATOR BOARD ASSEMBLY	5998-01-247-8169

F-16	AN/APG-68 Fire Control Radar	DMT	762R925G01	762R051G01	REGULATOR BOARD ASSEMBLY	5998-01-247-8169
F-16	AN/APG-68 Fire Control Radar	DMT	762R370G01	--	PROTECTION & CONTROL BOARD ASSEMBLY	5998-01-265-1040
F-16	AN/APG-68 Fire Control Radar	DMT	762R629G01	--	RF MONITOR BOARD ASSEMBLY	5998-01-274-4648
F-16	AN/APG-68 Fire Control Radar	DMT	772R023G01	762R629G01	RF MONITOR BOARD ASSEMBLY	5998-01-274-4648
F-16	AN/APG-68 Fire Control Radar	DMT	762R656G01	--	REGULATOR BOARD ASSEMBLY	5998-01-288-5420
F-16	AN/APG-68 Fire Control Radar	DMT	792R999G01	762R656G01	REGULATOR BOARD ASSEMBLY	5998-01-288-5420
F-16	AN/APG-68 Fire Control Radar	DMT	758R196G01	--	RF MONITOR BOARD ASSEMBLY	5998-01-303-5871
F-16	AN/APG-68 Fire Control Radar	DMT	785R902G01	785R262G01	PROTECTION CONTROL	5998-01-303-5871
F-16	AN/APG-68 Fire Control Radar	DMT	762R831G01	762R831	RF CONTROLLER BOARD ASSEMBLY	5998-01-303-5872
F-16	AN/APG-68 Fire Control Radar	DMT	762R978G01	--	PROTECTION & CONTROL BOARD ASSEMBLY	5998-01-306-9224
F-16	AN/APG-68 Fire Control Radar	DMT	756R553G01	--	RF MONITOR BOARD ASSEMBLY	NSL
F-16	AN/APG-68 Fire Control Radar	DMT	756R927G01	--	RF MONITOR BOARD ASSEMBLY	NSL
F-16	AN/APG-68 Fire Control Radar	DMT	756R990G01	--	REGULATOR BOARD ASSEMBLY	NSL
F-16	AN/APG-68 Fire Control Radar	DMT	758R873G01	--	RF MONITOR BOARD ASSEMBLY	NSL
F-16	AN/APG-68 Fire Control Radar	DMT	772R022G01	--	RF MONITOR BOARD ASSEMBLY	NSL
F-16	AN/APG-68 Fire Control Radar	HANGER, ENGINE EXHAUST SYSTEM	756R441G01	--	VIDEO INTERFACE BOARD ASSEMBLY	5998-01-194-4373
F-16	AN/APG-68 Fire Control Radar	MLPRF	750R821G01	--	FREQ. SYNTHESIZER	1270-01-168-5002
F-16	AN/APG-68 Fire Control Radar	MLPRF	750R824G01	--	FREQ. OSCILLATOR	1270-01-168-5004
F-16	AN/APG-68 Fire Control Radar	MLPRF	586R719H02	586R719H01	TRANSMIT-MICROWAVE ASSEMBLY	1270-01-173-4932
F-16	AN/APG-68 Fire Control Radar	MLPRF	758R063G01	--	HI RESOLUTION MODULE ADAPTER	1270-01-174-5747
F-16	AN/APG-68 Fire Control Radar	MLPRF	690R935G01	--	RECEIVER ASSEMBLY	1270-01-194-5732
F-16	AN/APG-68 Fire Control Radar	MLPRF	758R570G01	--	REFERENCE OSCILLATOR	1270-01-208-8409
F-16	AN/APG-68 Fire Control Radar	MLPRF	758R862G01	--	IF ASSEMBLY	1270-01-223-5840
F-16	AN/APG-68 Fire Control Radar	MLPRF	12609185	12607535	LVPS w/o Transformer	1280-01-126-0079
F-16	AN/APG-68 Fire Control Radar	MLPRF	12609185	12607535	LVPS w/ Transformer	1280-01-126-0079
F-16	AN/APG-68 Fire Control Radar	MLPRF	782R650G01	12609185	LVPS w/o Transformer	1280-01-126-0079
F-16	AN/APG-68 Fire Control Radar	MLPRF	782R650G01	12609185	LVPS w/ Transformer	1280-01-126-0079



F-16	AN/APG-68 Fire Control Radar	MLPRF	765R076G01	--	HI RESOLUTION MODULE ADAPTER	1285-01-395-7509
F-16	AN/APG-68 Fire Control Radar	MLPRF	691R748G01	--	LOW NOISE AMPLIFIER ASSEMBLY	5841-01-132-6867
F-16	AN/APG-68 Fire Control Radar	MLPRF	691R748G01	--	LOW NOISE AMPLIFIER ASSEMBLY w/ Rec Prot	5841-01-132-6867
F-16	AN/APG-68 Fire Control Radar	MLPRF	586R212H03	586R212	TRANSMIT-MICROWAVE ASSEMBLY	5841-01-203-4624
F-16	AN/APG-68 Fire Control Radar	MLPRF	750R450G04	586R212	TRANSMIT-MICROWAVE ASSEMBLY	5841-01-203-4624
F-16	AN/APG-68 Fire Control Radar	MLPRF	586R212H05	--	RECEIVER/TRANSMITTER	5841-01-291-6174
F-16	AN/APG-68 Fire Control Radar	MLPRF	586R212H07	--	TRANSMIT-MICROWAVE ASSEMBLY	5841-01-438-9423
F-16	AN/APG-68 Fire Control Radar	MLPRF	585R563H02	--	RECEIVER PROTECTOR	5895-01-153-9814
F-16	AN/APG-68 Fire Control Radar	MLPRF	585R563H03	588R499H01	RECEIVER PROTECTOR	5895-01-283-0952
F-16	AN/APG-68 Fire Control Radar	MLPRF	VLX1720	--	LIMITER,ELECTRICAL NOISE	5895-01-421-6495
F-16	AN/APG-68 Fire Control Radar	MLPRF	758R405G01	--	MLPRF CHASSIS ASSY	5975-01-551-8330
F-16	AN/APG-68 Fire Control Radar	MLPRF	756R222G01	--	CONTROLLER ANALOG BOARD ASSEMBLY	5998-01-195-8634
F-16	AN/APG-68 Fire Control Radar	MLPRF	750R962G01	--	SAMPLE DATA BOARD ASSEMBLY	5998-01-196-3759
F-16	AN/APG-68 Fire Control Radar	MLPRF	762R031G01	--	SAMPLE DATA BOARD ASSEMBLY	5998-01-278-5983
F-16	AN/APG-68 Fire Control Radar	MLPRF	762R613G01	--	CONTROLLER/CPU	5998-01-278-6462
F-16	AN/APG-68 Fire Control Radar	MLPRF	781R710G01	--	CONTROLLER/CPU BOARD ASSEMBLY	5998-01-411-1314
F-16	AN/APG-68 Fire Control Radar	MLPRF	785R772G01	--	CONTROLLER INTERFACE BOARD ASSY	5998-01-431-4658
F-16	AN/APG-68 Fire Control Radar	MLPRF	792R027G01	--	SAMPLE DATA BOARD ASSEMBLY	5998-01-439-0667
F-16	AN/APG-68 Fire Control Radar	MLPRF	792R689G01	--	SAMPLE DATA BOARD ASSEMBLY	5998-01-465-7637
F-16	AN/APG-68 Fire Control Radar	MLPRF	12604334	685R059G01	FREQUENCY MULTIPLIER	6625-01-124-0226
F-16	AN/APG-68 Fire Control Radar	MLPRF	12604334-1	685R059G01	FREQUENCY MULTIPLIER	6625-01-124-0226
F-16	AN/APG-68 Fire Control Radar	MLPRF	12604334-2	685R059G01	FREQUENCY MULTIPLIER	6625-01-124-0226
F-16	AN/APG-68 Fire Control Radar	MLPRF	12604334-3	685R059G01	FREQUENCY MULTIPLIER	6625-01-124-0226
F-16	AN/APG-68 Fire Control Radar	MLPRF	12604334-4	685R059G01	FREQUENCY MULTIPLIER	6625-01-124-0226
F-16	AN/APG-68 Fire Control Radar	MLPRF	685R059G01	--	FREQUENCY MULTIPLIER	6625-01-124-0226
F-16	AN/APG-68 Fire Control Radar	MLPRF	M00224-A	685R059G01	FREQUENCY MULTIPLIER	6625-01-124-0226
F-16	AN/APG-68 Fire Control Radar	MLPRF	M00X221	685R059G01	FREQUENCY MULTIPLIER	6625-01-124-0226

F-16	AN/APG-68 Fire Control Radar	MLPRF	M00X224	685R059G01	FREQUENCY MULTIPLIER	6625-01-124-0226
F-16	AN/APG-68 Fire Control Radar	MLPRF	12607539	685R989	FREQUENCY SYNTHESIZER	6625-01-126-0097
F-16	AN/APG-68 Fire Control Radar	MLPRF	12609799	685R989	FREQUENCY SYNTHESIZER	6625-01-126-0097
F-16	AN/APG-68 Fire Control Radar	MLPRF	685R989G01	685R989	FREQUENCY SYNTHESIZER	6625-01-126-0097
F-16	AN/APG-68 Fire Control Radar	MLPRF	756R492G01	--	CONTROLLER ANALOG BOARD ASSEMBLY	NSL
F-16	AN/APG-68 Fire Control Radar	MLPRF	756R914G01	--	CONTROLLER INTERFACE ASSEMBLY	NSL
F-16	AN/APG-68 Fire Control Radar	MLPRF	758R689G01	NSL	MLPRF CHASSIS ASSY	NSL
F-16	AN/APG-68 Fire Control Radar	MLPRF	758R734G01	NSL	MLPRF CHASSIS ASSY	NSL
F-16	AN/APG-68 Fire Control Radar	MLPRF	765R888G01	--	CONTROLLER/CPU BOARD ASSEMBLY	NSL
F-16	AN/APG-68 Fire Control Radar	PSP	756R504G01	756R505G01	DMAC MODULE	1270-01-202-5162
F-16	AN/APG-68 Fire Control Radar	PSP	688R609G01	--	32K RAM DIGITAL MODULE	5998-01-132-5747
F-16	AN/APG-68 Fire Control Radar	PSP	688R604G01	--	AUXILIARY BOARD ASSEMBLY	5998-01-132-5763
F-16	AN/APG-68 Fire Control Radar	PSP	750R504G01	688R639G01	MICM/MICC DIGITAL MODULE	5998-01-132-6877
F-16	AN/APG-68 Fire Control Radar	PSP	750R505G01	--	IXRM/IXRG DIGITAL MODULE	5998-01-132-6878
F-16	AN/APG-68 Fire Control Radar	PSP	750R502G01	--	ROUTER/PBM MEMORY DIGITAL MODULE	5998-01-132-6882
F-16	AN/APG-68 Fire Control Radar	PSP	0 & 0 & 0	756R241G01	MAP BUFFER/T-F BUFFER DIGITAL MODULE	5998-01-194-8126
F-16	AN/APG-68 Fire Control Radar	PSP	756R242G01	756R241G01	MAP BUFFER/T-F BUFFER DIGITAL MODULE	5998-01-194-8126
F-16	AN/APG-68 Fire Control Radar	PSP	756R183G01	--	SPM CGA DIGITAL MODULE	5998-01-194-8141
F-16	AN/APG-68 Fire Control Radar	PSP	758R598G01	--	SYMBOL INPUT/SYMBOL MEMORY DIGITAL MODULE	5998-01-195-4022
F-16	AN/APG-68 Fire Control Radar	PSP	756R450G01	--	AC NO 1/AC NO 2 DIGITAL MODULE	5998-01-195-4132
F-16	AN/APG-68 Fire Control Radar	PSP	756R451G01	--	AC NO 1/AC NO 2 DIGITAL MODULE	5998-01-195-4132
F-16	AN/APG-68 Fire Control Radar	PSP	694R158G01	--	SPC IO/TST OV DIGITAL MODULE	5998-01-195-7399
F-16	AN/APG-68 Fire Control Radar	PSP	694R942G01	--	CPU 1750 INT RAM DIGITAL MODULE	5998-01-195-7400
F-16	AN/APG-68 Fire Control Radar	PSP	756R533G01	--	CDP/PI BUFFER DIGITAL MODULE	5998-01-201-6843
F-16	AN/APG-68 Fire Control Radar	PSP	694R730G01	694R730	SPC CPU/SPC OV DIGITAL MODULE	5998-01-202-9187
F-16	AN/APG-68 Fire Control Radar	PSP	756R454G01	--	FITS/RCIF DIGITAL MODULE	5998-01-202-9188
F-16	AN/APG-68 Fire Control Radar	PSP	756R459G01	756R157G01	FITS/RCIF DIGITAL MODULE	5998-01-202-9188

F-16	AN/APG-68 Fire Control Radar	PSP	756R456G01	--	SPC INT/SPC MEMORY DIGITAL MODULE	5998-01-206-9857
F-16	AN/APG-68 Fire Control Radar	PSP	694R736G01	--	PBM CONT/PBM MEM CCA	5998-01-207-8828
F-16	AN/APG-68 Fire Control Radar	PSP	756R161G01	694R736G01	PBM CONTROL/MEMORY DIGITAL MODULE	5998-01-207-8828
F-16	AN/APG-68 Fire Control Radar	PSP	756R268G01	--	CTR LK/MES BUFFER DIGITAL MODULE	5998-01-208-8610
F-16	AN/APG-68 Fire Control Radar	PSP	694R728G01	--	FITS/RCIF CCA	5998-01-208-8626
F-16	AN/APG-68 Fire Control Radar	PSP	694R740G01	--	PBMIF/PRF GENERATOR DIGITAL MODULE	5998-01-212-4129
F-16	AN/APG-68 Fire Control Radar	PSP	756R411G01	--	SYNCHRONIZER/DIGITAL BOARD ASSEMBLY	5998-01-212-4130
F-16	AN/APG-68 Fire Control Radar	PSP	756R966G01	--	BM-F/BM DIGITAL MODULE	5998-01-232-4218
F-16	AN/APG-68 Fire Control Radar	PSP	756R749G01	--	MAP TF INPUT/MAP TF MEMORY DIGITAL MODULE	5998-01-232-4219
F-16	AN/APG-68 Fire Control Radar	PSP	756R912G01	--	CONTROLLER INTERFACE ASSEMBLY	5998-01-232-5232
F-16	AN/APG-68 Fire Control Radar	PSP	762R080G01	--	BULK MEMORY 32K RAM DIGITAL MODULE	5998-01-232-5234
F-16	AN/APG-68 Fire Control Radar	PSP	762R351G01	--	A-D INTERFACE/INPUT BUFFER DIGITAL MODULE	5998-01-241-9553
F-16	AN/APG-68 Fire Control Radar	PSP	762R353G01	--	SIGNAL GENERATOR/SYNCHRONIZER DIGITAL MODULE	5998-01-241-9554
F-16	AN/APG-68 Fire Control Radar	PSP	762R459G01	--	DMAC MODULE	5998-01-250-0277
F-16	AN/APG-68 Fire Control Radar	PSP	762R486G01	--	BM-F/BM DIGITAL MODULE	5998-01-256-4381
F-16	AN/APG-68 Fire Control Radar	PSP	762R519G01	--	BM-F/BM DIGITAL MODULE	5998-01-274-6297
F-16	AN/APG-68 Fire Control Radar	PSP	762R520G01	--	BULK MEMORY 32K RAM DIGITAL MODULE	5998-01-274-9459
F-16	AN/APG-68 Fire Control Radar	PSP	762R065G01	762R626G01	A-D INTERFACE/INPUT BUFFER DIGITAL MODULE	5998-01-275-5773
F-16	AN/APG-68 Fire Control Radar	PSP	762R674G01	--	PBM CONTROL/MEMORY DIGITAL MODULE	5998-01-285-3700
F-16	AN/APG-68 Fire Control Radar	PSP	762R985G01	--	BULK MEMORY 32K RAM DIGITAL MODULE	5998-01-285-9190
F-16	AN/APG-68 Fire Control Radar	PSP	762R973G01	--	BM-F/BM DIGITAL MODULE	5998-01-286-1473
F-16	AN/APG-68 Fire Control Radar	PSP	762R677G01	--	A34 DMA ROUTER CIRCUIT CARD ASSEMBLY	5998-01-286-5246
F-16	AN/APG-68 Fire Control Radar	PSP	762R678G01	--	CDP/PI BUFFER DIGITAL MODULE	5998-01-288-6937
F-16	AN/APG-68 Fire Control Radar	PSP	765R886G01	--	CONTROLLER/CPU BOARD ASSEMBLY	5998-01-298-9139
F-16	AN/APG-68 Fire Control Radar	PSP	762R992G01	762R992	MAP BUFFER/T-F BUFFER DIGITAL MODULE	5998-01-315-2446
F-16	AN/APG-68 Fire Control Radar	PSP	762R649G01	762R649	FITS/RCIF DIGITAL MODULE	5998-01-318-0309
F-16	AN/APG-68 Fire Control Radar	PSP	772R809G01	--	PBM CONTROL/MEMORY DIGITAL MODULE	5998-01-329-2520

F-16	AN/APG-68 Fire Control Radar	PSP	772R416G01	--	CPU 1750 INT RAM DIGITAL MODULE	5998-01-337-4608
F-16	AN/APG-68 Fire Control Radar	PSP	785R814G01	781R751G01	PROCESSOR BULK MEMORY	5998-01-352-4129
F-16	AN/APG-68 Fire Control Radar	PSP	781R984G01	--	MAP BUFFER/T-F BUFFER DIGITAL MODULE	5998-01-382-0663
F-16	AN/APG-68 Fire Control Radar	PSP	772R811G01	--	PBM CONTROL/MEMORY DIGITAL MODULE	5998-01-384-2692
F-16	AN/APG-68 Fire Control Radar	PSP	762R355G01	--	SIGNAL GENERATOR/SYNCHRONIZER DIGITAL MODULE	5998-01-384-2698
F-16	AN/APG-68 Fire Control Radar	PSP	762R627G01	--	A-D INTERFACE/INPUT BUFFER DIGITAL MODULE	5998-01-384-2703
F-16	AN/APG-68 Fire Control Radar	PSP	756R534G01	--	CDP/PI BUFFER DIGITAL MODULE	5998-01-385-4349
F-16	AN/APG-68 Fire Control Radar	PSP	762R354G01	762R354	SIGNAL GENERATOR/SYNCHRONIZER DIGITAL MODULE	5998-01-388-3760
F-16	AN/APG-68 Fire Control Radar	PSP	785R478G01	--	BULK MEMORY 32K RAM DIGITAL MODULE	5998-01-392-3863
F-16	AN/APG-68 Fire Control Radar	PSP	785R479G01	--	BULK MEMORY 32K RAM DIGITAL MODULE	5998-01-392-3864
F-16	AN/APG-68 Fire Control Radar	PSP	785R481G01	--	BM-F/BM DIGITAL MODULE	5998-01-392-3865
F-16	AN/APG-68 Fire Control Radar	PSP	785R480G01	--	BULK MEMORY 32K RAM DIGITAL MODULE	5998-01-392-3866
F-16	AN/APG-68 Fire Control Radar	PSP	785R477G01	--	BM-F/BM DIGITAL MODULE	5998-01-392-8013
F-16	AN/APG-68 Fire Control Radar	PSP	785R473G01	--	BM-F/BM DIGITAL MODULE	5998-01-393-2409
F-16	AN/APG-68 Fire Control Radar	PSP	785R474G01	--	BM-F/BM DIGITAL MODULE	5998-01-393-2410
F-16	AN/APG-68 Fire Control Radar	PSP	785R476G01	--	BM-F/BM DIGITAL MODULE	5998-01-393-2411
F-16	AN/APG-68 Fire Control Radar	PSP	762R626G01	--	A-D INTERFACE/INPUT BUFFER DIGITAL MODULE	5998-01-396-2193
F-16	AN/APG-68 Fire Control Radar	PSP	785R943G01	--	BM-F/BM DIGITAL MODULE	5998-01-425-7616
F-16	AN/APG-68 Fire Control Radar	PSP	750-1	--	PSP POWER SUPPLY	6130-01-473-8223
F-16	AN/APG-68 Fire Control Radar	PSP	762R084G01	--	DMAC MODULE	NSL
F-16	AN/APG-68 Fire Control Radar	PSP	762R352G01	--	A-D INTERFACE/INPUT BUFFER DIGITAL MODULE	NSL
F-16	AN/APG-68 Fire Control Radar	PSP Block 30 & 40	756R169G01	--	PBMIF/PRF GENERATOR DIGITAL MODULE	5998-01-194-3852
F-16	AN/APG-68 Fire Control Radar	PSP Block 30 & 40	756R151G01	--	SPM CGA DIGITAL MODULE	5998-01-207-7159
F-16	AN/APG-68 Fire Control Radar	RETAINER, BATTERY	765R005G01	--	POWER SUPPLY	6130-01-257-2835
F-16	AN/APG-68 Fire Control Radar	SEMICONDUCTOR DEVICE, DIODE	762R829G01	785R262G01	CIRCUIT CARD ASSEMBLY	5998-01-303-5871
F-16	AN/APG-68 Fire Control Radar		690R894G01	--	DIGIBUS INTERFACE	1270-01-193-1598
F-16	AN/APG-68 Fire Control Radar		691R750G01	--	RCR SUBASSY APG-68	1270-01-193-7344

F-16	AN/APG-68 Fire Control Radar		765R009G01	--	CHASSIS ASSEMBLY	1270-01-511-2897
F-16	AN/APG-68 Fire Control Radar		588R881H01	--	POWER SUPPLY	1280-01-439-0638
F-16	AN/APG-68 Fire Control Radar		688R726G01	--	WAVEGUIDE ASSEMBLY	5985-01-157-8193
F-16	AN/APG-68 Fire Control Radar		758R800G01	--	ANTENNA	5985-01-212-2950
F-16	AN/APG-68 Fire Control Radar		768R306G01	--	WAVEGUIDE	5985-01-357-0255
F-16	AN/APG-68 Fire Control Radar		803R644G01	16VZ001-15	ANTENNA	5985-01-445-7213
F-16	AN/APG-68 Fire Control Radar		758R211G01	--	CIRCUIT CARD ASSEMBLY	5998-01-179-8448
F-16	AN/APG-68 Fire Control Radar		756R469G01	--	DIGIBUS INTERFACE	5998-01-194-8125
F-16	AN/APG-68 Fire Control Radar		762R396G01	--	CIRCUIT CARD ASSEMBLY	5998-01-232-5233
F-16	AN/APG-68 Fire Control Radar		765R556G01	--	DIGIBUS BOARD ASSEMBLY	NSL
F-16	AN/APN-224		10068951-104	10068951-102	RADAR TRANSMITTER	5841-01-316-9997
F-16	AN/APN-224		10131946-101	--	RECEIVER ASSEMBLY	5841-01-317-2379
F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)	CLAMP,BLOCK,SECTION	85900000-02	--	SIGNAL DATA CONVERTER	5895-01-230-1284
F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)	CLAMP,BLOCK,SECTION	8800700008-1	85900000-02	SIGNAL DATA CONVERTER	5895-01-230-1284
F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)	CLAMP,BLOCK,SECTION	8800700008-2	85900000-02	SIGNAL DATA CONVERTER	5895-01-230-1284
F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)		8010000653-5	8010000653-1	CARA RECEIVER TRANSMITTER (S/N 4000 and above)	5841-01-246-9183
F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)		8010000653-6	8010000653-1	CARA RECEIVER TRANSMITTER	5841-01-301-4588
F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)		8010000788-1	8010000653-1	CARA RECEIVER TRANSMITTER	5841-01-349-9175
F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)		RT-1692	RT-1692/APN-232 (V)	CARA RECEIVER TRANSMITTER	5841-01-349-9175
F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)		85900000-03	8800700008-3	SIGNAL DATA CONVERTER	5895-01-259-2564

F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)		8800700008-3	--	SIGNAL DATA CONVERTER	5895-01-259-2564
F-16	AN/APN-232 COMBINED ALTITUDE RADAR ALTIMETER (CARA)		85900000-04	--	SIGNAL DATA CONVERTER	5895-01-445-1432
F-16	AN/FRC-178	CABLE ASSEMBLY,RADIO REQUENCY	250391	520-061-001 &-002	RADIO FREQ. AMPLIFIER	5996-01-211-3562
F-16	AN/FRC-178	CABLE ASSEMBLY,RADIO REQUENCY	250391-002	520-061-001 &-002	RADIO FREQ. AMPLIFIER	5996-01-211-3562
F-16	BENCH SET,ANURT26	TELETYPEWRITER	106066	D36URT26V	AIRFOIL RELEASE UNIT	5826-00-103-1454
F-16	Communications	--	DM001-302	--	Comm Modem; Seals intact	5895-01-426-5318 5895-01-490-1012
F-16	Communications	--	DM001-302P	--	Comm Modem; Seals intact	5895-01-494-6243
F-16	Displays	--	8520900-920	--	COLOR MFD (CMFD) Excludes Glass	1260-01-439-5023
F-16	Displays	--	8526500-920	16VE962001-20	COMMON COLOR MFD (CCMFD) Excludes Glass	1260-01-469-6512
F-16	Displays	--	MB383B-01	MB383B-00	ACMFD	1260-01-517-4127
F-16	Displays	--	51-042-02-02H	16VE359003-4	WAC Hud Electronics Unit	1270-01-377-4580
F-16	Displays	--	51-042-02-02H	16VE359003-4	WAC Hud Electronics Unit (4+ SRU Failures)	1270-01-377-4580
F-16	Displays	--	51-042-02-20B	16VE359003-5	WAC Hud Electronics Unit	1270-01-449-1574
F-16	Displays	--	51-042-02-20B	16VE359003-5	WAC Hud Electronics Unit (4+ SRU Failures)	1270-01-449-1574
F-16	Displays	--	51-042-02-95B	--	WAC Hud Electronics Unit	1270-01-468-8657
F-16	Displays	--	51-042-02-95B	--	WAC Hud Electronics Unit (4+ SRU Failures)	1270-01-468-8657
F-16	Displays	--	51-042-02-98B	--	WAC Hud Electronics Unit	1270-01-468-8658
F-16	Displays	--	51-042-02-98B	--	WAC Hud Electronics Unit (4+ SRU Failures)	1270-01-468-8658
F-16	Displays	--	51-042-02-96A	--	WAC Hud Electronics Unit	1270-01-483-2177
F-16	Displays	--	51-042-02-96A	--	WAC Hud Electronics Unit (4+ SRU Failures)	1270-01-483-2177
F-16	Displays	--	51-036-10-94A	--	WAC Hud Electronics Unit	1270-01-503-3099
F-16	Displays	--	51-036-10-94A	--	WAC Hud Electronics Unit (4+ SRU Failures)	1270-01-503-3099
F-16	Displays	--	51-042-02-94A	51-036-10-94A	WAC Hud Electronics Unit	1270-01-503-3099
F-16	Displays	--	51-042-02-94A	51-036-10-94A	WAC Hud Electronics Unit (4+ SRU Failures)	1270-01-503-3099
F-16	Displays	--	51-036-10-94C	--	WAC Hud Electronics Unit	1270-01-522-3435
F-16	Displays	--	51-036-10-94C	--	WAC Hud Electronics Unit (4+ SRU Failures)	1270-01-522-3435
F-16	Displays	--	79-077-06-01K	--	DISPLAY UNIT,HEAD-UP	1270-99-251-2706
F-16	Displays	--	79-129-01-02A	--	WAC Display Unit w/o Tube Replacement or Optics Repair	1270-99-701-9749
F-16	Displays	--	79-129-01-02A	--	WAC Display Unit w/o Optics Repair; w/ Tube Replacement	1270-99-701-9749

F-16	Displays	--	79-089-02-01K	79-089-01-01J	WAC Display Unit w/o Tube Replacement or Optics Repair	1270-99-799-2214
F-16	Displays	--	79-089-02-01K	79-089-01-01J	WAC Display Unit w/o Optics Repair; w/ Tube Replacement	1270-99-799-2214
F-16	Displays	--	10-01125-03	10-01125-05	Data Entry Display (DED)	5895-01-143-5443
F-16	Displays	--	10-01125-03	10-01125-05	Data Entry Display (DED) w/ Bezel Replacement	5895-01-143-5443
F-16	Displays	--	10-01125-06	10-01125-08	Data Entry Display (DED)	5895-01-143-5443
F-16	Displays	--	10-01125-06	10-01125-08	Data Entry Display (DED) w/ Bezel Replacement	5895-01-143-5443
F-16	Displays	--	16VE173001-1	10-01125	Data Entry Display (DED)	5895-01-143-5443
F-16	Displays	--	16VE173001-1	10-01125	Data Entry Display (DED) w/ Bezel Replacement	5895-01-143-5443
F-16	Displays	--	16VE173001-2	16VE173001-3	Data Entry Display (DED)	5895-01-143-5443
F-16	Displays	--	16VE173001-2	16VE173001-3	Data Entry Display (DED) w/ Bezel Replacement	5895-01-143-5443
F-16	Displays	--	16VE173003-1	16VE173003-2	Data Entry Display (DED)	5895-01-143-5443
F-16	Displays	--	16VE173003-1	16VE173003-2	Data Entry Display (DED) w/ Bezel Replacement	5895-01-143-5443
F-16	Displays	--	10-11476-01	--	Data Entry Display (DED)	5895-01-396-3089
F-16	Displays	--	10-11476-01	--	Data Entry Display (DED) w/ Bezel Replacement	5895-01-396-3089
F-16	Displays	--	4517-1000-00	--	IHUD PDU	NSL
F-16	Displays	--	51-042-02-94C	--	WAC Hud Electronics Unit	NSL
F-16	Displays	--	51-042-02-94C	--	WAC Hud Electronics Unit (4+ SRU Failures)	NSL
F-16	Displays	--	51-036-10-06E	--	WAC Hud Electronics Unit	
F-16	Displays	--	51-036-10-06E	--	WAC Hud Electronics Unit (4+ SRU Failures)	
F-16	Displays	CMFD	8520911-3	17811-005	BEZEL ASSEMBLY	5930-01-447-2524
F-16	Displays	CMFD	8517627-930	--	CIRCUIT CARD ASSEMBLY	5998-01-420-5981
F-16	Displays	CMFD	8520927-920	--	ELECTRONIC COMPONENT ASSEMBLY	5998-01-447-1307
F-16	Displays	CMFD	8520933-920	--	CIRCUIT CARD ASSEMBLY	5998-01-447-1318
F-16	Displays	CMFD	8521532-920	--	CIRCUIT CARD ASSEMBLY	5998-01-447-1320
F-16	Displays	CMFD	8520918-920	--	CIRCUIT CARD ASSEMBLY	5998-01-447-2023
F-16	Displays	CMFD	8520939-920	--	CIRCUIT CARD ASSEMBLY	5998-01-447-2874
F-16	Displays	CMFD	8520912-920	--	DISPLAY HEAD ASSEMBLY (EXCLUDES GLASS REPAIR / REPLACEMENT)	5998-01-447-2875
F-16	Displays	CMFD	8520921-920	--	ELECTRONIC COMPONENT ASSEMBLY	5998-01-447-3239
F-16	Displays	CMFD	8520933-921	--	CIRCUIT CARD ASSEMBLY	5998-01-454-4283
F-16	Displays	CMFD	8520927-921	--	ELECTRONIC COMPONENT ASSEMBLY	5998-01-454-6987
F-16	Displays	CMFD	8520939-921	--	CIRCUIT CARD ASSEMBLY	5998-01-457-5142
F-16	Displays	CMFD	8521535-920	--	CIRCUIT CARD ASSEMBLY	6130-01-447-2256
F-16	Displays	CMFD	8526570-920	--	DIMMER DRIVER CCA	NSL
F-16	Displays	CMFD	8526650-921	--	ASSY	NSL
F-16	Displays	DED	10-01128-03	10-01128-06	Display Head Assembly	5895-01-181-1224

F-16	Displays	DED	10-01128-03	10-01128-06	Display Head Assembly w/ Bezel Replacement	5895-01-181-1224
F-16	Displays	DED	10-01109-05	10-01109-06	ELECTRONIC TRAY ASSEMBLY	5998-01-187-3272
F-16	Displays	DED	10-01109-07	--	ELECTRONIC TRAY ASSEMBLY	5998-01-187-3272
F-16	Displays	DED	10-04896-01	--	ELECTRONIC TRAY ASSEMBLY	5998-01-239-0271
F-16	Displays	DED	10-01126-02	10-01126	POWER SUPPLY	6130-01-143-5943
F-16	Displays	DED	10-01126-02	10-01126	POWER SUPPLY w/ SRU or Major Component Replacement	6130-01-143-5943
F-16	Displays	DED	10-01126-04	10-01126-05	POWER SUPPLY	6130-01-143-5943
F-16	Displays	DED	10-01126-04	10-01126-05	POWER SUPPLY w/ SRU or Major Component Replacement	6130-01-143-5943
F-16	Displays	DED	16VE173002	16VE173002-1	POWER SUPPLY	6130-01-143-5943
F-16	Displays	DED	16VE173002	16VE173002-1	POWER SUPPLY w/ SRU or Major Component Replacement	6130-01-143-5943
F-16	Displays	DED	16VE173002-2	16VE173002-4	POWER SUPPLY	6130-01-143-5943
F-16	Displays	DED	16VE173002-2	16VE173002-4	POWER SUPPLY w/ SRU or Major Component Replacement	6130-01-143-5943
F-16	Displays	DED	16VE173002-5	10-01126	POWER SUPPLY	6130-01-143-5943
F-16	Displays	DED	16VE173002-5	10-01126	POWER SUPPLY w/ SRU or Major Component Replacement	6130-01-143-5943
F-16	Displays	DED	10-01126-06	16VE173002-6	POWER SUPPLY	6130-01-207-2734
F-16	Displays	DED	10-01126-06	16VE173002-6	POWER SUPPLY w/ SRU or Major Component Replacement	6130-01-207-2734
F-16	Displays	DED	10-01126-07	--	POWER SUPPLY	6130-21-914-2914
F-16	Displays	DED	10-01126-07	--	POWER SUPPLY w/ SRU or Major Component Replacement	6130-21-914-2914
F-16	Displays	DED	10-01128-07	--	Display Head Assembly	7025-21-913-6297
F-16	Displays	DED	10-01128-07	--	Display Head Assembly w/ Bezel Replacement	7025-21-913-6297
F-16	Displays	DOH HUD DU	229-029552-10	--	DU CHASSIS WIRED ASSEMBLY	5820-99-783-4026
F-16	Displays	DOH HUD DU	229-029558-10	--	VIDEO CARD PSP	5998-99-786-0117
F-16	Displays	DOH HUD DU	229-029558-11	--	VIDEO CARD PSP	5998-99-786-0117
F-16	Displays	DOH HUD DU	229-029558-12	--	VIDEO CARD PSP	5998-99-786-0117
F-16	Displays	DOH HUD DU	229-029551-10	--	DU MOTHERBOARD ASSEMBLY	5998-99-797-1959
F-16	Displays	DOH HUD DU	229-029560-10	--	DEFLECTION AMP PSP	5999-99-783-4027
F-16	Displays	DOH HUD DU	229-029560-11	--	DEFLECTION AMP PSP	5999-99-783-4027
F-16	Displays	DOH HUD DU	229-029560-12	--	DEFLECTION AMP PSP	5999-99-783-4027
F-16	Displays	DOH HUD DU	229-029555-12	--	Y DEFLECTION AMP PSP	5999-99-783-4028
F-16	Displays	DOH HUD DU	229-029563-10	--	LINE SCAN POWER SUPPLY	6130-99-783-4034
F-16	Displays	HEAD UP DISPLAY (HUD)	229-005785-06	229-005785-05	TUBE UNIT ASSEMBLY	1270-01-075-4767
F-16	Displays	HEAD UP DISPLAY (HUD)	229-010128	--	POWER SUPPLY	1270-01-079-5459



F-16	Displays	HEAD UP DISPLAY (HUD)	79-049-12	--	PILOT DISPLAY UNIT	1270-01-094-8505
F-16	Displays	HEAD UP DISPLAY (HUD)	51-026-03	51-026-02	ELECTRONIC UNIT	1270-01-122-9955
F-16	Displays	HEAD UP DISPLAY (HUD)	229-026253-01	229-026253-02	TUBE UNIT ASSEMBLY	1270-01-173-0441
F-16	Displays	HEAD UP DISPLAY (HUD)	79-049-13	--	PILOT DISPLAY UNIT	1270-01-199-7430
F-16	Displays	HEAD UP DISPLAY (HUD)	179-081-13-02C	--	HUD PDU (NVIS)	1270-01-462-3958
F-16	Displays	HEAD UP DISPLAY (HUD)	229-026251-04	--	CHASSIS ASSEMBLY	1270-99-735-6357
F-16	Displays	HEAD UP DISPLAY (HUD)	229-026255-10	--	INTEGRATED CONTROL PANEL (NVIS)	1290-01-464-9182
F-16	Displays	HEAD UP DISPLAY (HUD)	229-033881-01	--	INTEGRATED CONTROL PANEL	1290-99-883-5615
F-16	Displays	HEAD UP DISPLAY (HUD)	229-026255-10	--	INTEGRATED CONTROL PANEL (NON NVIS)	1290-99-984-7192
F-16	Displays	HEAD UP DISPLAY (HUD)	229-015270-01	229-015270-02	ANALOG OUTPUT CIRCUIT CARD ASSEMBLY	5998-01-100-7335
F-16	Displays	HEAD UP DISPLAY (HUD)	229-015270-02	--	ANALOG OUTPUT CIRCUIT CARD ASSEMBLY	5998-01-100-7335
F-16	Displays	HEAD UP DISPLAY (HUD)	229-014960-02	--	LOSS INTERFACE CIRCUIT CARD ASSEMBLY	5998-01-106-9835
F-16	Displays	HEAD UP DISPLAY (HUD)	229-005899-05	--	VIDEO DRIVE CIRCUIT CARD ASSEMBLY	5998-01-117-8597
F-16	Displays	HEAD UP DISPLAY (HUD)	229-026251-01	229-026251-02	CHASSIS ASSEMBLY	5999-01-173-5127
F-16	Displays	HEAD UP DISPLAY (HUD)	229-026251-02	--	CHASSIS ASSEMBLY	5999-01-173-5127
F-16	Displays	HEAD UP DISPLAY (HUD)	229-026251-03	229-026251-02	CHASSIS ASSEMBLY	5999-01-173-5127
F-16	Displays	HEAD UP DISPLAY (HUD)	0A3437-10	0A3437-10	POWER SUPPLY	6130-01-185-7755
F-16	Displays	HUD EU	7506-00098	--	POWER SUPPLY	6130-99-741-9556
F-16	Displays	HUD EU	7506-00104	--	POWER SUPPLY	6130-99-776-6884
F-16	Displays	Programmable Display Generator (PDG)	8002287-930	--	POWER SUPPLY	6130-01-234-8700
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO)	29390-79	--	CIRCUIT CARD ASSEMBLY	5998-01-085-9504
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO)	29410-79A	--	CIRCUIT CARD ASSEMBLY	5998-01-086-6714
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO)	29340-99	--	CIRCUIT CARD ASSEMBLY	5998-01-099-9472
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO)	PS74027-1	--	POWER SUPPLY	6130-01-075-6723
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO)	PS74028-1	--	POWER SUPPLY	6130-01-075-6724
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO)	PS74027-2	--	H.V. POWER SUPPLY	6130-01-149-3219
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO)	PS74028-2	0102-0002	H.V. POWER SUPPLY	6130-01-149-3220

F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29500-109	--	RADAR DATA PROCESSOR	5841-01-096-4833
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29550-69	--	E.U. A5 MUX MEMORY	5998-01-065-6683
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29520-69	--	E.U. A 2/3 MUX INTERFACE	5998-01-065-7865
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29580-79	--	E.U. A8 BIT/SELF-TEST	5998-01-067-7664
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29600-69	--	E.U. A10 MOVING SYMBOL GENERATOR	5998-01-067-7665
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29560-89	--	E.U. A6 CPU	5998-01-083-0486
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29570-79A	29570-79	E.U. A7 CPU CONTROLLER	5998-01-086-1366
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29580-79A	--	E.U. A8 BIT/SELF-TEST	5998-01-086-1367
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29610-79A	--	E.U. A11 FIXED SYMBOL GENERATOR	5998-01-086-1368
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29540-79	--	E.U. A4 DIGITAL MUX	5998-01-095-4941
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29620-89	29620-89/A	E.U. A12TIMING AND CONTROL	5998-01-095-4942
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29510-79	--	E.U. A1 VIDEO PROCESSOR	5998-01-099-9473
F-16	Displays	RADAR ELECTRO-OPTICAL UNIT (REO) EU	29650-19A	--	E.U. PSI POWER SUPPLY	6130-01-086-2340
F-16	Displays	UPDG	8517716-920	--	POWER SUPPLY	6130-01-468-1358
F-16	Displays	WAC HUD	179-077-10-01K	AE005054-01-01K	DISPLAY UNIT,HEAD-UP	1270-01-462-3959
F-16	Displays	WAC HUD	179-077-06-01K	AE007387-01-01K	DISPLAY UNIT,HEAD-UP	1270-01-462-3962
F-16	Displays	WAC HUD	229-026255-03	--	Control Panel	1270-99-735-6352
F-16	Displays	WAC HUD	229-026255-04	--	Control Panel	1270-99-735-6352
F-16	Displays	WAC HUD	229-026241-07	--	CIRCUIT CARD ASSEMBLY	1270-99-736-0404
F-16	Displays	WAC HUD	1229-026255-03	1229-026255-04	PANEL,CONTROL,ELECTRICAL-ELECTRONIC EQUIPMENT	1290-01-463-3340
F-16	Displays	WAC HUD	1229-026255-04	--	PANEL,CONTROL,ELECTRICAL-ELECTRONIC EQUIPMENT	1290-01-463-3340
F-16	Displays	WAC HUD	229-033880-01	--	Control Panel	1290-99-883-5615
F-16	Displays	WAC HUD	229-026250-02	229-026250-01	Discrete Interface CCA	5998-01-173-0666
F-16	Displays	WAC HUD	229-026256-05	--	Video CCA	5998-99-533-9125
F-16	Displays	WAC HUD	229-026256-11	--	Video CCA	5998-99-533-9125
F-16	Displays	WAC HUD	229-026256-12	--	Video CCA	5998-99-533-9125

F-16	Displays	WAC HUD	229-026259-05	--	Wac X-Deflection CCA	5998-99-771-4188
F-16	Displays	WAC HUD	229-026259-06	--	Wac X-Deflection CCA	5998-99-771-4188
F-16	Displays	WAC HUD	229-039050-04	--	Video Processor CCA	5998-99-797-1960
F-16	Displays	WAC HUD	229-039050-05	--	Video Processor CCA	5998-99-797-1960
F-16	Displays	WAC HUD	229-039050-06	--	Video Processor CCA	5998-99-797-1960
F-16	Displays	WAC HUD	229-026248-09	--	Video Processor CCA	5999-99-783-4031
F-16	Displays	WAC HUD	229-026248-11	--	Video Processor CCA	5999-99-783-4031
F-16	Displays	WAC HUD	229-026248-12	--	Video Processor CCA	5999-99-783-4031
F-16	Displays	WAC HUD	229-026257-01	229-026257-02	LINE SCAN	6130-01-173-0645
F-16	Displays	WAC HUD	229-026257-02	--	LINE SCAN	6130-01-173-0645
F-16	Displays	WAC HUD	229-026257-03	--	Wac LSPS	6130-99-736-0409
F-16	Displays	WAC HUD	229-049788-01	--	Control Panel	NSL
F-16	Displays	WAC HUD DU	229-026251-05	--	Chassis Wired	1270-99-720-7737
F-16	Displays	WAC HUD DU	229-026251-05	--	Chassis Wired w/Flex Assy Replacement	1270-99-720-7737
F-16	Displays	WAC HUD DU	229-026253-03	--	Tube Unit Assembly	1270-99-735-6356
F-16	Displays	WAC HUD DU	229-029554-03	--	TUBE UNIT ASSEMBLY	5960-99-513-3481
F-16	Displays	WAC HUD DU	229-026260-02	229-026260-01	Y DEFLECTION AMP	5998-01-174-4029
F-16	Displays	WAC HUD DU	229P0003-04-01K	229P0003-10-10K	Display Control PCP	5998-01-307-3820
F-16	Displays	WAC HUD DU	229P0003-10-01K	229P0003-10-10K	Display Control PCP	5998-01-307-3820
F-16	Displays	WAC HUD DU	229P0003-06-01K	229P0003-11-01K	Display Control PCP	5998-01-426-5075
F-16	Displays	WAC HUD DU	229P0003-11-01K	--	Display Control PCP	5998-01-426-5075
F-16	Displays	WAC HUD DU	229P0010-13-02C	--	DISPLAY CONTROL PSP	5998-01-426-8664
F-16	Displays	WAC HUD DU	229-P0010-14-02C	229P0010-13-02C	DISPLAY CONTROL PSP	5998-01-426-8664
F-16	Displays	WAC HUD DU	229P0003-10-02A	--	Display Control PCP	5998-01-434-0737
F-16	Displays	WAC HUD DU	229P0003-11-02A	--	Display Control PCP	5998-01-468-4767
F-16	Displays	WAC HUD DU	229P0010-11-02C	--	DISPLAY CONTROL PSP	5998-99-611-3828
F-16	Displays	WAC HUD DU	229P0010-12-02C	--	DISPLAY CONTROL PSP	5998-99-611-3828
F-16	Displays	WAC HUD DU	229-026925-07	--	Motherboard	5998-99-720-7739
F-16	Displays	WAC HUD DU	229-026925-08	--	Motherboard	5998-99-720-7739
F-16	Displays	WAC HUD DU	229-026260-04	229-026260-05	Wac Y-Deflection CCA	5998-99-771-4189
F-16	Displays	WAC HUD DU	7506-00089	--	POWER SUPPLY	6130-01-181-4397
F-16	Displays	WAC HUD DU	7506-00091	OA3437-10	POWER SUPPLY	6130-01-185-7755
F-16	Displays	WAC HUD DU	7506-00125	7506-00125A	POWER SUPPLY	6130-99-371-0166
F-16	Displays	WAC HUD DU	7506-00097	4-411-02	POWER SUPPLY	6130-99-735-6318
F-16	Displays	WAC HUD EU	229-026230-04	--	Chassis Electrical	1270-99-720-7735
F-16	Displays	WAC HUD EU	229-026236-04	229-026236-05	Processor Interface CCA	1270-99-721-7251
F-16	Displays	WAC HUD EU	229-026236-05	--	ELECTRONIC COMP	1270-99-721-7251
F-16	Displays	WAC HUD EU	229-026236-10	229-026236-05	ELECTRONIC COMP	1270-99-721-7251
F-16	Displays	WAC HUD EU	229-026241-05	--	Symbol Store CCA	1270-99-736-0404
F-16	Displays	WAC HUD EU	229-026241-06	--	Symbol Store CCA	1270-99-736-0404
F-16	Displays	WAC HUD EU	229-026239-01	--	MICROCIRCUIT ASSEMBLY	5962-01-170-9665
F-16	Displays	WAC HUD EU	229-026239-03	229-026239-10	MICROCIRCUIT ASSEMBLY	5962-01-170-9665
F-16	Displays	WAC HUD EU	229-026239-10	229-026239-01	MICROCIRCUIT ASSEMBLY	5962-01-170-9665
F-16	Displays	WAC HUD EU	229-026234-01	--	Arithmetic Logic CCA	5998-01-170-9661
F-16	Displays	WAC HUD EU	229-026234-10	229-026234-01	Arithmetic Logic CCA	5998-01-170-9661
F-16	Displays	WAC HUD EU	229-026235-01	--	Micro-Program CCA	5998-01-170-9662
F-16	Displays	WAC HUD EU	229-026236-01	229-026236-03	Proessor Interface CCA	5998-01-170-9663
F-16	Displays	WAC HUD EU	229-026236-02	--	Proessor Interface CCA	5998-01-170-9663
F-16	Displays	WAC HUD EU	229-026236-03	--	Proessor Interface CCA	5998-01-170-9663
F-16	Displays	WAC HUD EU	229-026244-01	229-026244-04	ASSEMBLY	5998-01-170-9670
F-16	Displays	WAC HUD EU	229-026244-03	229-026244-04	ASSEMBLY	5998-01-170-9670

F-16	Displays	WAC HUD EU	229-026244-04	--	ASSEMBLY	5998-01-170-9670
F-16	Displays	WAC HUD EU	229-030915-01	229-026245-01	LOSS INTERFACE	5998-01-170-9671
F-16	Displays	WAC HUD EU	229-030915-03	229-026245-03	LOSS INTERFACE	5998-01-170-9671
F-16	Displays	WAC HUD EU	229-030915-04	229-026245-04	LOSS INTERFACE	5998-01-170-9671
F-16	Displays	WAC HUD EU	229-026246-01	--	Mux Interface CCA	5998-01-173-0662
F-16	Displays	WAC HUD EU	229-026246-02	--	Mux Interface CCA	5998-01-173-0662
F-16	Displays	WAC HUD EU	229-026246-03	--	Mux Interface CCA	5998-01-173-0662
F-16	Displays	WAC HUD EU	229-026246-04	--	Mux Interface CCA	5998-01-173-0662
F-16	Displays	WAC HUD EU	229-026246-10	--	Mux Interface CCA	5998-01-173-0662
F-16	Displays	WAC HUD EU	229-026249-01	--	Analog Input CCA	5998-01-173-0665
F-16	Displays	WAC HUD EU	229-026249-03	229-026249-01	Analog Input CCA	5998-01-173-0665
F-16	Displays	WAC HUD EU	229-026249-04	229-026249-01	Analog Input CCA	5998-01-173-0665
F-16	Displays	WAC HUD EU	229-030915-10	--	Loss Interface CCA	5998-01-303-4370
F-16	Displays	WAC HUD EU	229-026244-07	--	Output Clock CCA	5998-01-311-9080
F-16	Displays	WAC HUD EU	229-026244-08	--	Output Clock CCA	5998-01-311-9080
F-16	Displays	WAC HUD EU	229-026244-11	--	Output Clock CCA	5998-01-311-9080
F-16	Displays	WAC HUD EU	229-026244-12	229-026244-11	Output Clock CCA	5998-01-311-9080
F-16	Displays	WAC HUD EU	229P0015-03-20B	229P0015-10-20B	EPROM STORE CCA	5998-01-387-6774
F-16	Displays	WAC HUD EU	229P0015-05-20B	229P0015-10-20B	EPROM STORE CCA	5998-01-387-6774
F-16	Displays	WAC HUD EU	229P0015-03-02H	229P0015-05-02H	EPROM STORE CCA	5998-01-387-6799
F-16	Displays	WAC HUD EU	229P0015-06-02H	229P0015-07-02H	EPROM STORE CCA	5998-01-387-6799
F-16	Displays	WAC HUD EU	229P0015-10-02H	229P0015-11-02H	EPROM STORE CCA	5998-01-387-6799
F-16	Displays	WAC HUD EU	229P0015-07-20B	229P0015-11-20B	EPROM STORE CCA	5998-01-426-5724
F-16	Displays	WAC HUD EU	229P0002-03-94A	--	EPROM STORE CCA	5998-01-450-9098
F-16	Displays	WAC HUD EU	229P0002-05-94A	--	EPROM STORE CCA	5998-01-450-9098
F-16	Displays	WAC HUD EU	229P0002-06-94A	--	EPROM STORE CCA	5998-01-450-9098
F-16	Displays	WAC HUD EU	229P0002-07-94A	--	EPROM STORE CCA	5998-01-450-9098
F-16	Displays	WAC HUD EU	229P0002-10-94A	--	EPROM STORE CCA	5998-01-450-9098
F-16	Displays	WAC HUD EU	229P0015-06-20B	229P0015-03-95B	EPROM STORE CCA	5998-01-450-9098
F-16	Displays	WAC HUD EU	229P0015-07-96A	229P0015-03-95B	EPROM STORE CCA	5998-01-450-9098
F-16	Displays	WAC HUD EU	229P0015-05-95B	229P0015-06-95B	EPROM STORE CCA	5998-01-469-1418
F-16	Displays	WAC HUD EU	229P0015-07-95B	229P0015-10-95B	EPROM STORE CCA	5998-01-469-1418
F-16	Displays	WAC HUD EU	229P0015-11-95B	--	EPROM STORE CCA	5998-01-469-1418
F-16	Displays	WAC HUD EU	229P0015-11-98B	229P0015-10-98B	EPROM STORE CCA	5998-01-469-1419
F-16	Displays	WAC HUD EU	229P0015-03-96A	229P0015-05-96A	EPROM STORE CCA	5998-01-482-9781
F-16	Displays	WAC HUD EU	229P0015-06-96A	229P0015-10-96A	EPROM STORE CCA	5998-01-482-9781
F-16	Displays	WAC HUD EU	229P0015-11-96A	229P0015-10-96A	EPROM STORE CCA	5998-01-482-9781
F-16	Displays	WAC HUD EU	229P0002-11-94A	--	EPROM STORE CCA	5998-01-503-3961
F-16	Displays	WAC HUD EU	229P0002-03-94C	229-P0002-05-94C	EPROM STORE CCA	5998-01-522-3876
F-16	Displays	WAC HUD EU	229P0002-05-94C	229-P0002-05-94C	EPROM STORE CCA	5998-01-522-3876
F-16	Displays	WAC HUD EU	229P0002-06-94C	229-P0002-05-94C	EPROM STORE CCA	5998-01-522-3876
F-16	Displays	WAC HUD EU	229P0002-07-94C	229-P0002-05-94C	EPROM STORE CCA	5998-01-522-3876
F-16	Displays	WAC HUD EU	229P0002-10-94C	229-P0002-05-94C	EPROM STORE CCA	5998-01-522-3876
F-16	Displays	WAC HUD EU	229P0002-11-94C	229-P0002-05-94C	EPROM STORE CCA	5998-01-522-3876
F-16	Displays	WAC HUD EU	229P0002-05-97A	--	EPROM STORE CCA	5998-01-547-5709
F-16	Displays	WAC HUD EU	229-P0002-05-97A	--	EPROM STORE CCA	5998-01-547-5709
F-16	Displays	WAC HUD EU	229P0002-06-97A	--	EPROM STORE CCA	5998-01-547-5709
F-16	Displays	WAC HUD EU	229P0002-07-97A	--	EPROM STORE CCA	5998-01-547-5709
F-16	Displays	WAC HUD EU	229-P0002-07-97A	--	EPROM STORE CCA	5998-01-547-5709
F-16	Displays	WAC HUD EU	229P0002-10-97A	--	EPROM STORE CCA	5998-01-547-5709

F-16	Displays	WAC HUD EU	229-P0002-10-97A	--	EPROM STORE CCA	5998-01-547-5709
F-16	Displays	WAC HUD EU	229P0002-11-97A	--	EPROM STORE CCA	5998-01-547-5709
F-16	Displays	WAC HUD EU	229P0015-10-97A	--	EPROM STORE CCA	5998-01-547-5709
F-16	Displays	WAC HUD EU	229P0002-05-99A	--	EPROM STORE CCA	5998-01-573-4161
F-16	Displays	WAC HUD EU	229P0002-07-99A	--	EPROM STORE CCA	5998-01-573-4161
F-16	Displays	WAC HUD EU	229P0002-10-99A	--	EPROM STORE CCA	5998-01-573-4161
F-16	Displays	WAC HUD EU	229P0002-11-99A	--	EPROM STORE CCA	5998-01-573-4161
F-16	Displays	WAC HUD EU	229P0002-11-06E	--	EPROM STORE CCA	5998-99-083-6593
F-16	Displays	WAC HUD EU	229-026238-10	--	Analog Output CCA	5998-99-547-6585
F-16	Displays	WAC HUD EU	229-026238-12	--	Analog Output CCA	5998-99-547-6585
F-16	Displays	WAC HUD EU	229-026238-20	--	Analog Output CCA	5998-99-547-6585
F-16	Displays	WAC HUD EU	229-026238-21	--	Analog Output CCA	5998-99-547-6585
F-16	Displays	WAC HUD EU	229-026240-04	--	ASSEMBLY	5998-99-735-6316
F-16	Displays	WAC HUD EU	229-026248-10	--	ASSEMBLY	5998-99-735-6316
F-16	Displays	WAC HUD EU	229-026260-03	--	Y DEFLECTION AMP	5998-99-735-6316
F-16	Displays	WAC HUD EU	229-026244-05	--	ASSEMBLY	5998-99-735-6350
F-16	Displays	WAC HUD EU	229-026244-06	--	ASSEMBLY	5998-99-735-6350
F-16	Displays	WAC HUD EU	229-026244-10	--	ASSEMBLY	5998-99-735-6350
F-16	Displays	WAC HUD EU	229-026247-05	--	Interface & Address Mod	5999-99-729-7429
F-16	Displays	WAC HUD EU	229-026247-06	--	Interface & Address Mod	5999-99-729-7429
F-16	Displays	WAC HUD EU	229-026247-10	--	Interface & Address Mod	5999-99-729-7429
F-16	Displays	WAC HUD EU	229-026240-10	229-026240-01	Symbol Store CCA	5999-99-735-6317
F-16	Displays	WAC HUD EU	229-026242-03	--	Scan Converter CCA	5999-99-735-6324
F-16	Displays	WAC HUD EU	229-026242-04	--	Scan Converter CCA	5999-99-735-6324
F-16	Displays	WAC HUD EU	229-026243-02	--	Scan Converter CCA	5999-99-736-0405
F-16	Displays	WAC HUD EU	229-026243-10	--	Scan Converter CCA	5999-99-736-0405
F-16	Displays	WAC HUD EU	229-030915-02	--	Loss Interface CCA	5999-99-776-6881
F-16	Displays	WAC HUD EU	229-026249-05	--	Analog Input CCA	5999-99-776-6882
F-16	Displays	WAC HUD EU	229-026249-06	--	Analog Input CCA	5999-99-776-6882
F-16	Displays	WAC HUD EU	229-026249-07	--	Analog Input CCA	5999-99-776-6882
F-16	Displays	WAC HUD EU	229-026230-10	--	Chassis Electrical	5999-99-776-6883
F-16	Displays	WAC HUD EU	229-026230-10	--	Chassis Electrical w/Connector Replacement and/or 3 SRU repairs	5999-99-776-6883
F-16	Displays	WAC HUD EU Chasis	229-026233-01	--	CHASSIS,MECHANICAL	1270-01-173-0440
F-16	Displays	WAC HUD EU Chasis	229-026232-06	--	MOTHERBOARD	1270-99-736-0403
F-16	Displays	WAC HUD EU Chasis	229-026232-06	--	Motherboard w/ Connector Replacement	1270-99-736-0403
F-16	Displays	WAC HUD EU Chasis	229-026231-02	--	WAC Cable Assy	1270-99-736-0408
F-16	Displays	WAC HUD EU Chasis	229-026232-10	--	MOTHERBOARD	4110-99-734-5813
F-16	Displays	WAC HUD EU Chasis	229-026232-10	--	Motherboard w/ Connector Replacement	4110-99-734-5813
F-16	Displays	WAC HUD EU Chasis	229-026232-01	--	MOTHERBOARD	5998-01-173-0544
F-16	Displays	WAC HUD EU Chasis	229-026232-01	--	MOTHERBOARD	5998-01-173-0544
F-16	Displays	WAC HUD EU Chasis	229-026232-04	229-026232-01	Motherboard w/ Connector Replacement	5998-01-173-0544
F-16	Displays	WAC HUD EU Chasis	229-026232-04	229-026232-01	Motherboard w/ Connector Replacement	5998-01-173-0544
F-16	Displays	WAC HUD EU Chasis	229-026232-11	--	Motherboard	5998-99-734-5813
F-16	Displays	WAC HUD EU Chasis	229-026232-11	--	Motherboard w/ Connector Replacement	5998-99-734-5813

F-16	Displays	WAC HUD EU Chasis	229-026231-01	--	WAC Cable Assy	6150-01-173-0554
F-16	Displays	WAC HUD EU Chasis	229-026231-10	--	WAC Cable Assy	6150-99-769-7847
F-16	Electronic Warfare (EW)	--	1D8200G3	--	INTERFERENCE BLANKER	5895-01-251-8547
F-16	Electronic Warfare (EW)	--	16VE019-8	1D8200G4	INTERFERENCE BLANKER	5895-01-279-3760
F-16	Electronic Warfare (EW)	--	1D8200G4	16VE019-8	INTERFERENCE BLANKER	5895-01-279-3760
F-16	Electronic Warfare (EW)	--	5188110-002	16VE278-2	ADVANCED INTERFERENCE BLANKER UNIT (AIBU)	5895-01-294-6314
F-16	Electronic Warfare (EW)	--	5188110-003	16VE278-3	ADVANCED INTERFERENCE BLANKER UNIT (AIBU)	5895-01-294-6315
F-16	Electronic Warfare (EW)	--	16VE278-5	16VE278-7	ADVANCED INTERFERENCE BLANKER UNIT (AIBU)	5895-01-308-0933
F-16	Electronic Warfare (EW)	--	5188110-005	16VE278-7	ADVANCED INTERFERENCE BLANKER UNIT (AIBU)	5895-01-308-0933
F-16	Electronic Warfare (EW)	--	5188110-006	16VE278-6	ADVANCED INTERFERENCE BLANKER UNIT (AIBU)	5895-01-331-0720
F-16	Electronic Warfare (EW)	--	5188110-008	16VE278-8	ADVANCED INTERFERENCE BLANKER UNIT (AIBU)	5895-01-331-0720
F-16	Electronic Warfare (EW)	--	5188110-004	16VE278-4	ADVANCED INTERFERENCE BLANKER UNIT (AIBU)	5895-01-347-8037
F-16	Electronic Warfare (EW)	--	16VE278-7	16VE278	ADVANCED INTERFERENCE BLANKER UNIT (AIBU)	5895-01-357-0739
F-16	Electronic Warfare (EW)	--	5188110-007	16VE278	ADVANCED INTERFERENCE BLANKER UNIT (AIBU)	5895-01-357-0739
F-16	Electronic Warfare (EW)	--	27000-1	16VE135-1	CD BAND ANTENNA	5985-01-128-7134
F-16	Electronic Warfare (EW)	--	27130-1	16VE221-1	CD BAND ANTENNA	5985-01-146-9283
F-16	Electronic Warfare (EW)	AIBU	5188154-001	--	INTERFACE CIRCUIT CARD ASSEMBLY	5998-01-270-7764
F-16	Electronic Warfare (EW)	AIBU	5188134-001	5188334-001	CPU/MEMORY CIRCUIT CARD ASSEMBLY	5998-01-270-9880
F-16	Electronic Warfare (EW)	AIBU	5188154-002	--	INTERFACE CIRCUIT CARD ASSEMBLY	5998-01-348-7544
F-16	Electronic Warfare (EW)	AIBU	5188034-001	--	CPU/MEMORY CIRCUIT CARD ASSEMBLY	5998-01-390-8577
F-16	Electronic Warfare (EW)	AIBU	5188054-001	--	INTERFACE CIRCUIT CARD ASSEMBLY	5998-01-399-3936
F-16	Electronic Warfare (EW)	AIBU	5188044-001	--	PULSE CONDITIONING CIRCUIT CARD ASSEMBLY	5998-01-418-7653
F-16	Electronic Warfare (EW)	AIBU	5188334-001	--	CPU/MEMORY CIRCUIT CARD ASSEMBLY	5998-01-418-7655
F-16	Electronic Warfare (EW)	AIBU	5188334-002	5188334-001	CPU/MEMORY CIRCUIT CARD ASSEMBLY	5998-01-418-7655
F-16	Electronic Warfare (EW)	AIBU	5188124-001	--	POWER SUPPLY	6130-01-262-2701
F-16	Engine	ENGINE,GAS TURBINE	5006052	--	CABLE ASSEMBLY	6150-01-103-1066
F-16	Engines	--	AY7707382-1	--	Controller, Starter	2925-01-436-7325
F-16	ENVIRONMENTAL CONTROL SYSTEM (ECS)	--	751865-2	--	AIR PRESSURE REGULATOR	1660-01-019-8576

F-16	ENVIRONMENTAL CONTROL SYSTEM (ECS)	--	764828-2	16VY001-2	COOLING TURBINE	1660-01-044-0180
F-16	ENVIRONMENTAL CONTROL SYSTEM (ECS)	--	764828-4	16VY001-4	COOLING TURBINE	1660-01-107-2459
F-16	ENVIRONMENTAL CONTROL SYSTEM (ECS)	--	11217-1	16VY010002-1	CONTROL BOX	1660-01-134-3020
F-16	ENVIRONMENTAL CONTROL SYSTEM (ECS)	--	11217-2	16VY010002-2	CONTROL BOX	1660-01-196-5999
F-16	ENVIRONMENTAL CONTROL SYSTEM (ECS)	--	764828-5	--	COOLING TURBINE	1660-01-328-7349
F-16	Environmental Control System (ECS)	--	3260060-0108	--	OXYGEN REGULATOR	1660-01-383-6734
F-16	ENVIRONMENTAL CONTROL SYSTEM (ECS)	--	764828-4-1	--	COOLING TURBINE	1660-01-588-4637
F-16	F-16	Displays	8001030-920	961700-A01	CORE MEMORY MODULE	5895-01-268-4634
F-16	Fire Control	--	5147419-031	--	(EFCC)	1270-01-433-0905
F-16	Fire Control	--	16E10090-5	16E10090-1	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	7025-01-242-2033
F-16	Fire Control	--	16E10090-801	16E10090-1	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	7025-01-242-2033
F-16	Fire Control	--	16E10090-805	16E10090-3	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	7025-01-242-2033
F-16	Fire Control	--	16E10090-807	16VE375-6	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	7025-01-355-8414
F-16	Fire Control	AIM-9 Launcher	8523875-10	--	POWER SUPPLY	6130-01-211-5474
F-16	Fire Control	AIM-9 Launcher	07-342-6000	--	POWER SUPPLY -- UPGRADE TO -6030	6130-01-246-9080
F-16	Fire Control	AIM-9 Launcher	8523875-30	--	POWER SUPPLY	6130-01-248-6604
F-16	Fire Control	AIM-9 Launcher	K50741000-30	--	POWER SUPPLY	6130-01-262-8352
F-16	Fire Control	AIM-9 Launcher	K50741000-10	16VE081-11	POWER SUPPLY	6130-01-274-2367
F-16	Fire Control	AIM-9 Launcher	07-342-6050	16VE081-11	POWER SUPPLY -- UPGRADE TO -6030	6130-01-312-8449
F-16	Fire Control	AIM-9 Launcher	9018690	--	POWER SUPPLY	6130-01-331-1438
F-16	Fire Control	AIM-9 Launcher	07-342-6030	--	POWER SUPPLY	6130-01-342-7707
F-16	Fire Control	AIM-9 Launcher	8523875-50	--	POWER SUPPLY	6130-01-359-5612
F-16	Fire Control	AIM-9 Launcher	3000	--	POWER SUPPLY	6130-01-420-9530
F-16	Fire Control	AIM-9 Launcher	9018869-1	--	POWER SUPPLY	6130-01-440-7591
F-16	Fire Control	AIRBORNE VIDEO TAPE RECORDER (AVTR)	16Z1450-1	--	AIRBORNE VIDEO TAPE RECORDER (AVTR)	1680-01-115-8047
F-16	Fire Control	AIRBORNE VIDEO TAPE RECORDER (AVTR)	16Z1450-5	16VEL50001-3	AIRBORNE VIDEO TAPE RECORDER (AVTR)	5836-01-411-0981
F-16	Fire Control	AIRBORNE VIDEO TAPE RECORDER (AVTR)	16Z1450-3	--	AIRBORNE VIDEO TAPE RECORDER (AVTR)	5895-01-323-4405
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7560512-011	--	16K CORE MEMORY FCC	1270-01-065-7719

F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7565700-011	16VE118001-1	ENHANCED FIRE CONTROL COMPUTER (EFCC)	1270-01-141-7376
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7565700-021	--	ENHANCED FIRE CONTROL COMPUTER (EFCC)	1270-01-222-1889
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7579884-031	7579884-31	ENHANCED FIRE CONTROL COMPUTER (EFCC)	1270-01-421-5847
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7565713-011	--	POWER INPUT MODULE ASSEMBLY	5945-01-173-0545
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7560521-011	7560524-011	CIRCUIT CARD ASSEMBLY, PIF	5998-01-065-3427
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7565637-011	--	POWER CONVERTER ASSEMBLY	5998-01-173-0452
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7560524-021	--	CIRCUIT CARD ASSEMBLY, PIF	5998-01-222-3849
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7565637-021	--	POWER CONVERTER ASSEMBLY	5998-01-253-2280
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7566795-011	--	WIRING HARNESS	6150-01-174-4044
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7565640-011	7565640-031	32K CORE MEMORY	7025-01-173-0451
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7565640-021	7565640-031	32K CORE MEMORY	7025-01-173-0451
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7565640-031	--	32K CORE MEMORY	7025-01-173-0451
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7565640-041	7565640-031	32K CORE MEMORY	7025-01-173-0451
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7579885-011	7579885-031	32K CORE MEMORY	7025-01-422-7699
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7579885-021	7579885-031	32K CORE MEMORY	7025-01-422-7699
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7579885-031	--	32K CORE MEMORY	7025-01-422-7699
F-16	Fire Control	ENHANCED FIRE CONTROL COMPUTER (EFCC)	7579885-041	7579885-031	32K CORE MEMORY	7025-01-422-7699
F-16	Fire Control	EXDEEU	16E10012-833	16E10012-1	CIRCUIT CARD ASSEMBLY	5998-01-152-1748
F-16	Fire Control	EXDEEU	16E10012-839	--	CIRCUIT CARD ASSEMBLY	5998-01-224-2782
F-16	Fire Control	EXDEEU	16E10094-1	16E10094-801	ASSEMBLY	5998-01-247-6360



F-16	Fire Control	EXDEEU	16E10094-3	16E10094-801	ASSEMBLY	5998-01-247-6360
F-16	Fire Control	EXDEEU	16E10094-5	16E10094-801	ASSEMBLY	5998-01-247-6360
F-16	Fire Control	EXDEEU	16E10094-801	--	ASSEMBLY	5998-01-247-6360
F-16	Fire Control	EXDEEU	16E10094-803	16E10094-805	ASSEMBLY	5998-01-292-9032
F-16	Fire Control	EXDEEU	16E10094-805	--	ASSEMBLY	5998-01-292-9032
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16E10096-1	16E10096-803	MEMORY CIRCUIT CARD ASSEMBLY	5998-01-247-4419
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16E10096-3	16E10096-803	MEMORY CIRCUIT CARD ASSEMBLY	5998-01-247-4419
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16E10096-803	--	MEMORY CIRCUIT CARD ASSEMBLY	5998-01-247-4419
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16E10096-805	16E10096-803	MEMORY CIRCUIT CARD ASSEMBLY	5998-01-247-4419
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16E10096-809	16E10096-803	MEMORY CIRCUIT CARD ASSEMBLY	5998-01-247-4419
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16E10096-809	16E10096-803	MEMORY CIRCUIT CARD ASSEMBLY	5998-01-247-4419
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16E10092-1	--	MOTHER BOARD	5998-01-247-6333
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16E10006-845	--	CENTRAL PROCESSOR CIRCUIT CARD ASSEMBLY	5998-01-292-7683
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16E10092-3	--	MOTHER BOARD	5998-01-423-4312
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16VE192-1	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16VE192-2	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16VE192-3	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16VE192-4	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16VE192-5	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	16VE192-6	--	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	708985-1	16VE192-6	POWER SUPPLY	6130-01-144-9322

F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	708985-2	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	708985-3	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	708985-4	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	708985-5	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	EXPANDED DATA ENTRY ELECTRONICS UNIT (EXDEEU)	708985-6	16VE192-6	POWER SUPPLY	6130-01-144-9322
F-16	Fire Control	FIRE CONTROL COMPUTER	7560535-011	--	POWER CONVERTER	1270-01-066-5979
F-16	Fire Control	FIRE CONTROL COMPUTER	7560535-021	--	POWER CONVERTER	1270-01-222-3783
F-16	Fire Control	XDEEU EXDEEU	16E10010-861	16E10010-859	AMUX CIRCUIT CARD ASSEMBLY	5998-01-271-7138
F-16	Fire Control	XDEEU EXDEEU	16E10010-863	16E10010	AMUX CIRCUIT CARD ASSEMBLY	5998-01-316-0048
F-16	Fire Control	XDEEU EXDEEU MLDEEU	16E10014-829	--	DISCREET/ANALOG CIRCUIT CARD ASSEMBLY	5998-01-304-1674
F-16	Fire Control	XDEEU EXDEEU MLDEEU	16E10016-829	--	COMM INTERFACE #1 CIRCUIT CARD ASSEMBLY	5998-01-439-0670
F-16	FLIGHT CONTROL COMPUTER (FLCC)	CONNECTOR,RECEPTACLE,ELECTRICAL	460744-03-01	--	PITCH 1 CIRCUIT CARD ASSEMBLY	5998-01-232-1409
F-16	Flight Control Instruments	--	A4132210015	AAU-34/A	ALTIMETER	6610-01-016-1583
F-16	Flight Control Instruments	--	A41322-10-015	3252022-0101	ALTIMETER	6610-01-035-0673
F-16	Flight Control Instruments	--	4025116-905	16VC004-5	CENTRAL AIR DATA COMPUTER (CADC)	6610-01-089-1018
F-16	Flight Control Instruments	--	4025116-907	16VC004-4	CENTRAL AIR DATA COMPUTER (CADC)	6610-01-308-1859
F-16	Flight Control Instruments	--	8518930-901	--	Upgraded CENTRAL AIR DATA COMPUTER (UCADC)	6610-01-372-8170
F-16	Flight Control Instruments	--	98700000-02	16VF041-2	VERTICAL VELOCITY INDICATOR	6610-01-395-3510
F-16	Flight Control Instruments	--	16C0605-813	--	FLIGHT CONTROL PANEL (FCP)	6615-01-042-7837
F-16	Flight Control Instruments	--	16C0605-823	16C0605-819	FLIGHT CONTROL PANEL (FCP)	6615-01-088-0618
F-16	Flight Control Instruments	--	16C0605-825	--	FLIGHT CONTROL PANEL (FCP) *DOES NOT INCLUDE REPAIR OF EDGE LIGHT	6615-01-127-3160
F-16	Flight Control Instruments	--	16C0605-827	--	FLIGHT CONTROL PANEL (FCP)	6615-01-396-9213
F-16	Flight Control Instruments	--	16C0200-809	16VC040-2	FLIGHT CONTROL DATA RECORDER (FCDR)	6625-01-114-6771

F-16	Flight Control Instruments	--	16C0200-813	--	FLIGHT CONTROL DATA RECORDER (FCDR)	6625-01-331-2554
F-16	Flight Control Instruments	--	16C0200-815	--	FLIGHT CONTROL DATA RECORDER (FCDR)	6625-01-331-2554
F-16	Flight Control Instruments	Auto Pilot Controller	16C0630-3	--	Auto Controller CCA	
F-16	Flight Control Instruments	CADC	4027114-901	--	FREQUENCY/DIGITAL CONTROL	5998-01-061-7716
F-16	Flight Control Instruments	CADC	4027102-902	--	INSTRUMENT CAUTION CIRCUIT CARD ASSEMBLY	5998-01-307-5242
F-16	Flight Control Instruments	CADC	4007515-903	8518987	TRANSMITTER, PRESSURE	6685-00-149-1026
F-16	Flight Control Instruments	CADC	4007515-902	--	RECEIVER TRANSMITTER	6685-00-259-3013
F-16	Flight Control Instruments	Data Comparator	16C0610-817	--	CIRCUIT CARD ASSY	5998-01-184-9085
F-16	Flight Control Instruments	FCP	16C0606-811	--	TORQUE DISC CIRCUIT CARD ASSEMBLY	5998-01-072-0093
F-16	Flight Control Instruments	FCP	16C0608-811	--	DATA REC CIRCUIT CARD ASSEMBLY	5998-01-087-7202
F-16	Flight Control Instruments	FCP	16C0608-807	--	DATA REC CIRCUIT CARD ASSEMBLY	5998-01-137-5818
F-16	Flight Control Instruments	FCP	16C0202-805	16C0202	CIRCUIT CARD ASSEMBLY	5998-01-330-4888
F-16	Flight Control Instruments	FCP	16C0606-813	--	TORQUE DISC CIRCUIT CARD ASSEMBLY	5998-01-398-8927
F-16	Flight Control Instruments	UCADC	8518945-902	--	CCA	5998-01-399-5953
F-16	GENERAL AVIONICS COMPUTER (GAC)		8908480-507	8908480-509	MEMORY MODULE	5998-01-308-8907
F-16	GENERAL AVIONICS COMPUTER (GAC)		8908480-509	--	MEMORY MODULE	5998-01-308-8907
F-16	GENERAL AVIONICS COMPUTER (GAC)		8908480-515	8908480-509	MEMORY MODULE	5998-01-308-8907
F-16	GENERAL AVIONICS COMPUTER (GAC)		8921250-505	--	MEMORY MODULE	5998-01-308-8907
F-16	GPS	CABLE ASSEMBLY,RADIO REQUENCY	164080	164080-005	ELECTRONIC AMPLIFIER	5996-01-223-3363
F-16	GPS IF MAGR		822-0204-002	R-2514A/U	RECEIVER, RADIO NAVIGATION	5826-01-387-0975
F-16	GROUND SUPPORT		16U472-1	16U472-5	CIRCUIT CARD ASSEMBLY	5998-01-079-4170
F-16	GROUND SUPPORT		16U472-5	--	CIRCUIT CARD ASSEMBLY	5998-01-079-4170
F-16	GROUND SUPPORT		16U368-809	--	CCA/ BUFFER ASSEMBLY	5998-01-237-5899
F-16	GROUND SUPPORT		16U368-811	16U368-809	CCA/ BUFFER ASSEMBLY	5998-01-237-5899
F-16	GROUND SUPPORT		16U3720-5	--	EPV SELF TEST ADAPTER	NSL
F-16	Gun System, M61A1	--	201F903	MC13857	(OVERHAUL)	1005-01-041-8667
F-16	Gun System, M61A1	--	201F904	217F429	(OVERHAUL)	1005-01-061-8335
F-16	Gun System, M61A1	--	211F547	MC5879-6	HYDRAULIC DRIVE	1005-01-119-7011
F-16	IFF	--	163300	163350	TRANSMITTER	5895-01-294-1053
F-16	IFF	--	164750	16VE311001-4	AIFF CIT	5895-01-294-1053
F-16	IFF	--	165615-0002	165615-0003	TRANSMITTER	5895-01-294-1053
F-16	IFF	--	164750-0002	16VE311001-7	AIFF CIT	5895-01-436-7592
F-16	IFF	--	164750-0003	--	AIFF CIT	5895-01-476-8255
F-16	IFF	--	166700-0100	--	AN/APX-109 + (V3)	NSL

F-16	IFF	--	166970-0100	--	Antenna, Upper, 109+	NSL
F-16	IFF	AN/APX-109 (V)2 AIFF	159222-0004	159222-0002	I/O MEMORY 2	5895-01-304-7576
F-16	IFF	AN/APX-109 (V)2 AIFF	8904250-002	159222-0002	I/O MEMORY 3	5895-01-304-7576
F-16	IFF	AN/APX-109 (V)2 AIFF	163242	164765	RF FRONT END	5895-01-307-8092
F-16	IFF	AN/APX-109 (V)2 AIFF	163950-0005	AS-3952/APX-109(V)2	ANTENNA	5985-01-316-4588
F-16	IFF	AN/APX-109 (V)2 AIFF	163950-0006	AS-3951/APX-109(V)2	ANTENNA	5985-01-316-4589
F-16	IFF	AN/APX-109 (V)2 AIFF	165010	165615	I/O ASSY	5998-01-302-2154
F-16	IFF	AN/APX-109 (V)2 AIFF	SK165010	SK165615	I/O ASSY	5998-01-302-2154
F-16	IFF	AN/APX-109 (V)2 AIFF	163313	164422	PROCESSOR, INTERROGATOR	5998-01-305-1039
F-16	IFF	AN/APX-109 (V)2 AIFF	165685	165585-0002	PROCESSOR, INTERROGATOR	5998-01-305-1039
F-16	IFF	AN/APX-109 (V)2 AIFF	159222-0003	159222-0001	CPU & MEMORY ASSY	5998-01-306-1489
F-16	IFF	AN/APX-109 (V)2 AIFF	8903910-501	8904210-001	CPU & MEMORY ASSY	5998-01-306-1489
F-16	IFF	AN/APX-109 (V)2 AIFF	SK159222	159222-0001	CPU & MEMORY ASSY	5998-01-306-1489
F-16	IFF	AN/APX-109 (V)2 AIFF	162188	164317	PROCESSOR, TRANSPONDER	5998-01-306-9759
F-16	IFF	AN/APX-109 (V)2 AIFF	162411	165039	POWER SUPPLY	6130-01-303-0448
F-16	IFF	AN/APX-109 (V)2 AIFF	165039-0002	165039	POWER SUPPLY	6130-01-303-0448
F-16	IFF	AN/APX-109 (V)2 AIFF	164754-002	--	INTERCONNECT	NSL
F-16	IFF	AN/APX-109 (V)2 AIFF	165585-0004	--	INTERROGATOR SIGNAL PROCESSOR	NSL
F-16	IFF	AN/APX-109 (V)2 AIFF	168300-0002	--	RF FRONT END	NSL
F-16	IFF	AN/APX-109 + (V)3 AIFF	163295	--	TRANSPONDER RECEIVER	5821-01-304-1699
F-16	IFF	AN/APX-109 + (V)3 AIFF	163310-0002	163310	INTERROGATOR RECEIVER	5895-01-306-2104
F-16	IFF	AN/APX-109 + (V)3 AIFF	163310-0003	163310	INTERROGATOR RECEIVER	5895-01-306-2104
F-16	IFF	AN/APX-109 + (V)3 AIFF	165615	162370	DISCRETE INPUT OUTPUT	5998-01-302-2154
F-16	IFF	AN/APX-109 + (V)3 AIFF	168300	--	RF FRONT END	NSL
F-16	IFF	AN/APX-109 + (V)3 AIFF	168940	--	POWER	NSL
F-16	IFF	AN/APX-109 + (V)3 AIFF	168960	--	TRANSMITTER	NSL
F-16	IFF	AN/APX-109 + (V)3 AIFF	163295-0002	--	A-5	NSL

F-16	IFF	AN/APX-109 + (V)3 AIFF	163295-0003	--	A-6	NSL
F-16	IFF	AN/APX-109 + (V)3 AIFF	163310-0002	--	A-7	NSL
F-16	IFF	AN/APX-109 + (V)3 AIFF	164317-0004	--	A-8	NSL
F-16	IFF	AN/APX-109 + (V)3 AIFF	164422-0002	--	INTERROGATOR SIGNAL PROCESSOR	NSL
F-16	IFF	AN/APX-109 + (V)3 AIFF	164765-0002	--	RF FRONT END	NSL
F-16	INTERFACE UNIT,FIRE CONTROL	FILTER	16E1234-813	--	F-16 A/B MISSILE LOGIC CCA	5998-01-108-3415
F-16	INTERFACE UNIT,FIRE CONTROL	PANEL POWER STATUS	16E1242-809	--	CCA	5998-01-101-3020
F-16	INTERFACE UNIT,FIRE CONTROL	PIN,STRAIGHT,HEADL ESS	16E1292-807	--	CCA, CONDITIONING LOGIC	5998-01-083-8515
F-16	MISSION PLANNING SYSTEM / PORTABLE FLIGHT PLANNING SYSTEM		35P1000000	--	DATA TRANSFER CARTRIDGE (DTUC) LOADER	4920-01-407-2212
F-16	NAVSTAR GPS		200-104500-01	--	FREQUENCY CONVERTER	5895-01-278-0765
F-16	NAVSTAR GPS		30151-8614	--	ELECTRONIC COMPONENT	5998-01-216-0591
F-16	NAVSTAR GPS		200-105038-02	--	SIGNAL CONVERTER	6625-01-248-3637
F-16	STORES CONTROL PANEL		16E1201-853	--	PANEL ASSY	1280-01-121-6879
F-16	Stores Management	--	16E10100-841	16VE236001-11	ADVANCED CENTRAL REMOTE INTERFACE UNIT (ACRIU)	1270-01-506-2367
F-16	Stores Management	--	16E10200-801	--	AFT STATION INTERFACE UNIT (ASIU)	1280-01-417-1296
F-16	Stores Management	--	16E1608-875	--	INTERFACE UNIT, REMOTE FIRE CONTROL	1290-01-080-0203
F-16	Stores Management	--	16E1607-807	16E1607-875	MISSILE REMOTE INTERFACE UNIT (MRIU)	1290-01-109-1499
F-16	Stores Management	--	16E1535-805	16E1535-813	(ACIU)	1290-01-148-6286
F-16	Stores Management	--	16E1535-817	16E1535-819	(ACIU)	1290-01-148-6286
F-16	Stores Management	--	16E1535-827	16E1535-835	(ACIU)	1290-01-148-6286
F-16	Stores Management	--	16E10180-5	--	(XCIU)	1290-01-224-8924
F-16	Stores Management	--	16E1535-837	--	(ACIU)	1290-01-227-9260
F-16	Stores Management	--	16E10080-805	16E10080-807	(ECIU)	1290-01-297-8068
F-16	Stores Management	--	16E10080-809	16E10080-807	(ECIU)	1290-01-297-8068
F-16	Stores Management	--	16E10080-811	--	(ECIU)	1290-01-322-3711
F-16	Stores Management	--	16E10180-801	--	(XCIU)	1290-01-340-6317
F-16	Stores Management	--	16E1535-839	--	(ACIU)	1290-01-366-5639
F-16	Stores Management	--	16E10080-817	--	(ECIU)	1290-01-376-5449
F-16	Stores Management	--	16E10100-839	16VE236001-10	ADVANCED CENTRAL REMOTE INTERFACE UNIT (ACRIU)	1290-01-463-3594
F-16	Stores Management	--	16E10080-829	16E10080	(ECIU)	1290-01-465-3027
F-16	Stores Management	--	16E1535-843	--	(ACIU)	1290-01-465-3028
F-16	Stores Management	--	16E10080-825	16E10080	(ECIU)	1290-01-465-3030
F-16	Stores Management	--	16E10080-827	16E10080	(ECIU)	1290-01-465-3032
F-16	Stores Management	--	16E10100-803	16E10100-807	ADVANCED CENTRAL REMOTE INTERFACE UNIT (ACRIU)	5945-01-170-9363
F-16	Stores Management	--	16E10100-815	16E10100-823	ADVANCED CENTRAL REMOTE INTERFACE UNIT (ACRIU)	5945-01-170-9363

F-16	Stores Management	--	16E10100-831	16E10100-803	ADVANCED CENTRAL REMOTE INTERFACE UNIT (ACRIU)	5945-01-170-9363
F-16	Stores Management	--	16E1606-831	--	(JRIU)	5998-01-080-3978
F-16	Stores Management	--	16E10150-3	--	ADVANCED MISSILE REMOTE INTERFACE UNIT (AMRIU) **MOD TO -801	5998-01-189-6233
F-16	Stores Management	--	16E10150-801	16E10150	ADVANCED MISSILE REMOTE INTERFACE UNIT (AMRIU)	5998-01-322-7746
F-16	Stores Management	--	16E10600-3	--	MUX LOADABLE DATA ENTRY ELECTRONICS UNIT (MLDEEU)	5998-01-417-9658
F-16	Stores Management	--	16VE957-30	16VE957-20	(CDEEU)	7025-01-478-9420
F-16	Stores Management	--	MB025A-21	--	(CDEEU)	7025-01-501-2665
F-16	Stores Management	--	MB025A-32	16VE957-32	(CDEEU)	7025-01-509-3748
F-16	Stores Management	--	MB025A-22	16VE957-22	(CDEEU)	7025-01-543-1818
F-16	Stores Management	ACIU	16E1522-3	16E1522-1	ASSEMBLY	5998-01-146-1533
F-16	Stores Management	ACIU	16E1520-1	16E1520-3	I/O CIRCUIT CARD ASSEMBLY	5998-01-146-1534
F-16	Stores Management	ACIU	16E1520-5	16E1520-801	I/O CIRCUIT CARD ASSEMBLY	5998-01-146-1534
F-16	Stores Management	ACIU	16E1520-803	16E1520-805	I/O CIRCUIT CARD ASSEMBLY	5998-01-146-1534
F-16	Stores Management	ACIU	16E1520-807	16E1520-1	I/O CIRCUIT CARD ASSEMBLY	5998-01-146-1534
F-16	Stores Management	ACIU	16E1518-1	16E1518-801	DMA/RAM CIRCUIT CARD ASSEMBLY	5998-01-146-1535
F-16	Stores Management	ACIU	16E1518-3	16E1518-5	DMA/RAM CIRCUIT CARD ASSEMBLY	5998-01-146-1535
F-16	Stores Management	ACIU	16E1514-1	16E1514-3	MULT. IND. CIRCUIT CARD ASSEMBLY	5998-01-146-1536
F-16	Stores Management	ACIU	16E1514-5	16E1514-809	MULT. IND. CIRCUIT CARD ASSEMBLY	5998-01-146-1536
F-16	Stores Management	ACIU	16E1514-813	16E1514-821	MULT. IND. CIRCUIT CARD ASSEMBLY	5998-01-146-1536
F-16	Stores Management	ACIU	16E1516-805	16E1516-3	ASSEMBLY	5998-01-146-9507
F-16	Stores Management	ACIU	16E1516-815	16E1516-819	ASSEMBLY	5998-01-146-9507
F-16	Stores Management	ACIU	16E1516-841	16E1516-833	ASSEMBLY	5998-01-146-9507
F-16	Stores Management	ACIU	16E1514-823	--	MULT. IND. CIRCUIT CARD ASSEMBLY	5998-01-189-8206
F-16	Stores Management	ACIU	16E1516-845	16E1516-843	ASSEMBLY	5998-01-263-9413
F-16	Stores Management	ACIU	16E1514-825	--	MULT. IND. CIRCUIT CARD ASSEMBLY	5998-01-280-1756
F-16	Stores Management	ACIU	16E1516-847	--	ASSEMBLY	5998-01-323-3467
F-16	Stores Management	ACIU	16E1516-849	16E1516-851	ASSEMBLY	5998-01-385-8520
F-16	Stores Management	ACIU	16E1514-827	--	MULT. IND. CIRCUIT CARD ASSEMBLY	5998-01-385-8524
F-16	Stores Management	ACRIU	16E10105-5	16E10105-805	MASTER INTERCONNECT ASSEMBLY	5895-01-170-9362
F-16	Stores Management	ACRIU	16E10105-801	16E10105-805	MASTER INTERCONNECT ASSEMBLY	5895-01-170-9362
F-16	Stores Management	ACRIU	16E10105-809	16E10105-807	MASTER INTERCONNECT ASSEMBLY	5895-01-214-0033
F-16	Stores Management	ACRIU	16E10112-1	16E10112-803	ANALOG I/O CIRCUIT CARD ASSEMBLY	5998-01-170-9678
F-16	Stores Management	ACRIU	16E10112-5	16E10112-803	ANALOG I/O CIRCUIT CARD ASSEMBLY	5998-01-170-9678
F-16	Stores Management	ACRIU	16E10114-801	16E10114-3	ASSEMBLY	5998-01-172-0314
F-16	Stores Management	ACRIU	16E10114-805	16E10114-809	ASSEMBLY	5998-01-172-0314
F-16	Stores Management	ACRIU	16E10114-815	16E10114-817	ASSEMBLY	5998-01-172-0314
F-16	Stores Management	ACRIU	16E10114-819	16E10114-3	ASSEMBLY	5998-01-172-0314
F-16	Stores Management	ACRIU	16E10116-807	16E10116-801	ASSEMBLY	5998-01-172-1509
F-16	Stores Management	ACRIU	16E10116-807	16E10116-803	ASSEMBLY	5998-01-172-1509
F-16	Stores Management	ACRIU	16E10112-805	--	ANALOG I/O CIRCUIT CARD ASSEMBLY	5998-01-238-0083
F-16	Stores Management	ACRIU	16E10114-821	--	ASSEMBLY	5998-01-388-0847
F-16	Stores Management	AMRIU	16E10154-803	--	ASSEMBLY	5998-01-326-8758
F-16	Stores Management	AMRIU	16E10157-801	--	ASSEMBLY	5998-01-330-4885
F-16	Stores Management	AMRIU	16E10157-803	--	ASSEMBLY	5998-01-459-3559
F-16	Stores Management	CDEEU	29446B-01	--	CDEEU Power Supply	5998-01-559-1236
F-16	Stores Management	CDEEU	23999A-03	--	CCA	5998-01-592-8704
F-16	Stores Management	ECA	16C0860-805	--	CIRCUIT CARD ASSEMBLY	5998-01-072-0083
F-16	Stores Management	ECA	16C0862-801	--	CIRCUIT CARD ASSEMBLY	5998-01-072-0084
F-16	Stores Management	ECA	16C0864-807	--	ASSEMBLY	5998-01-072-0085

F-16	Stores Management	ECA	16C0866-803	16C0864-803	CIRCUIT CARD ASSEMBLY	5998-01-072-0086
F-16	Stores Management	ECA	16C0858-801	--	CIRCUIT CARD ASSEMBLY	5998-01-090-2369
F-16	Stores Management	ECA	16C0894-801	--	ASSEMBLY	5998-01-113-7532
F-16	Stores Management	ECA	16C0878-807	--	AUTO PILOT CIRCUIT CARD ASSEMBLY	5998-01-116-9555
F-16	Stores Management	ECA	16C0890-809	--	CIRCUIT CARD ASSEMBLY	5998-01-117-8598
F-16	Stores Management	ECA	16C0892-803	--	CIRCUIT CARD ASSEMBLY	5998-01-125-3912
F-16	Stores Management	ECA	16C0866-805	16C0864-805	CIRCUIT CARD ASSEMBLY	5998-01-199-0760
F-16	Stores Management	ECA	16C0864-815	16C0864-817	ASSEMBLY	5998-01-331-0671
F-16	Stores Management	ECA	16C0864-817	--	ASSEMBLY	5998-01-331-0671
F-16	Stores Management	ECA	16C0894-803	16C0894	ASSEMBLY	5998-01-396-9211
F-16	Stores Management	ECA	16C0890-807	--	CIRCUIT CARD ASSEMBLY	5999-01-105-2225
F-16	Stores Management	ECIU	16E10078-801	16E10078-803	ASSEMBLY	5998-01-250-7393
F-16	Stores Management	ECIU	16E10078-805	16E10078-811	ASSEMBLY	5998-01-250-7393
F-16	Stores Management	ECIU	16E10078-813	16E10078-1	ASSEMBLY	5998-01-250-7393
F-16	Stores Management	ECIU	16E10082-1	16E10082-3	STORES DATA CIRCUIT CARD ASSEMBLY	5998-01-250-7394
F-16	Stores Management	ECIU	16E10082-801	16E10082-5	STORES DATA CIRCUIT CARD ASSEMBLY	5998-01-250-7394
F-16	Stores Management	ECIU	16E10082-805	16E10082-803	STORES DATA CIRCUIT CARD ASSEMBLY	5998-01-250-7394
F-16	Stores Management	ECIU	16E10084-801	16E10084-805	CIRCUIT CARD ASSEMBLY	5998-01-250-7395
F-16	Stores Management	ECIU	16E10084-803	16E10084-807	CIRCUIT CARD ASSEMBLY	5998-01-250-7395
F-16	Stores Management	ECIU	16E10084-809	16E10084-811	CIRCUIT CARD ASSEMBLY	5998-01-250-7395
F-16	Stores Management	ECIU	16E10084-813	16E10084-811	CIRCUIT CARD ASSEMBLY	5998-01-250-7395
F-16	Stores Management	ECIU	16E10088-1	--	ASSEMBLY	5998-01-266-0464
F-16	Stores Management	ECIU	16E10082-807	16E10082-813	STORES DATA CIRCUIT CARD ASSEMBLY	5998-01-322-9983
F-16	Stores Management	ECIU	16E10082-813	16E10082-809	STORES DATA CIRCUIT CARD ASSEMBLY	5998-01-322-9983
F-16	Stores Management	ECIU	16E10088-3	--	ASSEMBLY	5998-01-324-3582
F-16	Stores Management	ECIU	16E10084-819	16E10084-817	CIRCUIT CARD ASSEMBLY	5998-01-422-9014
F-16	Stores Management	ECIU ACIU	16VE183-1	5101000-001	PROGRAM MEMORY MODULE	5998-01-140-1965
F-16	Stores Management	ECIU ACIU	5101000-002	5101000-003	PROGRAM MEMORY MODULE	5998-01-140-1965
F-16	Stores Management	ECIU ACIU	5101000-006	5101000-008	PROGRAM MEMORY MODULE	5998-01-140-1965
F-16	Stores Management	ECIU ACIU	5101000-009	16VE183-1	PROGRAM MEMORY MODULE	5998-01-140-1965
F-16	Stores Management	ECIU ACIU	16VE183-4	5101000-010	PROGRAM MEMORY MODULE	5998-01-465-3764
F-16	Stores Management	ECIU ACIU	5101000-011	5101000-012	PROGRAM MEMORY MODULE	5998-01-465-3764
F-16	Stores Management	ECIU ACIU	5101000-013	5101000-014	PROGRAM MEMORY MODULE	5998-01-465-3764
F-16	Stores Management	ECIU ACIU	5101000-015	5101000-016	PROGRAM MEMORY MODULE	5998-01-465-3764
F-16	Stores Management	ECIU ACIU	11224-2	11224-1	POWER SUPPLY	6130-01-140-2238
F-16	Stores Management	ECIU ACIU	11224-3	16VE157-4	POWER SUPPLY	6130-01-140-2238
F-16	Stores Management	ECIU ACIU	11224-4	16VE157-4	POWER SUPPLY	6130-01-140-2238
F-16	Stores Management	ECIU ACIU	11224-5	16VE157-5	POWER SUPPLY	6130-01-301-3270
F-16	Stores Management	EXDEEU MLDEEU	16E10098-3	16E10098-1	COMM INTERFACE #2 CIRCUIT CARD ASSEMBLY	5998-01-247-4461

F-16	Stores Management	EXDEEU MLDEEU	16E10098-5	16E10098-1	COMM INTERFACE #2 CIRCUIT CARD ASSEMBLY	5998-01-247-4461
F-16	Stores Management	EXDEEU MLDEEU	16E10098-801	16E10098-1	COMM INTERFACE #2 CIRCUIT CARD ASSEMBLY	5998-01-247-4461
F-16	Stores Management	EXDEEU MLDEEU	16E10094-807	16E10094	OPERATOR INTERFACE CIRCUIT CARD ASSEMBLY	5998-01-353-1656
F-16	Stores Management	EXDEEU MLDEEU	16E10094-809	16E10094	OPERATOR INTERFACE CIRCUIT CARD ASSEMBLY	5998-01-353-1656
F-16	Stores Management	EXDEEU MLDEEU	16E10094-811	16E10094	OPERATOR INTERFACE CIRCUIT CARD ASSEMBLY	5998-01-353-1656
F-16	Stores Management	JRIU	16E1223-813	--	I/O JETTISON CIRCUIT CARD ASSEMBLY	5998-01-112-7124
F-16	Stores Management	JRIU AMRIU	16E1222-815	--	TRANSCEIVER CIRCUIT CARD ASSEMBLY	5998-01-072-2440
F-16	Stores Management	JRIU AMRIU	16E1222-819	--	TRANSCEIVER CIRCUIT CARD ASSEMBLY	5998-01-136-0642
F-16	Stores Management	JRIU AMRIU	16E1222-821	--	TRANSCEIVER CIRCUIT CARD ASSEMBLY	5998-01-189-2964
F-16	Stores Management	JRIU AMRIU	16E1222-825	--	TRANSCEIVER CIRCUIT CARD ASSEMBLY	5998-01-322-7205
F-16	Stores Management	JRIU AMRIU	16E1222-829	--	TRANSCEIVER CIRCUIT CARD ASSEMBLY	5998-01-388-0249
F-16	Stores Management	JRIU AMRIU	16E1222-833	--	TRANSCEIVER CIRCUIT CARD ASSEMBLY	5998-01-388-9809
F-16	Stores Management	JRIU AMRIU	16E1222-827	--	TRANSCEIVER CIRCUIT CARD ASSEMBLY	5998-01-423-2184
F-16	Stores Management	LAIMMD	16E4029-5	--	RELAY ASSEMBLY	5895-01-353-2220
F-16	Stores Management	LEFT HAND AFT INTERFACE MATRIX (LAIM D)	16E4014-801	--	CIRCUIT CARD ASSEMBLY	5998-01-350-8063
F-16	Stores Management	MAU-12 MAU-40/A MAU-50/A	7630933	7630933-10	BOMB RACK TEST SET	4933-01-049-7584
F-16	Stores Management	MLDEEU	16E10010-1	16E10010-843	ASSEMBLY	5998-01-152-1741
F-16	Stores Management	MLDEEU	16E10010-825	16E10010-843	ASSEMBLY	5998-01-152-1741
F-16	Stores Management	MLDEEU	16E10010-837	16E10010-843	ASSEMBLY	5998-01-152-1741
F-16	Stores Management	MLDEEU	16E10010-843	--	ASSEMBLY	5998-01-152-1741
F-16	Stores Management	MLDEEU	16E10010-827	--	ASSEMBLY	5998-01-163-1797
F-16	Stores Management	MLDEEU	16E10010-833	16E10010-827	ASSEMBLY	5998-01-163-1797
F-16	Stores Management	MLDEEU	16E10010-839	16E10010-827	ASSEMBLY	5998-01-163-1797
F-16	Stores Management	MLDEEU	16E10010-845	16E10010-827	ASSEMBLY	5998-01-163-1797
F-16	Stores Management	MLDEEU	16E10010-847	16E10010-827	ASSEMBLY	5998-01-163-1797
F-16	Stores Management	MLDEEU	16E10010-849	--	ASSEMBLY	5998-01-215-4557
F-16	Stores Management	MLDEEU	16E10602-3	--	CIRCUIT CARD ASSEMBLY	5998-01-417-8528
F-16	Stores Management	MLDEEU	16E10006-847	--	ASSEMBLY	5998-01-417-9660
F-16	Stores Management	MLDEEU	16E10606-3	--	MLDEEU/EXP. MEM	5998-01-418-7640
F-16	Stores Management	MLDEEU	16E10610-3	--	MOTHER BOARD	5998-01-419-8809
F-16	Stores Management	MLDEEU	16E10006-849	--	ASSEMBLY	5998-01-453-1162
F-16	Stores Management	MLDEEU	16E10014-833	--	ASSEMBLY	5998-01-456-0717
F-16	Stores Management	MLDEEU	1419000G1	1419000G1-1	POWER SUPPLY	6130-01-343-1930
F-16	Stores Management	MLDEEU	1419000G4	1419000G4-1	POWER SUPPLY	6130-01-343-1930
F-16	Stores Management	MRIU	16E1611-803	--	CHASSIS, HOUSING (MRIU)	



F-16	Stores Management	RIGHT HAND AFT INTERFACE MATRIX (LAIM C)	16E4023-3	16E4023	RIGHT HAND AFT INTERFACE MATRIX (LAIM C) **MOD -3 TO -5	5895-01-343-5744
F-16	Stores Management	RIGHT HAND AFT INTERFACE MATRIX (LAIM C)	16E4023-5	--	RIGHT HAND AFT INTERFACE MATRIX (LAIM C)	5895-01-354-4287
F-16	Stores Management	RIGHT HAND AFT INTERFACE MATRIX (LAIM C)	16E4023-803	--	RIGHT HAND AFT INTERFACE MATRIX (LAIM C)	5895-01-411-7679
F-16	Stores Management	RIGHT HAND AFT INTERFACE MATRIX (LAIM C)	16E4023-805	--	RIGHT HAND AFT INTERFACE MATRIX (LAIM C)	5895-01-425-8264
F-16	Stores Management	RIGHT HAND AFT INTERFACE MATRIX (LAIM C)	16E4023-801	--	RIGHT HAND AFT INTERFACE MATRIX (LAIM C)	5895-01-450-6414
F-16	Stores Management	XCIU	16E1238-809	--	STORE DATA PROCESSOR	5998-01-111-9800
F-16	Stores Management	XCIU	16E10190-5	16E1090-801	INTERCONNECT ASSY	5998-01-222-9568
F-16	Stores Management	XCIU	16VE042-8	11141-8	POWER SUPPLY	6130-01-100-1875
F-16	TEST ADAPTER		1950529-1	--	CIRCUIT CARD ASSEMBLY	5998-00-472-1385
F-16	VARIOUS		2800481-1	--	GUIDE INDICATOR	6605-01-127-8765
F-16	VARIOUS		501-1847-01	--	INDICATOR	6605-01-499-0864
F-16	VARIOUS		472144-006	--	INDICATOR	6680-01-107-2196
F-16	VOICE MESSAGE UNIT	--	5173100-002	16VF036002-1	ALARM SET, PILOT WARNING	6340-01-235-3351
F-16			MB391C-03	--	ACPDG	1280-01-517-2720
F-16			MB332A-03	--	(CCIU)	1290-01-523-9628
F-16			MB211G-01	--	DIGITAL VIDEO RECORDER (DVR)	5836-01-520-4682
F-16			16C0851-837	--	ELECTRONIC COMPONENTS ASSEMBLY	5998-01-123-0046
F-16			2115110-104	--	CIRCUIT CARD ASSEMBLY	5998-01-190-0718
F-16			DVRM-002A-00	--	DVR RMC	7045-01-562-8767
F-16 C-130	Electronic Warfare (EW)	--	1D8200G2	--	INTERFERENCE BLANKER	5895-01-237-0593
F-16 C-130	Electronic Warfare (EW)	--	1D5740G15	--	INTERFERENCE BLANKER	5895-01-510-4697
F-16 F-15	AN/AAQ-13 LANTIRN		2689570-1	49001400-1	PRESSURIZATION ASSY	1270-01-250-7263
F-16 F-15	Gun System, M61A1	--	211F467	MC13852-1	HYDRAULIC DRIVE	1005-01-093-2225
F-16C/D			200927980-10	--	DISPLAY UNIT, HEAD UP	1270-01-575-6660
F-16C/D			200927981-10	--	HEAD UP DISPLAY UNIT	1270-01-578-2401
F-16C/D			200927979-10	--	DISPLAY UNIT, HEAD UP	1270-01-578-2403
F-16D			146240-13	--	HEAD UP DISPLAY MONITOR	1270-01-357-1351
F-18			MB561C-03	--	MFCDR	1680-01-608-2552
F-4	AN/ALQ-125		690869-9	--	MEMORY MODULE	5999-01-110-9423
F-4	Flight Control Instruments	--	2021501	221501	LIQUID QUANTITY INDICATOR	6680-01-237-4642
F-4	Flight Control Instruments	--	20-215-01	2021501	INDICATOR	6680-01-237-4642
F-4	MICROWAVE ASSEMBLY	FUSE LINK,ELECTRICAL	616R032G001	616R032G01	MODULE, MIXER ASSEMBLY	1430-00-932-8553
F-4	MICROWAVE ASSEMBLY	FUSE LINK,ELECTRICAL	616R818G01	616R032G01	MODULE, MIXER ASSEMBLY	1430-00-932-8553
F-4G	AN/APR-38		226753-001	20276-02	POWER SUPPLY	6130-01-041-0597
F-4G	AN/APR-38		226759-001	20274-02	POWER SUPPLY	6130-01-044-0505

F-5	AN/APQ-153 RADAR SET	BOLT,MACHINE	633188-313	--	CIRCUIT CARD ASSEMBLY	5998-01-003-7225
F-5	AN/APQ-153 RADAR SET	DUPLEXER	633300-307	633300-313	RADAR RECEIVER/TRANSMITTER	1270-00-146-3788
F-5	AN/APQ-153 RADAR SET	DUPLEXER	700599-1	633353-403	MODULATOR ASSEMBLY	1290-00-025-5458
F-5	AN/APQ-153 RADAR SET	DUPLEXER	700630-1	633353-403	MODULATOR ASSEMBLY	1290-00-025-5458
F-5	AN/APQ-153 RADAR SET	INSULATOR,BUSHING	700685-1	633353-417	CIRCUIT CARD ASSEMBLY	5998-00-025-5464
F-5	AN/APQ-153 RADAR SET	INSULATOR,BUSHING	700685-3	633353-417	CIRCUIT CARD ASSEMBLY	5998-00-025-5464
F-5	AN/APQ-153 RADAR SET	LOCK,BEARING	633180-305	633180-1	YOKE AND SHIELD ASSEMBLY w/ Tube Replacement	1270-00-165-9922
F-5	AN/APQ-153 RADAR SET	LOCK,BEARING	633180-305	633180-1	YOKE AND SHIELD ASSEMBLY w/o Tube Replacement	1270-00-165-9922
F-5	AN/APQ-153 RADAR SET	MODULATOR SUBASSEMBLY	14-62909-3	RT-1059/APQ	RADAR RECEIVER/TRANSMITTER	1270-00-146-3788
F-5	AN/APQ-153 RADAR SET	PLATE,MOUNTING,TRANSMITTING SET	633500-319	14-62909-19	RADAR PROCESSOR	1270-00-394-6741
F-5	AN/APQ-153 RADAR SET	SCREW,MACHINE	633056-301	--	CIRCUIT CARD ASSEMBLY	6130-00-165-9311
F-5	AN/APQ-153 RADAR SET		633200-301	14-62909-7	RADAR INDICATOR	1270-00-139-1507
F-5	AN/APQ-153 RADAR SET		633500-307	14-62909-5	RADAR PROCESSOR	1270-00-139-1508
F-5	AN/APQ-153 RADAR SET		633500-315	14-62909-5	RADAR PROCESSOR	1270-00-139-1508
F-5	AN/APQ-153 RADAR SET		633157-307	633157-301	POST AMPLIFIER GENERATOR ASSEMBLY	1285-00-165-9897
F-5	AN/APQ-153 RADAR SET		633157-309	--	POST AMPLIFIER GENERATOR ASSEMBLY	1285-01-015-9794
F-5	AN/APQ-153 RADAR SET		700610-1	633353-411	POWER SUPPLY	1290-00-025-5462
F-5	AN/APQ-153 RADAR SET		700610-3	633353-411	POWER SUPPLY	1290-00-025-5462
F-5	AN/APQ-153 RADAR SET		633125-401	633125-415	AIR STRIP MIXER ASSEMBLY	5998-00-030-3304
F-5	AN/APQ-153 RADAR SET		633125-415	--	AIR STRIP MIXER ASSEMBLY	5998-00-030-3304
F-5	AN/APQ-153 RADAR SET		SD090010015-5	633125-415	AIR STRIP MIXER ASSEMBLY	5998-00-030-3304
F-5	AN/APQ-153 RADAR SET		633096-303	--	POWER DEFLECTION AMPLIFIER	5998-00-152-6335
F-5	AN/APQ-153 RADAR SET		633107-303	--	CIRCUIT CARD ASSEMBLY	5998-00-165-9893
F-5	AN/APQ-153 RADAR SET		633107-601	633107-303	CIRCUIT CARD ASSEMBLY	5998-00-165-9893
F-5	AN/APQ-153 RADAR SET		633107-301	--	CIRCUIT CARD ASSEMBLY	5998-00-377-9329
F-5	AN/APQ-153 RADAR SET		633107-305	--	CIRCUIT CARD ASSEMBLY	5998-01-012-0491
F-5	AN/APQ-153 RADAR SET		700685-4	633353-429	CIRCUIT CARD ASSEMBLY	5998-01-043-6552

F-5	AN/APQ-153 RADAR SET		14-62909-1	0010560-9	RADAR ANTENNA	6060-01-139-1505
F-5	AN/APQ-153 RADAR SET		633400-305	0010560-9	RADAR ANTENNA	6060-01-139-1505
F-5	AN/APQ-153 RADAR SET		633056-311	--	CIRCUIT CARD ASSEMBLY	6130-01-021-0759
F-5	AN/APQ-153 Radar AN/APQ-157 Radar	INSULATOR,BUSHING	633353-421	633353-405	HIGH VOLTAGE MODULE	1270-00-025-5456
F-5	AN/APQ-153 Radar AN/APQ-157 Radar	INSULATOR,BUSHING	633353-407	633353-417	CIRCUIT CARD ASSEMBLY	5998-00-025-5464
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633353-427	700600-6	HIGH VOLTAGE MODULE	1270-01-009-9328
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633500-323	633500-321	RADAR PROCESSOR	1270-01-022-4593
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633353-311	633353-403	MODULATOR ASSEMBLY	1290-00-025-5458
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633353-403	--	MODULATOR ASSEMBLY	1290-00-025-5458
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633353-413	633353-403	MODULATOR ASSEMBLY	1290-00-025-5458
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633353-401	633353-411	POWER SUPPLY	1290-00-025-5462
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633353-411	--	POWER SUPPLY	1290-00-025-5462
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633353-425	--	R/T CCA #1, DUAL PRF MASTER TIMING	5998-00-025-5463
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633353-417	--	CIRCUIT CARD ASSEMBLY	5998-00-025-5464
F-5	AN/APQ-153 Radar AN/APQ-157 Radar		633353-429	--	CIRCUIT CARD ASSEMBLY	5998-01-043-6552
F-5	AN/APQ-153 Radar AN/APQ-157 Radar AN/APQ-V159-1, -2, -3, -4 Radar		633353-457	--	CIRCUIT CARD ASSEMBLY	5998-01-070-1455
F-5	AN/APQ-153/157		633198-305	--	PROCESSOR A4 CCA	5998-00-152-6470
F-5	AN/APQ-157 RADAR SET	BOLT,MACHINE	633188-313	--	CIRCUIT CARD ASSEMBLY	5998-01-003-7225
F-5	AN/APQ-157 RADAR SET	INSULATOR,BUSHING	700685-1	633353-417	CIRCUIT CARD ASSEMBLY	5998-00-025-5464
F-5	AN/APQ-157 RADAR SET	INSULATOR,BUSHING	700685-3	633353-417	CIRCUIT CARD ASSEMBLY	5998-00-025-5464
F-5	AN/APQ-157 RADAR SET	LEVER,MANUAL CONTROL	633056-401	--	CIRCUIT CARD ASSEMBLY	5998-01-040-5099
F-5	AN/APQ-157 RADAR SET		633200-309	14-62909-15	RADAR INDICATOR	1270-00-139-1507
F-5	AN/APQ-157 RADAR SET		634100-301	--	RADAR PROCESSOR	1270-01-021-2963
F-5	AN/APQ-157 RADAR SET		633800-301	--	RADAR INDICATOR Rear w/ DVST Replacement	1270-01-022-6153
F-5	AN/APQ-157 RADAR SET		633800-301	--	RADAR INDICATOR Rear w/o DVST Replacement	1270-01-022-6153
F-5	AN/APQ-157 RADAR SET		633157-307	633157-301	POST AMPLIFIER GENERATOR ASSEMBLY	1285-00-165-9897

F-5	AN/APQ-157 RADAR SET		633157-309	--	POST AMPLIFIER GENERATOR ASSEMBLY	1285-01-015-9794
F-5	AN/APQ-157 RADAR SET		700599-1	633353-403	MODULATOR ASSEMBLY	1290-00-025-5458
F-5	AN/APQ-157 RADAR SET		700630-1	633353-403	MODULATOR ASSEMBLY	1290-00-025-5458
F-5	AN/APQ-157 RADAR SET		700610-1	633353-411	POWER SUPPLY	1290-00-025-5462
F-5	AN/APQ-157 RADAR SET		700610-3	633353-411	POWER SUPPLY	1290-00-025-5462
F-5	AN/APQ-157 RADAR SET		633125-413	CD4538BMJ/883B	LOCAL OSCILLATOR	5962-01-156-0047
F-5	AN/APQ-157 RADAR SET		633125-401	633125-415	AIR STRIP MIXER ASSEMBLY	5998-00-030-3304
F-5	AN/APQ-157 RADAR SET		633125-415	--	AIR STRIP MIXER ASSEMBLY	5998-00-030-3304
F-5	AN/APQ-157 RADAR SET		SD090010015-5	633125-415	AIR STRIP MIXER ASSEMBLY	5998-00-030-3304
F-5	AN/APQ-157 RADAR SET		633096-303	--	POWER DEFLECTION AMPLIFIER	5998-00-152-6335
F-5	AN/APQ-157 RADAR SET		633107-303	--	CIRCUIT CARD ASSEMBLY	5998-00-165-9893
F-5	AN/APQ-157 RADAR SET		633107-305	--	CIRCUIT CARD ASSEMBLY	5998-01-012-0491
F-5	AN/APQ-157 RADAR SET		14-62909-1	0010560-9	RADAR ANTENNA	6060-01-139-1505
F-5	AN/APQ-157 RADAR SET		633400-305	0010560-9	RADAR ANTENNA	6060-01-139-1505
F-5	AN/APQ-159	PANEL A,PRIMARY PLA	541838-104	5418383-104	ELECTRONIC COMPONENT	5998-00-152-6366
F-5	AN/APQ-159-1,-2,-3,-4 RADAR SET		633125-419	--	HIGH POWER DUPLEXER	1270-01-048-4897
F-5	AN/APQ-159-1,-2,-3,-4 RADAR SET		633368-351	--	POWER SUPPLY HEAT SINK MODULE ASSEMBLY	1270-01-050-5380
F-5	AN/APQ-160	PANEL A,PRIMARY PLA	5418383-104	--	ELECTRONIC COMPONENT	5998-00-152-6366
F-5	AN/APQ-V159-1,-2,-3,-4 Radar	--	633353-437	700630-3	AUXILIARY COMPONENT MODULE	5998-01-083-4322
F-5	AN/APQ-V159-1,-2,-3,-4 Radar		633353-431	--	HIGH VOLTAGE MODULE ASSEMBLY	1270-01-048-1549
F-5	AN/APQ-V159-1,-2,-3,-4 Radar		633353-433	700610-4	POWER SUPPLY MODULE	5998-01-083-4328
F-5	AN/APQ-V159-1,-2,-3,-4 Radar		633353-455	--	CIRCUIT CARD ASSEMBLY	5998-01-083-4329
F-5	AN/APQ-V159-1,-2,-3,-4 RADAR SET	--	634800-305	--	VIDEO INDICATOR	5841-01-073-3507
F-5	AN/APQ-V159-1,-2,-3,-4 RADAR SET	01-071-7473 RADAR TARGET DATA PROCESSOR	634518-1	--	CIRCUIT CARD ASSEMBLY	5998-01-076-7900
F-5	AN/APQ-V159-1,-2,-3,-4 RADAR SET	GEAR,SPUR	633076-351	--	CIRCUIT CARD ASSEMBLY	5998-01-061-0540
F-5	AN/APQ-V159-1,-2,-3,-4 RADAR SET	INSULATOR,BUSHING	633356-303	633356-1	PREAMPLIFIER	5996-00-169-9036

F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	INSULATOR,BUSHING	633356-307	633356-1	PREAMPLIFIER	5996-00-169-9036
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	MICROCIRCUIT,DIGITA L	634030-1	--	CIRCUIT CARD ASSEMBLY	5998-01-050-0091
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PANEL A,PRIMARY PLA	633098-301	5418383-104	ELECTRONIC COMPONENT	5998-00-152-6366
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PANEL A,PRIMARY PLA	633525-301	5418383-104	ELECTRONIC COMPONENT	5998-00-152-6366
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PANEL A,PRIMARY PLA	634101-1	--	CIRCUIT CARD ASSEMBLY	5998-01-083-8513
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PANEL A,PRIMARY PLA	634110-1	--	CIRCUIT CARD ASSEMBLY	5998-01-135-8071
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PANEL A,PRIMARY PLA	634106-1	--	CIRCUIT CARD ASSEMBLY	5998-01-139-2964
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PROCESSOR	634510-301	--	CIRCUIT CARD ASSEMBLY	5998-01-066-1177
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PROCESSOR	633074-353	--	CIRCUIT CARD ASSEMBLY	5998-01-067-2841
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PROCESSOR	634684-401	--	CIRCUIT CARD ASSEMBLY	5998-01-071-7510
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PROCESSOR	634512-1	--	CIRCUIT CARD ASSEMBLY	5998-01-076-7899
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PROCESSOR	633056-403	--	CIRCUIT CARD ASSEMBLY	5998-01-076-8407
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PROCESSOR	633080-353	--	CIRCUIT CARD ASSEMBLY	5998-01-076-8408
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PROCESSOR	634002-401	--	CIRCUIT CARD ASSEMBLY	5998-01-076-8409
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PROCESSOR	634016-305	--	CIRCUIT CARD ASSEMBLY	5998-01-076-8410
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	PROCESSOR	634504-303	--	CIRCUIT CARD ASSEMBLY	5998-01-076-8411
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	RECEIVER/XMTR	633922-303	571025	CIRCUIT CARD ASSEMBLY	5998-01-066-1175
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	ROD END ASSEMBLY	633608-1	--	CIRCUIT CARD ASSEMBLY	5998-01-021-3022
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET	ROD END ASSEMBLY	633604-305	633604-303	APQ-159	5998-01-056-9832
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634400-303	--	RADAR ANTENNA	1270-01-063-7873
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-435	3065316-3	MODULE ASSEMBLY	1270-01-066-5255
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634500-303	--	RADAR PROCESSOR	1270-01-071-7473
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634200-301	--	RADAR SET CONTROL	1270-01-071-8909
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634700-303	--	RADAR SIGNAL DATA CONVERTER	1270-01-076-6978
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634300-305	--	RADAR RECEIVER/TRANSMITTER	1270-01-077-4724
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-451	3065172-4	HIGH VOLTAGE POWER SUPPLY MODULE ASSEMBLY	1270-01-079-7136
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633180-351	--	YOKE AND SHIELD ASSEMBLY	1270-01-084-0231

F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633737-305	S14-101	MAGNETRON ASSEMBLY	5120-01-383-3936
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633200-351	18-62906-13	DATA DISPLAY INDICATOR, FRONT	5841-01-121-5928
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633800-351	--	DATA DISPLAY INDICATOR, REAR (REPLACING DVST)	5841-01-121-5930
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633800-351	--	DATA DISPLAY INDICATOR, REAR (W/O REPLACING DVST)	5841-01-121-5930
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633980-307	--	AMPLIFIER MODULE ASSEMBLY	5895-01-079-7114
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633738-1	--	LOCAL OSCILLATOR	5955-01-085-6030
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633737-303	--	MAGNETRON ASSEMBLY	5960-01-048-8228
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633804-1	--	POWER SUPPLY DEFLECTION AMPLIFIER	5996-01-021-7089
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634569-1	--	SERVO AMPLIFIER MODULE ASSEMBLY	5996-01-076-7374
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634569-301	--	SERVO AMPLIFIER MODULE ASSEMBLY	5996-01-121-5949
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633096-303	--	POWER DEFLECTION AMPLIFIER	5998-00-152-6335
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633103-303	633103-1	CIRCUIT CARD ASSEMBLY	5998-00-165-9892
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633544-301	--	CCA APQ-153	5998-00-386-6618
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633107-305	--	CIRCUIT CARD ASSEMBLY	5998-01-012-0491
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-429	3065160-1	CIRCUIT CARD ASSEMBLY	5998-01-065-9202
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-407	3065144-1	CIRCUIT CARD ASSEMBLY	5998-01-066-5415
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-409	3065148	CIRCUIT CARD ASSEMBLY	5998-01-066-5416
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-427	3065164	CIRCUIT CARD ASSEMBLY	5998-01-066-7082
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-445	3065152-1	CIRCUIT CARD ASSEMBLY	5998-01-067-5747
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-413	3065156	CIRCUIT CARD ASSEMBLY	5998-01-069-1027
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634506-1	--	CIRCUIT CARD ASSEMBLY	5998-01-076-8412
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634508-1	--	CIRCUIT CARD ASSEMBLY	5998-01-076-8413
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634614-1	--	CIRCUIT CARD ASSEMBLY	5998-01-076-8414
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		700610-4	--	CIRCUIT CARD ASSEMBLY	5998-01-083-4328
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		700634-101	633353-455	CIRCUIT CARD ASSEMBLY	5998-01-083-4329
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633357-353	--	CIRCUIT CARD ASSEMBLY	5998-01-128-2374
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633107-307	--	CIRCUIT CARD ASSEMBLY	5998-01-231-6187

F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634744-301	--	POWER SUPPLY MODULE ASSEMBLY	6130-01-070-8783
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633079-351	--	POWER SUPPLY MODULE ASSEMBLY	6130-01-081-8156
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		633600-351	--	RADAR POWER SUPPLY COUPLER	6130-01-121-5929
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634002-303	--	CIRCUIT CARD ASSEMBLY	NSL
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634500-501	--	CHASSIS, PROC.	NSL
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-449	--	VIDEO INDICATOR HIGH VOLTAGE POWER SUPPLY	NSL
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634805-453	--	VIDEO INDICATOR HIGH VOLTAGE POWER SUPPLY	NSL
F-5	AN/APQ-V159-1,-2,-3, 4 RADAR SET		634887-301	--	VIDEO INDICATOR HIGH VOLTAGE POWER SUPPLY	NSL
F-5	AN/AVQ-27	--	309151	--	LASER TARGET DESIGNATOR	5860-01-061-3993
F-5	BLANKING ELECTRONICS SYSTEM		85710700-601A	--	BLANKING ELECTRONICS UNIT	5841-01-050-7332
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		748871-1	--	REFRIGERATION UNIT	1660-00-006-1078
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		576609	--	REFRIGERATION UNIT	1660-00-033-9178
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		14-54920-19	--	REFRIGERATION UNIT	1660-00-399-2368
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		748871-2	14-54920-19	REFRIGERATION UNIT	1660-00-399-2368
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		749064-6	--	TURBINE FAN ASSEMBLY	1660-00-588-3462
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		751865-5	751865-2	DUAL VALVE CABIN TEMPERATURE CONTROL	1660-01-019-8576
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		751872-3	18-54925-3	REFRIGERATION UNIT	1660-01-019-8577
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		752001-1	--	COOLING TURBINE	1660-01-020-2107
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		751866-1	--	PRESURE REGULATOR VALVE	4820-01-034-3680
F-5	ENVIRONMENTAL CONTROL SYSTEM (ECS)		18-54925-3	--	REFRIGERATION UNIT	NSL
F-5	LEAD COMPUTING SIGHT ASG-32		292E920G1	14-62903-15	LEAD COMPUTING OPTICAL SIGHT DISPLAY	1270-01-052-3821
F-5	OPTICAL GUN SIGHT	--	5212553-521	--	NORTH OPTICAL SIGHT	1270-00-113-2277

F-5	OPTICAL GUN SIGHT		2223-100	9900143-1	INFINITY OPTICAL SIGHT	1270-00-556-2159
F-5	OPTICAL GUN SIGHT		6062-100	--	INFINITY OPTICAL SIGHT DISPLAY UNIT	1270-01-011-4638
F-5	OPTICAL GUN SIGHT		2223-100-1	--	INFINITY OPTICAL SIGHT DISPLAY UNIT	1270-01-064-2578
FAA	WXR-300 Color Radar System		622-7337-001	--	Radar Receiver Transmitter	
FAA			066-01171	--	SPEED IND	
FAA			066-50001	--	SPEED IND	
FAA			622-2501-001	--	Radar Antenna	
FAA			622-4331-001	--	Weather Radar Indicator	
FAA			622-4331-002	--	Weather Radar Indicator	
FAA			622-4331-003	--	Weather Radar Indicator	
STATION	AN/FRC-178 / GPS		248527	--	RADIO FREQ. TUNER	5895-01-211-0210
Ground Station	AN/FRC-178 / GPS		021-130165-01	--	RF PROCESSOR PRINTED WIRING BD	5998-01-471-3269
STATION	AN/FRC-178/GPS		146482-002	--	SYNCHRONIZER	5895-01-210-2066
Ground Station	AUTOMATED TEST EQUIPMENT		342669	342669-1	CIRCUIT CARD ASSEMBLY	5855-01-073-2355
STATION	GPS		149736-G01	--	CCA GPS CONTROL	5998-01-181-4376
STATION	GPS		021-104514-01	--	CCA	5998-01-184-9071
STATION	GPS		021-104420-01	--	CCA GPS MONITOR STATION	5998-01-184-9097
STATION	GPS		021-104491-01	--	ELECTRONIC COMPONENT	5998-01-185-1071
STATION	GPS		7939138-1	--	CCA GPS OCS	5998-01-215-1286
GROUND STATION	GPS GROUND ANTENNA STATION		7136-1101-004	146482-002	SYNCHRONIZER	5895-01-210-2066
GROUND STATION	GPS CONTROL CARD		572232-G01	--	ASYNC INPUT/OUTPUT CCA	5998-01-181-4375
GROUND STATION	GPS CONTROL CARD		572232-G02	572232-G01	ASYNC INPUT/OUTPUT CCA	5998-01-181-4375
GROUND STATION	GPS GROUND ANTENNA STATION		249290	444A-B479	DEMODULATOR	5895-01-276-9850
STATION	VARIOUS		0145111-004	--	MOTER D.C.	6105-01-209-8862
Ground Station	GPS Monitor Station	CABLE ASSEMBLY,RADIO FREQUENCY	SM4-382	146474-001	WAVEGUIDE SWITCH	5985-01-209-8922
GPS Monitor Station	NAVSTAR GPS AN/FSN-5(V)		7132-1010-010	EGD-0941-1	MODEM	1680-01-230-0524
GPS Monitor Station	NAVSTAR GPS AN/FSN-5(V)		190-104545-01	--	OSCILLATOR	5955-01-215-4526
GPS Monitor Station	NAVSTAR GPS AN/FSN-5(V)		4K5SL-7	--	ELECTRON TUBE	5960-01-224-3849
GPS Monitor Station	NAVSTAR GPS AN/FSN-5(V)		30150-8614	--	POWER SUPPLY	6130-01-216-0709
H-1	Displays	--	ECMK725C01M	--	DISPLAY UNIT,HEAD-UP	6610-01-435-3739
H-1	Displays		ECMK721A02M	--	SIGNAL PROCESSOR	7025-01-435-3738
H-1	Displays		ECMK722A02M	--	SIGNAL PROCESSOR	7025-01-436-0308
H-1	Displays		ECMK843A01M	--	DISPLAY UNIT	7025-01-443-7719
H-1			ECMK687A01M	--	DISPLAY UNIT	7025-01-431-6747
H-60	VARIOUS		2755-0309-1	9096183-01	IR BEACON ECU	6220-01-392-9841
H-60	VARIOUS		9096183-01	--	IR BEACON ECU	6220-01-392-9841
H-60	VARIOUS		61398-001	--	MAP DISPLAY	6605-01-331-4136
HH/MH-53	AN/AAQ-10		2024373-1	--	GEAR BOX	5855-01-073-0444



HH-53C CH-53G	AN/APN-172		2859363-1	2859363	MODULATOR	5841-01-222-5745
L-2	AN/USM-464		102770-351	800227P3	MAGNETIC TRANSPORT	7025-01-141-8961
L-2	AN/USM-464		77C718148P001	800227P3	MAGNETIC TRANSPORT	7025-01-141-8961
MULTIPLE	VARIOUS		102893	220-21201-101	CAMERA, TELEVISION	5821-01-025-8517
MULTIPLE	VARIOUS		125369-1	--	CONTROL, BEACON	5825-01-278-9790
MULTIPLE	VARIOUS		HG7502AJ02	--	RECEIVER TRANSMITTER	5841-01-134-8907
MULTIPLE	VARIOUS		2024404-1	--	CONTROL	5855-01-067-4087
MULTIPLE	VARIOUS		2024407-1	--	CONTROL	5855-01-067-4088
MULTIPLE	VARIOUS		814877-2	--	HEAT EXCHANGER	5855-01-067-4101
MULTIPLE	VARIOUS		794255-2	--	AMPLIFIER	5855-01-073-1832
MULTIPLE	VARIOUS		793783-1	--	AMPLIFIER	5855-01-073-1833
MULTIPLE	VARIOUS		794256-2	--	AMPLIFIER	5855-01-073-4988
MULTIPLE	VARIOUS		301793-1	--	POST AMPLIFIER	5895-01-067-4125
MULTIPLE	VARIOUS		220-27416-111	--	TRANSFORMER	5950-01-156-3959
MULTIPLE	VARIOUS		6790726-501	--	RADOME	5985-00-480-6833
MULTIPLE	VARIOUS		6790329	--	AMPLIFIER	5996-00-445-5954
MULTIPLE	VARIOUS		6979329	6790329	AMPLIFIER	5996-00-445-5954
MULTIPLE	VARIOUS		2819602-1	--	DRIVER	5998-00-001-5598
MULTIPLE	VARIOUS		1205-0454-1	--	CIRCUIT CARD ASSEMBLY	5998-00-090-6792
MULTIPLE	VARIOUS		1205-0453-1	--	CIRCUIT CARD ASSEMBLY	5998-00-090-6796
MULTIPLE	VARIOUS		1205-0456-1	--	CIRCUIT CARD ASSEMBLY	5998-00-137-4164
MULTIPLE	VARIOUS		6790761-501	--	CIRCUIT CARD ASSEMBLY	5998-00-480-6814
MULTIPLE	VARIOUS		6790765-501	--	CIRCUIT CARD ASSEMBLY	5998-00-480-6815
MULTIPLE	VARIOUS		6790760-501	6790769-501	CIRCUIT CARD ASSEMBLY	5998-00-480-6816
MULTIPLE	VARIOUS		6790773-501	--	CIRCUIT CARD ASSEMBLY	5998-00-480-6817
MULTIPLE	VARIOUS		6790777-501	--	CIRCUIT CARD ASSEMBLY	5998-00-480-6818
MULTIPLE	VARIOUS		6790781-501	--	CIRCUIT CARD ASSEMBLY	5998-00-480-6819
MULTIPLE	VARIOUS		1205-0457	--	RELAY ASSEMBLY	5998-00-482-0215
MULTIPLE	VARIOUS		1205-0452	--	PC BOARD	5998-00-484-7366
MULTIPLE	VARIOUS		880621-1	--	SCAN DRIVE PWB	5998-01-005-3531
MULTIPLE	VARIOUS		627221490-019	627221490&019	CIRCUIT CARD ASSEMBLY	5998-01-011-0502
MULTIPLE	VARIOUS		6790704-501	--	POWER SUPPLY	6130-00-480-6820
MULTIPLE	VARIOUS		2819561-1	--	POWER SUPPLY	6130-00-782-4387
MULTIPLE	VARIOUS		709197-1	--	POWER SUPPLY	6130-01-073-2331
MULTIPLE	VARIOUS		125371-1	992640-00	BASE	6150-01-279-8784
MULTIPLE	VARIOUS		1151598-1	--	GUNFIRE SIMULATOR	6230-00-422-4992
MULTIPLE	VARIOUS		1100392-1	1100392	SEARCHLIGHT	6260-00-232-9979
MULTIPLE	VARIOUS		2024365-1	--	SCAN OPTICS ASSEMBLY	NSL
MULTIPLE	VARIOUS		2024368-1	--	EMITTER ASSEMBLY	NSL
MULTIPLE	VARIOUS		2024369-1	--	REFRIGERATOR VAC-DE	NSL
MULTIPLE	VARIOUS		2024372-1	--	LENS SWITCHING ASSEMBLY	NSL
MULTIPLE	VARIOUS		41292902C	--	LOW VOLTAGE POWER SUPPLY	NSL
MULTIPLE	VARIOUS		41293300C	--	VIDEO CCA	NSL
MULTIPLE	VARIOUS		989109-2	--	MEMORY CORE STACKS	NSL
OH58			MB190A-06	--	OH58 DISPLAY	1260-01-540-3476
P3	Survival Systems	Emergency Locator Transmitter	110043	T1129URT26V	RADIO BEACON	5826-00-168-7660
P3	Survival Systems	Emergency Locator Transmitter	119195-1	T&1305-URT&26V	BEACON RADIO	5826-01-009-2815
P3/F3	AN/APS-137		883749-1	--	PULSE COMPRESSOR ASSY	5841-01-064-3045
P3/F3	AN/APS-137		883770-1	--	TWT Power Supply	6130-01-068-7751
P-3/KC-130R	Survival Systems		136832-1	D-45/JRT-26(V)	RADIO BEACON	5826-01-363-3503

R-4 F-111	AN/AAQ-9	HOUSING,BURNER	335551-1	--	FOCUS ASSEMBLY	1270-01-072-0364
S-3	AN/APS-137		761707-1	--	COMPRESSOR ASSEMBLY	5855-00-323-0967
S3/P3	AN/APS-137	ANTENNA ASSEMBLY	2850062-4	--	SUPPORT,ANTENNA	5985-01-347-0723
S3/P3	AN/APS-137		2892700-1	--	RECEIVING SET,RADAR	5840-01-256-7593
S3/P3	AN/APS-137		2800513-1	--	RADIO FREQUENCY ASS	5841-01-256-7310
S3/P3	AN/APS-137		2849899-1	--	ENCODER,ANTENNA	5841-01-256-7314
S3/P3	AN/APS-137		2892900-2	--	INTERFACE,RADAR ASS	5841-01-256-7318
S3/P3	AN/APS-137		2892600-2	--	SYNCHRONIZER-EXCITE	5841-01-263-1279
S3/P3	AN/APS-137		2892781-2	--	PULSE GENERATOR GROUP	5841-01-334-2937
S3/P3	AN/APS-137		2849900-3	--	CONTROL,RADAR SET	5841-01-381-3559
S3/P3	AN/APS-137		2850250-1	--	CONTROL-INDICATOR	5895-01-381-3530
S3/P3	AN/APS-137		2850311-1	--	CONVERTER,VIDEO	5895-01-382-1367
S3/P3	AN/APS-137		2849700-2	--	CONVERTER,SIGNAL DATA	5895-01-384-1432
S3/P3	AN/APS-137		2849595-3	--	ANTENNA ASSEMBLY	5985-01-256-7312
S3/P3	AN/APS-137		2800515-2	--	ANTENNA GIMBAL SUBA	5985-01-256-7313
S3/P3	AN/APS-137		2850062-2	--	SUPPORT ARM,SHROUD	5985-01-256-7315
S3/P3	AN/APS-137		2892746-1	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7736
S3/P3	AN/APS-137		2892510-1	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7813
S3/P3	AN/APS-137		2892625-1	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7815
S3/P3	AN/APS-137		2892614-1	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7816
S3/P3	AN/APS-137		2892620-1	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7818
S3/P3	AN/APS-137		2849617-1	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7821
S3/P3	AN/APS-137		2849665-2	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7830
S3/P3	AN/APS-137		2849383-1	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7832
S3/P3	AN/APS-137		2892927-1	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7855
S3/P3	AN/APS-137		2892939-1	--	CIRCUIT CARD ASSEMBLY	5998-01-256-7857
S3/P3	AN/APS-137		2892950-1	--	CIRCUIT CARD ASSEMBLY	5998-01-261-3069
S3/P3	AN/APS-137		2849641-1	--	CIRCUIT CARD ASSEMBLY	5998-01-261-3078
S3/P3	AN/APS-137		2892714-1	--	CIRCUIT CARD ASSEMBLY	5998-01-263-1467
S3/P3	AN/APS-137		2891833-1	--	CIRCUIT CARD ASSEMBLY	5998-01-263-1485
S3/P3	AN/APS-137		2892631-1	--	CIRCUIT CARD ASSEMBLY	5998-01-266-0987
S3/P3	AN/APS-137		2892533-1	--	CIRCUIT CARD ASSEMBLY	5998-01-287-8546
S3/P3	AN/APS-137		2892551-1	--	CIRCUIT CARD ASSEMBLY	5998-01-336-3784
S3/P3	AN/APS-137		2849611-3	--	CIRCUIT CARD ASSEMBLY	5998-01-336-9342
S3/P3	AN/APS-137		2892527-2	--	CIRCUIT CARD ASSEMBLY	5998-01-336-9344
S3/P3	AN/APS-137		2849998-6	--	CIRCUIT CARD ASSEMBLY	5998-01-346-2811
S3/P3	AN/APS-137		2892609-1	--	ELECTRONIC COMPONENTS ASSEMBLY	5999-01-256-7717
S3/P3	AN/APS-137		2892702-1	--	POWER SUPPLY	6130-01-267-3380
S3/P3	AN/APS-137		2892500-2	--	POWER SUPPLY SET	6130-01-277-8377
S3/P3	AN/APS-137		2855920-1	--	POWER SUPPLY	6130-01-281-6809
S3/P3	AN/APS-137		2892902-2	--	POWER SUPPLY ASSEMBLY	6130-01-338-9743
S3/P3	AN/APS-137		2892500-3	--	POWER SUPPLY SET	6130-01-500-9068
Special Operational Forces (SOF)	ACFT GUNNERY FIRE CONTROL COMPONENT		2819607-1	--	CONTROL	1270-00-001-7010
Special Operational Forces (SOF)	ACFT GUNNERY FIRE CONTROL COMPONENT		2819608-1	--	DIAG PANEL	1270-00-001-7012
Special Operational Forces (SOF)	ACFT GUNNERY FIRE CONTROL COMPONENT		2819606-1	--	FRAME ASSEMBLY	1270-00-001-7014
Operational Forces (SOF)	COOLER ASSEMBLY	COOLER ASSEMBLY	736989-1	--	PISTON, COMPRESSOR	4310-01-073-3521

Operational Forces (SOF)	Displays	CONTROL DISPLAY UNIT	50105213	--	CRT SUB ASSEMBLY	5998-01-320-8756
Operational Forces (SOF)	Displays	CONTROL DISPLAY UNIT	50105202	--	POWER SUP BOARD	5998-01-320-8766
Operational Forces (SOF)	Displays	CONTROL DISPLAY UNIT	50105203	--	X,Y,Z BOARD	5998-01-321-6829
Operational Forces (SOF)	VARIOUS		1205-0450-1	--	SERVO	1270-00-090-6779
Operational Forces (SOF)	VARIOUS		1060	01060-2	ROTARY ASSEMBLY	1270-00-140-3521
Operational Forces (SOF)	VARIOUS		6790755-502	--	CONTROL	1270-00-172-7788
Operational Forces (SOF)	VARIOUS		1205-0600	--	PEDESTAL	1270-00-232-1969
Operational Forces (SOF)	VARIOUS		768076-1	--	LENS SWITCH	1270-00-451-7108
Operational Forces (SOF)	VARIOUS		6790735-501	--	DATA PROCESSOR	1270-00-480-6821
Operational Forces (SOF)	VARIOUS		6790733-501	--	AMP DIRECT	1270-00-480-6828
Operational Forces (SOF)	VARIOUS		6790732-501	--	AMPLIFIER	1270-00-480-6829
Operational Forces (SOF)	VARIOUS		6790740-501	--	DISPLAY UNIT	1270-00-482-9869
Operational Forces (SOF)	VARIOUS		1205-0451	--	PC BOARD	1270-00-484-7365
Operational Forces (SOF)	VARIOUS		797	--	POWER AMPLIFIER	1270-00-484-7372
Operational Forces (SOF)	VARIOUS		1205-0408-1	--	CONTROL UNIT	1270-00-758-1531
T-35	VARIOUS		710-1296	--	FOLDING MIRROR	1270-00-542-8480
T-37	VARIOUS		805D0602-20	RT-1634	RECEIVER TRANSMITTER	5826-01-299-6162
T-37	VARIOUS		805C0620-38	ID-2472/ARN-154	INDICATOR, NAV SET	6605-01-294-5408
T-38	Displays	HUD	4453-1000-00	--	UP FRONT CONTROL PANEL	NSL
T-38	Displays		4452-1000-01	--	HEAD UP DISPLAY	NSL
T-38	Displays		4477-1000-80	--	SUB ASSY T-38 HUD	NSL
T-38	VARIOUS		552115	--	TURBINE	1660-00-798-3210
T-45	Displays	MFD	41267200M	--	CRT Assy	NSL
T-45	Displays	--	MK842A-04	--	T-45 MFD w/o CRT Replacement	NSL
T-45	Displays	--	MK842A-04	--	T-45 MFD w/ CRT Replacement	NSL
T-45	Displays	MULTIFUNCTION DISPLAY (MFD)	11413	--	BEZEL ASSEMBLY	NSL
T-45	Displays	MULTIFUNCTION DISPLAY (MFD)	41293403C	--	DIGITAL CIRCUIT CARD ASSEMBLY	NSL
T-45	Displays	MULTIFUNCTION DISPLAY (MFD)	41293502C	--	DEFLECTION ASSEMBLY	NSL
TA-7C	Displays		102894	220-21201-102	T.V. MONITOR	5821-01-025-8553
TBA	AN/AAQ-17		3140444-1	--	BACKPLANE ASSY	5998-01-497-7489
TBA	AN/ALR-56A/C		226508-001	--	MIXER PREAMPLIFIER	5865-00-477-5721
TBA	AN/ASG-29		186F209G3	--	FREQUENCY REGULATOR MODULE	5998-00-292-9329
TBA	AN/ASQ-T27		89016006-1	--	ANTENNA & AIR DATA SENSOR	6920-01-370-8455
TBA	AN/FRC-178 / GPS		146480-001	--	RECEIVER TRANSMITTER	5820-01-212-2091
TBA	AN/MST-T1		8030H03R305	--	RADIO FREQUENCY AMPLIFIER	5996-01-387-7281

TBA	Displays	--	MB240A-00	MB-240A-00	NIGHT FLAT PANEL DISPLAY	7025-01-589-3638
TBA	USQ-70 POSITION AND AZIMUTH DETERMING SYSTEM (PADS)		24069-02	24069-01	CONTROL PANEL CCA	5930-01-341-6430
TBA	VARIOUS		685119	--	ATTENUATOR, VARIABLE	NSL
TBA		BEARING, SLEEVE	10069982-102	--	DISPLAY ADJUST PANEL A1 CCA	
TBA		CIRCUIT CARD ASSEMBLY	021-120165	--	RF PROCESSOR PRINTED WIRING BD	5998-01-326-8763
TBA			MB136C-00	13214705	GDU	1055-01-481-0868
TBA			264A602-3	--	MULTIFUNCTION DISPLAY UNIT	1260-01-543-9004
TBA			MB359B-01	--	MULTIFUNCTION DISPLAY UNIT	1260-01-543-9004F
TBA			976177-02	--	CONTROLLER ASSY, HANDSTATION	1265-01-596-4951
TBA			C709480008	--	SLAVE SWITCHING UNIT	1270-00-146-8032
TBA			12976508-20	--	PIB	1290-01-465-9196
TBA			12976176-21	--	GUNNER HAND STATION	1290-01-574-3206
TBA			12976221-21	--	COMMANDER'S HAND STATION	1290-01-574-4863
TBA			A31U29710-1	--	CENTRIFUGAL FAN	4140-01-432-3808
TBA			MB211W-00	--	MDR	5836-01-HS2-0754
TBA			682R726G01	--	WIRED LPRF CHASSIS	5841-01-161-4659
TBA			MB428A-01	--	VDU	5841-01-527-6867
TBA			JG1072AJ02-NVG	--	HEIGHT INDICATOR	5841-01-HS1-2272
TBA			JG1218AB01	--	BORESIGHT UNIT	5850-01-461-5264
TBA			31-054234-01	--	RECEIVER CONTROLLER	5865-01-049-1178
TBA			441-10021-504	--	CONTROL INDICATOR, POWER SUPPLY	5895-01-286-5226
TBA			83-14002-003	--	COMMUNICATION CONTROL	5895-01-310-6235
TBA			MB503A-00	CV-4229(V)10B/AVS-	MINI SDC	5895-01-577-5425
TBA			10069982-101	--	DISPLAY ADJUST PANEL A1 CCA	5998-01-181-9115
TBA			10105793-101	10069976-102	DISPLAY ADJUST PANEL A1 CCA	5998-01-248-7010
TBA			030-0590-007	--	CIRCUIT CARD ASSY.	5998-01-503-4165
TBA			12470952-17	--	XWGLS CCA	5998-01-511-7873
TBA			12470952-19	--	XWGLS CCA	5998-01-569-3044
TBA			12976228-20	--	POWER SUPPLY	6130-01-465-8587
TBA			A036670009M	--	COMPUTER INTERFACE	6605-01-351-1033
TBA			MB0979B-00	698092-9	GDMU	6605-01-576-3335
TBA			HG1134AC01	--	SYMBOLGY DISPLAY UNIT	6605-15-U25-6465
TBA			001635V-01	--	RMM	6610-01-583-3255
TBA			A31U29684-2	A31U29684-5	SPECTRUM ANALYZER	6625-01-433-0282
TBA			MB386A-01	--	HUD FLAT PANEL DISPLAY	7025-01-589-3636
TBA			HDU23B	--	WARMING OVEN	7310-00-225-9825
TBA			16VE150001-5	--	Airborn Video Tape Recorder	NSL
TBA			31716A-02	--	LCD MODULE for APC E	NSL
TBA			781R723G01	--	MICROWAVE TRANSMITTER	NSL
TBA			795R517G01	--	HV POWER SUPPLY	NSL
TBA			88137A-00	--	LOW EXCITER	NSL
TBA			88138A-00	--	EXCITER HIGH BAND	NSL
TBA			AG1036AB01	--	CABLE ASSY. SDU	NSL
TBA			MA834U-00	--	BUSSED SDC/MSD	NSL
TBA			MK736H01M	--	CCU	NSL
TBA			12992807	--	COMMANDERS INTERFACE	
TBA			12992895	--	POWER DISTRIBUTION ASSY	
TBA			13017970	--	ENHANCED POWER DIST. ASSY	
TBA			13017991	--	FIRE CONTROL DISPLAY	

TBA			011623C-00	--	MCCU	
TBA			020575A-00	--	DIGITAL AIR DATA COMPUTER	
TBA			10020D-00	7-519410010-003	IMRU	
TBA			10097699-102	--	TUBE & CABLE ASSEMBLY	
TBA			11595B-04	--	PWR SUPPLY, LV EMPCD	
TBA			55683C-00	--	HCAM	
TBA			60111B-02	--	TRAY	
TBA			66245A-XX	--	SOLAR SHADE	
TBA			976231-01	12976231-1	GRIP & GIMBAL ASSY	
TBA			AR-001A-00	2292110-1	GRIFFIN	
TBA			BR-077A-00	13035052	STPU	
TBA			EIBU-001A-20	--	EIBU	
TBA			FC020A-00	--	FIRE CONTROL COMPUTER	
TBA			IH-084A-01	7-519430003-003	(IBRU)	
TBA			JDAM-002D-00	--	JDAM	
TBA			JDAM-002J-00	--	JDAM	
TBA			JDAM-002K-00	--	JDAM	
TBA			MB0955A-00	--	DIU	
TBA			MB1019W-00	--	ASDC	
TBA			MB1155C-03	12540726	CID	
TBA			MB136D-00	13547145	UGDU	
TBA			MB153A-01	13214706	MSU	
TBA			MB240H-00	--	NIGHT HUD (HDTS)	
TBA			MB386H-01	--	FLAT PANEL (HDTS)	
TBA			MB423B-06	2ZCG61030-0005	DMCH	
TBA			MB423B-10	2ZCH61030-0010	DMCH	
TBA			MB423C-XX	--	DMCH	
TBA			MB424A-01	--	FCAM	
TBA			MB424B-00	--	FCAM	
TBA			MB425A-02	--	HTU	
TBA			MB434A-00	--	VDC	
TBA			MB484A-00	--	AMTU	
TBA			MB488F-02	7-519410004-003	ISDU	
TBA			MB655A-XX	--	BRASSBOARD	
TBA			US34490592	--	SIGNAL GENERATOR	
TBA			VS-001D-01	--	SEEKER	
TBA			VS-001E-01	--	SEEKER	
UH-60	Displays	--	HH60-00001A-01	HH60-0001A-01	MULTI FUNCTION DISPLAY	1260-01-528-1171
UH-60	Displays	--	HH60-00001A-01	HH60-0001A-01	MULTI FUNCTION DISPLAY w/ Backlight Replacement	1260-01-528-1171
UH-60	Displays	HH-60 MFD	HH60-00005A-03	--	I/O MEZZANINE CCA	1260-01-528-1121
UH-60	Displays		S7060-55801-102	--	MULTIFUNCTION DISPLAY (MFD)	1260-01-493-6061
UH-60	VARIOUS		S7060-55801-101	--	MULTIFUNCTION DISPLAY (MFD)	6625-01-477-5575
V-22			MB037C-03	901-370-363-101	MFD	1260-01-476-4571
V-22			MB698A-01	901-370-373-101	SLIM MFD	1260-01-568-4500
V-22			MB036B-00	901-370-368-103	DEU II	1680-01-151-9013
V-22			901-172-201-101	--	CONVERTER CONTROL UNIT	1680-01-495-6018
V-22			MB200A-03	901-370-351-501	DDMS	1680-01-521-5195
V-22			MA748A-01	901-370-351-303	DIGITAL MAP SYSTEM	
V-22			MB037B-00	901-370-363-101	MFD	