


ROOSEVELT 36




FRONT ELEVATION
SCALE: 1/4"=1'





LEFT ELEVATION
SCALE: 3/16"=1'


ROOSEVELT 36



RIGHT ELEVATION
SCALE: 3/16"=1'



MAIN FLOOR
SCALE: 1/4"=1'
ALL HEADERS AND DR90 UNO,
TOP OF WINDOWS 90° AFF. UNO.



UPPER FLOOR
SCALE: 1/4"=1'
ALL HEADERS AND DR90 UNO,
TOP OF WINDOWS 90° AFF. UNO.