

1-877-433-5733
www.ezspotur.com



MINI POLE JACK
EZ-MPJ001











DECAL SAFETY All units have pictorial and written caution decals






## HOSE SAFETY

- All hydraulic hoses are <u>Cordura</u> protected.
- Hoses have an operating pressure of 3,000psi
- Hoses have a burst pressure of 12,000 psi.
- The spring hose unit ensures that the hydraulic line will not get pinched.
- The spring hose unit keeps the hoses out of the dirt

## CONNECTION SAFETY



Quick attach plate has gusset on top for extra support

Quick attach plate has doublers at the pin holes to insure they will not tear out.

**QUICK ATTACH GUSSET** 

**DOUBLERS** 



PULL UTILITY
POLES
&
TRANSMISSION
POLES









## CHAIN HOOK

#### CHAIN HOOK

- Allows for chain to be wrapped around the pole for added grip
- Use grade 80 chain or higher







<u>Cutting Edge</u> on the Bottom of the Pole Jack cuts through dirt mound at base of pole to ensure access to the pole

Width of base is 48.5 inches which provides a stable platform for pulling poles


## Clamp Specifications

#### 1. EXTRACTION CYLINDER

- 6"X12" EXTRACTION CYLINDER
- Break out force of 84,823 lbs
- Extracts pole from the ground


#### 2. CLAMP CYLINDERS

- 3"x6" CLAMP CYLINDERS
- Break out force of 21,206 lbs
- Grips pole securely



LIFTING POINT FOR PLACING POLE —
JACK WITH A DIGGER DERRICK TRUCK

OPTIONAL BATTERY BOX WITH RADIO TRANSMITTER
FOR USE WITH A DIGGER DERRICK TRUCK



## PRODUCT SPECIFICATIONS

- Universal Quick Tach' mounting system.
- Can be adapted to fit any machine.
- 1280 lbs. attachment weight.
- Jaws open to 31 inches
- Minimum pole diameter is 5 inches
- Stand-alone unit
- Rubber inserts can be purchased for removing metal and concrete poles.







### PRODUCT SPECIFICATIONS


- 1 7/16" 4140 pins for extraction cylinder
- 60,200 psi yield strength
- Comes complete with flush face coupler
- Spring hose mount included
- Wiring harness included.
- Composed of Grade 80 material or higher
- Core welded to withstand years of wear and tear



# Important Tips

- The Mini Pole Jack is strictly used for pulling poles and not handling poles.
- A Digger Derrick or other equipment is required to handle and control the pole when it is out of the ground.
- The base plate should never leave the ground when pulling poles
- The base of the Mini Pole Jack needs to be as flat as possible on the ground
- The jaws of the Mini Pole Jack should be parallel to the pole





## MINI POLE JACK VIDEO



