


Slotted holes allows micro adjustments
to the lower arm pivot ball
to eliminate binding

This row of holes are used for the
Bingo Universal Battery Holder

Holes used for the
Bingo High CG Battery Tray



Standard Yokomo front
bumper hole pattern

BINGO WASP DB

Slotted holes allows micro adjustments
to the lower arm pivot ball
to eliminate binding