


STEAM COLUMN & PIPING PARTS



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	F1227	Steam Chamber Column	17	F1456	Coil Supply Tube Ass'y (CF100)
2	F1269	Bearing Support Frame		F1458	Coil Supply Tube Ass'y (CF600)
3	F286	Bearing Locknut	18	F1324	Steam Coil (CF100)
4	F287	Bearing Adjustment Screw		F1288	Steam Coil (CF600)
5	F542	Pipe Plug	19	F1399	1/4" - 20 x 1" Screw
6	F1292	Union	20		(see page 19)
7	390401016	3/8" x 2" Pipe Nipple	22	400518040	Insulation (order by length)
8	F1289	Solenoid Valve	23	FG143	Pipe Tee
9	F1296	Steam Nozzle	24	SC196	Pipe Weldment
10	F1394	Steam Spreader	25	SC505	Coupling
11	F1397	Pipe Nipple (3/8" x close)	26	F1461	Elbow w/Fitting
12	F894	Drawband	27	F1439	Condenser
13	IB139	3/8" - 16 x 1-1/4" Bolt	29	F896	Drawband Eye
14	VSB134	3/8" Lockwasher	30	F1457	Coil Return Tube Ass'y (CF100)
15	IB140	3/8" Flat Washer		F1459	Coil Return Tube Ass'y (CF600)
16	F1449	Connector Flare	31	F1448	Column Supply Tube Ass'y