



NOTES:

1. TO ENTER FLOAT FOR INSPECTION OR REPAIR REMOVE FEMALE SIDE CORNER PLATES OR CUT OUT END/SIDE PANELS AS SHOWN. AFTER COMPLETION OF INSPECTION/REPAIR REPLACE PANEL, SEAL WELD, AND TEST FOR LEAKS AS DESCRIBED IN NOTE 2.
2. TEST FOR LEAKS BY APPLYING INTERNAL AIR PRESSURE OF 3 PSI MAXIMUM. BRUSH ALL EXTERNAL WELD SEAMS WITH WATER AND SOAP SOLUTION. LEAKS WILL BE DETECTED BY FORMATION OF SOAP BUBBLES.



THRUSTMASTER OF TEXAS, INC. | ^{TITLE} GA, FM5400 40' X 10' X 5'

ALL DATA ON THIS DOCUMENT ARE PROPRIETARY AND MAY NOT BE USED, REPRODUCED, OR DISCLOSED WITHOUT THE EXPRESS WRITTEN CONSENT OF THE MANUFACTURER OF THIS ITEM. IN CASE ANY PROVISION FOR THE LIMITED RIGHTS RELEASE TO THE UNITED STATES GOVERNMENT BY U.S. PATENT & TRADEMARK OFFICE IS APPLICABLE, THE USER SHALL NOT REPRODUCE OR TRANSMIT THIS INFORMATION TO ANY OTHER PARTY WITHOUT THE WRITTEN CONSENT OF THE MANUFACTURER OF THIS ITEM.		DIMENSIONING CONVENTION	SCALE: 1:48	SIZE: D	MATERIAL:	DWG/PART NO. D130325
	THIRD ANGLE PROJECTION	INCHES (mm)	ENG. REF: D129934	FINISH:		
	DO NOT SCALE		CAGE: 65848	EST. WT.: 27623 LBS	PROJECT REF NO: FM210367	SHEET 1 of 1