# **Panasonic**

**Proprietary Telephones** 

# Quick Reference Guide

### Model KX-T7720E/KX-T7730E/KX-T7750E

### Important Information

#### When using the KX-T7700 series, keep the following in mind.

- If there is any problem, unplug the extension and connect a known working phone. If the known working phone operates properly, have the defective phone repaired by your maintainer. If the known working phone does not operate properly, check the PABX System and the internal extension wiring.
- Keep the unit away from heating appliances and electrical noise generating devices such as fluorescent lamps and motors.
- The unit should be kept free of dust, moisture and vibration, and should not be exposed to direct sunlight.
- Do not use benzine, thinner, or any abrasive powder to clean the cabinet. Wipe it with a soft cloth.
- Do not disassemble this unit. Dangerous electrical shock could result. The unit must only be disassembled and repaired by qualified service technicians.
- When a failure occurs which exposes any internal parts, disconnect the telephone line and mains supply immediately and return the unit to your maintainer.
- This unit is designed to be installed under controlled conditions of ambient temperature and a relative humidity.
- Avoid installing the unit in damp or humid environments, such as bathrooms or swimming pools.
- 999 or 112 can be dialled on the product after accessing the CO line for the purpose of making outgoing calls to the BT emergency (999) and (112) services.

#### **WARNING:**

TO PREVENT THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS PRODUCT TO RAIN OR ANY TYPE OF MOISTURE.

THIS HANDSET EARPIECE IS MAGNETISED AND MAY RETAIN SMALL FERROUS OBJECTS.

#### IMPORTANT NOTICE:

Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependent on local power, is available for use in an emergency.


#### Notes:

- In this manual, the suffix of each model number is omitted.
- For further information, refer to the Main Unit/PABX Manuals.


Outside (CO) Line button Off-hook On-hook Feature number

<sup>\* &</sup>quot;Location of Controls" is shown on page 8.

Desired Function	Operation				
Making Calls					
Calling	To an extension  To an external party  To an external party  □ ► phone no. ► (((-))				
Redial	PEDIAL > ((1/2)				
One-touch Dialling	To program  PROGRAM  PROGRAM  PROGRAM  PROGRAM  STORE  PROGRAM  PROGRAM				
	To dial  scott - assigned as a One-touch dialling button				
Calling an operator	<b>№</b> • • • • • • • • • • • • • • • • • • •				
Personal Speed Dialling	To set    X   KX-TE Series   KX-TE Series   Personal speed   dial no.				
	To dial  KX-TE Series  KX-TDA Series  KX-TDA Series  (Check the type of your Main Unit.)  Fersonal speed dial no.  [TE: 0-9 [TDA: 00-99 (Default: 00-09)]				
System Speed Dialling	To dial  System speed dial no.  TE: 00-99 TDA: 000-999				



<b>Desired Function</b>	Operation					
	When the Dialled Extension is Busy/No Answer					
	Sender	While hearing a busy tone  2 ☐ KX-TE Series  1 ☐ KX-TDA Series  (Check the type of your Main Unit.)				
Call Waiting	Receiver	KX-TE Series   For outside calls   To alk to the new party (While hearing the Call Waiting tone)   Terminating a current status   Holding a current status (extension)   HOLD   Cancel   KX-TE Series   For outside calls   To alk to the new party (While hearing the Call Waiting tone)   Cancel   Call Waiting tone   Call Waitin				




<b>Desired Function</b>	Operation			
	Useful Features			
Setting Absent Message	(Check the type of your Main Unit.)  parameter (if required) ▶ # ▶ ☞    KX-TE Series   KX-TDA			
	☐KX-TE Series			
Forwarding a call	All calls    Dextension no.			
	All calls    Extension no.   #   Follow Me   7   your extension no.			
Clearing the setting	KX-TE Series  KX-TDA Series  (Check the type of your Main Unit.)			

<b>Desired Function</b>	Operation			
	Useful Features			
Log-in/Log-out	KX-TE Series   7 3 6 0 # For Log-in   7 3 6 1 # For Log-out     KX-TDA Series			
Do Not Disturb (DND)	KX-TE Series    WINDOND   A Set   Cancel   Market   Marke			
Locking your extension	KX-TE Series  7 7 lock code lock code ▶ # Lock 7 7 lock code ▶ # Unlock  KX-TDA Series  KX-TDA Series  Lock ★ 7 7 0 ▶ extension PIN* Unlock  * PIN: Personal Identification Number (Check the type of your Main Unit.)			

<sup>\*</sup> Consult your dealer for more details about the feature access numbers.

### **Location of Controls**

#### **RINGER Volume Selector**



- \* The KX-T7750 does not have a microphone.
- \* The display and headset jack are only available on the KX-T7730.
- \* Headset (not included) Not available: KX-T7090

### Location of Controls

- **PROGRAM:** Used to enter and exit the programming mode.
- CONF (Conference): Used to establish a multiple party conversation.
- 3 INTERCOM: Used to make or receive intercom calls.
- FWD/DND (Call Forwarding/Do Not Disturb): Used to perform Call Forwarding or Do Not Disturb.
- **FLASH/RECALL:** Used for External Feature Access or to disconnect the current call and make another call without hanging up.
- 6 AUTO ANS (Auto Answer) (KX-T7720/7730): Used to receive an incoming call in the hands-free mode.

**MUTE (KX-T7720/7730):** Used to mute the microphone during a conversation.

**VOICE CALL (KX-T7750):** Used to receive a notification via monitor in place of ringing.

- **AUTO DIAL/STORE:** Used for speed dialling or storing program changes.
- **8 TRANSFER:** Used to transfer a call to another party.
- 9 REDIAL: Used to redial.
- 10 HOLD: Used to place a call on hold.
- SP-PHONE (Speaker Phone) (KX-T7720/7730): Used for the handsfree operation.

**MONITOR (KX-T7750):** Used for handsfree dialling. You can monitor the other party's voice handsfree.

Navigator Key (KX-T7730): Used to adjust the volume and the display contrast or select desired items for each function.


Volume Key (KX-T7720/7750): Used to adjust the volume.

- (Button assignment is required.)


  Flexible Outside (CO) Line Button:
  Used to make or receive an outside call.
  Pressing this button seizes an idle outside line automatically. (Button assignment is required.) Also used as function buttons.
- PAUSE: Used to insert a pause during dialling.
- (15) MESSAGE: Used to leave a message waiting indication or call back the party who left the message waiting indication.
- **16** Message/Ringer Lamp: The Message/ Ringer lamp informs you visually that you have a message or a call.
  - When you receive a call, the lamp flashes depending on the ringing pattern. When someone has left you a message, the lamp is lit continuously.
     When the ringing pattern is set to Single (Slow flash), Double (Moderate flash), or Triple (Rapid flash) in your PABX, the lamp flashes. When the other ringing patterns are set in your PABX, the lamp may not flash. (e.g., S-Double, Call Waiting Tone1).

# Initial Settings

### ♦ Speaker volume \*




#### ◆ Handset/Headset volume \*



### ♠ Ringer volume




### ♦ Display contrast \*




\* The above settings may return to default settings if the telephone line cord is disconnected or the main unit's power is interrupted.

### Connection




### Wall Mounting


1 Pull down the handset hook until it locks, so the tab holds the handset.



2 Remove the attached stand.




 KX-T7730 model illustrated on this page. 3 Mount the unit on the wall.



To temporarily place the handset down during a conversation,

hook it over the top edge of the phone as shown.



#### Other Information:

This unit is capable of being used in conjunction with hearing aids fitted with inductive coil pick-ups. The handset should be held as for normal conversation. For operation the hearing aid should be set to its "T" position or as directed in the operating instructions for the hearing aid.



#### Included Accessories:

Accessory	Qty	White Model	Black Model
Handset	1	PQJX2PSL01Z	PQJX2PKAL01Z
Handset Cord	1	PSJA1084Z	PSJA1084X
Telephone Line Cord	1	PSJA1064Z	PSJA1064Z
Stand	1	PSYL1002Z1	PSYL1002Z2
Overlay*	1	PSGD1066Z	PSGD1066Z

<sup>\*</sup>The overlay is only available on the KX-T7730.

# $\epsilon$

This product is intended to be connected to Panasonic KX series PABX only. Panasonic Communications Company (U.K.) Ltd. declares that this equipment is in compliance with the essential requirements and other relevant provisions of Radio & Telecommunications Terminal Equipment (R&TTE) Directive 1999/5/EC. Declarations of Conformity for the relevant Panasonic products described in this manual are available for download by visiting: <a href="http://www.doc.panasonic.de">http://www.doc.panasonic.de</a>

#### Contact:

Panasonic Services Europe a Division of Panasonic Marketing Europe GmbH Panasonic Testing Centre Winsbergring 15, 22525 Hamburg, Germany

#### Panasonic Business Systems U.K.

Panasonic House, Willoughby Road, Bracknell, Berkshire RG12 8FP

© 2002 Panasonic Communications Co., Ltd. All Rights Reserved.