

Turbo Stage Solenoid / Line Lock Wiring

• This example energizes the Line-Lock solenoid while Transbrake is depressed, but releases the Line-Lock solenoid while the Stage Solenoid Switch is depressed, thereby allowing the driver to move the car into the beam by modulating the brake pedal / lever. Once the Stage Solenoid Switch is released, the Line-Lock solenoid will be re-energized.