
# CDL OCALA CVT SCHOOL CDL CLASS B AIR BRAKE TEST






PRIMARY

SERVICE BRAKE

SPRING BRAKE




#### SAFE START TRUCK CHECK ABS/DEF LIGHTS






# BUILD UP AIR UNTIL GOVERNOR CUT OFF BETWEEN 120 AND 140 psi



# GOVENOR CUT OFF? EXPLAIN RESULTS PROPER RANGE WORKING PROPERLY.




## AIR BRAKE LEAK TEST

# SHOULD NOT LOSE MORE THAN 3psi IN ONE MINUTE



#### PRESS AND HOLD BRAKE



2 TURN TRUCK OFF AND PUT KEY IN ACCESORY



(3) PUSH IN YELLOW VALVE



## YOU MUST WAIT FOR AIR TO STABILIZE, THEN BEGIN YOUR ONE MINUTE COUNTDOWN.




ONE MINUTE LATER STOP TIMMER, LIFT FOOT OF BRAKE AND EXPLAIN THE RESULTS

## LOW AIR WARNING

WITHOUT RESTARTING TRUCK FAN BRAKES UNTIL ALARM COMES ON. ALARM SHOULD COME ON AT 55 psi OR ABOVE.



# EXPLAIN RESULTS, ALARM CAME ON, 55 PSI AND ABOVE PROPER RANGE WORKING PROPERLY



## **SPRING BRAKE**


CONTINUE TO FAN BRAKES UNTIL THE VALVES POP OUT. VALVES SHOULD POP OUT BETWEEN 20 TO 45 psi OR ABOVE.



# VALVE POPPED OUT BETWEEN 20 TO 45 PSI, PROPER RANGE WORKING PROPERLY




# VALVE POPPED OUT BETWEEN 20 TO 45 PSI, PROPER RANGE WORKING PROPERLY



### SINGLE BRAKE CHAMBER STEER TIRES





#### DUAL BRAKE CHAMBER DRIVE TIRES



