



#67200



30"x23" BACK FOLDING HOCKEY GOAL





Installation Instructions Please read instructions COMPLETELY before assembly.



DO NOT RETURN PRODUCT TO THE STORE

Missing Parts, Need Placements, or Help with Assembly

Please Contact Customer Service:

203 591 9032 WATERBURY, CT 06710, U.S.A.



NOTE: Precision connection will fit snugly, use a rubber mallet or block of wood if needed.

1. Begin assembly

Begin assembly at the base of the goal and work upwards. Follow the diagram. Insert top shelf screws, do not overtighten. Note: Pull pins from both folding legs and unfold. Reinsert pins to lock position prior to assembly.

2. Lacing the goal net

Open the goal and put pin in.

Place the sewn part of the net at the top corners, by the top shelf. (See Figure 1 & 2).

Tape or secure the net to the frame. This makes it easy to lace Figure 1 & 2.

The black rope is for the red frame.

White rope is for the white base frame wire.

3. Lacing front of goal

The black rope is for the red frame.

Start at the bottom corner.

Loop and tie off net and frame with a double knot at the little hole on the folding section. *(See Figure 3).*

Lace every **OTHER** box of the net. Tie off to the other side of the net to the hole on the folding section. *(See Figure 4).*

4. Lacing bottom base

Use the white rope to lace the base. Loop and tie the net and frame together. (See Figure 3).


Lace every **OTHER** box of the net. Tie off to the other side. Loop and tie off the net of the frame. *(See Figure 4).*

5. Finishing

Cut the extra rope and tie the pins to the net, so it does not get lost. (See Figure 5).

6. Folding & storage

Pull two pins out, fold the goal and re-insert pins in top hole for storage.






Figure 1

