

#17



#87091

Folding Goal & Throwback



NO.	DRAWING	DESCRIPTION	PART #	QTY.
1		Front Top Bent Tube	1221	2
2		Front Top Straight Tube	1229	1
3		Left Front Upright	1225L	1
4		Right Front Upright	1225R	1
5		Front Folding Tube	1223	2
6		Bottom Back Bent Tube	1206	1
7		Left Bottom Bent Folding Tube	1204L	1
8		Right Bottom Bent Folding Tube	1204R	1
9		Back Bottom Straight Tube	1208	2
10		Front Bottom Throwback Base	1408	1
11		Front Bottom Throwback Base with Swedge	1407	1
12		Side Tilting Assembly	1412 1410 1411	2 2 2
13		8mm Folding Section Bolt	5310	2
14		8mm Self Locking nut	008 Spare	2 1
15		Pull Pin 59mm 2 3/8"	4659	6
16		Black Bungee	9191 Spare	36 2
17		Black Throw Back	67127	1
18		Wrench	017	1
19		Allen Wrench	018	1
20		15" Rope Black	9144	4

Installation
Instructions
Please read instructions
COMPLETELY
before assembly.



**DO NOT RETURN
PRODUCT TO THE
STORE**

Missing Parts,
Need Replacements, or
Help with Assembly

Please Contact
Customer Service:

Service@ezgoal.net
203 591 9032



Note: Precision Connections will fit snugly.
Use a rubber mallet or block of wood if needed.

#87091

Folding Goal & Throwback

Follow the diagrams.

1. Connect the folding section and base parts together.

Part 1223 to parts 1204L and 1204R.

The folding section bolts should be on the inside and in front.

The nuts should be on the outside. Do not over tighten the nuts.

The pull pins should be in the front of the folding section.

2. Make sure the big slot on the bottom base tube that connects to the folding section is facing up. See diagrams.

Insert the pull pins into the folding section while in the open position.

Assemble the bottom base of the goal first, then the front uprights.

Put front upright parts 1204L & 1204R in the proper locations.

Make sure the big slot on the 1.5" tube is facing in towards the back of the goal.

3. Attaching the Side Bars/Side Tilting Assembly

The side bars can be removed easy at anytime for game play.

Note: The goal folding section pull pins must be in at all times when the sides bars are not being used.

The side bars are only needed when using the net as a throwback. The side bars can be left on in position or stored on the goal, hanging straight down behind the front 1.5" uprights or taken off.

Attach the side bars by inserting the steel plates into the slots on the upright tubes.

Note: Make sure the 1.5" upright tubes with the slots are on the correct sides of the goal.

The Left and Right big slots on the 1.5" tubes must face towards the back center of the goal.

The side bar plate goes into the big slot on the back side of the 1.5" tube and must secure in the small slot in the front. Insert the pull pin from the inside of the goal out. **The plate must be secured in both big and small slots for the pull pin to go through the hole. See Diagrams:**

Press the silver tilting adjustment button. It is located on the center tube with many holes. Extend the sides bars. Connect the bottom side bar plate into the large top rectangle slot on the bottom base tube. Insert the pull pin from the inside of the goal out

4. Note: Use the 4 pieces of rope to secure the pull pins to the side bars. This will prevent losing the pull pins in the grass. Insert the extra rope thru the small hole on the side bar plates and tie the pull pins to plates.








5. Folding the Goal and Throwback

The goal and throwback can be folded together.

Take the pull pins out of the bottom side bars and store side bars here

Remove the pull pins out of the folding section and fold goal.

Secure the folded triangle section with a rope for Storage **See Diagrams:**



6. Installation of Throwback Black Net

Note: The tilting side bars and bottom front throwback tube needs to be on before installing the throwback net.



Note: Safety glasses should be used while securing or removing throwback net from frame.

Evenly connect the bungees to the net before putting it on the frame.

There should be **9** bungees on each side of the net.


Connect all bungees, then secure them to the goal.

Replacement bungees can be ordered online at ezgoal.net



Hook bottom throwback tube to folding section .

Bottom Front Throwback Tube



7. Adjusting the Angle of the Throwback Frame

The throwback side bars have a **special patent pending feature** that enables you to adjust the throwback without going from hole to hole.

Note: Pull out both bottom folding section pull pins before adjusting the tilting throwback. Store pins in the extra front holes on the folding section.


1 Push the silver middle button in, twist to the right.

2 Do the same with the other side bar.

3 Adjust the tilting angle.





4 Twist both bars back to the left and locate holes.

Note: Do not use the bottom 2 Safety slots on the side bars.



Adjusting Throwback












- 1 Button In
- 2 Twist Right
- 3 Tilt Throwback
- 4 Twist Left



Larger Views of Assembly Drawings

#87091

Folding Goal
& Throwback



Practice Play Fold-It-Away™


EZGOAL™ Sports

Backstop Rebounder Kit

Fits all goals and rebounders

Lacrosse main net kit

Order Kit
#87679
#69126



To Order the Backstop Rebounder Visit **ezgoal.net**
CUSTOMER ASSISTANCE

For help, replacement parts, questions or concerns about your EZ Goal Products, EMAIL or Call

EZ Goal Sports
Customer Service:
WATERBURY, CT 06710, U.S.A.

Service@Ezgoal.net or 203 591 9032

SAFETY PRECAUTIONS



WARNING

Manufacturer suggests wearing safety goggles for net assembly, to protect against bungee cords hitting eye. As with any play equipment, children **MUST** be supervised at all times.
Use product on a level surface.
Never use near steps or stairs.
For outdoor use only.
Allow 8 feet from structures such as a fence, garage, house, overhanging branches, laundry lines, or electrical wires.
Use common sense, and all the same precautions as you would when playing sports.
Secure unit, so high winds do not blow it over.



WARNING

NEVER allow anyone (people or pets) to stand behind the net or in any possible path of a ball or puck should you miss the net or should the ball or puck go through the net. Inspect unit before and during each use. Replace any worn or damaged parts.
Never allow children to stand on unit. This could cause damage to unit and result in an injury.
Do not use bungees for any other purposes other than to apply net.
As with any sporting activity, always wear the recommended safety equipment.
Never leave children unattended.
Use protective eyewear when securing bungees.