





PHONE 214-477-1344 FAX 972-317-6889
 PO BOX 294488 LEWISVILLE, TX 75029

INSA SERIES 5100 CONTROL MODULE - FRONT



<i>Position in Illustration 1</i>	<i>OrderNo.</i>	<i>Description</i>
1	600.010.01	Manometer 10 Bar
2	600.032.01	Cover
3	100.003.04	ECB Card
4	600.007.01	Pressure Regulator Big
5	600.020.01	Head For FD Controller
6	600.008.01	Pressure Regulator Small
7	600.062.01	Main Switch

INSA SERIES 5100 CONTROL MODULE – BACK




<i>Positioni n Illustr.18</i>	<i>OrderNr.</i>	<i>Description</i>
1	100.002.01	Connecting Socket 7Pole
2	600.052.01	Inline Socket
3	100.018.01	Voltage Switch 230/115V
4	100.016.02	Fuse 2.0A
5	100.016.01	Fuse 0.5A
6	200.076.01	Air Feeding Selector
7	600.011.01	Pneumatic Connector
8	600.032.01	Pneumatic Connector
9	600.012.01	Pneumatic Connector
10	500.052.01	Earthing Screw



PHONE 214-477-1344 FAX 972-317-6889
 PO BOX 294488 LEWISVILLE, TX 75029

INSA SERIES 5100 CONTROL MODULE - INTERIOR PARTS



<i>Position in Illustr.19</i>	<i>OrderNo</i>	<i>Description</i>
1	100.008.01	FD Regulating Knob
2	600.005.01	Solenoid Valve
3	200.061.01	Connector
4	200.047.03	Needle Valve
5	200.076.01	Selector
6	100.003.04	ECB Card
7	600.035.01	Transformer