

How to set up NMEA output from a Trimble 750 \1000 to a X20

Requires cable part number ZTN67091







750 Connect cable ZNT67091 to Port A or B

THE

1000 Connect cable ZNT67091 to Port A, B, C, or D





From main Screen press Settings





Press System






Press the Advanced tab






Select NEMA Output tab



Select NEMA output port

- FIAM P



Select port that cable ZTN67091 is plugged into

When proper Port is green – Select green Check mark –






Press the Baud Rate tab —



Select Baud rate to match X20 monitor selected rate

Best choice Usually is 38,400bps

Press green Check mark -





Your setup is now complete return to main screen Using red X And left arrow where the X was

