


# Metric Hex Bolt Diameters and Thread Pitches

Length is measured from under the head to the end of the bolt

Note: Head sizes may differ from what is shown due to differences between metric standards



**IMPORTANT:** Make sure to print this chart to Actual Size (no scaling).  
After printing, measure the ruler in the margin to ensure correct scale.