EVERY INCH RV INSPECTION SERVICES

Roof



Sample

Premier "Every Inch" Inspection Points for Motor Homes

Every Inch RV Inspection Services appreciates your interest in our business and looks forward to opportunity to provide you with the most advanced RV inspection available in today's RV market.

There are two inspection levels identified in this document. The <u>Premier "Every Inch" Inspection</u> will include all of the points detailed below. This report will consist of 80 to 100 photos describing the items that have been identified during this comprehensive inspection. Also included in this report is 360 photos of the interior of the RV which allow you to look around like you were in the RV. Fluid sampling and analysis can also be added to the <u>Premier "Every Inch"</u> <u>Inspection</u> at a reduced cost if purchased at the time the inspection is ordered.

The second level of inspection is the <u>Essentials Inspection</u>. The points that will be inspected are identified by the <u>(E)</u> at the end of each point. This report will consist of 30 to 50 photos describing the items that have been identified during this limited inspection.

	Inspect and rate the overall Roof Condition. (E) Identify the Roof material type and the sealants that have been applied to the roof.(P) Evaluate the condition of the various sealant and joints around the roofing components.(P) Rate the condition of the roof vents, air conditioners, antenna, other components that are mounted on the roof.(E) Identify areas of concern and potential water intrusion points.(P)			
Sidewall and End Caps				
	Inspect and identify the material type of the front and rear caps.(P)			
	Evaluate the aging and general overall condition of the front and rear caps.(P)			
	Inspect and evaluate the appearance and functional condition of the sidewalls, entrance doors, windows and cargo access doors. (E)			
	Inspect and evaluate any damage, discoloration and delamination of the side wall and end cap components.(P)			
Slic	Slide Out Rooms			
	Identify the types of slideout room drive systems.(P)			
	Identify the type of roof material for the slideout room.(P)			
	Inspect and rate the roof condition. (E)			
	Inspect and evaluate the condition of the seals, sweeps and gaskets for possible damage. (E)			
	Evaluate the attached wiring and utility harness that feed underneath the slide out room.(P)			
Aw	nings and Slide Out Toppers			
	Inspect and identify operational type (manual vs electric) of the awnings, slideout toppers and window awnings.(P)			
	Operate and rate condition of the awning frames and latching mechanisms. (E)			
	Evaluate and rate the condition of fabric material of the awnings.(P)			
Cha	assis Turn Signal and Running Lights (12-volt DC)			
	Inspect the condition of the 7-pin connector receptacle.(P)			
	Activate and evaluate the operation of the DOT lights. (E)			
	Visually inspect the chassis battery compartment the electrical connections and batteries. (F)			

	Inspect and rate the condition of the power cord and its connection ends. (E) Identify any damage or repair of the power cord. (P) Remove cover panel of 120-volt circuit breaker box to visually inspect the condition of the wiring, circuit breakers and grounding connections. (E) List any heat discoloration to the wiring and connections. (P) Verify the separation of all the wiring types. (P) Test and verify the output operation of the 120 VAC to 12 VDC converter for charging of the deep cycle batteries. (E)
cor	nerator- Engine — if installed *strongly recommend performing oil analysis to determine internal combustion engine inponent condition. Identify and note the model, serial number and run hours of the generator. (E) Check oil level. (E) Start, operate and test the onboard generator under load. (P) Test the voltage output and frequency (60 cycles). (P)
det □	nerator - Radiator - if installed on this model of Generator *strongly recommend performing coolant analysis to termine the condition of the coolant fluid and the internal cooling system. Location of the radiator and cooling fans.(P) Visually inspect the coolant reservoir, radiator and hoses.(E)
	rerter – if installed Identify and note the model and serial number of the inverter.(P) Visually inspect the wiring and electrical connections and fuses/circuit breakers.(E) Place electrical load on inverter to verify proper operation.(P) Test voltage and frequency output of the inverter under fifty percent load.(P)
	Locate and note the location of the battery stack.(P) Evaluate the condition, age and matched sizing of the battery stack.(E) Evaluate and determine if positive and negative cables are correctly matched for balanced load.(P) Access and visually inspect the wiring, fuse panel and fuses of the 12-volt DC electrical system.(E) Evaluate the operation of the fresh water /waste water monitor panel for incorrect tank readings.(P)
	Verify the fresh water connections for the City Water hookup are operational. (E) Verify the onboard fresh water tank and pressure pump system will operate and maintain pressure. (E) Operationally test all fresh water fixtures inside and outside of the RV.(P) Visually inspect the water filtration system (if installed) for leaks and filter placement. (P)
	Operationally test and inspect both waste (gray and black) plumbing systems for leaks under the sinks, shower, around the toilet and discharge lines. [E] Identify the type drain valve controls.(P) Verify the drain valves for both systems will maintain water in their tanks.(P) Operate both drain valves and test for ease of operation. [E] Verify the drain cap is in place and will hold waste water.
	Perform and document LP gas timed leak test at cook top burner spud for 5 minutes at 8 inches of water column gas pressure. (E) Test the Ground Fault Circuit Interrupter (GFCI) circuits in the 6-foot range of the water areas of the bathroom, kitchen and exterior receptacles. (E)

	Test all wall receptacles for correct polarity and ground fault. (E) Test the exterior skin for Hot Skin that would cause electrical shock. (E) Emergency Exit Windows – Verify all safety windows are operational. (E) Fire Extinguisher – Verify unit is secure in bracket and dial indicates extinguisher is fully charged. (E) Smoke/Fire Detector – Test and verify operation of units. (E) Carbon Monoxide Detector (if applicable) – Test and verify operation of unit. (E) LP Gas Detector – Verify gas detection and audio alarm. Document expiration date of detector. (E) Verify the rubber grommet is properly sealed around LP gas line of water heater. (E)
	Gas System Visually inspect all hoses and pressure regulators for damage and age deterioration. (E) Verify plastic cover has been installed over regulator. (E) On Split tank system verify the red colored single stage regulator is installed. (P)
	ME tank - if equipped If tank is visible, conduct a visual inspection of tank for rust or physical damage. List the location of the tank.(P) Document the manufacture date of the ASME tank if accessible.(P) List the gallon capacity of the tank.(P)
	Identify the brand, model and type of refrigerator. (E) Note the location of the vent panels used by refrigerator. (P) Operate on all heat sources – 120-volt AC, LP gas and for 3 way refrigerators, 12-volt DC. (E) Collect serial and model number and verify with manufacturer if recall notice has been issued and completed for this unit. (E) Visually verify if baffle system on back of refrigerator area is correct and directing heat away from gas coils. (P) Test for interior temperature of upper and lower refrigerator compartments and ice maker (if installed) *if refrigerator has been operating for minimum of 12 hours. (P) Check condition of door frame, shelving, crisper drawers, door shelves and interior light. (P) Evaluate and rate the door gasket seals of freezer and refrigerator box areas. (P)
	Identify the brand, model and type of water heater. (E) Visually inspect burner assembly and gas exhaust system for blockages and insect infestation. (P) Fill tank with water (if necessary) and verify operation on all heat sources — LP gas and 120-volt AC if equipped with heating element. (E) If installed, operate and verify positioning of bypass valves on back of water heater. (P) Determine if proper drain plug has been installed in water heater tank. (P) If installed, inspect and evaluate if the correct type of dauber screen has been is being used. (P)
Fur	If accessible, identify the brand, model and type of furnace(s) that have been installed.(P) Identify the type of thermostat controls being used to operate furnace(s).(P) Visually inspect air intake and exhaust assemblies for blockages and insect infestation.(P) Operate and verify warm air discharge out of vents and proper return air flow to unit.(E) Monitor for unusual noise or vibration of blower motor.(P) If installed, inspect and evaluate if the correct type of dauber screen is being used.(P)
Co:	ok Top/ Stove Evaluate and rate the condition of the cook top or stove.(P) List presence and condition of stove top covers.(P) Verify the ignition and operation of all top burners and the oven flame (if equipped).(E)

Inspect and rate the condition of the metal grill top and rubber grommets of top burner area.(P) Evaluate the presence of the control knobs, door handles and oven racks of the unit.(P)
Conditioner(s) Identify and list the type of cooling unit/heat pump.(P) Perform cooling efficiency test (Delta T) on each unit.(E) Inspect the air filter(s) debris and cleanliness.(P)
Asher/ Dryer Visually inspect and verify a wash and rinse cycle of the washer and dryer.(P) Visually inspect for leaks or damaged hoses.(P) Evaluate and rate the exterior condition of the dryer exhaust vent.(P)
crowave/Convection Oven Identify and list the brand, model, type and output wattage of the unit.(E) Verify the rack and turn tables are installed.(P) Operate unit for 60 seconds utilizing cup of water and then list water temperature.(P)
thwasher - if installed Identify and list the brand, model and type of unit. (E) Verify operation of unit and inspect for leaks and non-functioning rotating racks and wash bars.(P)
House Vacuum System – if installed Identify and list the brand, model and type of unit.(E) Verify the operation and visually inspect the various components of the hose assembly, access doors and dirt bag.(P
ctric Fireplace – if installed Identify and list the brand, model and type of unit.(E) Operate and verify the various heat settings, fan speed levels and the back lighting.(P)
ok Top Exhaust Fan Operate and verify condition of the exhaust function and fan speeds. Visually inspect the filter and lighting.(P) Evaluate and rate the exterior condition of the exhaust vent.(P)
iling Mounted Fans and Ceiling Exhaust Vents Visually inspect the condition of the blades and motor.(P) Operate and verify condition of the blade direction and fan speeds.(E) Verify lighting if equipped.(P)
erior Conditions and Appearance Visually inspect all ceilings, walls, interior doors and flooring for signs of water intrusion, surface damage and/or staining. (E) Operate all windows and doors noting any deficiencies or missing components.(P) Evaluate the window coverings.(P) Operate all interior, exterior and décor lighting - 12-volt and 120-volts. (E)
binets and Closet Condition Inspect and evaluate all cabinet doors, drawers and pull out operation. (E) Visually inspect all counter tops and flat surface areas of the kitchen, living room, bathroom, bedroom and storage areas for scratches and damage. (P) Identify and list all broken and loose cabinet and closet hardware. (P) Note if appearance of previous damage repairs have been performed. (P)

Fui	rniture	
	Visually inspect the condition of the dinette table/booth, chairs, recliners and sofa. (E) Inspect and note furniture fabric tears, discoloration and signs of excessive wear. (P)	
	Visually inspect and note signs of mattress damage or staining. (E)	
	tertainment System Visually inspect and operate all TV and stereo equipment.(E) Verify DVD/disc players and radios are operational.(E) Verify local channels antenna and 12-volt DC power signal booster is operational.(P) Raise and lower roof mounted antenna if equipped.(P)	
	Verify remotes are operational.(P)	
	ower/Tub Enclosure Visually inspect the glass panels, curtains and soap dish areas.(P) Evaluate and rate the seals around the frame work and doors for water leaks.(E) Operate the door and latch system to verify its operation.(E) Inspect and evaluate the stains and chemical/mineral buildup.(P)	
Motor Home - Please note the following items: Due to insurance issues the Motor Home can NOT be driven by the Inspector. Also, the lack of clearance under the motor home and safety issues the Inspector will conduct the following visual inspections from the outer perimeter of the motor home.		
	assis and Undercarriage Visually inspect for rust, damage and excessive oil on the underside of the motor home. (E)	
	eering Visually inspect for bent or damaged components and hydraulic leaks.(E)	
	veling System Identify and note the brand and type of system.(P) Operate by extending and retracting leveling system.(E) Check for hydraulic leaks or mechanical issues.(P)	
	gine *strongly recommend performing oil analysis to determine internal combustion engine component condition. Make and model of the engine. (E) Verify oil level on the dipstick. (E) Indications of engine issues or any noises while running. (E) Are there noticeable oil or exhaust leaks. (P) Note the oil pressure reading on the dash gauges.	
int∈ □	diator *strongly recommend performing coolant analysis to determine the condition of the coolant fluid and the ernal cooling system. Location of the radiator and cooling fans.(P) Visually inspect the coolant reservoir, radiator and hoses.(E)	
the	Ansmission *strongly recommend performing transmission fluid analysis to determine the condition of the fluid and e internal components of the transmission. Type of transmission.(P) Fluid level on dipstick.(E) Indications of contaminated transmission fluid.(E)	

Rui	nning Gear (Motor Home)
	Type and number of axles. <mark>(E)</mark>
	Weight Ratings for Each Axle Set.(P)
	Inspect the frame, axles, springs, rims and other components for rust, oil stains and visible damage. (E)
	Document the information on the tires as to their age, tire tread condition and weight capacities. (E)
	Check tire pressure.(P)
	Inspect and rate tire tread condition.(P)
	Note any valve extensions and pressure monitors.(P)
Hit	ch System/Hook Up
	Inspect and identify the type of system used to tow vehicles. (E)
	Evaluate and list modifications to hitch system.(P)
We	eight Labels and Data Plates
	Identify and document the Vehicle Identification Number (VIN). <mark>(E)</mark>
	Document the License plate info.(E)
	List the Inspection sticker information — if applicable. (E)
	List the RVIA inspection seal number. <mark>(E)</mark>
	List the Gross Vehicle Weight Rating. <mark>(E)</mark>
	List date of manufacturer. (E)
	List the Manufacturer's Build Sheet (if available).(P)
	List Owner Stated Comments (if present).(P)