

WHITE WINGS LAUNDRY DETERGENT

PORTION
CONTROL
#9

USE

Low-foaming concentrated detergent that cleans, brightens, and freshens. Fresh lemon scent. Add packet to washer while filling with water. After water-soluble packet dissolves, add clothing. Use 1 water-soluble packet per 16-20 pounds of laundry.

APPLICATION

Adjust water temperature, based on type of fabric. For white and colorfast fabrics, use hot water. For permanent press fabrics, use warm water. Best results are obtained with a cold water rinse. Do not place the water-soluble packet directly on the clothes.

STANDARD MACHINE: Begin to fill washer with water. Add 1-2 packets of White Wings® Ultra Laundry Detergent. When using cold water, make sure the packet and powder are completely dissolved before adding clothes. Use one packet per 16-20 lbs. of laundry.

HIGH EFFICIENCY (HE) MACHINE: Add one packet of White Wings® Ultra Laundry Detergent directly to the back of the drum. (Do not place in chemical dispensing unit.) Then, add clothes. Use one pack per 20-25 lbs. of laundry.

NOTE: This laundry detergent cleans all washable synthetics, colors, whites, cottons, and permanent press fabrics. Because of the heavy duty composition, it is not recommended for use on silks or woolsens. This detergent has a concentrated cleaning strength to remove ground-in dirt, stains, and dulling gray.

BENEFITS

- Simple to use
- Cost-effective - No overpour

PACK

1 recloseable case contains: 250 x 1.2oz packets.

Case Pack:	250 x 1.2oz packet	Ti:	20
Case Weight:	19	Hi:	5
Case Length:	8.5	Cases/Skid:	100
Case Width:	8.5	Case UPC:	071206002198
Case Height:	9	Inner UPC:	N/A
Case Cube:	0.38		



ORDER #
PSPC9

Professional
Supply **PS**