# COFFEE CLEAN COFFEE POT CLEANER

### PORTION CONTROL #15



# **USE**

For use on coffee pot & equipment to remove coffee stains from glass, plastic, and metal surfaces.

# **APPLICATION**

DIRECTIONS FOR POUROVER OR SINGLE POT MACHINE

1. Discard coffee filter and grounds from coffee maker. 2. Pour contents of Coffee Clean packet into empty coffee pot and fill with hot water. 3. Pour solution in coffee maker sump. CAUTION: DO NOT POUR INTO A RESERVOIR MACHINE. 4. Brew solution through coffee maker and discard. 5. Rinse by brewing with fresh water and discard. 6. Let air dry.

For Pot Cleaning: Pour contents of Coffee Clean packet into empty coffee pot and fill with hot water, soak, rinse thoroughly, air dry.

For tough stains, soak components in the Coffee Clean solution.

### ORDER # PSPC15



# **BENEFITS**

- Simple to use
- Cost-effective No overpour

### PACK

1 recloseable case contains: 150 x 0.25oz packets.

 Case Pack:
 150 x 0.25oz packet Ti:
 25

 Case Weight:
 4
 Hi:
 4

 Case Length:
 9.75
 Cases/Skid:
 100

**Case Width:** 7.75 **Case UPC:** 071206108821

Case Height: 7.875 Inner UPC: N/A

Case Cube: 0.34

