


LX250R




手把管总成



No.	U8 Code	ERP(BOM) 参考 订单：2506022-MC-05	EN name	Qty
1	60100-LX22-0042	60100-LX22-0042	handlebar	1
2	32300-LK22-0021	32300-LK22-0021	start switch	1
3	92021-SX22-0011	92021-SX22-0011	rubber cable tie	2
4	96020-LX25-0011	96020-LX25-0011	Foam padding cover	1
5	96010-LX24-0011	96010-LX24-0011	Foam padding, anti-collision rubber	1
6	32400-LX22-0021	32400-LX22-0021	Circle Kill switch, Left	1
7	60300-LX22-0031	60300-LX22-0031	right grip	1
8	61200-LK22-0021	61200-LK22-0021	right handlebar protector	1
9	60400-LX24-0011	60400-LX24-0011(加油器)	accelerator	1
10				
11	60404-LX24-0011	60404-LX24-0011	accelerator cable boot	1
12	60700-LX24-0051	60700-LX24-0051	throttle cable	1
13	60600-LX25-0101	60600-LX25-0101	clutch cable	1
14	60900-LX24-0041	60900-LX24-0041	clutch lever assy	1
15	61100-LK22-0021	61100-LK22-0021	left handlebar protector	1


16	60200-LX22-0011	60200-LX22-0011	left grip	1
----	-----------------	-----------------	-----------	---

前碟刹总成




No.	U8 Code	ERP (BOM)	EN name	Qty
1	41500-LX22-0171	41500-LX22-0171	front disc brake assy	1
1-1	/		Front disc brake housing	1
1-2	/		front brake lever	1
1-3	/		Front disc brake downpump bracket	1
1-4	/		front disc brake shoes	1
2	99408-QCBJ-0191		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	2

后碟刹总成




No.	U8 Code	ERP(BOM)	EN name	Qty
1	84130-LX22-0011	84130-LX22-0011	rear disc brake plate protector	1
2	99108-QCBJ-0011		Internal hexagonal large flat head bolt	2
3	41600-LX22-0081	41600-LX22-0081	rear disc brake assy	1
3-1	/		rear disc brake shoes	1
3-2	/		Rear disc brake/pump bracket.	1
3-3	/		Rear disc brake housing.	1
4	99108-QCBJ-0031		Internal hexagonal large flat head bolt	1
5	99108-QCBJ-0021		Internal hexagonal large flat head bolt	2

前减、上联板总成



No.	U8 Code	ERP(BOM)	EN name	Qty
1	50801-LX22-0012	50801-LX22-0012	protector, front right shock absorber	1
2	/		Installation components for the front shield cover.	6
3	50800-LX22-0091	50800-LX22-0091	front right shock absorber	1
4	99103-QCBJ-0261		GBT5787 hexagonal flange bolt (small plate internal plum blossom)	8
5	50400-LX24-0011	50400-LX24-0011	lower connecting plate	1
6	50700-LX22-0091	50700-LX22-0091	front left shock absorber	1
7	50701-LX22-0012	50701-LX22-0012	protector, front left shock absorber	1
8	50304-LX22-0011	50304-LX22-0011	dust cover, steering column	1
9	95010-LX22-0011	95010-LX22-0011	tapered roller bearing	1
10	50304-LX22-0021	50304-LX22-0011	dust cover, steering column	1
11	50301-LX22-0011	50301-LX22-0011	adjusting nut, steering column	1
12	99104-QCBJ-0271		GBT70.1 hexagon socket cylindrical head screws	2
13	50200-LX24-0011	50200-LX24-0011	upper connecting plate	1
14	50303-LX22-0011	50303-LX22-0011	fastening bolt, steering column	1
15	99103-QCBJ-0241		GBT5787 hexagonal flange bolt (small plate internal plum blossom)	2
16	50201-LX24-0011	50201-LX24-0011	handlebar clip	2
17	50202-LX24-0011	50202-LX24-0011	handlebar clip seat	2

前轮总成




No.	U8 Code	ERP(BOM)	EN name	Qty
1	91011-LX22-0011	91011-LX22-0011	nut, front wheel axle	1
2	91060-LX25-0011	91060-LX25-0011	front wheel bush	2
3	99410-QCBJ-0011		internal plum blossom flat round head bolt	6
4	41501-LX22-0031	41501-LX22-0031	front brake disc	1
5	40200-LX22-0031	40200-LX22-0031	front tire	1
6	40800-LX22-0092	40800-LX22-0092	front wheel rim assy	1
7	40100-LX22-0031	40100-LX22-0031	front inner tire	1
8	/		Padding strap.	1
9	40500-LX22-0011	40500-LX22-0011	front tire clamp	1
10	91010-LX22-0011	91010-LX22-0011	front wheel axle	1

后轮总成




No.	U8 Code	ERP(BOM)	EN name	Qty
1	50503-LX22-0031	50503-LX22-0031	chain adjuster, left	1
2	91030-LX22-0022	91030-LX22-0022	rear wheel axle	1
3	91071-LX25-0011	91071-LX25-0011	left bush, rear wheel	1
4	99107-QCBJ-0021		Internal plum blossom countersunk head bolt	6
5	99203-QCBJ-0021		GBT6187 hexagonal flange locking nut	6
6	41300-LX22-0131	41300-LX22-0131	sprocket	1
7	40400-LX22-0041	40400-LX22-0041	rear tire	1
8	40900-LX22-0142	40900-LX22-0142	rear wheel rim assy	1
9	40300-LX22-0041	40300-LX22-0041	rear inner tire	1
10	/		Padding strap.	1
11	40600-LX22-0011	40600-LX22-0011	rear tire clamp	1
12	91072-LX25-0011	91072-LX25-0011	right bush, rear wheel	1
13	41601-LX22-0051	41601-LX22-0051	rear brake disc	1
14	99410-QCBJ-0011		internal plum blossom flat round head bolt	6
15	50503-LX22-0041	50503-LX22-0041	chain adjuster	1
16	91031-LX22-0011	91031-LX22-0011	nut, rear wheel axle	1

前后轮毂总成



No.	U8 Code	ERP(BOM)	EN name	Qty
1	40904-LX22-0023		rear hub assy	1
1-1	40906-LX22-0021		Rear wheel hub bearing.	3
1-2	94010-LX22-0061		#ERROR!	2
1-3	/		Rear wheel hub separator.	1
2	40804-LX22-0023		front hub assy	1
2-1	/		front wheel hub separator.	1
2-2	40806-LX22-0031		bearing	2
2-3	94010-LX22-0051		#ERROR!	2


车架总成



No.	U8 Code	ERP(BOM)	EN name	Qty
1	99201-QCBJ-0021		GBT6170 hex nut	2
2	99104-QCBJ-0071		GBT70.1 hexagon socket cylindrical head	2
3	93006-LX22-0031	93006-LX22-0031	cable fixing clip	2
4	50105-LX25-0061	50105-LX25-0061	main frame	1
5	99408-QCBJ-0171		GBT5789 hexagonal flange bolt (large plate	4
6	50104-LX22-0091	50104-LX22-0091	upper right suspension plate,engine	1
7	99408-QCBJ-0381		GBT5789 hexagonal flange bolt (large plate	2
8	41900-LX22-0031	41900-LX22-0031	rear brake padel	1
8-1	99109-QCBJ-0011		Hexagonal half-round head.	2
8-2	41902-LX22-0011	41902-LX22-0011	triangular plate, rear brake padel	1
8-3	/		Rear brake pedal main body.	1
8-4	95040-LX22-0011		deep groove ball bearing	2
9	99104-QCBJ-0161		GBT70.1 hexagon socket cylindrical head	1
10	99201-QCBJ-0021		GBT6170 hex nut	1
11	99101-QCBJ-0031		GBT5783 hexagonal head bolt	1
12	99408-QCBJ-0181		GBT5789 hexagonal flange bolt (large plate	2
13	99203-QCBJ-0021		GBT6187 hexagonal flange locking nut	2
14	99412-MX22-0011		internal hexagonal step bolt	2
15	50106-LX25-0011	50106-LX25-0011	rear frame	1
16	99302-QCBJ-0011		GBT96 large washer	3

17	99108-QCBJ-0031		Internal hexagonal large flat head bolt	2
18	51100-LX24-0011	51100-LX24-0011	front right footrest	1
18-1	/		Main body of the front right footrest.	1
18-2	51102-LX22-0011		spring, front right footrest	1
18-3	51003-LX22-0011		front footrest pin	2
18-4	99401-QCBJ-0013		GBT91 split pin	2
19	42000-LX24-0031	42000-LX24-0031	return spring, rear brake	1
20	99203-QCBJ-0031		GBT6187 hexagonal flange locking nut	3
21	99408-QCBJ-0191		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	1
22	92005-LX22-0011	92005-LX22-0011	chain lower protector	1
23	51601-LX22-0011		Side support spring.	1
24	99108-QCBJ-0011		Internal hexagonal large flat head bolt	1
25	92009-LX22-0011	92009-LX22-0011	fuel tank shock pad	1
26	99408-QCBJ-0371		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	2
27	50103-LX25-0021	50103-LX25-0021	upper suspension plate, engine	1
28	51000-LX24-0011	51000-LX24-0011	front left footrest	1
28-1	51002-LX22-0011		spring, front left footrest	1
28-2	/		Main body of the front left footrest.	1
29	99002-LX22-0011		side stand spring hanger	1
30	99107-QCBJ-0051		Internal plum blossom countersunk head bolt	1
31	91110-LX24-0011	91110-LX22-0011	step bush	1
32	51600-LX24-0021	51605-LX25-0011	side stand	1


平叉总成



No.	U8 Code	ERP(BOM)	EN name	Qty
1	99408-QCBJ-0361		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	1
2	50900-LX22-0091	50900-LX22-0091	rear shock absorber	1
3	99203-QCBJ-0041		GBT6187 hexagonal flange locking nut	3
4	94010-LX22-0021	94010-LX22-0011	oil seal	4
5	95030-LX22-0011	95030-LX22-0011	rolling needle bearing	6
6	91080-LX22-0041	91080-LX22-0041	bush	1
7	91040-LX22-0021	91040-LX22-0021	flange head axle	1
8	51400-LX22-0021	51400-LX22-0021	Linkage Arm Assy, U-shaped	1
9	91050-LX22-0021	91050-LX22-0021	T-shaped flat head bolt	1
10	91040-LX22-0071	91040-LX22-0021	flange head axle	1
11	91120-LX22-0011	91120-LX22-0011	butterfly shaped bush	4
12	94010-LX22-0011	94010-LX22-0011	oil seal	4
13	91080-LX22-0111	91080-LX22-0031	bush	1
14	91050-LX22-0051	91050-LX22-0021	T-shaped flat head bolt	1
15	95030-MX24-0011	95030-LX22-0011	rolling needle bearing	1
16	91020-LX22-0011	91020-LX22-0011	fork axle	1
17	94010-LX22-0041	94010-LX22-0011	oil seal	2
18	91130-LX22-0101	91130-LX22-0101	T bushing	1
19	95050-LX22-0011	95050-LX22-0011	pulling ball bearing	2
20	95030-LX22-0021	95030-LX22-0011	rolling needle bearing	2

21	94010-LX22-0031	94010-LX22-0011	oil seal	2
22	91080-LX22-0031	91080-LX22-0031	bush	2
23	99108-QCBJ-0021		Internal hexagonal large flat head bolt	2
24	93004-LX22-0021	93004-LX22-0021	oil pipe clip, rear disc brake	2
25	99202-QCBJ-0061		GBT6177 hexagonal flange nut	2
26	99101-QCBJ-0051		GBT5783 Hexagonal Head Bolt (Hexagonal Side Dimensions: 10)	2
27	51500-LX22-0041	51500-LX22-0041	Triangle Linkage arm	1
28	20100-LX22-0061	20100-LX22-0061	chain	1
28-1	/		Chain body.	1
28-2	/		Chain joint.	1
28-3	/		Connecting link plate.	1
28-4	/		Connecting clip.	1
29	99108-QCBJ-0031		Internal hexagonal large flat head bolt	4
30	99304-QCBJ-0041		non standard flat pad	4
31	99203-QCBJ-0031		GBT6187 hexagonal flange locking nut	1
32	99202-QCBJ-0041		GBT6177 hexagonal flange nut	1
33	99203-QCBJ-0061		GBT6187 hexagonal flange locking nut	1
34	91130-LX22-0101	91130-LX22-0101	T bushing	1
35	92004-LX22-0022	92004-LX22-0022	chain protector	1
36	50500-LX22-0071	50500-LX22-0091	Rear swing arm assy	1
37	99203-QCBJ-0011		GBT6187 hexagonal flange locking nut	2
38	99409-QCBJ-0051		GBT5789 hexagonal flange bolt (large plate)	2
39	50600-LX22-0021	50600-LX22-0021	chain guide	1
40	99409-QCBJ-0011		GBT5789 hexagonal flange bolt (large plate)	1


发动机总成



No.	U8 Code	ERP(BOM)	EN name	Qty
1	10802-LX25-0041	10802-LX25-0041	Exhaust pipe	1
1-1	/	10802-LX25-0041	Exhaust pipe	1
1-2	/		Exhaust port spring.	2
1-3	/		Muffler only	1
2	99408-QCBJ-0181		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	1
3	10801-LX25-0011	10801-LX25-0011	rear segment, muffler	1
4	91100-MX22-0011	91100-LX22-0011	flanging bush	2
5	99103-QCBJ-0241		GBT5787 hexagonal flange bolt (small plate internal plum blossom)	2
6	99202-QCBJ-0031		GBT6177 hexagonal flange nut	2
7	10100-LX22-0223	10100-LX22-0234	engine	1
7-1	/		Exhaust port sealing gasket.	1
7-2	/	10100-LX22-0234	engine	1
8	10400-LX24-0011	10400-LX24-0011	gearshift rod	1
9	10200-LX24-0011	10200-LX24-0011	left rear cover	1
9-1	/		Left rear cover mounting bolt.	2
9-2	/	10200-LX24-0011	Left rear cover main body.	1
10	10300-LX24-0041	10300-LX24-0041	intake pipe	1
10-1	/		Connecting strap for the intake pipe to the engine.	1
10-2	/	10300-LX24-0041	Intake pipe main body.	1

10-3	/		Connecting clamp for the intake pipe and throttle valve.	1
11	11208-LX22-0061	11208-LX22-0061	EFI fuel pipe	1
12	11205-LX24-0011	11205-LX24-0011	throttle body assy	1
13	10700-LX22-0111	10700-LX22-0111	air filter	1
13-1	/		Air filter coupling clamp to throttle valve.	1
13-2	/	10700-LX22-0111	Air filter housing.	1
14	10701-LX22-0021	10701-LX22-0021	filter element	1
15	10702-LX22-0011	10702-LX22-0011	dust bag	1


覆盖件



No.	U8 Code	ERP(BOM)	EN name	Qty
1	81020-LX25-0011	81020-LX25-0011	front fender	1
2	99408-QCBJ-0231		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	4
3	81010-LX22-0013	81010-LX22-0013	Front air deflector, number plate	1
4	81040-LX25-0011	81040-LX25-0011	front right cover	1
5	99203-QCBJ-0021		GBT6187 hexagonal flange locking nut	2
6	84090-LX25-0011	84090-LX25-0011	frame right decorative cover	1
7	99108-QCBJ-0011		Internal hexagonal large flat head bolt	6
8	91110-LX22-0011	91110-LX22-0011	step bush	2
9	99412-MX22-0011		internal hexagonal step bolt	2
10	81080-LX25-0012	81080-LX25-0012	Right vehicle body.	1

11	99112-QCBJ-0031		GBT845 cross groove large pan head self tapping screw	2
12	84050-LX25-0011	84050-LX25-0011	air filter rear cover	1
13	92013-LX22-0011	92013-LX22-0011	Metal washers.	2
14	99112-QCBJ-0071		GBT845 cross groove large pan head self tapping screw	2
15	84030-LX25-0011	84030-LX25-0011	rear shock fender	1
16	99408-QCBJ-0231		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	2
17	99302-QCBJ-0011		GBT96 large washer	2
18	99108-QCBJ-0041		Internal hexagonal large flat head bolt	2
19	81090-LX25-0012	81090-LX25-0012	tail fender	1
20	84060-LX25-0011	84060-LX25-0011	Battery box.	1
21	99108-QCBJ-0021		Internal hexagonal large flat head bolt	1
22	99112-QCBJ-0041		GBT845 cross groove large pan head self tapping screw	2
23	99202-QCBJ-0021		GBT6177 hexagonal flange nut	1
24	99106-QCBJ-0021		GBT819 cruciform countersunk screw.	1
25	84040-LX25-0011	84040-LX25-0011	air filter front cover	1
26	93007-LX22-0011	93007-LX22-0011	side cover rubber plug	5
27	93002-LX22-0011		clip, air filter	1
28	81030-LX25-0011	81030-LX25-0011	front left cover	1
29	81050-LX25-0012	81050-LX25-0012	left side cover	1
30	84080-LX22-0011	84080-LX22-0011	frame left decorative cover	1
31	81070-LX25-0012	81070-LX25-0012	Left vehicle body.	1
32	92018-LX22-0011	92018-LX22-0011	pulling belt, side stand	1


油箱、座垫



No.	U8 Code	ERP(BOM)	EN name	Qty
-----	---------	----------	---------	-----

1	80100-LX25-0031	80100-LX25-0012	fuel tank assy	1
1-1	80101-LX22-0011		fuel tank cap	1
1-2	/		Fuel tank assembly main body.	1
2	99005-LX22-0011		Special bolts for fuel tank guard panels.	2
3	99408-QCBJ-0241		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	1
4	99304-QCBJ-0011		non standard flat pad	1
5	99108-QCBJ-0011		Internal hexagonal large flat head bolt	2
6	91100-LX22-0011	91100-LX22-0011	flanging bush	2
7	99419-QCBJ-0021		Seat cushion mounting bolts.	1
8	70103-LX25-0011	70103-LX25-0011	Seat cushion press block.	1
9	70100-LX25-0031	70100-LX25-0031	seat	1
10	92017-LX22-0021	92017-LX22-0021	oil pump washer	1
11	99111-QCBJ-0021		cross shaped gasket screw	4
12	11203-LX22-0011	11203-LX22-0021	fuel pump	1


水冷器



No.	U8 Code	ERP(BOM)	EN name	Qty
1	99103-QCBJ-0021		#ERROR!	4
2	84100-LX22-0011	84100-LX22-0011	#ERROR!	1
3	10906-LX22-0011	10906-LX22-0011	#ERROR!	1
4	10905-LX25-0061	10905-LX25-0061	#ERROR!	1
4-1	/		#ERROR!	1
4-2	/	10905-LX25-0061	Right water cooler main body.	1
5	99103-QCBJ-0051		#ERROR!	4
6	91100-LX22-0021	91100-LX22-0011	#ERROR!	4
7	84110-LX22-0011	84110-LX22-0011	#ERROR!	1
8	10903-LX22-0011	10903-LX22-0011	#ERROR!	1
8-1	/		Water-cooling pipe clamp.	6

8-2	/		Water cooling tube 3 main body.	1
9	10904-LX22-0021	10904-LX22-0021	#ERROR!	1
10	10901-LX22-0111	10901-LX22-0111	#ERROR!	1
10-2	/		Water cooling tube 1 main body.	1
11	10902-LX24-0011	10902-LX24-0011	#ERROR!	1
11-2	/		Water cooling tube 2 main body.	1
12	10907-LX22-0011	10907-LX22-0011	#ERROR!	1

电器件



No.	U8 Code	ERP(BOM)	EN name	Qty
1	32600-LX22-0011	32600-LX22-0011	hour meter	1
2	30400-LX24-0041	30400-LX24-0041	ignition coil	1
3	99408-QCBJ-0231		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	2
4	99202-QCBJ-0021		GBT6177 hexagonal flange nut	4
5	30300-LX22-0061	30300-LX22-0061	regulator	1
6	30700-LX25-0051	30700-LX25-0051	main cable	1
7	11201-LX24-0011	11201-LX24-0011	ECU	1
8	99101-QCBJ-0091		GBT5783 hexagonal head bolt	2
9	30100-LX24-0011	30100-LX22-0031	battery	1
10	99408-QCBJ-0231		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	1
11	87110-LX25-0011	87110-LX25-0011	battery bracket	1
12	32001-LX25-0011	32001-LX25-0011	ignition lock	1
13	99408-QCBJ-0221		GBT5789 hexagonal flange bolt (large plate internal plum blossom)	2
14	87010-LX25-0021	87010-LX25-0021	upper bracket, air deflector	1
15	30200-LX22-0011	30200-LX22-0011	relay	1
16	99106-QCBJ-0061		GBT819 cruciform countersunk screw.	2