



Oil level verification for a 75 drive head.

1. Remove plug in 75 cover.
2. Use a piece of wire, with the drive in the vertical position, as a dip stick. Measure the distance from the plug surface to the oil. Proper oil volume measures between 2 and 2 3/8 inches.