

QUICK REFERENCE GUIDE for Common Wear Parts



VT651/VT801 Series
Vacuum Sweeper




Table of Contents

Mesh Screens & Doors	3
Intake Components	4
Seal-Suction System	5
Water Components	6
Hooper Door Seals	7
Gutter Broom Brush	8
Suction Nozzle Rubber Curtains	9
Suction Nozzle Trunking Assembly	10
Suction Nozzle Wheel	11
Cowl & Radiator Seals	12
Cowl Seals & Soundproofing	13
John Deere Engine Filters	14
Air Cleaner	15
Channel Brush Curtains	16
Wide Sweep Brush Assembly	17
Powaboom Assembly	18
Hydraulic Tank Filters	19
Water Filter Assembly	20




Mesh Screens & Doors





Intake Components




Common Wear Parts - Revised 08/17/2016

Duct Standard




Seal-Suction System






Water Components






Hooper Door Seals



7005517 Door Seal (Re-circulation Port)




Gutter Broom Brush






Suction Nozzle Rubber Curtains



Complete Nozzle Rubber Kit – 4PC 282538-1




Suction Nozzle Trunking Assembly






Suction Nozzle Wheel



Complete Nozzle Wheel Assembly 63491-1




Cowl & Radiator Seals






Cowl Seals & Soundproofing







John Deere Engine Filters






Air Cleaner








Channel Brush Curtains






Wide Sweep Brush Assembly






Powaboom Assembly (Option)






Hydraulic Tank Filters





Water Filter Assembly





VT651/801 OPTIMAL PERFORMANCE SERVICE SCHEDULE

Part Number	Description	U.O.M		SERVICE HOURS		
			Location of Part	EVERY 50 HOURS	600 HOURS	1200 HOURS
217-47	Seal - Access Door	EA	Body		X	X
7012780	Rear door seal	EA	Body			X
7005517	Rear door re-circ seal (Short)	EA	Body			X
7003891	Seal - Rubber Nozzle to Body	EA	Body		X	×
7015594	Wear Plate	EA	Body		X	X
282577-1	Intake Flap	EA	Body			X
40516-1-B	Clip - Flap	EA	Body			X
281217-1	Door Seal	EA	Body			×
7010257	Cowl Seal	EA	Cowling			×
7010258	Cowl Seal	EA	Cowling			X
7010373	Radiator Seal	EA	Cowling			X
7010371	Radiator Seal	EA	Cowling			X
7019998	Retaining Strip top	EA	Cowling			X
7020009	Retaining Strip Rear	EA	Cowling			×
7024867	Cowl Seal	EA	Cowling			×
348-22	Filter - Oil	EA	Engine	X	X	×
348-39	Filter - Fuel	EA	Engine	X	X	X
348-40	Water sediment filter	EA	Engine	X	X	x
348-41	Fan Belt	EA	Engine		X	
7005390	Filter - Hydraulic Suction	EA	Engine		X	×
295095-2	Filter - Main Air	EA	Engine	X	X	x
295095-3	Filter - Safety Air	EA	Engine	x	x	x
7025972	Filter - Hydraulic Return	EA	Engine		X	×
7033091-SP	Impeller kit 800 dia.	EA	Engine		- "	X*
7003618	Seal fancase duct	EA	Engine		×	Ŷ
7002395	Seal cowl/fancase	EA	Engine		x	Ÿ
7039700	Tyre - Nozzle	EA	Sweepgear		X	x
33491-1	Nozzie wheel assembly	EA	Sweepgear		_ ^	Ÿ
282538-1	Rubber - Nozzle Set Std	EA	Sweepgear		×	- X
200055-1	Curtain - Rubber W.S.B.	EA	Sweepgear		x	x
7018771	Curtain W.S.B.	EA	Sweepgear		^	x
33334-1	Curtain - Rubber Nozzle	EA	Sweepgear		×	Ÿ
37368-1	Curtain - Rubber Mudflap	EA	Sweepgear		x	ŵ
504-54	Clip - Hose (Nozzle Trunking)	EA	Sweepgear		x	- 0
94992-2	Trunking - 8 Inch Dia	EA	Sweepgear		x	ŷ
835-60	Channel Brush 4 Row 650mm dia.Steel	EA	Sweepgear	×	x	ŵ
295050-406	Main Broom	EA	Sweepgear	x	x	Ŷ
72-39	Air bowl filter	EA	Systems Locker		x	x
15916-1-B	Trunking 200mm dia.	EA	Wanderhose		x	Ÿ
15917-1-B	Trunking extension 200mm dia.	EA	Wanderhose		x	Ŷ
504-52	Hose Clip for 200mm dia	EA	Wanderhose		x	- x
21-78	Tip fan yellow	EA	Water System	×	x	- û
21-67	Double Swivel Holder	EA	Water System	^	_ ^	÷
277-247	Rear Filter - Water	EA	Water System	X	X	- x
3974-1-C	Filter - Water Tank	EA			x	- 0
7019000	Nozzle Holder Assembly W.S.B.	EA	Water System		x	- 0
7021284		EA	Water System		X	
7021284	Water valve (without coil) Water valve coil	EA	Water System Water System			- :



PARTS DEPARTMENT

Kevin Stutts, Parts Manager P: 704.658.1333 ext. 106 -or- Option #4 Johnstonnorthamerica.com

•				 	
Y	$\boldsymbol{\alpha}$	r ı	oca	D2	ıΔr•

"ing	pe:	CE GH	na ne	DE 3	се я	nec	essa



Contact us:

Johnston North America

Parts Department 105 Motorsports Road Mooresville, NC 28115

Website: http://johnstonnorthamerica.com

Kevin Stutts, Parts Manager

Phone: 704.658.1333 ext. 106

Kevin.stutts@johnstonnorthamerica.com

-or- Option #4

When contacting us:

 Always provide the EQ number of the machine when calling in or emailing an inquiry.

Note: The EQ/Serial Number is located on the rear of the truck under the hopper on the cross member.

- When verifying a part number, please present/state the part number you think it is.
- If part number cannot be located in the appropriate parts manual, be very descriptive of the location on the machine and function of the part required. Photos are recommended.
- Shipping Instructions State on your PO whether the parts are to be shipped by air, truck, UPS...etc.

