

PM 1.4



It is mechanically driven by the power take-off of the tractor. The spreader is equipped with solid support legs, which means that it can be left standing with spreading material in the hopper, and, since it is easy to fit on to the tractor, it can quickly be driven to the right place when material is to be spread for the safety of drivers or pedestrians. The PM is simply and robustly constructed with a minimum of mechanical features, so that its maintenance requirements are just as minimal.

Standard features:

- Agitator
- Safety grate
- Standard rubber base
- Spring base and spring base adjustment
- Cardan shaft, 1 3/8" X 6 hub. Length = 310 mm (12")
- Transmission, 540 RPM right
- Delivery roller with 3 mm cams
- Rubber base for fine material

Options:

- Hopper extension - 60 litre (2.0 ft3)
- Hopper extension - 140 litre (5.0 ft3)

Capacity	140 litres	5.0 cubic feet
Total Width	1091 mm	43 inches
Spreading Width	1010 mm	40 inches
Weight	91 kg	201 lbs.
Linear Working Range (Salt) @ typical application rates	8.4 km	5.2 miles