



PLEASE READ THESE INSTRUCTIONS THOROUGHLY BEFORE USING.


Digital Kitchen Scales

Getting started

1. Before first use, remove the insulating pull tab from the battery compartment.
2. Press the  button to power up the scale.
3. After a few seconds  or  will appear depending on the unit of measurement selected.
4. Place the food on the weighing surface area, the weight will then be displayed.



Operation

Changing the weighing units

1. To change the unit of measurement, press the  button on the control panel.
2. The scale will cycle between grams and pounds:ounces with each press of the button.


Operation

Tare function

1. Press  to turn the scale on.
2. Place a container on the weighing surface area, the screen will display the weight of the container.
3. Press  to clear the weight of the container (reset to zero).
The **TARE** indicator will light up on the display.
4. Next, place the food into the container, the screen will then display the weight of food only. Repeat this action to weigh additional foods.
5. When weighing items, keep them as close to the centre of the glass platform as possible, this will enable more accurate readings.

Operation

Manual switch off

- Press and hold the  button until the display clears, the scale is now switched off.

Technical

Specification

- **Batteries:** 1 x CR2032 / 3v
- **Temperature Range:** 0°C to +45°C
- **Product Weight:** 445g
- **Weighing capacity:** 5000g x 1g / 11lb x 0.05oz
- **Unit measurements:** g / lb:oz

Warning

indicators

1. Over-load Indication: When the scale is over-loaded (more than 5kg), the screen will display "O-Ld".
2. Low Power Indication: When the battery power is low the display will show "LO" and will turn off automatically after few seconds.

Warnings

- For accurate results, place the scale on a hard, flat surface.
- Do not drop or strike the scale, otherwise the scale is easy to damage.
- Please use a damp cloth to clean the scale, do not allow water to get inside the scale.
- To ensure the life of the scale, do not submerge the scale under water and keep away from hot conditions.
- Do not use harsh chemicals to clean the scale.
- Please do not jump or stamp on the scale and avoid dropping it.
- Do not overload the scale, otherwise the sensor will be damaged.
- Do not place heavy items on the scale when not in use.
- Do not store the scale in an upright position.
- Due to the continuous improvements, this product is subject to change without notice.
- Not suitable for legal trade.

Battery installation:

1. Remove the battery compartment cover on the underside of the scale.
2. Insert the new battery, ensuring it is aligned to the correct polarity.
3. Replace the battery cover and securely screw back in place.

Battery safety:

- Only use the specified batteries. Do not dispose of batteries in the regular household waste or by fire, as leakage and/or explosion may result in injury.
- Insert the battery following the correct polarity.
- Do not short circuit the battery terminals.
- Upon disposal of the scale, remove the battery and dispose at the appropriate recycling facility.
- To prolong the scale's life, remove exhausted batteries immediately.
- Remove battery if the scale will not be used for a long period of time.
- **Warning!** Batteries should always be kept away from small children.

Key Function

