


PHOENIX MIRAGE EVERMORE



Care & Maintenance

Phoenix Mirage EVERMORE should be cleaned periodically. A regular cleaning program will help to maintain the aesthetics and life of the material.

Remove dust and dirt from EVERMORE With a damp, soft cloth or sponge and a solution of mild soap and/or liquid detergent in water. Rinse or wipe the EVERMORE again thoroughly with lukewarm water and a clean cloth. Always use a soft damp cloth or shammy leather to blot dry the panels, microfiber cloths are not suitable and do not use cleaners based with alcohol. Rubbing with a dry cloth can scratch the material and create a static charge so any cleaning materials must be damp and free from other cleaning products or debris.

DO NOT:

- Use squeegees or scrapers as they may scratch the sheet
- Use scouring compounds or solvents such as: acetone, gasoline, benzene, carbon tetrachloride, or lacquer thinner to clean the sheet.
- Use abrasives or highly alkaline cleaners
- Do not use window or glass cleaner.
- Use a dry cloth or a cloth of synthetic fiber such as rayon or polyester as they may scratch the sheet.

DO:

- Use warm water, mild detergent, and a soft cloth or chamois
- Rinse surface thoroughly after cleaning with lukewarm water
- Blot dry with slightly damp, soft cloth or chamois

IMPORTANT

Information is a guide only and it is recommended that the user evaluate the products under actual end-use conditions.

Storage Instruction

Phoenix Mirage EVERMORE panels are shipped with a protective PE film needs to be removed within (30) days of arrival. DO NOT remove prior to installation. EVERMORE should be stored at room temperature in a dry environment that is not exposed to direct sunlight or heat. Panels should be stored horizontally (flat), as delivered, to prevent warpage. Due to possibilities for expansion and contraction, allow materials to come to room temperature prior to fabrication or installation.