

PATRIOT® VOICEPLUS

Advanced Easy to Use Reading Appliance

User Manual

v1.4

1-800-364-1608



Congratulations on your purchase of the Patriot VOICE PLUS.

Read your mail, newspapers, books, magazines, and much more.

The internal battery provides a good backup for those times when power is not temporarily available. Further is that its easy to place near your comfortable chair or you can move it to the kitchen area or other areas of your home because its lightweight and easy to transport and will work on its battery avoiding the hassle of plugging and unplugging power from your outlet source. Simply disconnect from the rear of the unit and operate on its internal battery.

Please take a moment to acquaint yourself with the various controls on the unit that allow you to set the preference to best meet your needs. Explore by touch and feel the tactile rings surrounding the controls on the canopy front of the unit.

Enclosed in package is the Patriot VOICE PLUS portable reader, the AC adapter, and this User Manual.

We again thank you and are pleased you are empowered with this adaptive device to maintain your quality of life and independence.



Step One - Remove unit from box and set the unit atop a sturdy surface upright with handle on top and the six pack of tactile controls facing the user. We suggest you take a moment to gently feel the entire unit from top handle to the rear of the unit and canvas your hands over the sides, the bottom, and the canopy that houses the six tactile controls. Note that there are three square controls stacked atop three round controls.

Step Two - Connect one end of the supplied USB cable into the supplied AC power adapter. Next, plug the AC power adapter to a standard household 110V outlet, then plug the opposite USB end into the USB outlet located in the rear of the unit.


Step Three - Locate the power button beneath the front control panel it is a textured push button and only button available beneath the front canopy. Press and hold for 3 seconds or until you hear/feel a vibrato sound, then release, the audible sound signifies power has successfully been turned on. There will be silence for about 20 seconds which is then followed up by a music tune and audio announcement "Patriot at your service". At this moment it is ready to operate!

Instruction for Use - Continued

Step Four - Place your document onto the base, aligning the document with the edges of the base. Remove your hands out of the way so there is a clear unobstructed view of the document.

Please Note: Direction of document is irrelevant as the unit can read in a full 360 degree pattern, sideways, upside down and vice versa.

Step Five - The unit will begin reading aloud automatically.



PLEASE NOTE: GENTLE TAP THE BUTTONS

(EXCEPT POWER AND ASK BUTTONS WHICH ARE PRESSED AND HELD)



Step Six - The pause button is the round button located at the center of the bottom row. To the right of the pause button is a round button to advance forward reading and to the left of the pause button is a round button to reverse backward reading.

Instruction for Use - Continued

Step Seven - The buttons along the top are as follows:



Top left Button (Camera Button) - allows you to take a picture of your document to read aloud. This is especially useful when reading a book by allowing you to simply turn the page and then click this button to read the next page.



Top Center Button (Ask Button) - allows you to press and hold so that you can ask informational questions such as talking time, talking date, talking weather. Please note: this feature is optional and requires active WiFi connection for use. It is completely separate from the reader and you may ignore this Ask Button if you have no interest in this feature or have no access to WiFi.



Top Right Button (Settings Button) - allows you to open the Setting Menu. Press the bottom center button (Selection Button) to make changes to Voice, Language, WiFi, Rate, and Volume. The bottom right and left buttons cycle between the options to adjust the settings. For example, select Volume and then press the bottom right button to allow you to change the settings.

Note: When reading is paused, the right arrow will allow you to read word by word forward and the left arrow will read word by word backward.

Long press on Pause/Play button will spell the current word.

Long Press on the top left "Manual Scan" button will read across columns within the document such as a bank statement or spreadsheet.

Long Press the lower left "Left Arrow" button will announce the battery life.

Note: When reading is paused, the right arrow will allow you to read word by word forward and the left arrow will read word by word backward.

Long press on Pause/Play button will spell the current word.

Long Press on the top left "Manual Scan" button will read across columns within the document such as a bank statement or spreadsheet.

Long Press the lower left "Left Arrow" button will announce the battery life.

We offer an optional cap in case you would like to block a specific button from being used.

Patriot VOICE PLUS with Amazon Alexa Connecting to WiFi and Enabling Voice Query

Open the Settings Menu by pressing the upper right square button (Settings Button) and then pressing the lower center round button (Selection Button) until you hear "WiFi".

Then press the lower right button (Right Arrow Button) until you hear the name of the WiFi network that exists in your home. Press the lower center button (Pause/Selection Button) to select the appropriate WiFi and now press the Right Arrow Button to put in each character of the password for your WiFi network. Note that each character must be selected by pressing the Pause/Selection Button before advancing to the next character. Repeat repeat this process until the entire password is entered.

After completing the password entry, you may press the Pause/Selection button to verify that the password is completely accurate and then press the upper right square button (Menu/Settings Button) to activate the connection. Wait until you hear "Connected" to verify that unit is indeed connected to your WiFi. Failure to connect is announced as "Not Connected". Verify that your password is correct and repeat connection to your WiFi and enter your password carefully.

Once connected successfully, you may press the Upper Center Question Button to ask questions to gather information as to time, date, weather, and more. Make sure to hold the button down while asking your question. "Just Press and Ask"

Utterances - What can I ask my Patriot Voice Plus?

What is the weather? What date is it? Who is the 16th President of the United States? Wikipedia green apples. Play my Katie Perry radio station. Read Chapter 3 verse 16 in the Bible App. What is the my news Flash? What is my Sports Briefing? When does the New York Yankees play again? What was the score of the last Orlando Magic game? How tall is Mount Everest? How deep is the Pacific Ocean? Who wrote Harry Potter? What is the capital city of Spain? What is the population of Tampa Florida? Who plays Jon Snow in Game of Thrones? What's the definition of precarious? How do you spell ceiling? What's 5 times 3? **Translate Good Morning to Spanish.**

Additional skills can be enabled simply by asking, Enable [the name of the skill]

For example, when is the high tide, when is the low tide, what is my daily horoscope, what is the price of Apple stock, and so on. These skills are one of over 14,000 ADDITIONAL SKILLS that can be enabled just by asking.

Tying into their ITunes or Spotify or I heart or Pandora account is all possible and can be linked as well.

Each Patriot Voice Plus comes with a unique own account that can be managed by any computer, tablet, smart phone with the free download-able Alexa app. This makes it easier for clients that want to either self manage their app using their other devices or their family and love ones can assist, or they can call us and we would be happy to assist in client specific accounts that might want to be linked.

Patriot VOICE PLUS Specifications

Power: USB 5V 2.0A

Dimension/Weight w/o Packaging : 14"H x 11"W x 9"D, 5 LBS. Dimension/Weight w/Packaging: 14"H x 12"W x 10"D, 6 LBS. Camera: Auto Focus/Constant Scan 16 Mega-pixel Software: Proprietary Interface

Microphone/Voice Services: Alexa Voice Service Body: Specialized Aluminum Powder Coat Silver Painted Warranty: Two Years Standard Parts and Labor Internal Battery: Lithium Ion High Capacity (6 hours) Headphone Jack: 3.5 mm



Patriot Vision Industries, LLC, is an affiliate of Low VisionAids, Inc. Patriot, Magnifying America, the words and their symbols/logo/mark are licensed trademarks owned by Low VisionAids, Inc. Patriot Voice Plus with Amazon Alexa. Alexa, Amazon are trademarks of Amazon.com, Inc. or it's affiliates. Copyright 2018. All Right Reserved. Designed & Assembled in USA.