


HOW TO USE YOUR

ELECTROLUX[®]

CLEANER/MODEL L



**Let's keep
in touch!**

...call or write me, your
friendly Electrolux man, at the
address or phone at right, if
you need any help with your
cleaning problems.

CUSTOMER'S NAME _____ DATE _____

SERIAL NO. _____ ELECTROLUX MAN'S NAME _____

ADDRESS, ELECTROLUX CORPORATION _____ TELEPHONE _____


PATENTS: More than 50 patents assure Electrolux users of exclusive Electrolux time-saving and work-saving advantages.

Guarantee

The Electrolux® Cleaner which you receive herewith has been thoroughly tested at the factory of Electrolux Corporation in Old Greenwich, Connecticut. Electrolux Corporation hereby guarantees for a period of two years from date of purchase from Electrolux that upon return of the Cleaner to an Electrolux office within that period, it will repair or replace, free of cost to you, any part of such Cleaner which our examination shall disclose to be defective in workmanship or material, except that with respect to the hose, the wands, the detachable electric cord (if any), the cleaning tools and other attachments including the rug washer and the power nozzle, such guarantee shall be limited to a period of one year from date of such purchase.

ELECTROLUX CORPORATION

By



Treasurer



Congratulations

...and welcome to the family of happy Electrolux users. You now have in your own home one of America's finest, easiest-to-use home-cleaning and home-care tools: the new Electrolux® Cleaner—Model L. It's ready and eager to go to work for you.

As your friendly Electrolux man, I've already had the privilege of showing you how much easier your Electrolux makes your home-cleaning. Now in this little book, I'm going to answer all the questions you might have about using your Electrolux Cleaner and its work-saving attachments.

Read it over carefully—it will give you many ideas for getting the most out of your new cleaner.

If you ever have any additional questions about your Electrolux Cleaner...or if you want to find out more about one of the other fine Electrolux products for complete home maintenance...be sure to write or call me at your nearest Electrolux branch. I'll be glad to help.

Once again—thank you, and congratulations on joining the millions of satisfied home-makers who clean their homes the "Electrolux Way."

Your friendly Electrolux Man




**ELECTROLUX
CORPORATION**

235 East 42nd Street, New York, N.Y. 10017


Makers of America's most advanced vacuum cleaners since 1924

table of contents

Assembling the cleaner	12
Attachments	6
Bedding	17
Cord Winder	6
Date purchased	2
Filter bags, how to order	23
Floor cleaning	16
Front cover, how to open	9
Furniture cleaning	15
Gleaner* air-flow concentrator	15
Guarantee	2
Miscellaneous cleaning jobs	16, 17
Polisher and Carpet Beautifier	18
Power Nozzle	8, 15
Rug cleaning	14
Rug washing	19
Salesman's name	2
Serial number of cleaner	2
Service, where available	21
Sprayer	20
Upholstery cleaning	17
Vacuum adjuster	16
Vaporizer	20
Wall cleaning	16
Your branch address	2

Home of Electrolux Products,
Old Greenwich, Conn. 





let's get acquainted with your new **ELECTROLUX®**

Automatic Cord Winder is handy optional
attachment for your cleaner

Blower End

Cord Holder

Swivel-connector

Two-section Wand

Hose Handle

Vacuum Adjuster

Multi-purpose floor tool

cleaner and its work-saving attachments

On-off switch

Clip for small tool

Upholstery tool-dusting brush

Button to Open Cover

Front Cover

Suction End

Electric Socket for Power Nozzle


Notice that the Electrolux® hose is tapered—smaller at the handle end, larger at the other end, to prevent clogging.


Depending on the type of cleaning you are going to do, you may attach your cleaning tool directly to the hose handle, or use one or two sections of the light-weight wands between the hose handle and the tool. The swivel-connector is always used with the larger cleaning tool.



Above you see your smaller cleaning tool. When the hinged sides are extended, it is an upholstery cleaner that cleans on flat or curved surfaces. Fold the sides back, reverse the tool and it becomes a dusting brush.

Your larger multi-purpose tool is reversible. Simply attach it to the swivel-connector, always being sure that plate marked "This Side Up" is visible when the cleaner is in use. Use the smooth side of the tool for rugs, and the brush side for floors, walls and ceilings.





THE REVOLUTIONARY NEW POWER NOZZLE

This new and remarkable attachment is available with your Electrolux Cleaner. The Power Nozzle has a rapidly spinning, **motor-driven** brush that quickly cleans your carpets and at the same time gently fluffs the nap of the carpet to keep or restore

its luxurious look. Because the brush is driven by its own separate electric motor, you do not lose any of the powerful suction of your Electrolux Cleaner. A circuit breaker prevents overloading. Push button at rear to re-start.

How to be sure of always getting top cleaning power and efficiency from your Electrolux cleaner

The answer is simple: always use only a genuine Electrolux® automatic self-sealing disposable filter bag. This is the bag that automatically seals in the dirt and dust your Electrolux Cleaner picks up—so that you never touch it, breathe it or see it! On the following two pages you'll see how the exclusive Electrolux filter bag operates to give you longer cleaning power and efficiency.

it's Shine up time

use **Electrolux PRODUCTS**



PATENTED SEAL

IMPORTANT
use
only genuine
Electrolux®
filter bags

USE HANDY ENVELOPE
TO ORDER BAGS

TO GIVE YOUR HOME THAT
POLISHED LOOK

- WOOD FLOOR WAX
- WAX STRIPPER
- TILE FLOOR WAX
- FURNITURE POLISH

**ECONOMICAL,
LONG-LASTING
HOME-TESTED**

ELECTROLUX CORPORATION • 235 E. 42nd St. • New York, N.Y. 10017



How to remove and insert your Electrolux® dust bag.

To remove the bag, stand the cleaner on end, open the front cover by pressing the button at the top and take out the used filter bag.



It is time to change bags either when the bag is full or when the dirt inside reduces the suction. Fine powdery dirt will reduce the suction sooner than loose linty dirt.

Throw the used bag away—never try to use it over again. The bag is automatically sealed with the dirt inside.



Insert the new genuine Electrolux disposable filter bag. Close the front cover, and your cleaner is again ready for use. Your cleaner will operate only when there's a bag inside.


*this is why
the
ELECTROLUX®
automatic
self-sealing
filter bag
keeps on
trapping dirt
long after
other
bags fail*



This is the filter bag that traps all the dirt your Electrolux Cleaner picks up. There's no other bag like it. Why? Looking at it from the outside, you can see **part** of the reason. You can see that when the cleaner opens the Electrolux bag seals itself, locks in all the dirt. But that's not all . . .




It's the **inside** of the bag that counts! An ordinary vacuum cleaner bag consists of just a single thickness of paper or cloth. But if you tore open an Electrolux filter bag, you'd see inside three layers of **filter liner**, each with millions of tiny filters that trap dirt and let air through.



ordinary bag

Take an ordinary dirt bag, cloth or paper. There's only **one** surface to trap the dirt. As the cleaner picks up dirt, the pores of this ordinary bag clog quickly. Suction goes down quickly. You waste time and effort trying to clean with a dust-clogged bag that chokes off the cleaning power.



Electrolux bag

Now look what happens inside the Electrolux filter bag: the layers of filter paper trap the dirt while air keeps on flowing through the bag... the suction keeps on picking up more dirt. When ordinary bags clog up, you can be sure that the Electrolux bag is still working for you.


use only genuine Electrolux[®] filter bags

*They guarantee best
performance in your
Electrolux Cleaner. When
you need more,
use the handy re-order
envelope packed
with the bags or tear off
the order form
inside of the back cover.*

*Mail it with your
check or money order to
one of the regional
offices listed at the top of
the order form.*


**now we're
ready
to
put your
cleaner
to
work
for you!**

Now that we've looked over your cleaner, your attachments and your filter bags, we're ready to let your cleaner do the jobs it was meant for. Here are the easy, step-by-step ways to put your Electrolux Cleaner and its attachments together, so that the powerful cleaning action can go to work!




1 Slip the larger end of the hose into the suction end of the cleaner until it clicks. To remove, press buttons on side and pull out.

5 Pushing the swivel connector onto the wand as far as it will go, locks it into place. Pressure on the spring clip unlocks it.



2 The two sections of your wand fit together. For all cleaning at floor level, insert one section into the other, twist lightly.



6 Your smaller cleaning tool is slipped into place with a twist, either on the hose handle or the wand, whichever is more convenient.






3 Slip the hose handle into one end of the wand. Now you're ready to attach the tool to the other end of the wand.

7 By reversing it, it converts from a dusting brush to an upholstery or fabric cleaner. Adjustable wings add to its versatility.




4 To use the larger cleaning tool, first attach the swivel-connector to the tool. In use, be sure the plate marked "THIS SIDE UP" is visible.

8 The Automatic Cord Winder has window-shade action. Just pull the cord out and plug it into a convenient electric outlet.




How to attach the power nozzle.



Connect the hose to the suction end of the cleaner. Attach the other end to the wand of the Electrolux® Power Nozzle.

The connecting cord for the Power Nozzle is on the hose. Plug cord from Power Nozzle into receptacle at bent end of hose.



Plug hose cord into cleaner receptacle. When you turn on cleaner, Power Nozzle starts. Close flap when receptacle is not in use.



*look how easy
it is to
clean your rugs
and carpets!*

with the larger multi-purpose tool

Just put hose in suction end, wand on hose, and the larger multi-purpose tool on the end of the wand, as shown on page 12. Use the tool with the bristles up, smooth rug-cleaning surface down on the carpet. Let the Electrolux Cleaner do the work. Simply guide the tool back and forth in free and easy strokes until every area has been covered.




If threads or other surface litter are tangled in the nap, a tip of the lever at one end of the tool brings the Gleaner® air-flow concentrator into action. Even dog hairs can be picked up easily. Caution: be sure Gleaner is in OFF position when cleaning looped pile rugs, hooked rugs or rag rugs.

...or with the new Power Nozzle


Attach the Power Nozzle as described on page 13—then let the swift but gentle motor-driven brush action clean and beautify your carpet! The rotating brush helps make the powerful Electrolux suction even more effective. It fluffs the nap. If an obstacle jams the Power Nozzle, turn cleaner off and remove the obstruction. Press the Reset Button of the Safety Switch on nozzle before starting cleaner.

Your Power Nozzle slips easily under low furniture to take care of even those hard-to-reach places. Use it as often as you wish—it “gentles” fine carpeting. The Power Nozzle is available as an optional attachment to your Electrolux Cleaner.




important cleaning **"How-to's"** for all around your home


How to clean FLOORS without spreading dust. Put hose in suction end, wand on hose, and larger multi-purpose tool on wand. Use tool with bristles **down**. Your cleaner will pick up all the scratchy dust and grit...keep your polished floors gleaming longer. Lower wand with a slight twist to clean beneath furniture.




How to take the drudgery out of cleaning STAIRWAYS. Put hose in suction end, use only **one** section of wand. Use larger tool with bristles **up** for carpeted stairways, bristles **down** for uncarpeted stairs. Use brush end of smaller tool for banisters. Move your cleaner right up the stairs with you...cleaning a step or two at a time.



How to clean WALLS to save redecorating bills. Attach large multi-purpose tool same way as for floors...brush walls with bristle side. Dust clings to walls and ceilings, too. But regular cleaning keeps them fresh-looking, saves on repainting and redecorating bills. If lint clings to brush, whisk it clean with suction from the open hose end.




How to get the deep-down dirt out of your UPHOLSTERED FURNITURE. Attach hose to suction end, insert hose handle **through** the brush of the smaller multi-purpose tool. Now extend the hinged sides of the tool. Your cleaner will remove the deep dirt as well as surface dust. Note that the hinged sides of the tool make it a contour cleaner that will clean round and square edges as well as flat surfaces.



How to clean filmy CURTAINS...DRAPES. Use the smaller multi-purpose tool, as shown...or reverse the tool and use the dusting brush.


To tame the powerful suction so that it doesn't "suck in" filmy fabrics, twist the Vacuum Adjuster until the suction is gentle enough.



How to keep BEDDING fresh and airy. Use the smaller multi-purpose tool in the same way as for cleaning upholstered furniture.

Frequent cleaning airs and freshens mattresses, pillows and blankets...removes fine dust seeping from pillows or mattress fillers.

To clean exposed bed-springs, reverse the tool and use the brush.




**More tips on
getting the
most out
of your
Electrolux
Cleaner**




LAMP SHADE




CUFFS



KITCHEN CABINET



FIREPLACE



ASH TRAY



CAR



FUR COAT



TV



HAT



PETS



POCKETS




**Ask to see the new
ELECTROLUX 3 Brush B-8
Floor Polisher and
Carpet Beautifier**

- Brings back Floor and Carpet Beauty
- Banishes Floor Care Drudgery forever
- As a Floor Polisher it cleans and polishes every type floor to gleaming lustre in minutes
- Fingertip control
- Floating brushes adjust to flooring
- Easy to carry — Fold down handle
- Wax Mist Sprayer for easy application of wax
- Its Carpet Beautifier attachment for shampooing restores natural rug beauty — keeps carpets brighter, cleaner longer — quick foaming sudser — quickly covers large areas — quick drying — professional quality cleaning
- Double insulated to conform to the requirements of Underwriters Laboratories, Inc.

***The Air-Powered Single Brush
Rug Washer is an economical
work-saving attachment to
your ELECTROLUX Cleaner
with it you may...***

- shampoo your rugs and carpeting without getting down on hands and knees
- no rinsing or wiping up required
- dispenses the right amount of shampoo
- restores carpet beauty without soaking
- quick, easy, saves rug cleaning bills
- Does an excellent job in just a little more time.





The Electrolux® Vaporizer

for effective, economical moth protection
attaches to blower end of your Electrolux
Cleaner

vaporizes moth crystals to form a gas
that is deadly to moths when the gas is
confined as in a closet.



The Electrolux® Sprayer


sprays insecticide,
garden spray,
moth-proofing liquids

may be used to spray
paint if paint is thinned

a dial on top controls
the amount of spray



Crevice Tool...
puts your Electrolux
Cleaner's suction
to work in
radiators, other
hard-to-reach places.



White Dusting
Brush
...for delicate
lampshades or
other furnishings
that need
special care.



White Wall Brush...ideal for cleaning
all kinds of walls and ceilings, painted
or papered.




MOTH CRYSTALS


ELECTROLUX
Waxes, Polishes, Shampoos,
Household Aids
of top quality
to match
the Electrolux appliances
they're used with




FURNITURE POLISH



NUVO® SHAMPOO



TURBO SHAMPOO



TILE FLOOR WAX



WOOD FLOOR WAX



FLOOR CLEANER
AND WAX STRIPPER

ELECTROLUX®

where quality and service come first!

For parts, supplies and information, call, write or visit the Authorized Electrolux Sales and Service Center nearest you

ALABAMA

Birmingham—1103-05 S. 20th St.
Dothan—230 N. Foster St.
Enterprise—702 S. Main St.
Florence—1625 Darby Drive
Gadsden—217 S. Fifth St.
Huntsville—2105 Whitesburg Drive S.
Mobile—8-10 S. Hamilton St.
Montgomery—1615 S. Decatur St.

ARIZONA

Mesa—9 South Morris St.
Phoenix—446 W. Washington St.
Tucson—5414 East Pima St.

ARKANSAS

El Dorado—115 South Jefferson St.
Fort Smith—1610 Towson Ave.
Jonesboro—716 S. Main St.
Little Rock—5610 West 12th St.

CALIFORNIA

Bakersfield—923 Niles St.
Fresno—3064 East McKinley
Glendale—454 W. Broadway
Huntington Park—7410 State St.
Long Beach—2189 Pacific Ave.
Los Angeles—350 S. LaBrea
—1910 Westwood Blvd.
Oakland—3035 Telegraph Ave.
Palo Alto—4039 El Camino Real
Paramount—16234 Paramount Blvd.
Pasadena—2302 E. Colorado St.
Redding—3038 Bechelli Lane
Sacramento—3016 J St.
San Bernardino—1222 F St.
San Diego—4491 El Cajon Blvd.
San Francisco—1855 Lawton St.
San Jose—980 E. Santa Clara St.
San Leandro—14616 E. 14th St.
Santa Ana—1229 W. 5th St.
Santa Barbara—11 W. de la Guerra
Santa Rosa—1404 Fourth St.
Stockton—1140 W. Fremont
Tulare—1478 East Tulare Ave.
Van Nuys—14420 Friar St.
Vista—649 South Santa Fe
West Covina—226 S. Glendora Ave.

COLORADO

Colorado Springs—732 S. Tejon
Denver—2325 Champa St.

CONNECTICUT

Bridgeport—3610 Main St.
East Hartford—1123 Main St.
Greenwich—415 Greenwich Ave.
Hamden—1384 Dixwell Ave.

Hartford—430 New Park Ave.
Norwich—320 W. Main St.
Stamford—1107 Main St.
Torrington—441 Main St.
Waterbury—1722 E. Main St.

DELAWARE

Claymont—200 Gov. Printz Blvd.
Newark—70 E. Cleveland Ave.

DISTRICT OF COLUMBIA

Washington—1341 4th St., N.E.
—6803 Marlboro Pike, S.E.

FLORIDA

Clearwater—303 N. Ft. Harrison St.
Coral Gables—1616 Ponce de Leon Blvd.
Ft. Lauderdale—2117 S. Andrews Ave.
Gainesville—2224 N.W. Sixth St.
Hollywood—2007 Tyler St.
Jacksonville—5930 Beach Blvd.
Melbourne—411 Strawberry Ave., No. 5,
Brand Arcade
Miami—8200 N.E. 2nd Ave.
—1930 West Flagler St.
North Miami Beach—1947 N.E. 163 St.
Orlando—928-930 North Mills St.
Pensacola—3622 Barrancas Ave.
St. Petersburg—2907 4th St., N.
Sarasota—244 S. Pineapple Ave.
Tallahassee—1324 S. Adams St.
Tampa—114 E. Columbus Dr.
West Palm Beach—2800 S. Dixie Hwy.

GEORGIA

Albany—934 West Broad Ave.
Atlanta—1576 Piedmont Ave. N.E.
—1155 Peachtree St., N.W.
Augusta—416-418 13th St.
Columbus—1001 13th St.
Macon—815 Second St.
Rome—1505 N. Broad St.
Savannah—15 E. Park Ave.
Valdosta—504 E. Ann St.

IDAHO

Boise—918 N. Orchard St.
Idaho Falls—379 "F" Street

ILLINOIS

Belleville—1407 W. Main St.
Bloomington—620 North Main St.
Chicago—2946 Milwaukee Ave.
—5683 N. Lincoln Ave.
—2312 W. 79th St.
—301 West 115th St.
Danville—104 W. Main St.
Decatur—1159 East Cantrell St.

Elgin—1018 N. Liberty St.
Evanston—1800 Central St.
Forest Park—7412 Madison St.
Freeport—521 W. Galena St.
Galesburg—1345 N. Seminary St.
Godfrey—5516 Godfrey Rd.
Harvey—27 West 159th St.
Joliet—456 N. Chicago St.
Kankakee—150 North Schuyler Ave.
La Grange—5410 S. La Grange Rd.
—Countryside
La Salle—948 Third St.
Marion—301 S. Court St.
Moline—1808 7th St.
Olney—327 S. Whittle Ave.
Peoria—711 Main St.
Princeton—909½ Main St.
Quincy—2802 Broadway
Rockford—505 E. State St.
Skokie—4844 Main St.
Springfield—1153 W. Governor St.
Villa Park—126 South Myrtle
Waukegan—232 N. Genesee St.

INDIANA

Anderson—2303 Meridian St.
Angola—303 W. Maumee St.
East Chicago—1916 Broadway
Evansville—1414 N. Main St.
Fort Wayne—3030 Maumee Ave.
Gary—729 E. Ridge Rd.
Goshen—123 E. Lincoln Ave.
Hammond—6131 Calumet Ave.
Indianapolis—6035 E. 34th St.
Lafayette—1001 E. Main St.
South Bend—1913 S. Michigan St.
Terre Haute—1700 8th St.

IOWA

Cedar Rapids—188 Jacolyn Dr., N.W.
Davenport—1914 Brady St.
Des Moines—547 28th St.
Dubuque—1732 Central Ave.
Ft. Dodge—301 S. 21st St.
Ottumwa—411 Church St.
Sioux City—611 Pearl St.
Waterloo—2831 Falls Ave.
West Des Moines—920 Grand Ave.

KANSAS

Mission—5631 Johnson Drive
Topeka—525 Topeka Blvd.
Wichita—1028 S. Broadway

KENTUCKY

Bowling Green—101 Laurel Ave.
Danville—307 Stanford Ave.
Frankfort—321 Ann St.

Lexington—2220 Idle Hour
Shopping Ctr., Richmond Rd.
Louisville—Colony Way,
3929 Shelbyville Rd.
Paducah—111 S. 6th St.
Richmond—615 East Main St.

LOUISIANA

Baton Rouge—1804 North Blvd.
Monroe—1023 N. Sixth St.
New Orleans—1935 Tulane Ave.
Shreveport—1704 Fairfield Ave.

MAINE

Augusta—157 Water St.
Brewer—391 Wilson St.
Portland—30-A Preble St.

MARYLAND

Annapolis—233 West St.
Baltimore—4905 Frankford Ave.
—102 E. 25th St.
Frederick—611 N. Market St.
Glen Burnie—313 Crain Hwy., S.E.
Hagerstown—479 N. Potomac St.
Rockville—1081 Rockville Pike
Salisbury—1525 Edgemore Ave.
Wheaton—11300 Viers Mill Rd.

MASSACHUSETTS

Boston—84 Brookline Ave.
Brockton—98 Crescent St.
Burlington—288 Cambridge St.
Cambridge—25 Belmont St.
Collingswood—556 Haddon Ave.
Fitchburg—72 Franklin Rd.
Framingham—405 Worcester Rd.
Greenfield—37 Federal St.
Lawrence—194 Broadway
Lynn—36 Union St.
New Bedford—1549 Acushnet Ave.
Pittsfield—23 Bradford St.
Plymouth—317 Court St.
Quincy—35 Cottage Ave.
Roslindale—336 Belgrade Ave.
Springfield—605 State St.
Worcester—120 June St.

MICHIGAN

Ann Arbor—526 Second St.
Dearborn—23914 Cherry Hill Rd.
Detroit—15251 W. McNichols Rd.
Flint—1718 Dupont
Grand Rapids—1322 Edna St., S.E.
Kalamazoo—1319 Portage St.
Lansing—515 E. Michigan Ave.
Pontiac—2397 Elizabeth Lake Rd.
St. Joseph—2948 Niles Ave.

MINNESOTA

Austin—226 2nd Ave., N.E.
Bloomington—9901 Lyndale Ave. S.
Duluth—1920 W. Superior St.
Fergus Falls—414 Stanton Ave.
Hibbing—606 E. Howard St.
Mankato—129 E. Main St.
Minneapolis—1612 Harmon Pl.
Rochester—410 Third Ave., S.E.
St. Cloud—No. 6 19½ Ave. S.
St. Paul—492 Rice St.

MISSISSIPPI

Greenville—Abraham Shopping
Center Bldg. 1449
Gulfport—1522 Pass Road
Jackson—509 S. State St.
Tupelo—1127 West Main
Southaven—6087 Millbranch Rd.

MISSOURI

Cape Girardeau—104 S. Sprigg St.
Columbia—200 Business Rt. #63,
Eastgate Plaza
Kansas City—1534 Walnut St.
Shrewsbury—7500 Devonshire
St. Joseph—306 S. Belt Highway
Springfield—1924 S. Glenstone
University City—7811 Olive Blvd.

MONTANA

Billings—1604 Grand Ave., Suite 3
Great Falls—2305 Tenth Ave., S.

NEBRASKA

Grand Island—2308 South Locust
Norfolk—408 Madison Ave.
North Platte—219 So. Jeffers
Omaha—4622 South 24th St.

NEVADA

Las Vegas—1208 E. Stewart
Reno—618 S. Center St.

NEW HAMPSHIRE

Claremont—154 Pleasant St.
Manchester—1351 Elm St.
Rochester—12 Portland St.

NEW JERSEY

Bloomfield—23½ Belleville Ave.
Burlington—Route 130
Chester—Route 24 and Oakdale Rd.
Clifton—319 Lakeview Ave.
East Brunswick—293 Highway 18
East Orange—12 Halsted St.
Elizabeth—1179 E. Grand St.
Englewood—38 W. Palisades Ave.
Fair Lawn—24-19-21 Fair Lawn Ave.

Jersey City—580 Newark Ave.
Little Silver—508 Prospect Ave.
Plainfield—1609 Park Ave.
Ramsey—4 E. Main St.
Trenton—1609 N. Olden Ave. Ext.
Vineland—153 S. Delsea Dr.

NEW MEXICO

Albuquerque—1309 San Mateo, N.E.
Roswell—113 East 7th St.

NEW YORK

Albany—518 Clinton Ave.
Binghamton—157 Main St.
Buffalo—769 Main St.
—914 Broadway
Elmira—200 Pennsylvania Ave.
Fulton—111 W. Broadway St.
Glens Falls—55 Warren St.
Hastings-on-Hudson—603 Warburton Ave.
High Point—1228 Montlieu Ave.
Jamestown—112 E. Second St.
Kingston—524 Broadway
Mt. Vernon—130 Gramatan Ave.
Newburgh—5-11 Washington Terrace
New Rochelle—667 Main St.

New York City

Manhattan—1834 Second Ave.
—4863 Broadway
—80 Fifth Ave.
—155 W. 72nd St.
Bronx—2337 Grand Concourse
—128 W. Fordham Rd.
Brooklyn—457 Dean St.
—6717 Fifth Ave.
—6805 Bay Parkway
—1257 Flatbush Ave.
Staten Island—1806 Hylan Blvd.
Queens—
Bayside—47-16 Bell Blvd.
Elmhurst—76-15 Broadway
Flushing—164-01 Northern Blvd.
Forest Hills—104-12 Metropolitan Ave.
Glendale—6504 Myrtle Ave.
Jackson Heights—8411 Northern Blvd.
Long Island City—25-49 Steinway St.
Queens Village—211-17 Jamaica Ave.

Long Island

Bayshore—133 Fourth Ave.
Floral Park—149 Tulip Ave.
Glen Cove—260 Glen St.
Hempstead—26 North Franklin St.

Hicksville—67 Broadway
Huntington—217 New York Ave.
Long Beach—123 W. Park Ave.
Patchogue—453-455 E. Main St.
Port Jefferson—1051 Main St.
Roslyn—1051 Northern Blvd.,
Flower Hill
Smithtown—400 W. Main St.
Valley Stream—32 W. Merrick Rd.
Wantagh—3249 Sunrise Hwy.
Peekskill—1709-1711 Main St.
Poughkeepsie—641 Main St.
Riverdale—5902-A Riverdale Ave.
Rochester—176 Garson Ave.
—201 W. Main St.
Schenectady—726 State St.
Syracuse—815 N. Salina St.
Troy—3 Franklin Square
Utica—218 Columbia St.
Watertown—285 State St.
White Plains—456
—Mamaroneck Ave.
Yonkers—929 Yonkers Ave.

NORTH CAROLINA

Asheville—635 Merrimon Ave.
Charlotte—1534 West Boulevard
Durham—224 Morgan St.
Fayetteville—537 Hillsboro St.
Gastonia—341 E. Franklin Ave.
Greensboro—712 W. Market St.
Hickory—1835 12th Ave., N.E.
New Bern—1214 Fulcher's Lane
Raleigh—2007 Fairview Rd.
Rocky Mount—723 Walnut St.
Williamston—205 Washington St.
Winston-Salem—1176 W. Fourth St.

NORTH DAKOTA

Bismarck—716 E. Broadway
Fargo—303 Roberts St.

OHIO

Akron—899 N. Howard St.
Canton—4229 Fourth St., N.W.
Cincinnati—22 W. Ninth St.
Cleveland—2419 St. Clair Ave.
—4466 State Rd.
Columbus—3345-49 So. Blvd.
Dayton—257 Wayne Ave.
Lima—641 N. Main St.

Norwood—2401 Robertson Ave.
Portsmouth—4019 Gallia St.
Toledo—3932 Secor Road
Youngstown—2920 Market St.
Zanesville—706 Putnam Ave.

OKLAHOMA

Bartlesville—221 Commanche St.
Enid—316 S. Van Buren
Lawton—1629 Cache Road
Oklahoma City—815 S.W. 29th St.
Tulsa—1506 S. Utica

OREGON

Eugene—628 Blair Blvd.
Portland—1515 N.E. Broadway
Salem—1079 Broadway

PENNSYLVANIA

Allentown—1407 Cedar Crest Blvd.
Altoona—719 Seventh St.
Bellefonte—109 West Bishop St.
Carlisle—141 No. Hanover St.
Chambersburg—229 N. Second St.
Du Bois—115 N. Stockdale St.
Easton—916 Northampton St.
Erie—30 W. 12th St.
Glenside—325 North Easton Rd.
Hanover—43 E. Walnut St.
Harrisburg—316 Emerald St.
Johnstown—721 Bedford St.
Kingston—223 Wyoming
Lancaster—146 College Ave.
Lebanon—543 Lehman St.
Lewistown—37 Valley St.
New Castle—117 N. Mercer St.
Philadelphia—6326 Rising Sun Ave.
—1802 Shunk St.
Pittsburgh—3100 Banksville Rd.
Pottsville—344 S. Center St.
Reading—209 N. Fifth St.
Scranton—719-723
—W. Lackawanna Ave.
Upper Darby—8102 West Chester Pike
West Chester—134 East Gay St.
Williamsport—521 Market St.
York—348 W. Market St.

RHODE ISLAND

East Providence—509-511
—Waterman Ave.
Warwick—203 Buttonwoods Ave.
Woonsocket—85 B Front St.

SOUTH CAROLINA

Anderson—921 South Main St.
Charleston—195½ King St.
Columbia—701 Saluda Ave.
Florence—376 W. Evans St.
Greenville—916 Pendleton St.
Spartanburg—938 E. Main St.

SOUTH DAKOTA

Aberdeen—308 Sixth Ave., S.W.
Rapid City—524 Fifth St.
Sioux Falls—2113 S. Minnesota

TENNESSEE

Chattanooga—3910-C
—Tennessee Ave.
Columbia—1300 Hatcher Lane
—At Alpin
Cookeville—205 Reagan
Jackson—540 North Hays Ave.
Knoxville—5307 Clinton Highway
Memphis—116 N. Cleveland St.
Murfreesboro—109 E. Lytle St.
Nashville—2518 Nolensville Rd.

TEXAS

Abilene—640 Butternut St.
Amarillo—1001 W. 8th St.
Austin—1413 S. Congress Ave.
Beaumont—2010 Park St.
Corpus Christi—3925 Ayers St.
Dallas—4220 Live Oak St.
El Paso—2121 N. Piedras St.
Ft. Worth—3801 B Southwest Blvd.
Houston—2007 Broadway
—2138 Portsmouth St.
Longview—701-B E. Methvin St.
Lubbock—2412 Broadway
Lufkin—428 Atkinson Drive
Odessa—1025 N. Whitaker
San Antonio—926 Brooklyn Ave.
Waco—1817 Franklin Ave., Box 642
Wichita Falls—1005½ Baylor St.

UTAH

Salt Lake City—71 W. Broadway
Ogden—320 Washington Blvd.

VERMONT

Burlington—157 Cherry St.

VIRGINIA

Alexandria—2600 Commonwealth Ave.
Arlington—2757 N. Washington Blvd.
Charlottesville—738 S. 1st St.
Danville—2046 N. Main St.
Fairfax—11108 Lee Hwy.
Fredericksburg—531 Caroline St.
Galax—518 South Main St.
Hampton—821 N. King St.
Lynchburg—1210 12th St.
Martinsville—324 Memorial Blvd.
Newport News—10371 Warwick Blvd.
Norfolk—6225 Chesapeake Blvd.
Petersburg—1236 W. Washington St.
Portsmouth—3621 Turnpike Rd.
Richmond—6103 W. Broad St.
Roanoke—4135 Salem Turnpike
—2102 Williamson Rd., N.E.
Staunton—804 Spring Hill Road
Virginia Beach—1709 Virginia Beach Blvd.
Wise—116 Main St.

WASHINGTON

Seattle—4231 Stone Way, N.
Spokane—N. 1108 Washington St.
Tacoma—3015-3017 Sixth Ave.
Walla Walla—1128 Plaza Ct.,
—Plaza Shopping Ctr.
Yakima—406 W. Chestnut St.

WEST VIRGINIA

Beckley—501 Temple St.
Bluefield—125½ North St.
Charleston—504 A Washington St. W.
Clarksburg—518 Milford St.
Huntington—1020 Adams Ave.
Parkersburg—657-659 Seventh St.
Wheeling—2202 National Rd., Elm Grove

WISCONSIN

Eau Claire—511 Bellinger St.
Green Bay—315 N. Monroe Ave.
La Crosse—948 Mississippi St.
Madison—1112 South Park St.
Milwaukee—3732 W. Lisbon Ave.
Oshkosh—901 S. Main St.
Racine—1341 Washington Ave.
Waukesha—147 East North St.
Wausau—115 4th Street
West Allis—8307 W. Becher St.

WYOMING

Cheyenne—1910 Thomes Ave.

OTHER ELECTROLUX BRANCHES AND REPRESENTATIVES READY TO SERVE YOU

ALASKA

Anchorage—Conrights Furn. & Appl.
—Wolf's Dept. Store, Inc.
Fairbanks—C & C Industrial Supply
—Cooper's Hardware Co.
Juneau—Lyles's Hardware & Furn.

Ketchikan—Service Electric Co.
Kodiak—Donnelly & Acheson
Palmer—Reed's Hardware
Seward—Seward Hardware Co.
Sitka—City Electric & Refrig.

HAWAII

Honolulu—Theo. H. Davis & Co., Ltd.

PUERTO RICO

Puerto Nuevo—550 De Diego Ave.

BERMUDA

Hamilton—Appliance Services Ltd.

For Canadian branch locations, write Electrolux (Canada) Ltd., 630 Dorchester Boulevard W., Montreal 2, Canada

ELECTROLUX REGIONAL OFFICES

3001 North Fulton Drive, N.W.
Atlanta, Ga. 30305

6650 North Northwest Highway
Chicago, Ill. 60631

Foothill Village
Salt Lake City, Utah 84108

808 Swifton Center
Cincinnati, Ohio 45237

2333 A Cottman Avenue
Philadelphia, Pa. 19111

55 State Street
Springfield, Mass. 01101

1632 E. 15th Street
Tulsa, Okla. 74102

Send Filter Bag orders to Electrolux Corporation at one of the addresses listed above

FOR FASTEST PARCEL POST DELIVERY ALWAYS USE ZIP CODE

**YOU WILL FIND CONVENIENT RE-ORDER ENVELOPE IN EVERY PACKAGE OF
ELECTROLUX[®] FILTER BAGS — OR YOU MAY USE THIS PAGE AS AN ORDER FORM**



CONTENTS—
MERCHANDISE
MAY BE OPENED
FOR POSTAL
INSPECTION

IF UNDELIVERABLE,
RETURN TO SENDER—
RETURN POSTAGE
GUARANTEED.

Please PRINT Legibly

Name

Street Address

City

State

Zip Code

IMPORTANT

YOU CAN SAVE A SUBSTANTIAL SUM BY ENCLOSING REMITTANCE WITH ORDER. MAKE PAYABLE TO ELECTROLUX CORPORATION.

Send me one package of Electrolux Self-Sealing Filter Bags as indicated below

Prepaid
\$3.45
Plus Tax

☐

For which I am enclosing \$3.45, plus state & local taxes.

C. O. D.
\$4.47
Plus Tax

☐

For which I will pay \$4.47 upon delivery, plus state & local taxes.

To insure prompt delivery include state and local taxes where applicable.

PRICES SUBJECT TO CHANGE WITHOUT NOTICE.

Delivery is prepaid from our delivery shipping points when check or money order accompanies your order. If you prefer you may stop at your nearest Electrolux Authorized Factory Branch and pick up your package of filter bags.

CUT ALONG DOTTED LINE.



*use only
genuine
Electrolux®
filter bags*

FOR YOUR PROTECTION Electrolux Automatic Self-Sealing Disposable Filter Bags are sold only through Electrolux Regional Offices and Electrolux Authorized Factory Branches and their Sales Representatives. These exclusive filter-lined bags are covered by twelve patents.



the standard of excellence in home cleaning
THE CLEANER WITH THE AUTOMATIC SELF-SEALING DISPOSABLE BAG

Electrolux is the maker of America's most advanced vacuum cleaners since 1924