



# Slow-Rise Day/Nite Roller Shades



## Operating Instructions

### *To Lower Shade:*

Slow-Rise Roller Shades can be lowered to any position. To do so, grasp the bottom rail, pull to desired height and let go. The shade will remain in this location.

### *To Make Shade Rise:*

Apply a light, short tug to the bottom rail and let go. The shade will rise smoothly to the upper stop position.

## Adjustment Instructions

### *Upper Stop Position Setting (clear knob):*

To lower "stop position," turn clear knob clockwise.  
To raise "stop position," turn clear knob counter-clockwise.

### *Speed Adjustment (black knob):*

To make the shade rise faster, turn the black knob clockwise.  
To make the shade rise slower, turn the black knob counter-clockwise.



*To see video demonstrations of these instructions, go to:*  
**[www.youtube.com/user/SlowRiseRollerShades](http://www.youtube.com/user/SlowRiseRollerShades)**