

# **LIVE ROUND SOUND**

**"The whole nine yards in rugged and portable audio systems"**

## **USER MANUAL**

**Contact:**

- Email – Support@liveroundsound.com
- Phone - John Richardson: (904)-608-6111
- Phone - John Foley: (904)-608-8313

Hello! Congratulations on purchasing your Live Round Sound audio system. We hope it's everything you expect and more. Below, you will find some information about your ammo can and some answers to any questions you might have. Remember...if you have any questions at all, PLEASE do not hesitate to call, email, or even text us. Our contact information can be found on the first page of this manual.

**DISCLAIMER:** Live Round Sound highly suggests you do not tamper with any of the equipment installed within the box. The systems are built and tuned to be the highest quality with safety in mind and are not designed to be tampered with. Tampering of the equipment in any way may result in damage. Live Round Sound will not be at fault for any damages that occur due to tampering of the system. Do not turn the system on while charging. Always turn the system off when not in use. Always keep the box closed and latched when in use. These systems are NOT waterproof. Internals should always be kept closed to prevent outside conditions affecting internal equipment. Please be sure to listen for distortion at loud volumes due to the risk that equipment may be damaged. Only use the charger provided by Live Round Sound when charging the battery.

### **General Q & A:**

**-When should I charge my battery?** All systems should be charged when the battery reaches roughly 11.5 on the voltmeter. Allowing the system to drop below this may damage the battery or amplifier.

**-How do I charge my battery?** Only use the charger provided by Live Round Sound. Simply plug in the charger to the rear of the box. When your charger shows a full charge, you're good to go! Always remember to turn off your system when not in use and while the battery is charging.

**-How should I set my MP3 Player equalizer/music settings?** We highly recommend reducing bass boosters or bass levels with equalizer settings. For iPhone users, please set your music settings to "Bass Reducer" or "Treble Booster". This ensures sound quality as well as preventing distortion that could cause damage to the speakers.

**-How loud can I raise the volume?** We tune each amp to be able to take most types of music. However, we cannot tune the amp to withstand max volume for all songs. The cans are certainly designed to be turned up loud, however, the higher the volume, the more risk of distortion. Also, the more bass within a song (ex. Hip-Hop/Rap music) the higher the risk of distortion. The answer? Turn it up as loud as you like; just be sure to listen for distortion if you listen to bass heavy music.

**-My music won't play. What's wrong?** Be sure your battery has a fresh charge. If the problem persists, please get in contact with Live Round Sound.

## **Equipment:**

**Amplifier-** The equipment inside your ammo can is completely installed and ready to go when it is shipped. We tune each amp to get the highest sound quality and highest output out of the music while keeping the audio system safe.

**Speakers-** Your speaker is also ready to go upon purchase. We highly suggest you do not tamper with the speaker in any way.

**Toggle Switch-** Your ammo can is equipped with an ON/OFF toggle switch. The switch can only be in the on or off position.

**Dry Box-** Every box is hand cut and hand assembled. Always be sure to keep the box closed and latched when playing music. The free air environment can cause damage at higher volumes to the speaker.

**Bluetooth-** Every Canteen is Bluetooth only. Simply turn on the Canteen, connect to your phone or Bluetooth enabled device, then enjoy!