
















DESK ASSEMBLY INSTRUCTIONS

AX1 	BX2 	CX1 	DX1 	
EX2 	FX14 			
H1X4 	H2X10 	H3X2 	T1X1 	T2X1 

1



DESK ASSEMBLY INSTRUCTIONS



DESK ASSEMBLY INSTRUCTIONS

