


1. Introduction to Control Panel



2. Maintenance



Fault list:

Fault	Display on Screen	Fault analysis
Pressure	PRESS	PRESSURE SENSOR FAILURE
High Temperature	HT	Equipment high temperature malfunction
Phase Sequence	Ph Se	Input phase sequence error
Temperature Sensor	Temp sen	Temperature Sensor Failure
Low Voltage	LVD	Low working voltage
High Voltage	HV	High working voltage
Pressure High	Pre High	The pressure is higher than the set value
Fan Current	FanC	Fan overcurrent protection
Airhead Current	AHC	Main motor overcurrent protection
Time for Maintenance	Waring MATT	The maintenance is about to expire. Please maintain it as soon as possible

3. Fault code description

