

The Shell Application

Series SH0000D for Tabbed Navigation

Application Overview

The Shell application is the central launching point for all the applications on the PageWriter. The Shell application offers three application choices per screen, and quick access to alert type changes. The screen ID numbers for the Shell interface screens begin with "SH."

Interface Flow




Fig. 1 - User interface flow for the Shell Application.

Interface Reference Diagram






Fig. 2 - User interface reference diagram for the Shell application.

Screen ID Number: SH0100D



Screen Name

Wheel Home Screen (View 1)

Screen Form

Shell Wheel Form

Screen Description

This screen allows the user to select applications to use on the PageWriter.

Screen Functionality

This screen allows the user to select an on-screen application to open. The user can select the Read button to open the Read application (RE0000D), the Write button to open the Write application (WR0000D), or the Addresses button to open the Addresses application (AD0000D). The user can use the NavDisc™ up or down to move between the different button options. The NavDisc™ also spins the wheel to bring up the next three applications (SH0200D, SH0300D). The Tab key moves the highlight around the on-screen buttons. The user can quick-access alert types by clicking on the Alert button (the speaker icon at the lower right) to cycle through the settings for the alert type.

Screen Sub-levels

N/A

Enter From

N/A



Navigate To

SH0200D, SH0300D, AD0100D, RE0100D, WR0100D

Cancel To

N/A

Screen ID Number: SH0200C



Screen Name

Wheel Home Screen (View 2)

Screen Form

Shell Wheel Form

Screen Description

This screen allows the user to select applications to use on the PageWriter.

Screen Functionality

This screen allows the user to select an on-screen application to open. The user can select the Customize button to open the Customize application (CU0000D), the Set Time button to open the Set Time application (ST0000D), or the Partner button to open the Partner application (PC0000D). The user can use the NavDisc™ up or down to move between the different button options. The NavDisc™ also spins the wheel to bring up the next three or previous three applications (SH0100D, SH0300D). The Tab key moves the highlight around the on-screen buttons. The user can quick-access alert types by clicking on the Alert button (the speaker icon at the lower right) to cycle through the settings for the alert type.

Screen Sub-levels

N/A

Enter From



SH0100D, SH0300D

Navigate To

SH0100D, SH0300D, CU0100D, ST0100D, PC0100D

Cancel To

N/A

Screen ID Number: SH0300D**Screen Name**

Wheel Home Screen (View 3)

Screen Form

Shell Wheel Form

Screen Description

This screen allows the user to select applications to use on the PageWriter.

Screen Functionality

This screen allows the user to select an on-screen application to open. The user can select the Radio Mode button to open the Radio Mode application (RM0000D), or the Power Off button to turn the PageWriter off. The user can use the NavDisc™ up or down to move between the different button options. The NavDisc™ also spins the wheel to bring up the previous three applications (SH0100D, SH0200D). The Tab key moves the highlight around the on-screen buttons. The user can quick-access alert types by clicking on the Alert button (the speaker icon at the lower right) to cycle through the settings for the alert type.

Screen Sub-levels

N/A

Enter From

SH0100D, SH0200D

Navigate To

SH0100D, SH0200D, RM0100D

Cancel To

N/A