
BOE User Guide



Fiat Toleno - Wee Beastie

User Guide – Roller Team Toleno L

Thank you for booking our campervan, Roller Team Toleno L.

It differs slightly from our other van, but you will find the space and equipment spacious and practical.

This guide give you an overview of all the equipment onboard to make your stay as comfortable and easy as possible.

If you have any questions that are not covered in this manual, please do not hesitate to ask either John or Martin who will be happy to help at any time.



Use of the power system

- The power control panel is situated immediately above the side sliding door as you enter the van.
- To turn on the power, press the top left button this will illuminate the panel
- Second button down on the left powers the internal lights
- Third button powers the water pump
- Top right button powers the external light that is on the outside of the van



ENSURE POWER DOES NOT FALL BELOW 12.4 VOLTS

Use of the power system (continued)


- The second button on the right provides the levels of:
 - Battery
 - Clean Water Tank
 - Dirty Water Tank
- The van has a large leisure battery, it is important that it is kept well charged to <u>prevent</u> <u>damage, keep above 12.4 volts</u>
- The control panel shall tell you the status
- It can be topped up when driving, or running the engine
- Connected to external power



Use of the power system (continued)


- The fuse box is located under the sofa on the drivers side, it is contained in the small cupboard
- If you need to reset the power to the 12v system this can be done here using the reset buttons on the top right
- Alternatively, the fuses can be removed/replaced
- The external charging point runs off 240v power & is protected by a series of circuit breakers located on the right hand side
- Most system run off the 12v (battery) system i.e. lights, heater, water pump
- There are two USB charging points in the lounge area under the black lamps & two in the drivers area
- There are plugs in the van, these are only functional when plugged into external power (240v)
- The microwave only works on external power





Turning on the gas

- The isolation valves for the gas system are located in the lower left cupboard in the kitchen
- These must be isolated before driving
- The following can be isolated individually
 - Stove
 - Water/Cabin Heater
 - Fridge
- Prior to using the above appliances, the gas will need to be turned on by turning thru 90 deg
- Gas is supplied from an underslung LPG tank



Gas is isolated/closed in picture above

Filling up gas/water

- Filling up the gas is a straightforward procedure
- It is essential you plan your usage wisely as not all petrol stations have LPG
- The following website shows where filling points are located & price


https://www.autogas.app/

- With normal use, the tank will generally last 2-3 days, but will last longer if you are not running the fridge and heating regularly
- Level indicator is located to the right of the drivers seat
- To fill up, remove red cover & connect LPG hose following instructions (handy video below!)

https://www.youtube.com/watch?v=lGXu5dhe3RQ

- When releasing nozzle there is usually a small puff of gas this is completely normal
- To top up water, remove cap & insert hose provided
- When full, there is an automatic overflow beneath the van – you will see water coming out onto floor when full






Operation of the fridge


- The fridge has the ability to run from three power sourced
 - Electrics when hooked up
 - · Battery onboard
 - Gas supply
- When driving, the fridge should be run off the battery as this is being charged by the engine
- At a campsite, you can select electric
- Alternatively, you can use gas, you will need to turn the gas on (see later page)
- DO NOT USE GAS WHEN DRIVING!
- Set the temperature on the dial on the right
- To ignite the gas, you need to push in the dial on the right & the igniter button
- You know the fridge is working when the dial on the far right turns green

Use of the heating & hot water


- The control panel for the heating system is located next to the power panel
- It can run off either gas or main power if hooked up
- To turn on, press & hold the round dial the unit will power up
- To set the temperature turn dial to the van symbol, press dial and rotate to desired temperature
- Temperature in van is controlled by thermostat
- To turn water on, turn dial until thermometer selected & select eco or boost
- To select input power, turn dial to bottle symbol and select either 'gas' or 'EL2' if connected to power
- Finally, select fan speed for heating, by turning dial & select 'eco' or 'high'
- To turn off, reduce temperature to 'off' & turn off fan & water heater

https://www.youtube.com/watch?v=yLXnPyq fT5A&t=1s





- There are various air vents within the van
 - Beneath the fridge
 - Sleeping area
 - Bathroom
- To maximise heating, try not to block these vents
- Handy tip to dry wet kit, the bathroom gets very warm & toasty, simply hang kit up in here to dry!
- If you encounter an error code, it is usually because the 12v power is not turned on at control panel – switch this on
- Other errors can generally be cleared by resetting the unit by turning on/off or removing fuse



Bathroom

The bathroom has a shower & toilet

Shower


- For hot water, ensure you have turned on the water heater & waited 10 mins to get to temperature
- Pull the shower curtain & control temperature with tap the water does get very hot so be careful
- The water tank is 10L in the heater so you need to use sparingly


Toilet

- To use the toilet, open the hatch located under the seat this seals in the cassette & reduces smells
- Once finished, flush using button on wall like a conventional toilet
- · Close hatch
- There is a small dial beneath flush to tell you how full cassette is

Sink

- The sink acts as a bowl, rather than draining constantly
- Lower sink by turning latch and pressing to release from magnet
- When finished, fold up again which will drain sink into waste tank








- The cooker is a simple gas stove
- Turn on the gas at the isolator switch
- Lift glass top
- Use igniter to light gas
- Ensure windows and/or door is open to vent fumes
- Do not put hot items on glass top
- For sink, ensure water pump turned on and lift tap
- Operate like conventional tap



Setting up table


- It is easy to set up the table in the lounge area
- Take the table top from directly behind the drivers seat where is stored
- The table leg is stored in the cupboard above the fridge
- Place the table leg in the silver hole on the floor & slot table on top



Setting up the bed

- The bed can be used either as two singles, or a king size double
- Lift the cushion up, this will reveal the bed/slats
- Lift the bed slats to about 45 degrees & pullout
- Once extended, laydown on floor
- Position cushion & back on the slats to make up one side of bed
- Repeat for other side









- There are various windows in the van that can be opened for fresh air
- Remember to close before driving as this may cause considerable damage
- Push the button on the lower two handles to unlock
- Open two vertical handles
- Secure in place with strut/screw
- Mosquito nets or blinds are pulled up/down
- On passenger side, to not open window if you are using the sliding door – this will cause damage when you open the door

Beware of sliding door! Open handle & secure with strut **Push Small** Button on Handle to Unlock



- To open, push large button & push bar up
- Slide & lock bar in desired position ensuring to engage wind latch
- · Opposite to close
- Ensure windows are closed during high winds
- Windows must be closed before driving
- Blind & mosquito netting pull across



If your vehicle has broken down, please call us on 0333 070 2506

In the event of a breakdown...

Please phone either John or Martin immediately to let us know you are ok and what we can do to help.

In the event of an accident...

In the event of an accident

Please do not admit liability or discuss blame with the other party until you have sought advice from our claims START team.

Obtain the other driver(s):

- vehicle registration number
- name of his/her insurers
- motor insurance certificate number.

Obtain the name, address and telephone number of:

- any other driver(s) involved
- any other person(s) involved
- any witnesses
- attending police officers

If it is safe and appropriate to do so take a photo of the accident scene, third parties and damaged vehicles.

Please phone either John or Martin immediately to let us know you are ok and what we can do to help.