

# Mid-Century Collection










## Modular Display Cabinet - Bottom Unit

**Assembly Instructions for:**  
**KN004 - Walnut/White**


### **⚠️WARNING:**

**ADULT ASSEMBLY REQUIRED** - This product contains hardware that, before being assembled, can pose a choking hazard to children under the age of 3 years. Care should be taken when unpacking and assembling this product.

PARTS LIST


<div>A</div> 	<div>B</div> 	<div>C</div> 	<div>D</div> 	<div>E</div> 
Top Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Bottom Panel 1 PC	Left Door Panel 1 PC
<div>F</div> 	<div>G</div> 	<div>H</div> 	<div>J</div> 	
Right Door Panel 1 PC	Glass Shelf 2 PCS	Front / Rear Rail 2 PCS	Back Panel 1 PC	




Step 1.




- |     |   |     |
|-----|---|-----|
| #10 |  | x 1 |
| #11 |  | x 2 |

Step 2.




- |    |   |     |
|----|---|-----|
| #2 |  | x 2 |
| #3 |  | x 2 |
| #4 |  | x 4 |


Step 3.



Step 4.




Step 5.




Step 6.





#8  x 20




#9  x 8

Step 7.



- |    |   |      |
|----|---|------|
| #1 |    | x 2  |
| #5 |   | x 4  |
| #6 |  | x 4  |
| #7 |  | x 24 |

Step 8.





# Hinge Adjustment Instructions

## For Proper Door Alignment (optional)



### Left - Right Adjustment

Tightening/Loosening the center screw in the hinge will move the door to the left and right





### Up - Down Adjustment

Loosen the screws attaching both hinges to the inner wall of the side panel.  
Shift the door and hinges up and down for best alignment.














### In - Out Adjustment

Loosen the screw on the end of both hinges. Shift the door in and out for best alignment.




## HARDWARE LIST

#1		#2		#3		#4	 8x30mm	#5	 4x22mm
	Handle 2 PCS		Cam Bolt 18 PCS (+1 Extra)		Cam Lock 18 PCS (+1 Extra)		Wood Dowel 16 PCS (+1 Extra)		Round Head Bolt 4 PCS (+1 Extra)
#6		#7	 7x15mm	#8	 8x12mm	#9		#10	
	Hinge 4 PCS		Flat Head Screw 24 PCS (+1 Extra)		Short Screw 20 PCS (+1 Extra)		Shelf Holder 8 PCS (+1 Extra)		Double Magnet 1 PC
#11	 6x15mm								
	Round Head Screw 2 PCS (+1 Extra)								

## ADDITIONAL TOOLS (Not Provided)

Note: It is not recommended to use power tools during assembly.



Phillips Head Screwdriver

Note: Wood dowels are intended for alignment. Additional clearance between wood dowel and pre-drilled hole is intentional for ease of assembly.