




STROBE ALERT When  
Beam is NOT LEVEL

Battery Level  
Indicator

Anchored to Spreader  
Beam with powerful  
Neodymium Magnets

Teather Device with  
1/4" Safety Strap



- Milwaukee 18v Battery lasts up to a week when fully charged and in good condition
- Ensure it is checked prior to each use to ensure strobe alert
- Any tampering with device voids instrument



Battery Level Indicator



Anchored to Crane Block with powerful Neodymium Magnets – **Battery** in **bottom** position

STROBE ALERT When Crane Block is SIDE-LOADED



STROBE ALERT – SIDE LOADED

- Milwaukee 12v Battery lasts up to a week when fully charged and in good condition
- Ensure it is checked prior to each use to ensure strobe alert
- Any tampering with device voids instrument