Aeration Anywhere

Quick Start Guide

Gasoline Start

- 1. Check engine oil
- 2. Turn OFF the valve to the large low-pressure (silver colour) regulator
- 3. On the engine, place throttle in idle position, turn gasoline valve <u>ON</u> and the choke <u>ON</u> (typical start procedure for an engine)

Propane/Natural Gas Start

IMPORTANT Turn OFF the gasoline valve on the engine. ALSO, if the engine was previously run on gasoline, the gasoline valve must be turned off AND the engine must be run until the carburetor is run dry of ALL gasoline (The engine will not run properly if both gasoline and propane/natural gas is being fed to the engine)

- 1. Check engine oil
- 2. After the gasoline valve on the engine is turned off, make sure choke is also OFF. (Choke does not help starting with propane/natural gas)
- 3. Set the throttle to idle position
- 4. Turn <u>ON</u> all propane/natural gas valves (gas will not flow until the engine starts running)
- 5. Press propane/natural gas primer button on back of large low-pressure (silver colour) regulator for 1-2 seconds.
- 6. Turn key to "start" position for a maximum of 5 seconds.
- 7. If the engine does not start, repeat steps 5 and 6 until engine starts.

Cold Weather Start

- 1. Follow Gasoline Start procedure until engine is warm.
- 2. Once engine is warm, turn OFF the gasoline valve on the engine and allow it to run until it quits (all gasoline has been used in the carburetor)
- 3. Follow Propane/Natural Gas Start procedure.

Switching Between Propane and Natural Gas

1. Adjust the needle on the top of the large low-pressure regulator according to the Century Fuels manual.

