Flex Fireplace Series

Summary Brochure

ecosmart™
Fire

ecosmartfire.com

Endless design flexibility

EcoSmart's Flex Series offers unprecedented choice and flexibility. From small to large, residential, commercial or hospitality environments we make it easy to achieve your interior design vision with our flueless fireplaces.

Flex benefits

- Four fewer General Contractors
- No gas, no electric
- No chimney or venting
- No hole in envelope of building (no potential for future water leaks)
- No "Call Backs". It works and works and works

- Works in a power outage
- Eco-friendly
- Residential or commercial
- Indoor or outdoor
- 219 models, ranging from 455mm/18in to 4,015mm/158in

- Up to 80% less than custom fireplaces
- These models comply with existing standards in the USA, Europe, UK and Australia. UL Listed, EN 16647 BSI Certified, ACCC Safety Mandate compliant.
- Zero clearance

Quick & easy installation

Flex Fireplaces are very simple to install. They don't require flue or chimney, nor gas or power connections. You can utilise timber frame to secure the appliance, and no insulation around the fireplace is required.

1 Construct framework

2 Add fireplace

3 Finish surround

1. Select fireplace style

Choosing your Flex fireplace style is simple: a fireplace for a single room application, or a model that will work as a room divider and service multiple spaces.

1.

2.

Single Room

1. Single Sided
Features one open side - view the flame from the front.
MODEL: FLEX 50SS

2. Left Corner
Features two open sides - view the flame from the front and from the left corner.
MODEL: FLEX 104LC.BXR (INCLUDES RIGHT SIDE DECORATIVE BOX)

3. Right Corner
Features two open sides - view the flame from the front and from the right corner.
MODEL: FLEX 86RC

4. Bay
Features three open sides - view the flame from the front and both left and right sides.
MODEL: FLEX 122.BX2 (INCLUDES RIGHT AND LEFT SIDE DECORATIVE BOXES)

3.

4.

5a.

5b.

6. @Rosemont House Luxury B&B, VIC.

Room Dividers

5a+5b. Double Sided
Features two open sides - view the flame from the front and the back.
MODEL: FLEX 50DB

6. Peninsula
Features three open sides - view the flame from the front, back and open side. Install left or right.
MODEL: FLEX 18PN

7. Bench
Features all open sides - view the flame from the top, front, back, left and right sides.
MODEL: FLEX 104IL

8. Island
Features four open sides - view the flame from the front, back, left and right sides.
MODEL: FLEX 122BN

7.

8.

2. Select size of viewing area

To select the correct size for your Flex fireplace, consider:
- the total dimensions of your wall
- the viewing area of your appliance once installed, and
- the room size to ensure you have enough ventilation available.

Flex 18" 32" 42" 50" 60" 68" 78" 86" 104" 122" 140" 158"

Viewing area sizes

455mm	810mm	1,065mm	1,270mm	1,525mm	1,730mm	1,985mm	2,185mm	2,645mm	3,100mm	3,560mm	4,015mm
18in	32in	42in	50in	60in	68in	78in	86in	104in	122in	140in	158in
Flex 18	Flex 32	Flex 42	Flex 50	Flex 60	Flex 68	Flex 78	Flex 86	Flex 104	Flex 122	Flex 140	Flex 158

An example of selecting the ideal viewing area based on a 2,500mm [98in] wall.

Wall Length **2,500mm [98in]**

Flex 50

Flex 68

Flex 86

Viewing Area

3. Select configuration

Flex fireplaces offer 4 viewing area configurations for most models. Select flame only view or a view with 1 or 2 decorative side boxes.

Steel log sets are available as an optional accessory.

Flame only

Flame plus 2 side boxes (.BX2)

Flame plus 1 side box on the Left (.BXL)

Flame plus 1 side box on the Right (.BXR)

Viewing area configurations

	Flex 18	Flex 32	Flex 42	Flex 50	Flex 68	Flex 86	Flex 104	Flex 122	Flex 158
Flame Only	Flex 18	Flex 32	Flex 42	Flex 50	Flex 68	Flex 86	Flex 104	Flex 122	Flex 158
With 1 Side Box		Flex 50.BX	Flex 60.BX	Flex 68.BX	Flex 86.BX	Flex 104.BX	Flex 122.BX	Flex 140.BX	
With 2 Side Boxes		Flex 68.BX2	Flex 78.BX2	Flex 86.BX2	Flex 104.BX2	Flex 122.BX2	Flex 140.BX2	Flex 158.BX2	
Minimum Room Size	40m³ [1413f³]	80m³ [2825f³]	90m³ [3178f³]	110m³ [3884f³]	115m³ [4061f³]	220m³ [7768f³]	230m³ [8122f³]	330m³ [11652f³]	345m³ [12183f³]

Included accessories

Jerry Can, Safety Spout & e-NRG bottle adaptor

Lighting Rod & Lighter

Black Glass Charcoal

Glass Fire Screen/s

Baffles (N/A Flex 18)

Which Flex are you?

		Single Sided (SS)	Left Corner (LC)	Right Corner (RC)	Bay (BY)	Peninsula (PN)	Double Sided (DB)	Island (IL)	Bench (BN)
40m² [1,413F]	**Flex 18** viewing area 18in [455mm]					Flip all			
80m² [2,825F]	**Flex 32** viewing area 32in [810mm]								
90m² [3,178F]	**Flex 42** viewing area 42in [1,065mm]								
Ranging between 80m² [2,825F] - 110m² [3,884F]	**Flex 50** viewing area 50in [1,270mm]						Flip	Flip	Flip
90m² [3,178F]	**Flex 60** viewing area 60in [1,525mm]						Flip	Flip	Flip
Ranging between 80m² [2,825F] - 115m² [4,061F]	**Flex 68** viewing area 68in [1,730mm]	Flex 68SS Flame Only / Flex 68SS.BXL Flame + Box Left / Flex 68SS.BXR Flame + Box Right / Flex 68SS.BX2 Flame + Box X2					Flip	Flip	Flip
90m² [3,178F]	**Flex 78** viewing area 78in [1,985mm]								
Ranging between 110m² [3,884F] - 220m² [7,768F]	**Flex 86** viewing area 86in [2,185mm]					Flip	Flip	Flip	Flip
Ranging between 115m² [4,061F] - 230m² [8,122F]	**Flex 104** viewing area 104in [2,645mm]					Flip	Flip	Flip	Flip
Ranging between 220m² [7,768F] - 330m² [11,652F]	**Flex 122** viewing area 122in [3,100mm]						Flip	Flip	Flip
Ranging between 330m² [11,652F] - 345m² [12,183F]	**Flex 140** viewing area 140in [3,560mm]						Flip	Flip	Flip
	Flex 158 viewing area 158in [4,015mm]								

Minimum Room Size

Remember to consider the **Minimum Room Size** when choosing your Flex fireplace.

ecosmartfire.com