International Aerospace & Defense LLC

Part Number	Nomenclature
10420-11968E	Altimeter
10450-11110	Altimeter
10460-11938	Altimeter
101011	Accelerometer
104-384016-1	Accelerometer
112959-01	Accelerometer
1470-8-02	Accelerometer
18-1151	Accelerometer
2117-800	Accelerometer
2117-812	Accelerometer
2119-001	Accelerometer
2119-001-1	Accelerometer
2119-001-2	Accelerometer
2119-001-3	Accelerometer
2119-500	Accelerometer
3415-2M-A	Accelerometer
3416-3A-A1	Accelerometer
3416-4A-B1	Accelerometer
3419-5A-A1	Accelerometer
3419-5D-A2	Accelerometer
4905-2-A	Accelerometer
554KN-02	Accelerometer
67573-301	Accelerometer
691CK-04	Accelerometer
691CK-05	Accelerometer
691-CU-8-06	Accelerometer
691CU-8-06	Accelerometer
691K-02	Accelerometer
971-4193-001	Accelerometer
971-4193-002	Accelerometer
981-3088-010	Accelerometer
A3850-1	Accelerometer
A7240-4	Accelerometer
BG67C	Accelerometer
BG67C4	Accelerometer
GG22C	Accelerometer
GG47A	Accelerometer
GG47B	Accelerometer
GG47B1	Accelerometer
GG47B4	Accelerometer

MX-2916/ASW-12(V) Accelerometer

Primary Part Number	Nomenclature	Manufacture
MX-2916A/ASW-12(V)	Accelerometer	Bendix
MX-4282/ASW-12	Accelerometer	Bendix
MX-4870/ASW-12(V)	Accelerometer	Bendix
MX-4870A/ASW-12(V)	Accelerometer	Bendix
110441-01	Actuator	Lear Siegler
113040-01	Actuator	Lear Siegler
300220-01	Actuator	Lear Siegler
300220-02	Actuator	Lear Siegler
300445-01	Actuator	Lear Siegler
300445-02	Actuator	Lear Siegler
35070-1014	Actuator	Cessna
35070-1028	Actuator	Cessna
7-24282	Aft Throttle Control Assembly	Teleflex
C-07202-2	Coaxial Control Shaker	Safe Flight
C-25502	Coaxial Control Shaker	Safe Flight
DL1326M11	Electro-Mechanical Actuator	Nash Controls
DYLZ3991-3	Butterfly Valve and Actuator	Barber-Colman
KSA 470	Actuator	Bendix King
MG 112	Trim Actuator	Bendix King
MG 113	Actuator	Bendix King
MG112A1	Trim Adapter	Bendix King
MG112B1	Trim Actuator	Bendix King
MG113A1	Actuator	Bendix King
MG113A2	Actuator	Bendix King
MG113A3	Actuator	Bendix King
MG113E1	Actuator	Bendix King
MG113E1 Super "E"	Actuator	Bendix King
MG113E3	Actuator	Bendix King
MG113E3 Super "E"	Actuator	Bendix King
MG70A10	Actuator	Honeywell
MG70A11	Actuator	Honeywell
MG70A12	Actuator	Honeywell
MG70A13	Actuator	Honeywell
MG70A14	Actuator	Honeywell
MG70A8	Actuator	Honeywell
MG70A9	Actuator	Honeywell
TA-495A	Pitch Actuator	Cessna
T-38 Inst & Display	T-38 Inst & Display	ATOS
T-38 Wiring Diagrams	T-38 Wiring Diagrams	ATOS
100414	Airspeed Indicator	Aerosonic
101-384074-7	Airspeed Indicator	Aero Mach
10-150	Airspeed Indicator	Aerosonic
104AMA/JA/1	Airspeed Indicator	Smith Industries
10-61818-151	Airspeed Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
10-61818-161	Airspeed Indicator	Ametek/GE

10-61818-171	Airspeed Indicator	Ametek/GE
10-61818-18	Airspeed Indicator	Ametek/GE
11-1004	Airspeed Indicator	AID
11-1004-1	Airspeed Indicator	AID
111-AMA	Airspeed Indicator	Smith Industries
115-384033	Airspeed Indicator	AID
115-384033-1	Airspeed Indicator	AID
115-384033-3	Airspeed Indicator	AID
115823-01	Airspeed-Mach Controller	Lear Siegler
1159SCAV408-1	Airspeed Indicator	Flightline Systems
1159SCAV408-2	Airspeed Indicator	Flightline Systems
115-AMA	Airspeed Indicator	Smith Industries
11B306	Airspeed Indicator	Beechcraft
1214BX-8-05	Airspeed Indicator	Kollsman
1214CX-8-05	Airspeed Indicator	Kollsman
1214DX-8-05	Airspeed Indicator	Kollsman
1214X-8-05	Airspeed Indicator	Kollsman
1296-5-0193	Airspeed Indicator	Kollsman
1297B-5-03	Airspeed Indicator	Kollsman
1297B-5-05	Airspeed Indicator	Kollsman
1297B-8-05	Airspeed Indicator	Kollsman
1297C-4-04	Airspeed Indicator	Kollsman
1297C-4-05	Airspeed Indicator	Kollsman
1297C-8-04	Airspeed Indicator	Kollsman
1297C-8-05	Airspeed Indicator	Kollsman
12C1006-811	Airspeed Indicator	General Dynamics
12C1006-813	Airspeed Indicator	General Dynamics
12C1006-817	Airspeed Indicator	General Dynamics
130-380044-3	Indicator	Meggitt Avionics
130-380045-3	Indicator	Meggitt Avionics
1389X-5-01	Airspeed Indicator	Kollsman
1397B-05	Airspeed Computer	Kollsman
1402-C1	Airspeed Indicator	Pioneer
1426-1AE-A1	Airspeed Indicator	Pioneer
1426-1Z-A1	Airspeed Indicator	Pioneer
1426-2J-A1	Airspeed Indicator	Pioneer
1426-37A-A6	Airspeed Indicator	Pioneer
1426-37E-A6	Airspeed Indicator	Pioneer
1426-37F-A6	Airspeed Indicator	Pioneer
1426-37G-A6	Airspeed Indicator	Pioneer
1426-47J-B17	Airspeed Indicator	Bendix
1426-5A-A1	Airspeed Indicator	Bendix
1426-5A-B1	Airspeed Indicator	Bendix

Primary Part Number	Nomenclature	Manufacture
1426-A1	Airspeed Indicator	Pioneer
1432-22B-A-A1	Airspeed Indicator	Pioneer
1440-55B-B55-1	Airspeed Indicator	Bendix
1440-55C-C55-1	Airspeed Indicator	Bendix
1440-55D-C55-1	Airspeed Indicator	Bendix

1440-55E-D55-1	Airspeed Indicator	Bendix
1441-07	Airspeed Indicator	Bendix
1442-51C-A51-1	Airspeed Indicator	Bendix
1443-56-A56-1	Airspeed Indicator	Bendix
1443-56A-A56-1	Airspeed Indicator	Bendix
1445-58A-A58-1	Airspeed Indicator	Bendix
1450-55E-A55-1	Airspeed Indicator	Bendix
1451-51C-A51-1	Airspeed Indicator	Bendix
1454-62A-A62-1	Airspeed Indicator	Bendix
1454-62A-B62-1	Airspeed Indicator	Bendix
1458-47U-C1	Airspeed Indicator	Bendix
1458-64A-A1	Airspeed Indicator	Bendix
1458-64A-B1	Airspeed Indicator	Bendix
1460-62A-A62-1	Airspeed Indicator	Bendix
1460-62A-B62-1	Airspeed Indicator	Bendix
1463-55F-B55-1	Airspeed Indicator	Bendix
1463-55F-B55-4	Airspeed Indicator	Bendix
1463-55K-B55-1	Airspeed Indicator	Bendix
1463-55K-B55-2	Airspeed Indicator	Bendix
1518-01	Airspeed Indicator	Aero Mach
1518-03	Airspeed Indicator	Aero Mach
1518-05	Airspeed Indicator	Aero Mach
1701BX-8-010	Airspeed Indicator	Kollsman
1701BX-8-03	Airspeed Indicator	Kollsman
1701BX-8-04	Airspeed Indicator	Kollsman
1701CX-8-010	Airspeed Indicator	Kollsman
1701CX-8-03	Airspeed Indicator	Kollsman
1701CX-8-04	Airspeed Indicator	Kollsman
1701CX-8-05	Airspeed Indicator	Kollsman
1701DX-10-04	Airspeed Indicator	Kollsman
1701DX-4-04	Airspeed Indicator	Kollsman
1701DX-8-04	Airspeed Indicator	Kollsman
18000-1A1A1	Airspeed Indicator	Bendix
18000-1B3A1	Airspeed Indicator	Bendix
18000-1B4B1	Airspeed Indicator	Bendix
18000-1B4C1	Airspeed Indicator	Bendix
18000-1B4D1	Airspeed Indicator	Bendix
18000-1B4E1	Airspeed Indicator	Bendix
18008-8A11A1	Airspeed Indicator	Bendix

Primary Part Number	Nomenclature	Manufacture
18008-8A11A2	Airspeed Indicator	Bendix
18-1420	Airspeed Indicator	Courter
18-1454	Airspeed Indicator	Courter
18-1792-2	Airspeed Indicator	Courter
18-1793	Airspeed Indicator	Courter
1836B-05	Airspeed Indicator	Kollsman
1877B-041011	Airspeed Indicator	Kollsman
1877B-041013	Airspeed Indicator	Kollsman
1914B-01	Airspeed Indicator	Kollsman

1939-041010	Airspeed Indicator	Kollsman
1947-03	Airspeed Amplifier	Kollsman
1952-04-03	Airspeed Indicator	Kollsman
1952B-4-03	Airspeed Indicator	Kollsman
1957-04-03	Airspeed Indicator	Kollsman
1964713-1	Airspeed Indicator	Bendix
1964714-1	Airspeed Indicator	Bendix
1964715-1	Airspeed Indicator	Bendix
1964715-2	Airspeed Indicator	Bendix
20130-( )	Airspeed Indicator	Aerosonic
20140-01110	Airspeed Indicator	Aerosonic
20140-01130	Airspeed Indicator	Aerosonic
20140-0351	Indicator	Aerosonic
20240-11371	Airspeed Indicator	Aerosonic
2030-2030-00-1210	Airspeed Indicator	Aerosonic
2083-05	Airspeed Indicator	Smith Industries
2083-06	Airspeed Indicator	Smith Industries
2083-07	Airspeed Indicator	Smith Industries
2083-08-01	Airspeed Indicator	Ametek/GE
2083-09	Airspeed Indicator	Smith Industries
2083-09-01	Airspeed Indicator	Ametek/GE
2083-10	Airspeed Indicator	Smith Industries
2083-10-01	Airspeed Indicator	Ametek/GE
2083-11	Airspeed Indicator	Smith Industries
2083-11-01	Airspeed Indicator	Ametek/GE
2083-2	Airspeed Indicator	Smith Industries
209-070-276-1	Indicator	Bell
2103-800	Airspeed Indicator	Burton
2261-02-01	TAT/SAT/TAS Indicator	Ametek/GE
22-696-037	Airspeed Indicator	Garwin
2272-04-01	Airspeed Indicator	Kollsman
2353-04-01	Airspeed Indicator	Kollsman
2403/W/1	Airspeed Indicator	Smith Industries
2404KAB/1	Airspeed Indicator	Smith Industries
2405KAB/1	Airspeed Indicator	Smith Industries
Primary Part Number	**Nomenclature**	**Manufacture**
2406KAB/1	Airspeed Indicator	Smith Industries
2407KAB/1	Airspeed Indicator	Smith Industries
2408KAB/1	Airspeed Indicator	Smith Industries
2409KAB/1	Airspeed Indicator	Smith Industries
2410KAB/1	Airspeed Indicator	Smith Industries
2411KAB/1	Airspeed Indicator	Smith Industries
24482	Airspeed Indicator	Airesearch
24482-1	Airspeed Indicator	Airesearch
24482-1-1	Airspeed Indicator	Airesearch
2450KAB/1	Airspeed Indicator	Smith Industries
2450KAB/10	Airspeed Indicator	Smith Industries
2450KAB/2	Airspeed Indicator	Smith Industries
2450KAB/4	Airspeed Indicator	Smith Industries

2450KAB/5	Airspeed Indicator	Smith Industries
2450KAB/6	Airspeed Indicator	Smith Industries
2450KAB/7	Airspeed Indicator	Smith Industries
2450KAB/8	Airspeed Indicator	Smith Industries
2450KAB/9	Airspeed Indicator	Smith Industries
25615-()	Indicator	Bendix
25615-C33A-70-A3	Indicator	Bendix
2586883-1	Airspeed Computer	Sperry
2586883-2	Airspeed Computer	Sperry
2586883-3	Airspeed Computer	Sperry
2586883-4	Airspeed Computer	Sperry
2594466-901	Airspeed Indicator	Honeywell
2594466-902	Airspeed Indicator	Honeywell
2594466-904	Airspeed Indicator	Honeywell
2594466-905	Airspeed Indicator	Honeywell
2594466-906	Airspeed Indicator	Honeywell
26200-1A-1-A1	Airspeed Indicator	Bendix
26700-1A-1-A1	Airspeed Indicator	Bendix
269098	Airspeed Indicator	Garrett
27-001-1	Airspeed Indicator	Alcor
27-001-2	Airspeed Indicator	Alcor
27-001-3	Airspeed Indicator	Alcor
27-19193-( )	Airspeed Indicator	Aerosonic
2803-08	Airspeed Indicator	Smith Industries
31000-1A-A1	Airspeed-Mach Warning Switch	Pioneer Central
31000-9A-A1	Airspeed-Mach Warning Switch	Pioneer Central
31006-A1	Airspeed-Mach Warning Switch	Pioneer Central
347010	Airspeed Indicator	Kollsman
347015	Airspeed Indicator	Kollsman
347025	Airspeed Indicator	Kollsman
347030	Airspeed Indicator	Kollsman

Primary Part Number	Nomenclature	Manufacture
350020	Airspeed Switch	Flightline Systems
352-01-3	Airspeed Indicator	Courter
352-01-4	Airspeed Indicator	Courter
35-380036-9	Airspeed Indicator	Instruments Inc.
37070()	SAT/TAS/TAT Computer	Kollsman
37070-235	SAT/TAS/TAT Computer	Kollsman
37230-003	Airspeed Indicator	IDC
37230-007	Airspeed Indicator	IDC
37230-008	Airspeed Indicator	IDC
38399-330	Airspeed Indicator	Badin
38399-480	Airspeed Indicator	Badin
38399-490	Airspeed Indicator	Badin
39948-B2233	Airspeed Indicator	Kollsman
40-140-4	Airspeed Indicator	Servo Development C
40-140-6	Airspeed Indicator	Servo Development C
4018366-901	Airspeed Indicator	Sperry
4018366-902	Airspeed Indicator	Sperry

4018366-903	Airspeed Indicator	Sperry
4018366-904	Airspeed Indicator	Sperry
4018366-905	Airspeed Indicator	Sperry
4018366-906	Airspeed Indicator	Sperry
4031609-901	Airspeed Indicator	Honeywell
4031609-902	Airspeed Indicator	Honeywell
4031609-903	Airspeed Indicator	Honeywell
4031609-904	Airspeed Indicator	Honeywell
4031609-905	Airspeed Indicator	Honeywell
4031609-906	Airspeed Indicator	Honeywell
4031609-907	Airspeed Indicator	Honeywell
4031609-908	Airspeed Indicator	Honeywell
4055372-901	Airspeed Indicator	Howell
4055372-903	Airspeed Indicator	Honeywell
417710	Airspeed, Repeater	Norden Ketay
44105-J/K	Airspeed Indicator	IDC
4909-2-A	Air Data Control	Eclipse Pioneer
4935-1-A	Air Data Control	Eclipse Pioneer
510-18295	Airspeed Indicator	IDC
510-18352	Airspeed Indicator	IDC
510-18356	Airspeed Indicator	IDC
512-1834	Airspeed Indicator	IDC
512-18354	Airspeed Indicator	IDC
513-18295B	Airspeed Indicator	IDC
513-18352	Airspeed Indicator	IDC
532-39948-B0501	Airspeed Indicator	IDC
534-21663	Airspeed Indicator	IDC

Primary Part Number	Nomenclature	Manufacture
534-23070-001	Airspeed Indicator	IDC
534-23070-003	Airspeed Indicator	IDC
534-23070-004	Airspeed Indicator	IDC
534-23070-011	Airspeed Indicator	IDC
534-23070-012	Airspeed Indicator	IDC
534-23070-013	Airspeed Indicator	IDC
534-23070-014	Airspeed Indicator	IDC
534-23070-401	Airspeed Indicator	IDC
534-23070-402	Airspeed Indicator	IDC
534-23070-403	Airspeed Indicator	IDC
534-23070-404	Airspeed Indicator	IDC
534-23070-411	Airspeed Indicator	IDC
534-23070-413	Airspeed Indicator	IDC
534-23070-414	Airspeed Indicator	IDC
534-23070-451	Airspeed Indicator	IDC
534-23070-452	Airspeed Indicator	IDC
534-23070-453	Airspeed Indicator	IDC
534-23070-454	Airspeed Indicator	IDC
534-23070-461	Airspeed Indicator	IDC
534-23070-462	Airspeed Indicator	IDC
534-23070-463	Airspeed Indicator	IDC

534-23070-464	Airspeed Indicator	IDC
534-23070-651	Airspeed Indicator	IDC
534-23080-002	Airspeed Indicator	IDC
568BK-0115	Airspeed Indicator	Kollsman
575-24030-210	Airspeed Indicator	IDC
575-24030-226	Airspeed Indicator	IDC
575-24030-230	Airspeed Indicator	IDC
575-24030-239	Airspeed Indicator	IDC
575-24030-241	Airspeed Indicator	IDC
575-24030-242	Airspeed Indicator	IDC
575-24030-267	Airspeed Indicator	IDC
575-24030-310	Airspeed Indicator	IDC
575-24030-326	Airspeed Indicator	IDC
575-24030-330	Airspeed Indicator	IDC
575-24030-339	Airspeed Indicator	IDC
575-24030-341	Airspeed Indicator	IDC
575-24030-342	Airspeed Indicator	IDC
575-24030-367	Airspeed Indicator	IDC
575-24030-610	Airspeed Indicator	IDC
575-24030-626	Airspeed Indicator	IDC
575-24030-630	Airspeed Indicator	IDC
575-24030-639	Airspeed Indicator	IDC
575-24030-641	Airspeed Indicator	IDC

Primary Part Number	Nomenclature	Manufacture
575-24030-642	Airspeed Indicator	IDC
575-24030-710	Airspeed Indicator	IDC
575-24030-726	Airspeed Indicator	IDC
575-24030-730	Airspeed Indicator	IDC
575-24030-739	Airspeed Indicator	IDC
575-24030-741	Airspeed Indicator	IDC
575-24030-742	Airspeed Indicator	IDC
575-25850-200	Airspeed Indicator	IDC
575-25850-300	Airspeed Indicator	IDC
575-26465-811	Airspeed Indicator	IDC
575-26465-833	Airspeed Indicator	IDC
575-26465-860	Airspeed Indicator	IDC
575-26465-911	Airspeed Indicator	IDC
575-26465-933	Airspeed Indicator	IDC
575-26465-960	Airspeed Indicator	IDC
575-29846-300	Airspeed Indicator	IDC
575-29946-200	Airspeed Indicator	IDC
575-31500-400	Airspeed Indicator	IDC
575-31500-500	Airspeed Indicator	IDC
575-31500-600	Airspeed Indicator	IDC
575-31500-700	Airspeed Indicator	IDC
575-31500-809	Airspeed Indicator	IDC
575-32755-200	Airspeed Indicator	IDC
575-32755-300	Airspeed Indicator	IDC
575-32755-400	Airspeed Indicator	IDC

575-32755-600	Airspeed Indicator	IDC
575-32755-700	Airspeed Indicator	IDC
575-32815-200	Airspeed Indicator	IDC
575-32815-300	Airspeed Indicator	IDC
575-32815-400	Airspeed Indicator	IDC
575-32815-500	Airspeed Indicator	IDC
575-32815-600	Airspeed Indicator	IDC
575-32815-700	Airspeed Indicator	IDC
575-32815-8100	Airspeed Indicator	IDC
575-32815-9100	Airspeed Indicator	IDC
575-33025-400	Airspeed Indicator	IDC
575-33025-500	Airspeed Indicator	IDC
575-33025-800	Airspeed Indicator	IDC
575-33025-900	Airspeed Indicator	IDC
575-33075-()	Airspeed Indicator	IDC
575-33115-()	Airspeed Indicator	IDC
575-3520-200	Airspeed Indicator	IDC
575-35250-300	Airspeed Indicator	IDC
575-35250-400	Airspeed Indicator	IDC

Primary Part Number	Nomenclature	Manufacture
575-35250-500	Airspeed Indicator	IDC
575-35900-400	Airspeed Indicator	IDC
575-35900-500	Airspeed Indicator	IDC
575-35900-600	Airspeed Indicator	IDC
575-35900-700	Airspeed Indicator	IDC
585-33986-002	Airspeed Indicator	IDC
586BK-0110	Airspeed Indicator	Kollsman
586BK-0115	Airspeed Indicator	Kollsman
586BK-0142	Airspeed Indicator	Kollsman
586BK-0148	Airspeed Indicator	Kollsman
586BK-0149	Airspeed Indicator	Kollsman
586BK-0153	Airspeed Indicator	Kollsman
586BK-0154	Airspeed Indicator	Kollsman
586BK-0155	Airspeed Indicator	Kollsman
586BK-0171	Airspeed Indicator	Kollsman
586BK-0172	Airspeed Indicator	Kollsman
586BK-0173	Airspeed Indicator	Kollsman
586BK-0174	Airspeed Indicator	Kollsman
586BK-0175	Airspeed Indicator	Kollsman
586BK-0189	Airspeed Indicator	Kollsman
586BK-0190	Airspeed Indicator	Kollsman
586BK-0192	Airspeed Indicator	Kollsman
586BK-030	Airspeed Indicator	Kollsman
586BK-038	Airspeed Indicator	Kollsman
586BK-047	Airspeed Indicator	Kollsman
586BK-053	Airspeed Indicator	Kollsman
586BK-07	Airspeed Indicator	Kollsman
586BK-083	Airspeed Indicator	Kollsman
586BK-096	Airspeed Indicator	Kollsman

586BK-1-0153	Airspeed Indicator	Kollsman
586BK-13-0155	Airspeed Indicator	Kollsman
586BK-4-0153	Airspeed Indicator	Kollsman
586CK-4-0158	Airspeed Indicator	Kollsman
586CK-4-0160	Airspeed Indicator	Kollsman
586K-026	Airspeed Indicator	Kollsman
586K-028	Airspeed Indicator	Kollsman
5A16	Airspeed Indicator	Thommen
5A58	Airspeed Indicator	Thommen
60-4905	Airspeed Indicator	Karnish
630-30980-100	SAT/TAS Computer	IDC
630-30980-300	SAT/TA Computer	IDC
630-37070	SAT/TAS/TAT Computer	Kollsman
630-37070-235	SAT/TAS/TAT Computer	Kollsman
64010-1	Airspeed Indicator	Jaeger
Primary Part Number	**Nomenclature**	**Manufacture**
64032-229-1	Airspeed Indicator	Thomson
64040-560-1	Airspeed Indicator	Jaeger
64050-660-1	Airspeed Indicator	Thales
64050-661-1	Airspeed Indicator	Thales
64050-662-1	Airspeed Indicator	Thales
64050-663-1	Airspeed Indicator	Thales
7002638-901	Airspeed Indicator	Sperry
7002638-902	Airspeed Indicator	Honeywell
7002638-903	Airspeed Indicator	Honeywell
7002638-904	Airspeed Indicator	Honeywell
7002638-905	Airspeed Indicator	Honeywell
7002638-906	Airspeed Indicator	Sperry
7002638-908	Airspeed Indicator	Honeywell
7002638-909	Airspeed Indicator	Honeywell
70450-21942-101	Airspeed Indicator	Aerosonic
724CU-4-012	Airspeed Indicator	Kollsman
724CU-5-011	Airspeed Indicator	Kollsman
724CU-5-03	Airspeed Indicator	Kollsman
724CU-8-011	Airspeed Indicator	Kollsman
724DU-4-012	Airspeed Indicator	Kollsman
724DX-4-012	Airspeed Indicator	Kollsman
739CK-8-015	Airspeed Indicator	Kollsman
739CU-4-030	Airspeed Indicator	Kollsman
739CU-4-034	Airspeed Indicator	Kollsman
739CU-5-015	Airspeed Indicator	Kollsman
739CX-4-023	Airspeed Indicator	Kollsman
739CX-4-028	Airspeed Indicator	Kollsman
739CX-8-015	Airspeed Indicator	Kollsman
739CX-8-033	Airspeed Indicator	Kollsman
739DU-4-035	Airspeed Indicator	Kollsman
757-31500-436	Airspeed Indicator	IDC
8.039	Airspeed Indicator	Aeritalia
8.039.003	Airspeed Indicator	Aeritalia

8.039.008.1	Airspeed Indicator	Aeritalia
8.039.408.1	Airspeed Indicator	Aeritalia
8.039.503	Airspeed Indicator	Aeritalia
8.039.508.1	Airspeed Indicator	Aeritalia
8.039.603	Airspeed Indicator	Aeritalia
8.039.608.1	Airspeed Indicator	Aeritalia
8.039.703	Airspeed Indicator	Aeritalia
8.039.708.1	Airspeed Indicator	Aeritalia
8.039.808.1	Airspeed Indicator	Aeritalia
8000B.156	Airspeed Indicator	United Instruments
8000-B.156	Airspeed Indicator	United Instruments

Primary Part Number	Nomenclature	Manufacture
8000-B.166	Airspeed Indicator	United Instruments
8000-B.464	Airspeed Indicator	United Instruments
8000-B.71	Airspeed Indicator	United Instruments
8000T	Airspeed Indicator	United Instruments
8025	Airspeed Indicator	United Instruments
8025-B.167	Airspeed Indicator	United Instruments
8025-B.447	Airspeed Indicator	United Instruments
8025-B.465	Airspeed Indicator	United Instruments
8025T	Airspeed Indicator	United Instruments
8030 Series	Airspeed Indicator	United Instruments
8030-B.168	Airspeed Indicator	United Instruments
8030-B.466	Airspeed Indicator	United Instruments
8030-B.77	Airspeed Indicator	United Instruments
8030T	Airspeed Indicator	United Instruments
8040 Series	Airspeed Indicator	United Instruments
8059-2	Airspeed Indicator	Aero Mechanism Inc
8125	Airspeed Indicator	United Instruments
8125 Series	Airspeed Indicator	United Instruments
8125-B.178	Airspeed Indicator	United Instruments
8125-B.97	Airspeed Indicator	United Instruments
8130 Series	Airspeed Indicator	United Instruments
8130-B.185	Airspeed Indicator	United Instruments
8135	Airspeed Indicator	United Instruments
8140 Series	Airspeed Indicator	United Instruments
815BX-4-05	Airspeed Indicator	Kollsman
815BX-8-05	Airspeed Indicator	Kollsman
815K-03	Airspeed Indicator	Kollsman
815U-8-05	Airspeed Indicator	Kollsman
8200	Airspeed Indicator	United Instruments
8220	Airspeed Indicator	United Instruments
8220B.475	Airspeed Indicator	United Instruments
8220B.485	Airspeed Indicator	United Instruments
8230	Airspeed Indicator	United Instruments
8230B.476	Airspeed Indicator	United Instruments
8230B.486	Airspeed Indicator	United Instruments
8235	Airspeed Indicator	United Instruments
8235B.496	Airspeed Indicator	United Instruments

8235B.497	Airspeed Indicator	United Instruments
8240	Airspeed Indicator	United Instruments
8240B.484	Airspeed Indicator	United Instruments
8240B.487	Airspeed Indicator	United Instruments
865DN-5-02	Airspeed Indicator	Kollsman
865DU-03	Airspeed Indicator	Kollsman
865DU-5-03	Airspeed Indicator	Kollsman

Primary Part Number	Nomenclature	Manufacture
865FN-4-043	Airspeed Indicator	Kollsman
865FN-5-02	Airspeed Indicator	Kollsman
865FN-5-028	Airspeed Indicator	Kollsman
865FN-5-031	Airspeed Indicator	Kollsman
865FN-8-029	Airspeed Indicator	Kollsman
865FN-8-032	Airspeed Indicator	Kollsman
865FN-8-04	Airspeed Indicator	Kollsman
865FNU-4-047	Airspeed Indicator	Kollsman
865FNU-8-032	Airspeed Indicator	Kollsman
865FNX-8-035	Airspeed Indicator	Kollsman
865FU-5-03	Airspeed Indicator	Kollsman
865FU-5-033	Airspeed Indicator	Kollsman
865FU-8-013	Airspeed Indicator	Kollsman
865FU-8-036	Airspeed Indicator	Kollsman
865FU-8-041	Airspeed Indicator	Kollsman
865FU-8-042	Airspeed Indicator	Kollsman
89537500001	Airspeed Indicator	Kollsman
895537500002	Airspeed Indicator	Kollsman
8DJ120AAE1	Indicator	Ametek
8DJ120AAP1	Indicator	Ametek
950BU-5-03	Airspeed Indicator	Kollsman
950CU-4-04	Airspeed Indicator	Kollsman
950CU-8-03	Airspeed Indicator	Kollsman
950CU-8-04	Airspeed Indicator	Kollsman
950DX-4-03	Airspeed Indicator	Kollsman
950EX-4-03	Airspeed Indicator	Kollsman
A 29277 10 001	Airspeed Indicator	Kollsman
A 29277 10 021	Airspeed Indicator	Kollsman
A 31777 10 001	Airspeed Indicator	Kollsman
A24330-00-003	Airspeed-Mach Controller	Kollsman
A24950-00-005	Airspeed Transducer	Kollsman
A28061-00-001	Airspeed Transmitter	Kollsman
A29277-10-001	Airspeed Indicator	Kollsman
A29277-10-021	Airspeed Indicator	Kollsman
A29381 04 001	Airspeed Indicator	Kollsman
A29381 04 006	Airspeed Indicator	Kollsman
A30421 10 001	Airspeed Indicator	Kollsman
A31777-10-001	Airspeed Indicator	Kollsman
A32461 10 001	Airspeed Indicator	Kollsman
A32461 10 002	Airspeed Indicator	Kollsman
A32461 10 003	Airspeed Indicator	Kollsman

A3288110001	Airspeed Indicator	Kollsman
A33971 10 005	Indicator	Kollsman
A34091 10 001	Airspeed Indicator	Kollsman

Primary Part Number	Nomenclature	Manufacture
A35111 10 006	Airspeed Indicator	Kollsman
A3519000001	Airspeed Controller	Kollsman
A3615710160	Airspeed Indicator	Kollsman
A3615710260	Airspeed Indicator	Kollsman
A38641 10 003	Airspeed Indicator	Kollsman
A4101910004	Airspeed Indicator	Kollsman
A4144710024	Airspeed Indicator	Kollsman
A4144710025	Airspeed Indicator	Kollsman
A43217-10-018	Airspeed Indicator	Kollsman
AC-118	Airspeed Indicator	US Gauge
AC-118-1	Airspeed Indicator	US Gauge
AC-130	Airspeed Indicator	US Gauge
AC-131	Airspeed Indicator	Karnish
AV-1159C-TS-4620	Airspeed Indicator	GIV
AVU-17/A	Airspeed Indicator	Astek
AVU-8/A	Airspeed Indicator	Astek
AVU-AC/A	Indicator	Bendix
AW-2 3/4-20-B	Airspeed Indicator	US Gauge
AW-2 3/4-20-C	Airspeed Indicator	US Gauge
AW-2 3/4-20-C2	Airspeed Indicator	US Gauge
AW-2 3/4-20-C3	Airspeed Indicator	US Gauge
AW-2-3/4-16BSF12	Airspeed Indicator	US Gauge
AW-2-3/4-16BYF12	Airspeed Indicator	US Gauge
AW2812AH04	Airspeed Indicator	US Gauge
AW2812BC	Airspeed Indicator	Ametek/US Gauge
AW2812BK	Airspeed Indicator	Ametek/US Gauge
AW2812BL	Airspeed Indicator	Ametek/US Gauge
AW2812BL01	Airspeed Indicator	Ametek/US Gauge
AW2812BL04	Airspeed Indicator	Ametek/US Gauge
AW2823AK01	Airspeed Indicator	Ametek/US Gauge
AW2823AK02	Airspeed Indicator	Ametek/US Gauge
AW2823AK03	Airspeed Indicator	Ametek/US Gauge
AW2823AK04	Airspeed Indicator	Ametek/US Gauge
AW2823AK05	Airspeed Indicator	Ametek/US Gauge
AW2823AK06	Airspeed Indicator	Ametek/US Gauge
AW2823AK07	Airspeed Indicator	Ametek/US Gauge
AW2823AK08	Airspeed Indicator	Ametek/US Gauge
AW2823AK09	Airspeed Indicator	Ametek/US Gauge
AW2823AK10	Airspeed Indicator	Ametek/US Gauge
AW2823AK11	Airspeed Indicator	Ametek/US Gauge
AW2823AK12	Airspeed Indicator	Ametek/US Gauge
AW2823AK13	Airspeed Indicator	Ametek/US Gauge
AW2823AK15	Airspeed Indicator	Ametek/US Gauge
AW2823AK16	Airspeed Indicator	Ametek/US Gauge

Primary Part Number	Nomenclature	Manufacture

AW2823AK17	Airspeed Indicator	Ametek/US Gauge
AW2823AK18	Airspeed Indicator	Ametek/US Gauge
AW2823AK19	Airspeed Indicator	Ametek/US Gauge
AW2823AM01	Airspeed Indicator	Ametek/US Gauge
AW2823AM02	Airspeed Indicator	Ametek/US Gauge
AW2829AB01	Airspeed Indicator	Ametek/GE
AW2829AD00	Airspeed Indicator	Ametek/GE
AW2829AD01	Airspeed Indicator	Ametek/GE
AW2829AE01	Airspeed Indicator	Ametek/GE
AW2829AE02	Airspeed Indicator	Ametek/GE
AW2829AE04	Airspeed Indicator	Ametek/GE
AW2829AE05	Airspeed Indicator	Ametek/GE
AW2829AE06	Airspeed Indicator	Ametek/GE
AW2829AE07	Airspeed Indicator	Ametek/GE
AW2829AE08	Airspeed Indicator	Ametek/GE
AW2829AH01	Airspeed Indicator	Ametek/GE
AW2829AH02	Airspeed Indicator	Ametek/GE
AW2829AM01	Airspeed Indicator	Ametek/GE
AW2829AM02	Airspeed Indicator	Ametek/GE
AW2829AM03	Airspeed Indicator	Ametek/GE
AW2829AM04	Airspeed Indicator	Ametek/GE
AW2829AN01	Airspeed Indicator	Ametek/GE
AW2837	Airspeed Indicator	Ametek/GE
B 29277 10 001	Airspeed Indicator	Kollsman
B0101 12101	Airspeed Indicator	Lear Siegler
B0150 14901	Airspeed Indicator	Lear Siegler
B0200-81105	Airspeed Data	Lear Siegler
B0200-81110	Airspeed Data	Lear Siegler
B0200-81111	Airspeed Data	Lear Siegler
B0200-81127	Airspeed Data	Lear Siegler
B0240 23101	Airspeed Indicator	Lear Siegler
B0243 81122	Airspeed Indicator	Lear Siegler
B0243 84112	Airspeed Indicator	Lear Siegler
B0243-81113	Airspeed Data	Lear Siegler
B0243-81921	Airspeed Data	Lear Siegler
B0243-81923	Airspeed Data	Lear Siegler
B0243-81925	Airspeed Data	Lear Siegler
B0245 81110	Airspeed Indicator	Lear Siegler
B0704 10008	Airspeed-Mach Warning Switch	Lear Siegler
B0705 10001	Airspeed-Mach Warning Switch	Lear Siegler
B23661 10 001	Airspeed Indicator	Kollsman
B23661 10 004	Airspeed Indicator	Kollsman
B24302 04 003	Airspeed Indicator	Kollsman
B24330 00 003	Airspeed-Mach Controller	Kollsman

Primary Part Number	Nomenclature	Manufacture
B29277-10-001	Airspeed Indicator	Kollsman
B3288110001	Airspeed Indicator	Kollsman
B36337 10 001	Airspeed Indicator	Kollsman
B38077 10 001	Airspeed Indicator	Kollsman

B38077 10 002	Airspeed Indicator	Kollsman
B38077 10 021	Airspeed Indicator	Kollsman
B4270000001	Airspeed-Mach Transmitter	Kollsman
B-8	Airspeed Indicator	Pioneer
BO151 14901	Airspeed Indicator	Lear Siegler
C0240-23101	Airspeed Indicator	Lear Siegler
C08151 04 005	Airspeed Indicator	Kollsman
C-14	Airspeed Indicator	Pioneer
C18135-10-008	Airspeed Indicator	Kollsman
C18135-10-009	Airspeed Indicator	Kollsman
C18135-10-010	Airspeed Indicator	Kollsman
C19522 04 003	Airspeed Indicator	Kollsman
C19522 04 003W	Airspeed Indicator	Kollsman
C19522 10 001	Airspeed Indicator	Kollsman
C24302 04 003	Airspeed Indicator	Kollsman
C24330 00 003	Airspeed-Mach Controller	Kollsman
C28171 00 015	Airspeed Indicator	Kollsman
C3435210005	Airspeed Indicator	Kollsman
C3435210006	Airspeed Indicator	Kollsman
C3743110001	Airspeed Indicator	Kollsman
C661010-0204	Airspeed Indicator	Cessna
C661010-0206	Airspeed Indicator	Cessna
C661060-0201	Airspeed Indicator	Cessna
C661063-0113	Airspeed Indicator	Cessna
D15590	Airspeed,Controller	Norden Ketay
D15600	Airspeed Indicator	Norden Ketay
E07241 04 003	Airspeed Indicator	Kollsman
E07391 10 057	Airspeed Indicator	Kollsman
E0739104059	Airspeed Indicator	Kollsman
E0739110059	Airspeed Indicator	Kollsman
EA-5171	Airspeed Indicator	Sigma Tek
EA-5172	Airspeed Indicator	Sigma Tek
EA-5173	Airspeed Indicator	Sigma Tek
EA-5174	Airspeed Indicator	Sigma Tek
EA-5174-9-CES	Airspeed Indicator	Sigma Tek
EA-5175	Airspeed Indicator	Electric Auto-Lite Co
EA-5176	Airspeed Indicator	Sigma Tek
EO7241-04-003	Airspeed Indicator	Kollsman
F0739310067	Indicator	Kollsman
F09501-04-003	Airspeed Indicator	Kollsman

Primary Part Number	Nomenclature	Manufacture
F-1	Airspeed Indicator	Pioneer
F-1A	Airspeed Indicator	Pioneer
F-2	Airspeed Indicator	Pioneer
F-3	Airspeed Indicator	Pioneer
H09501 04 003	Airspeed Indicator	Kollsman
JG873A1	Airspeed Indicator	Honeywell
JG873A4	Airspeed Indicator	Honeywell
JG873A5	Airspeed Indicator	Honeywell

KAB05	Airspeed Indicator	Smith Industries
KAB08	Airspeed Indicator	Smith Industries
KAB14	Airspeed Indicator	Smith Industries
KAB2401	Airspeed Indicator	Smith Industries
KAB2402/W/1	Airspeed Indicator	Smith Industries
KAB2403W/1	Airspeed Indicator	Smith Industries
KAD480	Air Data System	Bendix
KDC222	Air Data Computer	Bendix
KMA 0701	Airspeed Indicator	Smith Industries
KMA 0702	Airspeed Indicator	Smith Industries
KS200	Airspeed Transducer	Kollsman
LPE22251-2M	Airspeed Indicator	Pioneer
MO-1	Air Data Control	Eclipse Pioneer
MS28045-T2	Airspeed Indicator	Aerosonic
MS28045-WI	Airspeed Indicator	Aerosonic
NV270AS4	Airspeed Indicator	Smith Industries
PG11A	Airspeed-Mach Controller	Honeywell
PG11A-1	Airspeed-Mach Controller	Honeywell
PG11A-1A	Airspeed-Mach Controller	Honeywell
PG11D-1	Airspeed-Mach Controller	Honeywell
PG11D-2	Airspeed-Mach Controller	Honeywell
PW 0703 KMA/1	Airspeed Indicator	Smith Industries
PW 0704 KMA/1	Airspeed Indicator	Smith Industries
R6610-887-9301-VJNK	Indicator	Kollsman
S-1470N10	Airspeed Indicator	US Gauge
S-15-KAW	Airspeed Indicator	Aerosonic
S15KILR1	Airspeed Indicator	Aerosonic
S-225-3	Airspeed Indicator	Lear Siegler
S-25-KAW	Airspeed Indicator	Aerosonic
S-25-KAW2	Airspeed Indicator	Aerosonic
S-25-KAW3	Airspeed Indicator	Aerosonic
S25KILR1	Airspeed Indicator	Aerosonic
S407A	Airspeed Indicator	Kollsman
S423B	Airspeed Indicator	Kollsman
S423C	Airspeed Indicator	Kollsman
S85-AVU-8/A	Airspeed Indicator	Instrument Tech

Primary Part Number	Nomenclature	Manufacture
S85-AVU-8/A/A	Airspeed Indicator	Instrument Tech
S85-AVU-8/BA	Indicator	Aerosonic
S85-AVU-8/CA	Indicator	Aerosonic
S85-AVU-8B/A	Airspeed Indicator	Instrument Tech
SK-40-10	Indicator	Aerosonic
SK-40-LC-1	Indicator	Aerosonic
SLZ7011A	Vertical Speed Indicator	Teledyne
SLZ9140	Vertical Speed Indicator	Teledyne
SLZ9141	Vertical Speed Indicator	Teledyne
SLZ9157-1	Vertical Speed Indicator	Teledyne
SLZ9157-3	Vertical Speed Indicator	Teledyne
SLZ9200A	Vertical Speed Indicator	Teledyne

SLZ9200A-1	Vertical Speed Indicator	Teledyne
T16-311-200M026	Air Speed Indicator	UMA Inc
UI-8000T	Airspeed Indicator	United Instruments
UI-8030T	Airspeed Indicator	United Instruments
UI-8200	Airspeed Indicator	United Instruments
WL 602 AMA-1	Airspeed Indicator	Smith Industries
WL/111 AMA/JA/1	Airspeed Indicator	Smith Industries
WL/111 AMA/JA/2	Airspeed Indicator	Smith Industries
WL/111AMA/JA/5	Airspeed Indicator	Smith Industries
WL/115 AMA/JA/1	Airspeed Indicator	Smith Industries
WL/115 AMA/JA/3	Airspeed Indicator	Smith Industries
WL/115 AMA/JA/4	Airspeed Indicator	Smith Industries
WL101AMS1	Airspeed Indicator	GE
WL101AMS2	Airspeed Indicator	GE
WL101AMS5	Airspeed Indicator	GE
WL101AMS6	Airspeed Indicator	GE
WL270AS2	Airspeed Indicator	Smith Industries
006-15536-0006	Radar Altimeter	Bendix King
006-5514-01	Altimeter	United Instruments
01-200-102	Altimeter	Smith Industries
01-200-103	Altimeter	Smith Industries
01-200-105	Altimeter	Smith Industries
01-200-106	Altimeter	Smith Industries
03606-0620	ATC Transponder	Narco
03753-0620	Altitude Encoder	Narco
066-01156-0101	ATCRBS Transponder	Bendix King
066-01156-0201	ATCRBS Transponder	Honeywell
066-03064-0005	ALTIMETER	Bendix King
066-1061-01	Radar Altimeter	Bendix King
066-1061-03	Radar Altimeter	Bendix King
066-3054-00	Radar Altimeter Indicator	Bendix King
066-3054-01	Radar Altimeter Indicator	Bendix King

Primary Part Number	Nomenclature	Manufacture
066-3054-03	Radar Altimeter Indicator	Bendix King
066-3054-04	Radar Altitude Indicator	Bendix King
066-3062-01	Altimeter	Bendix King
066-3062-02	Altimeter	Bendix King
066-3062-03	Altimeter	Bendix King
10035-011076	Altimeter	Aerosonic
10035-11326	Altimeter	Aerosonic
10080-0130	Altimeter	Aerosonic
101-00153	Pitot Static Test Set	Barfield
101-00164	Pitot Static Test Set	Barfield
101-00165	Pitot Static Test Set	Barfield
101-00168	Pitot Static Test Set	Barfield
101-00169	Pitot Static Test Set	Barfield
101420	Altimeter	Aerosonic
101435	Altimeter	Aerosonic
101-435-1179	Altimeter	Aerosonic

101450	Altimeter	Aerosonic
101450-31243	Altimeter	Aerosonic
101450-41883	Altimeter	Aerosonic
1014B	ATC Transponder	Sperry
101617	Altimeter	Aerosonic
101627	Altimeter	Aerosonic
101627-01696	Altimeter	Aerosonic
101635	Altimeter	Aerosonic
101720	Altimeter	Aerosonic
101720-01999	Altimeter	Aerosonic
101730	Altimeter	Aerosonic
101735	Altimeter	Aerosonic
101735-011002	Altimeter	Aerosonic
101735-01456	Indicator	Aerosnonic
101735-01500	Indicator	Aerosnonic
101750	Altimeter	Aerosonic
101920	Altimeter	Aerosonic
101935	Altimeter	Aerosonic
102200-01831	Altimeter	Aerosonic
102220-11886	Altimeter	Aerosonic
104-384064-1	Altimeter	Kollsman
104-384065-1	Altimeter	Kollsman
10450	Altimeter	Aerosonic
10450-11525	Altimeter	Aerosonic
10450-3127	Altimeter	Kollsman
10450-31327	Altimeter	Aerosonic
10450-3190	Altimeter	Aerosonic
105A	ATC Transponder	Cessna

Primary Part Number	Nomenclature	Manufacture
10-61826-10	Altimeter	Smith Industries
10-61826-6	SERVOED ALTITUDE INDICATOR	GE
10-61826-8	Altimeter	Smith Industries
1130-013	Altimeter	Kollsman
1130-014	Altimeter	Kollsman
1130-033	Altimeter	Kollsman
1130-034	Altimeter	Kollsman
1-1337-01	Cabin Altimeter	Jaeger
1-1337AA	Cabin Altimeter	Jaeger
1165	Altitude Encoder	IIMorrow
116956-01	Altitude Controller	Lear Siegler
12002-0105	Altimeter	Mac Leod Instrument
12002-0106	Altimeter	Mac Leod Instrument
12003	Altimeter	Mac Leod Instrument
12003M	Altimeter	Mac Leod Instrument
12008-13	Altimeter	Mac Leod Instrument
12008-9	Altimeter	Mac Leod Instrument
12009-1000	Altimeter	Mac Leod Instrument
12009-2000	Altimeter	Mac Leod Instrument
1265X-4-03	Cabin Pressure Indicator	Kollsman

13300-4B	Cabin Altitude Controller	IDC
13300-4C	Cabin Altitude Controller	IDC
13300-4D	Cabin Altitude Controller	IDC
13300-4E	Cabin Altitude Controller	IDC
13-3006	Altimeter	AID
13-3006-1	Altimeter	AID
13-3006-2	Altimeter	AID
13-3006-3	Altimeter	AID
13-3006-4	Altimeter	AID
13-3006-5	Altimeter	AID
13300-7	Cabin Altitude Controller	IDC
13502-0201	Altimeter	Mac Leod Instrument
13502-0202	Altimeter	Mac Leod Instrument
13503	Altimeter	Mac Leod Instrument
13503M	Altimeter	Mac Leod Instrument
13508-1	Altimeter	Mac Leod Instrument
13508-5	Altimeter	Mac Leod Instrument
1350AM/MS/1	Altimeter	Smith Industries
13522-1000	Altimeter	Mac Leod Instrument
13522-1100	Altimeter	Mac Leod Instrument
1521BU-4-02	Cabin Altitude Indicator	Kollsman
1521BX-4-06	Cabin Altitude Indicator	Kollsman
1521U-4-02	Cabin Altitude Indicator	Kollsman
1537-2D-A	Altimeter	Pioneer

Primary Part Number	Nomenclature	Manufacture
1537-2F-B	Altimeter	Pioneer
154019-1	Altitude Encoder	Aero Mechanism
154019-2	Altitude Encoder	Aero Mechanism
154019-3	Altitude Encoder	Aero Mechanism
154019-4	Altitude Encoder	Aero Mechanism
154993-1	Altimeter	Aero Mechanism
154993-1-LX	Altimeter	Aero Mechanism
154993-2	Altimeter	Aero Mechanism
154993-2-LX	Altimeter	Aero Mechanism
154993-3	Altimeter	Aero Mechanism
154993-3-LX	Altimeter	Aero Mechanism
154993-4	Altimeter	Aero Mechanism
154993-4-LX	Altimeter	Aero Mechanism
154993-5	Altimeter	Aero Mechanism
154993-5-LX	Altimeter	Aero Mechanism
154993-6	Altimeter	Aero Mechanism
154993-6-LX	Altimeter	Aero Mechanism
155020-1	Altimeter	Aero Mechanism
155020-1-LX	Altimeter	Aero Mechanism
155020-2	Altimeter	Aero Mechanism
155020-2-LX	Altimeter	Aero Mechanism
15510-1-A	Altitude Controller	Eclipse Pioneer
15510-1-B	Altitude Controller	Eclipse Pioneer
15510-1-C	Altitude Controller	Eclipse Pioneer

15510-1-D	Altitude Controller	Eclipse Pioneer
1555-2P-B	Altimeter	Pioneer
1556-2K-A	Altimeter	Pioneer
155751	Altimeter	Aero Mechanism
1583-2Q-A	Altimeter	Pioneer
1583-2R-A	Altimeter	Pioneer
1587-9A1-A1	Altimeter	Bendix
16007-261	Altimeter	Kollsman
16007-262	Altimeter	Kollsman
16007-3	Altimeter	IDC
16007-408	Altimeter	Kollsman
16007-5	Altimeter	IDC
16007-508	Altimeter	Kollsman
16007-6	Altimeter	IDC
16007-7	Altimeter	IDC
16007-708	Altimeter	Kollsman
16007-808	Altimeter	Kollsman
16100-1	Altimeter	IDC
16100-2	Altimeter	IDC
16100-5	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
16100-6	Altimeter	IDC
16100-7	Altimeter	IDC
16100-8	Altimeter	IDC
16297-1	Cabin Altitude Controller	IDC
16297-2	Cabin Altitude Controller	IDC
16OC180242-1	Altimeter	Clifton Precision
1845X-4-03	Altimeter	Kollsman
1845X4-03D	Altimeter	Kollsman
1845X4-03DF	Altimeter	Kollsman
1846X-4-03	Altimeter	Kollsman
1848X	Altimeter	Kollsman
18960010000	Altimeter Test Set	Kollsman
1C407	Altitude Hold	Century Flight System
1C407-1	Altitude Hold	Century Flight System
1C727	Altitude Hold	Century Flight System
1C727-1	Altitude Hold	Century Flight System
1D747	Altitude Hold	Century Flight System
1U171-002	Altimeter	Sigma Tek
1U171-003	Altimeter	Sigma Tek
1U171-004	Altimeter	Sigma Tek
1U306	Altimeter	Sigma Tek
1U306A	Altimeter	Sigma Tek
1U309A	Altimeter	Sigma Tek
20087-23	Altimeter	Kollsman
20206-03	Altimeter	Kollsman
2027-04-01	Cabin Differential Ind.	Kollsman
2055-01-01	SERVOED ALTITUDE INDICATOR	GE
2057-01-01	Altimeter	Smith Industries

2057-02-01	Altimeter	Smith Industries
2067635-0701	Altimeter	Bendix
2067635-0707	Altimeter	Bendix
2067635-0711	Altimeter	Bendix
2067635-5112	Altimeter	Bendix
2067635-5117	Altimeter	Bendix
2067635-5119	Altimeter	Bendix
2067635-5123	Altimeter	Bendix
2070135-5101	Altimeter	Bendix
2109-2A	Cabin Altimeter	Kearflex
2203J	Altitude Controller	Bendix
2206CX-4-04	Altimeter	Kollsman
2206X-4-03	Altimeter	Kollsman
2206X-4-04	Altimeter	Kollsman
22-371	Altimeter	Electric Auto-Lite Co
22-372	Altimeter	Electric Auto-Lite Co

Primary Part Number	Nomenclature	Manufacture
22-373	Altimeter	Electric Auto-Lite Co
22-374	Altimeter	Kollsman
22-374-B01-2	Altimeter	Kollsman
22-377	Altimeter	Electric Auto-Lite Co
224K-031	Altimeter	Kollsman
22-977-02	Altimeter	Electric Auto-Lite Co
22-980	Altimeter	Garwin
2371-10-02	Altimeter	Kollsman
2371-04-02	Altimeter	Kollsman
2371XL-01-06	Altimeter	Kollsman
24929-934	Altimeter	Kollsman
25-3003-1	Pitot Static Test Set	R C Allen
25-3003-1A	Pitot Static Test Set	R C Allen
25-3003-2	Pitot Static Test Set	R C Allen
25-3003-2A	Pitot Static Test Set	R C Allen
25-3003-3	Pitot Static Test Set	R C Allen
25-3005	Pitot Static Test Set	TGH Aviation
25-3005-1	Pitot Static Test Set	R C Allen
25-3005-2	Pitot Static Test Set	R C Allen
25-3005-2 115 VAC	Pitot Static Test Set	R C Allen
25-3005-3	Pitot Static Test Set	R C Allen
254BK-8-045	Cabin Pressure Indicator	Kollsman
26980-002	Altimeter	Kollsman
26980-101	Altimeter	Kollsman
26980-102	Altimeter	Kollsman
26980-103	Altimeter	Kollsman
26980-104	Altimeter	Kollsman
28007-()	Altimeter	Kollsman
28007-201	Altimeter	Kollsman
28007-202	Altimeter	Kollsman
28007-203	Altimeter	Kollsman
28007-204	Altimeter	IDC

28007-205	Altimeter	IDC
28007-206	Altimeter	Kollsman
28007-207	Altimeter	Kollsman
28007-208	Altimeter	Kollsman
28007-209	Altimeter	Kollsman
28007-210	Altimeter	Kollsman
28007-211	Altimeter	IDC
28007-212	Altimeter	Kollsman
28007-213	Altimeter	Kollsman
28007-214	Altimeter	IDC
28007-215	Altimeter	Kollsman
28007-216	Altimeter	Kollsman

Primary Part Number	Nomenclature	Manufacture
28007-217	Altimeter	Kollsman
28007-218	Altimeter	Kollsman
28007-219	Altimeter	Kollsman
28007-220	Altimeter	Kollsman
28007-221	Altimeter	Kollsman
28007-222	Altimeter	Kollsman
28007-224	Altimeter	Kollsman
28007-225	Altimeter	Kollsman
28007-226	Altimeter	Kollsman
28007-227	Altimeter	Kollsman
28007-228	Altimeter	IDC
28007-229	Altimeter	Kollsman
28007-230	Altimeter	Kollsman
28007-231	Altimeter	Kollsman
28007-261	Altimeter	Kollsman
28007-262	Altimeter	Kollsman
28007-708	Altimeter	Kollsman
28007-921	Altimeter	Kollsman
28007-923	Altimeter	Kollsman
28704-001	Altimeter	IDC
29007-708	Altimeter	Kollsman
29400	Radar Altitude Indicator	IDC
3000-0101	Cabin Altimeter	United Instruments
3019A	Height Indicator	Progressitron
31101-A11	Altitude Encoder	Kollsman
31101-B1	Altitude Encoder	Bendix
31101-B11	Altitude Encoder	Bendix
31101-B13	Altitude Encoder	Bendix
31101-B22	Altitude Encoder	Bendix
31101-B26	Altitude Encoder	Bendix
31101-B27	Altitude Encoder	Bendix
31101-B28	Altitude Encoder	Bendix
31101-B3	Altitude Encoder	Bendix
31101-B32	Altitude Encoder	Bendix
31101-B7	Altitude Encoder	Bendix
31103-A1A	Altitude Computer	Bendix

31103-A22	Altitude Computer	Bendix
31103-A24	Altitude Computer	Bendix
31103-A25	Altitude Computer	Bendix
31103-B14	Altitude Computer	Bendix
3139-1-A	Altitude Alert System	Eclipse Pioneer
31400-002	Altimeter	Kollsman
31400-003	Altimeter	Kollsman
31400-004	Altimeter	Kollsman

Primary Part Number	Nomenclature	Manufacture
31400-005	Altimeter	Kollsman
31400-007	Altimeter	Kollsman
31400-008	Altimeter	Kollsman
31400-011	Altimeter	Kollsman
31400-013	Altimeter	Kollsman
31400-014	Altimeter	Kollsman
31400-015	Altimeter	Kollsman
31400-016	Altimeter	Kollsman
31400-017	Altimeter	Kollsman
31400-018	Altimeter	Kollsman
314200-01-01	Altimeter	Lear Siegler
314200-02-01	Altimeter	Lear Siegler
314200-03-01	Altimeter	Lear Siegler
314200-04-01	Altimeter	Lear Siegler
314200-05-01	Altimeter	Lear Siegler
314200-06-01	Altimeter	Lear Siegler
314200-07-01	Altimeter	Lear Siegler
314200-08-01	Altimeter	Lear Siegler
314200-09-01	Altimeter	Lear Siegler
314200-10-01	Altimeter	Lear Siegler
314200-11-01	Altimeter	Lear Siegler
314200-12-01	Altimeter	Lear Siegler
314200-13-01	Altimeter	Lear Siegler
314200-14-01	Altimeter	Lear Siegler
314200-15-01	Altimeter	Lear Siegler
314200-16-01	Altimeter	Lear Siegler
314200-17-01	Altimeter	Lear Siegler
314200-18-01	Altimeter	Lear Siegler
314200-19-01	Altimeter	Lear Siegler
314200-20-01	Altimeter	Lear Siegler
314200-21-01	Altimeter	Lear Siegler
314200-22-01	Altimeter	Lear Siegler
314200-23-01	Altimeter	Lear Siegler
314200-24-01	Altimeter	Lear Siegler
314300-03-01	Altimeter	Lear Siegler
3252001-0101	Altimeter	Bendix
3252010-0101	Altimeter	Kollsman
3252010-1101	Altimeter	Clifton Precision
3252011-0101	Altimeter	Kollsman
3252011-0301	Altimeter	Kollsman

3252011-1101	Altimeter	Kollsman
3252011-1501	Altimeter	Kollsman
3252013-0101	Altimeter	Bendix
3252013-0201	Altimeter	Bendix

Primary Part Number	Nomenclature	Manufacture
3252013-0401	Altimeter	Bendix
3252013-0501	Altimeter	Bendix
3252013-0601	Altimeter	Bendix
3252013-0701	Altimeter	Bendix
3252013-0801	Altimeter	Bendix
3252013-0901	Altimeter	Bendix
3252013-1101	Altimeter	Bendix
3252013-1201	Altimeter	Bendix
3252013-1401	Altimeter	Bendix
3252013-1501	Altimeter	Bendix
3252014-0601	Altimeter	Bendix
3252014-0701	Altimeter	Bendix
3252014-0801	Altimeter	Bendix
3252014-0901	Altimeter	Bendix
3252014-1001	Altimeter	Bendix
3252014-1101	Altimeter	Bendix
3252014-1201	Altimeter	Bendix
3252014-1301	Altimeter	Bendix
3252022-0101	Altimeter	Clifton Precision
3252022-0201	Altimeter	Clifton Precision
325210-0101	Altimeter	Kollsman
3311A-J44	Cabin Altimeter	United Instruments
3311A-J61	Cabin Altimeter	United Instruments
3311A-J67	Cabin Altimeter	United Instruments
3311A-J68	Cabin Altimeter	United Instruments
339H-1/1A/1B	Radar Altitude Indicator	Collins
339H-2	Radar Altitude Indicator	Collins
339H-4	Radar Altitude Indicator	Collins
339H-4A	Radar Altitude Indicator	Collins
35-3-46B	Altimeter	United Instruments
36920-001	Altimeter	Kollsman
371	Altimeter	Kollsman
37-1000	Altimeter	AID
37-1001	Altimeter	AID
37-1001-1	Altimeter	AID
37-1001-2	Altimeter	AID
37-1001-4	Altimeter	AID
37-1005	Altimeter	AID
371-4-01	Altimeter	Kollsman
371K-010	Altimeter	Kollsman
371K-05	Altimeter	Kollsman
371P-4-01	Altimeter	Kollsman
374	Altimeter	Weston
375	Altimeter	Weston

Primary Part Number	Nomenclature	Manufacture
37500-(XXX)	Altimeter	Badin
375A	Altimeter	Electric Auto-Lite Co
375B	Altimeter	Electric Auto-Lite Co
37630-001	Altimeter	Kollsman
38547	Altitude Hold Sensor	ARC
3A50/3A51	Altimeter	Thommen
3A54/3A55	Altimeter	Thommen
3A62/3A63	Altimeter	Thommen
3A66/3A67	Altimeter	Thommen
400447-903	Radar Altitude Indicator	Sperry
4005123-901	Altimeter	Honeywell
4005123-902	Altimeter	Honeywell
4005123-903	Altimeter	Honeywell
4005123-906	Altimeter	Honeywell
4005123-907	Altimeter	Honeywell
4016341-901	Altimeter	Sperry
4016341-902	Altimeter	Sperry
4016341-903	Altimeter	Sperry
4016341-904	Altimeter	Sperry
4016341-905	Altimeter	Sperry
4016341-906	Altimeter	Sperry
4016341-907	Altimeter	Sperry
4018285-906	Altitude Alert System	Sperry
4018285-907	Altitude Alert System	Sperry
4018285-909	Altitude Alert System	Sperry
4019953-904	Altimeter	Sperry
4019953-905	Altimeter	Sperry
40400-101	Altimeter	Kollsman
40400-105	Altimeter	Kollsman
40400-111	Altimeter	Kollsman
41707	Altimeter	IDC
42540-2114	Altimeter	Cessna
42540-2128	Altimeter	Cessna
42540-2214	Altimeter	Cessna
42540-2228	Altimeter	Cessna
42540-3114	Altimeter	Cessna
42540-3128	Altimeter	Cessna
42540-3214	Altimeter	Cessna
42540-3228	Altimeter	Cessna
42540-4114	Altimeter	Cessna
42540-4128	Altimeter	Cessna
42540-4214	Altimeter	Cessna
42540-4228	Altimeter	Cessna
42540-5114	Altimeter	Cessna

Primary Part Number	Nomenclature	Manufacture
42540-5128	Altimeter	Cessna
42540-5214	Altimeter	Cessna

42540-5228	Altimeter	Cessna
42540-6114	Altimeter	Cessna
42540-6128	Altimeter	Cessna
42540-6214	Altimeter	Cessna
42540-6228	Altimeter	Cessna
42540-7114	Altimeter	Cessna
42540-7128	Altimeter	Cessna
42540-7214	Altimeter	Cessna
42540-7228	Altimeter	Cessna
428-2003	Altitude Encoder	IIMorrow
43300-6128	Altimeter	Cessna
43300-6228	Altimeter	Cessna
43932-052	Altimeter	Kollsman
44707-B2261	Altimeter	Kollsman
44929-013	Altimeter	Kollsman
45050-1103	Altimeter	Aerosonic
462	Altimeter	IFR
46-20	Altimeter	IFR
48707-001	Altimeter	IDC
48707-002	Altimeter	IDC
48707-003	Altimeter	IDC
48707-101	Altimeter	IDC
48707-102	Altimeter	IDC
48707-103	Altimeter	IDC
48707-104	Altimeter	IDC
48707-201	Altimeter	IDC
48707-202	Altimeter	IDC
48707-203	Altimeter	IDC
48707-204	Altimeter	IDC
487107-004	Altimeter	IDC
5035	Altimeter	United Instruments
5035P	Altimeter	United Instruments
518-16007	Altimeter	IDC
518-16007-1	Altimeter	IDC
518-16007-160	Altimeter	IDC
518-16007-300	Altimeter	IDC
518-16007-311	Altimeter	IDC
518-16007-312	Altimeter	IDC
518-16007-313	Altimeter	IDC
518-16007-314	Altimeter	IDC
518-16007-331	Altimeter	IDC
518-16007-332	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
518-16007-333	Altimeter	IDC
518-16007-334	Altimeter	IDC
518-16007-335	Altimeter	IDC
518-16007-336	Altimeter	IDC
518-16007-337	Altimeter	IDC
518-16007-338	Altimeter	IDC

518-16007-60	Altimeter	IDC
518-16007-760	Altimeter	IDC
518-16007-A14	Altimeter	IDC
518-16007-B40	Altimeter	IDC
518-28007	Altimeter	Kollsman
518-28007 ()	Altimeter	Kollsman
518-28007-001	Altimeter	IDC
518-28007-002	Altimeter	IDC
518-28007-003	Altimeter	IDC
518-28007-004	Altimeter	IDC
518-28007-005	Altimeter	IDC
518-28007-006	Altimeter	IDC
518-28007-007	Altimeter	IDC
518-28007-008	Altimeter	IDC
518-28007-011	Altimeter	IDC
518-28007-012	Altimeter	IDC
518-28007-015	Altimeter	IDC
518-28007-016	Altimeter	IDC
518-28007-209	Altimeter	IDC
518-28007-210	Altimeter	IDC
518-28007-211	Altimeter	IDC
518-28007-212	Altimeter	IDC
518-28007-213	Altimeter	IDC
518-28007-214	Altimeter	IDC
518-28007-215	Altimeter	IDC
518-28007-216	Altimeter	IDC
518-28007-217	Altimeter	IDC
518-28007-218	Altimeter	IDC
518-28007-219	Altimeter	IDC
518-28007-220	Altimeter	IDC
518-28007-427	Altimeter	IDC
518-28007-429	Altimeter	IDC
518-28007-431	Altimeter	IDC
518-28007-433	Altimeter	IDC
518-28007-921	Altimeter	Kollsman
518-28007-923	Altimeter	Kollsman
519-22702-500	Altimeter	IDC
519-28702	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
519-28704-()	Altimeter	IDC
520-26980	Altimeter	IDC
521-29007-001	Altimeter	IDC
521-29007-002	Altimeter	IDC
521-29007-003	Altimeter	IDC
521-29007-004	Altimeter	IDC
521-29007-005	Altimeter	IDC
521-29007-006	Altimeter	IDC
521-29007-007	Altimeter	IDC
521-29007-008	Altimeter	IDC

521-29007-009	Altimeter	IDC
521-29007-010	Altimeter	IDC
521-29007-011	Altimeter	IDC
521-29007-012	Altimeter	IDC
521-29007-013	Altimeter	IDC
521-29007-014	Altimeter	IDC
521-29007-015	Altimeter	IDC
521-29007-016	Altimeter	IDC
521-29007-018	Altimeter	IDC
521-29007-019	Altimeter	IDC
521-29007-020	Altimeter	IDC
521-29007-021	Altimeter	IDC
521-29007-022	Altimeter	IDC
521-29007-023	Altimeter	IDC
521-29007-024	Altimeter	IDC
521-29007-025	Altimeter	IDC
521-29007-026	Altimeter	IDC
521-29007-027	Altimeter	IDC
521-29007-028	Altimeter	IDC
521-29007-029	Altimeter	IDC
521-29007-030	Altimeter	IDC
521-29007-031	Altimeter	IDC
521-29007-032	Altimeter	IDC
521-29007-033	Altimeter	IDC
521-29007-034	Altimeter	IDC
521-29007-035	Altimeter	IDC
521-29007-036	Altimeter	IDC
521-29007-037	Altimeter	IDC
521-29007-038	Altimeter	IDC
521-29007-039	Altimeter	IDC
521-29007-040	Altimeter	IDC
521-29007-041	Altimeter	IDC
521-29007-042	Altimeter	IDC
521-29007-043	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
521-29007-044	Altimeter	IDC
521-29007-046	Altimeter	IDC
521-29007-047	Altimeter	IDC
521-29007-048	Altimeter	IDC
521-29007-049	Altimeter	IDC
521-29007-050	Altimeter	IDC
521-29007-051	Altimeter	IDC
521-29007-052	Altimeter	IDC
521-29007-053	Altimeter	IDC
521-29007-054	Altimeter	IDC
521-29007-055	Altimeter	IDC
521-29007-056	Altimeter	IDC
521-29007-057	Altimeter	IDC
521-29007-058	Altimeter	IDC

521-29007-059	Altimeter	IDC
521-29007-060	Altimeter	IDC
521-29007-061	Altimeter	IDC
521-29007-062	Altimeter	IDC
521-29007-063	Altimeter	IDC
521-29007-064	Altimeter	IDC
521-29007-065	Altimeter	IDC
521-29007-066	Altimeter	IDC
521-29007-067	Altimeter	IDC
521-29007-068	Altimeter	IDC
521-29007-069	Altimeter	IDC
521-29007-070	Altimeter	IDC
521-29007-071	Altimeter	IDC
521-29007-072	Altimeter	IDC
521-29007-073	Altimeter	IDC
521-29007-074	Altimeter	IDC
521-29007-0745	Altimeter	IDC
521-29007-075	Altimeter	IDC
521-29007-076	Altimeter	IDC
521-29007-077	Altimeter	IDC
521-29007-078	Altimeter	IDC
521-29007-079	Altimeter	IDC
521-29007-080	Altimeter	IDC
521-29007-081	Altimeter	IDC
521-29007-082	Altimeter	IDC
521-29007-083	Altimeter	IDC
521-29007-084	Altimeter	IDC
521-29007-085	Altimeter	IDC
521-29007-086	Altimeter	IDC
521-29007-087	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
521-29007-088	Altimeter	IDC
521-29007-089	Altimeter	IDC
521-29007-090	Altimeter	IDC
521-29007-091	Altimeter	IDC
521-29007-092	Altimeter	IDC
521-29007-093	Altimeter	IDC
521-29007-094	Altimeter	IDC
521-29007-095	Altimeter	IDC
521-29007-096	Altimeter	IDC
521-29007-097	Altimeter	IDC
521-29007-098	Altimeter	IDC
521-29007-099	Altimeter	IDC
521-29007-17	Altimeter	IDC
521-29007-700	Altimeter	IDC
521-29007-800	Altimeter	IDC
522-29711-001	Altimeter	IDC
522-29711-4000	Altimeter	IDC
522-29711-4001	Altimeter	IDC

522-29711-4002	Altimeter	IDC
522-29711-4003	Altimeter	IDC
522-29711-4004	Altimeter	IDC
522-29711-4005	Altimeter	IDC
522-29711-4006	Altimeter	IDC
522-29711-4007	Altimeter	IDC
522-29711-4008	Altimeter	IDC
522-29711-4021	Altimeter	IDC
522-29711-4022	Altimeter	IDC
522-29711-4051	Altimeter	IDC
522-29711-4501	Altimeter	IDC
522-29711-4502	Altimeter	IDC
522-29711-4503	Altimeter	IDC
522-29711-4504	Altimeter	IDC
522-29711-4601	Altimeter	IDC
522-29711-4602	Altimeter	IDC
522-29711-4603	Altimeter	IDC
522-29711-4604	Altimeter	IDC
522-29711-4801	Altimeter	IDC
522-29711-4802	Altimeter	IDC
522-29711-4803	Altimeter	IDC
522-29711-4804	Altimeter	IDC
522-29711-4805	Altimeter	IDC
522-29711-4806	Altimeter	IDC
522-29711-4807	Altimeter	IDC
522-29711-4808	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
522-29711-4901	Altimeter	IDC
522-29711-4902	Altimeter	IDC
522-29711-4903	Altimeter	IDC
522-29711-4904	Altimeter	IDC
522-29711-4907	Altimeter	IDC
522-29711-4908	Altimeter	IDC
522-29711-4913	Altimeter	IDC
522-29711-4914	Altimeter	IDC
522-29711-4921	Altimeter	IDC
522-29711-4922	Altimeter	IDC
522-3698-002	Radio Altimeter	Rockwell Collins
522-3698-003	Radio Altimeter	Rockwell Collins
522-3698-004	Radio Altimeter	Rockwell Collins
522-3698-005	Radio Altimeter	Rockwell Collins
522-3698-006	Radio Altimeter	Rockwell Collins
522-4114-002	Radar Altitude Indicator	Collins
523-29702	Altimeter	IDC
525-18711-B3	Altimeter	IDC
525-18711-B4	Altimeter	IDC
528-49707-010	Altimeter	IDC
528-49707-100	Altimeter	IDC
528-49707-300	Altimeter	IDC

540-20545-007	Altitude Alerter	IDC
540-20545-008	Altitude Alerter	IDC
540-22722-001	Altitude Alerter	IDC
540-22722-002	Altitude Alerter	IDC
540-22722-004	Altitude Alerter	IDC
540-25050	Altitude Alerter	IDC
540-25100	Altitude Alerter	IDC
54141-564-1	Altimeter	Jaeger
544KN-02	Altimeter	Kollsman
544KN-04	Altimeter	Kollsman
544KN-05	Altimeter	Kollsman
5506-S	Altimeter	United Instruments
570-23932-001	Altimeter	IDC
570-23932-002	Altimeter	IDC
570-23932-003	Altimeter	IDC
570-23932-004	Altimeter	IDC
570-23932-005	Altimeter	IDC
570-23932-006	Altimeter	IDC
570-23932-008	Altimeter	IDC
570-23932-011	Altimeter	IDC
570-23932-012	Altimeter	IDC
570-23932-013	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
570-23932-014	Altimeter	IDC
570-23932-021	Altimeter	IDC
570-23932-022	Altimeter	IDC
570-23932-023	Altimeter	IDC
570-23932-024	Altimeter	IDC
570-23932-031	Altimeter	IDC
570-23932-032	Altimeter	IDC
570-23932-033	Altimeter	IDC
570-23932-034	Altimeter	IDC
570-23932-043	Altimeter	IDC
570-23932-051	Altimeter	IDC
570-23932-053	Altimeter	IDC
570-23932-054	Altimeter	IDC
570-23932-056	Altimeter	IDC
570-23932-201	Altimeter	IDC
570-23932-202	Altimeter	IDC
570-23932-203	Altimeter	IDC
570-23932-211	Altimeter	IDC
570-23932-212	Altimeter	IDC
570-23932-213	Altimeter	IDC
570-23932-214	Altimeter	IDC
570-23932-301	Altimeter	IDC
570-23932-302	Altimeter	IDC
570-23932-303	Altimeter	IDC
570-23932-304	Altimeter	IDC
570-23932-311	Altimeter	IDC

570-23932-312	Altimeter	IDC
570-23932-313	Altimeter	IDC
570-23932-314	Altimeter	IDC
570-23932-401	Altimeter	IDC
570-23932-402	Altimeter	IDC
570-23932-403	Altimeter	IDC
570-23932-404	Altimeter	IDC
570-23932-411	Altimeter	IDC
570-23932-412	Altimeter	IDC
570-23932-413	Altimeter	IDC
570-23932-414	Altimeter	IDC
570-23932-901	Altimeter	IDC
570-23932-902	Altimeter	IDC
570-23932-951	Altimeter	IDC
570-2429	Altimeter	IDC
570-24929-001	Altimeter	IDC
570-24929-002	Altimeter	IDC
570-24929-003	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
570-24929-004	Altimeter	IDC
570-24929-005	Altimeter	IDC
570-24929-006	Altimeter	IDC
570-24929-007	Altimeter	IDC
570-24929-008	Altimeter	IDC
570-24929-011	Altimeter	IDC
570-24929-012	Altimeter	IDC
570-24929-013	Altimeter	IDC
570-24929-014	Altimeter	IDC
570-24929-015	Altimeter	IDC
570-24929-016	Altimeter	IDC
570-24929-017	Altimeter	IDC
570-24929-018	Altimeter	IDC
570-24929-021	Altimeter	IDC
570-24929-022	Altimeter	IDC
570-24929-023	Altimeter	IDC
570-24929-024	Altimeter	IDC
570-24929-025	Altimeter	IDC
570-24929-026	Altimeter	IDC
570-24929-027	Altimeter	IDC
570-24929-028	Altimeter	IDC
570-24929-029	Altimeter	IDC
570-24929-030	Altimeter	IDC
570-24929-031	Altimeter	IDC
570-24929-032	Altimeter	IDC
570-24929-101	Altimeter	IDC
570-24929-102	Altimeter	IDC
570-24929-103	Altimeter	IDC
570-24929-104	Altimeter	IDC
570-24929-105	Altimeter	IDC

570-24929-106	Altimeter	IDC
570-24929-201	Altimeter	IDC
570-24929-202	Altimeter	IDC
570-24929-203	Altimeter	IDC
570-24929-204	Altimeter	IDC
570-24929-211	Altimeter	IDC
570-24929-212	Altimeter	IDC
570-24929-213	Altimeter	IDC
570-24929-214	Altimeter	IDC
570-24929-301	Altimeter	IDC
570-24929-302	Altimeter	IDC
570-24929-303	Altimeter	IDC
570-24929-304	Altimeter	IDC
570-24929-311	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
570-24929-312	Altimeter	IDC
570-24929-313	Altimeter	IDC
570-24929-314	Altimeter	IDC
570-24929-401	Altimeter	IDC
570-24929-402	Altimeter	IDC
570-24929-403	Altimeter	IDC
570-24929-404	Altimeter	IDC
570-24929-411	Altimeter	IDC
570-24929-412	Altimeter	IDC
570-24929-413	Altimeter	IDC
570-24929-414	Altimeter	IDC
570-24929-501	Altimeter	IDC
570-24929-502	Altimeter	IDC
571-25005-001	Altimeter	IDC
571-25005-002	Altimeter	IDC
571-25005-011	Altimeter	IDC
571-25005-012	Altimeter	IDC
571-25005-021	Altimeter	IDC
571-25005-022	Altimeter	IDC
571-25005-031	Altimeter	IDC
571-25005-032	Altimeter	IDC
571-25005-041	Altimeter	IDC
571-25005-042	Altimeter	IDC
571-25005-051	Altimeter	IDC
571-25005-052	Altimeter	IDC
571-25005-101	Altimeter	IDC
571-25005-102	Altimeter	IDC
571-25005-111	Altimeter	IDC
571-25005-112	Altimeter	IDC
571-25005-121	Altimeter	IDC
571-25005-122	Altimeter	IDC
571-25005-201	Altimeter	IDC
571-25005-202	Altimeter	IDC
571-25005-211	Altimeter	IDC

571-25005-212	Altimeter	IDC
571-25005-221	Altimeter	IDC
571-25005-222	Altimeter	IDC
571-25005-301	Altimeter	IDC
571-25005-302	Altimeter	IDC
571-25005-311	Altimeter	IDC
571-25005-312	Altimeter	IDC
571-25005-321	Altimeter	IDC
571-25005-322	Altimeter	IDC
571-25005-501	Altimeter	IDC

Primary Part Number	Nomenclature	Manufacture
571-25005-502	Altimeter	IDC
571-29020	Altimeter	IDC
5932	Altimeter	United Instruments
5932A	Altimeter	United Instruments
5932AP	Altimeter	United Instruments
5932P	Altimeter	United Instruments
5934	Altimeter	United Instruments
5934-1	Altimeter	United Instruments
5934-1D	Altimeter	United Instruments
5934A	Altimeter	United Instruments
5934A-1	Altimeter	United Instruments
5934A-1D	Altimeter	United Instruments
5934AD-1	Altimeter	United Instruments
5934AD-1D	Altimeter	United Instruments
5934AM	Altimeter	United Instruments
5934AM-1	Altimeter	United Instruments
5934AM-1D	Altimeter	United Instruments
5934D-1D	Altimeter	United Instruments
5934M	Altimeter	United Instruments
5934M-1	Altimeter	United Instruments
5934M-1D	Altimeter	United Instruments
5934P	Altimeter	United Instruments
5934P-1	Altimeter	United Instruments
5934PA	Altimeter	United Instruments
5934PA-1	Altimeter	United Instruments
5934PA-1D	Altimeter	United Instruments
5934PA-1L	Altimeter	United Instruments
5934PA-A93	Altimeter	United Instruments
5934PAD-1	Altimeter	United Instruments
5934PAD-1D	Altimeter	United Instruments
5934PAM	Altimeter	United Instruments
5934PAM-1	Altimeter	United Instruments
5934PAM-1D	Altimeter	United Instruments
5934PAM-1L	Altimeter	United Instruments
5934PD-1	Altimeter	United Instruments
5934PD-1D	Altimeter	United Instruments
5934PD-3	Altimeter	United Instruments
5934PM	Altimeter	United Instruments

5934PM-1	Altimeter	United Instruments
5934PM-1D	Altimeter	United Instruments
6000	Pitot Static Test Set	QED/Johnson Instrum
6000 SERIES	Pitot Static Test Set	QED/Johnson Instrum
600-0083-000	Altitude Encoder Circuit Board	Spectronics
6097768-100	ATC Transponder	Sperry

Primary Part Number	Nomenclature	Manufacture
622-1270-001	ATC Transponder	Collins
622-9210-004	ATC Mode S Transponder	Collins
622-9210-005	ATC Mode S Transponder	Collins
622-9210-006	ATC Mode S Transponder	Collins
622-9210-007	ATC Mode S Transponder	Collins
622-9210-008	ATC Mode S Transponder	Collins
622-9210-108	ATC Mode S Transponder	Collins
622-9352-002	ATC Mode S Transponder	Collins
622-9352-003	ATC Mode S Transponder	Collins
622-9352-004	ATC Mode S Transponder	Collins
622-9352-005	ATC Mode S Transponder	Collins
622-9352-006	ATC Mode S Transponder	Collins
622-9352-007	ATC Mode S Transponder	Collins
622-9352-008	ATC Mode S Transponder	Collins
622-9352-108	ATC Mode S Transponder	Collins
640-22722-003	Altitude Alerter	IDC
64111-950-1	Altimeter	Thomson
64111-951-1	Altimeter	Thomson
64111-952-1	Altimeter	Thomson
64141-360-1	Altimeter	Sextant
64141-361-1	Altimeter	Sextant
64141-362-1	Altimeter	Sextant
64141-370-1	Altimeter	Sextant
64141-372-1	Altimeter	Sextant
64141-520-1	Altimeter	Thomson
64141-530-1	Altimeter	Thomson
64141-560-1	Altimeter	Jaeger
64141-564-1	Altimeter	Jaeger
64141-570-1	Altimeter	Jaeger
64141-573-1	Altimeter	Jaeger
64142-523-1	Altimeter	Jaeger
64142-540-1	Altimeter	Jaeger
661206	Altitude Controller	Sperry
664374	Altitude Controller	Sperry
671	Altimeter	Kollsman
671BK-010	Altimeter	Kollsman
671BK-011	Altimeter	Kollsman
671BK-03	Altimeter	Kollsman
671BK-07	Altimeter	Kollsman
671BU-010	Altimeter	Kollsman
671CK-010	Altimeter	Kollsman
671CK-018	Altimeter	Kollsman

671CKL-010	Altimeter	Kollsman
671CLU-4-035	Altimeter	Kollsman

Primary Part Number	Nomenclature	Manufacture
671CLU4-035	Altimeter	Kollsman
671CLU4-035D	Altimeter	Kollsman
671CLU4-035DF	Altimeter	Kollsman
671CLU-4-038	Altimeter	Kollsman
671CLU-8-030	Altimeter	Kollsman
671CP-19-017	Altimeter	Kollsman
671CP-8-016	Altimeter	Kollsman
671CPU-015	Altimeter	Kollsman
671CPU-19-015	Altimeter	Kollsman
671CPU19-015	Altimeter	Kollsman
671CPU19-015D	Altimeter	Kollsman
671CPU19-015DF	Altimeter	Kollsman
671CPU-8-030	Altimeter	Kollsman
671CPX-10-051	Sensitive Altimeter	Kollsman
671CPX-4-037	Altimeter	Kollsman
671CPX4-037D	Altimeter	Kollsman
671CPX4-037DF	Altimeter	Kollsman
671CPX-4-038	Altimeter	Kollsman
671CU-015	Altimeter	Kollsman
671K-03	Altimeter	Kollsman
671P-19-017	Altimeter	Kollsman
691-1201	Altimeter	Kollsman
7000839-901	Altimeter	Sperry
7000839-902	Altimeter	Sperry
7000839-903	Altimeter	Sperry
7000839-904	Altimeter	Sperry
7000839-905	Altimeter	Sperry
7000839-906	Altimeter	Sperry
709	Altimeter	Kollsman
709K-01	Altimeter	Kollsman
720-15900	Cabin Altitude Rate And Diff.	IDC
72A219006	Height Indicator	Stewart Warner
744BKN-02	Altimeter	Kollsman
744BKN-04	Altimeter	Kollsman
744BKN-08	Altimeter	Kollsman
744KN-02	Altimeter	Kollsman
74830	Altimeter	Hamilton Standard
7502BC Series	Radar Altimeter Systems	Honeywell
751AM/FA/1	Altimeter	Smith Industries
8.040.(XXX).2	Altimeter	Aeritalia
8.040.008.1	Altimeter	Aeritalia
8.040.503	Altimeter	Aeritalia
8.040.508.1	Altimeter	Aeritalia
8.040.603	Altimeter	Aeritalia

Primary Part Number	Nomenclature	Manufacture

8.040.608.1	Altimeter	Aeritalia
8.040.703	Altimeter	Aeritalia
8.040.708.1	Altimeter	Aeritalia
8.040.900-3	Altimeter	Aeritalia
8.040.910-3	Altimeter	Aeritalia
8018	Altimeter	AMINC
8040B	Altimeter	Aero Mechanism
8047/10NVG	Altimeter	Ultra Electronics
8047-20A	Altimeter	Aero Mechanism
8047-20B	Altimeter	Aero Mechanism
81-22-22	Altimeter	Marconi
8140	Altimeter	Aero Mechanism
8140B	Altimeter	Aero Mechanism
8140B-20	Altimeter	Aero Mechanism
8140-LR	Altimeter	Aero Mechanism
8140-LW	Altimeter	Aero Mechanism
8142	Altimeter	Aero Mechanism
8142B	Altimeter	Aero Mechanism
8142-LR	Altimeter	Aero Mechanism
8142-LW	Altimeter	Aero Mechanism
8161B	Altimeter	Aero Mechanism Inc
859A	Altitude Transponder	Cessna
8800-M	Altitude Encoder	Shadin Avionics
8800-T	Altitude Encoder	Shadin Avionics
88430409004	Altimeter	Kollsman
940	Altimeter	Kollsman
940L-02	Altimeter	Kollsman
987-10-031	Altimeter	Kollsman
995-29400	Radar Altitude Indicator	IDC
A-20(0105)	Altimeter	Aerosonic
A25561-04-001	Altimeter	Bendix
A26541 10 001	Altimeter	Kollsman
A27397-10-004	Cabin Pressure Indicator	Kollsman
A2796000003	Altitude Controller	Kollsman
A28934 04 002	Altimeter	Kollsman
A29167-10-001	Altimeter	Kollsman
A29534 01 004	Altimeter	Kollsman
A29534 04 001	Altimeter	Kollsman
A-30	Altitude Encoder	ACK Technologies
A30357-04-001	Cabin Altimeter	Kollsman
A32057 10 001	Altimeter	Kollsman
A32057 10 021	Altimeter	Kollsman
A32657 10 001	Altimeter	Kollsman
A32657 10 006	Altimeter	Kollsman

Primary Part Number	Nomenclature	Manufacture
A33014-10-008	Altimeter	Kollsman
A34160-00-001	Altitude Controller	Kollsman
A35-AAU-8A/A	Altimeter	Aerosonic
A35AAU8AA	Altimeter	Aerospace Corporatic

A35AAU8AAF	Altimeter	Aerospace Corporatic
A3811910008	Altimeter	Kollsman
A3943910101	Altimeter	Kollsman
A4017910028	Altimeter	Kollsman
A4132210003	Altimeter	Kollsman
A4132210015	Altimeter	Kollsman
A4186910015	Altimeter	Kollsman
A4289910012	Altimeter	Kollsman
A4289910016	Altimeter	Kollsman
A42899-10-016	Altimeter	Kollsman
A4289910115	Altimeter	Kollsman
A4289910216	Altimeter	Kollsman
A42899-10-216	Altimeter	Kollsman
A4289910217	Altimeter	Kollsman
A42899-10-217	Altimeter	Kollsman
A428991022	Altimeter	Kollsman
A4289910315	Altimeter	Kollsman
A4370000001	Altitude Computer	Kollsman
A4370000003	Altitude Encoder	Kollsman
A4370000007	Altitude Encoder	Kollsman
A4370000010	Altitude Encoder	Kollsman
A4370000011	Altitude Encoder	Kollsman
A4370000013	Altitude Encoder	Kollsman
A4370000022	Altitude Encoder	Kollsman
A4370000026	Altitude Encoder	Kollsman
A4370000027	Altitude Encoder	Kollsman
A4370000028	Altitude Encoder	Kollsman
A4370000030	Altitude Encoder	Kollsman
A4370000032	Altitude Encoder	Kollsman
A4370000039	Altitude Encoder	Kollsman
A4370000050	Altitude Encoder	Kollsman
A50-MA-3	Altimeter	Aerosonic
A8/A-10-3	Altimeter	Aerosonic
A80AAU8A	Altimeter	Aerosonic
A80AAU8AA	Altimeter	Aerosonic
A80AAU8AF	Altimeter	Aerosonic
A-80-MA	Altimeter	Aerosonic
A80MA1	Altimeter	Aerosonic
A80MA1F	Altimeter	Aerosonic
A80MB	Altimeter	Aerosonic

Primary Part Number	Nomenclature	Manufacture
A-80-MB	Altimeter	Aerosonic
A80MBF	Altimeter	Aerosonic
AA-801A	Altitude Alerter	Cessna
AAU-21/A	Altimeter	Kollsman
AAU-24/A	Altimeter	Kollsman
AAU-27/A	Altimeter	Aerosonic
AAU31/A	Altimeter	Kollsman
AAU-31/A	Altimeter	Kollsman

AAU-32/A	Altimeter	Kollsman
AAU-32/A-1	Altimeter	Aerosonic
AAU-32/A-2	Altimeter	Kollsman
AAU-32/A-3	Altimeter	Kollsman
AAU-32/A-4	Altimeter	Kollsman
AAU-3A/A	Cabin Altimeter	Kearflex
AAU-8/A	Altimeter	Kollsman
AF200	Cabin Pressure Indicator	Aerosonic
AF200A	Cabin Pressure Indicator	Aerosonic
AK-350	Altitude Encoder	Ameri-King
ALT-55	Radar Altimeter	Collins
AM150	Altitude Encoder	Aero Mechanism
AM165	Altitude Encoder	Aero Mechanism
AN/APN-133A	Altimeter	Stewart Warner
AN/APN-209(v)7	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209A(V)2	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209A(V)3	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209B(V)1	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209B(V)2	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209B(V)3	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209B(V)4	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209B(V)5	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209B(V)6	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209B(V)7	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209C(V)1	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209C(V)2	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209C(V)3	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209C(V)4	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209C(V)5	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209C(V)6	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209D(V)1	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209D(V)2	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209D(V)3	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209D(V)4	Radar Altimeter-Electronic Set	Honeywell
AN/APN-209D(V)5	Radar Altimeter-Electronic Set	Honeywell
AN/APN-20D(V)6	Radar Altimeter-Electronic Set	Honeywell

Primary Part Number	Nomenclature	Manufacture
AN5760-1	Altimeter	Kollsman
AN5760-2	Altimeter	Kollsman
AN5760-2A	Altimeter	Kollsman
AN5760-4	Altimeter	Kollsman
AN5760-L2	Altimeter	Kollsman
AN5760-L2A	Altimeter	Kollsman
AN5760-L4B	Altimeter	Kollsman
AN5760-T2A	Altimeter	Kollsman
AN5760-T4A	Altimeter	Kollsman
AN5761-1	Altimeter	Pioneer
AR500	Altitude Encoder	Narco
AR-50-MA-KL	Altimeter	Aerosonic

AR800	Altitude Encoder	Narco
AR850	Altitude Encoder	Narco
AT3000	Altitude Encoder	Terra
ATC-1400A	Altitude Encoder	IFR
ATS-100	Altitude Encoder Test Set	Trans-Cal
ATS-200	Altitude Encoder Test Set	Trans-Cal
AW-1-7/8-21 AH	Cabin Differential Ind.	US Gauge
AW2056AB03	Cabin Differential Ind.	Ametek/GE
AW2056AB04	Cabin Differential Ind.	Ametek/GE
AW2835AB01	Cabin Altitude	Ametek/GE
AW2835AB02	Cabin Altitude	Ametek/GE
AW2835AB04	Cabin Altitude	Ametek/GE
AW2835AB05	Cabin Altitude	Ametek/GE
AW2835AB06	Cabin Altitude	Ametek/GE
AW2835AE01	Cabin Altimeter	US Gauge
AW2835AE02	Cabin Altitude Indicator	US Gauge
AW2835AGO1	Cabin Altitude	Ametek/US Gauge
B0020 14107	Master Altimeter Indicator	Astek
B0020 14110	Altimeter	Lear Siegler
B0020 14201	Altimeter	Lear Siegler
B0020 14211	Altimeter	Lear Siegler
B0020 14902	Master Altimeter Indicator	Astek
B0020-14211	Altimeter	Lear Siegler
B0020-14211F	Altimeter	Lear Siegler
B0030 22102	Altimeter	Astek
B0030 22103	Altimeter	Astek
B003022102	Altimeter	Astek
B0030-22103	Altimeter	Astek
B0060-81102	Altimeter	Astek
B0063	Altimeter	Lear Siegler
B0652-71104-1	Altitude Controller	Lear Siegler
B0652-71105-1	Altitude Controller	Lear Siegler
Primary Part Number	**Nomenclature**	**Manufacture**
B0652-71108-1	Altitude Controller	Lear Siegler
B0652-71111-1	Altitude Controller	Lear Siegler
B0652-71113-1	Altitude Controller	Lear Siegler
B1800-81103	Altimeter	Lear Siegler
B1800-81108	Altimeter	Lear Siegler
B26541 10 001	Altimeter	Kollsman
B26849 00 001	Altimeter	Kollsman
B27546 10 001	Altimeter	Kollsman
B2796000003	Altitude Controller	Kollsman
B29227 10 001	Altimeter	Kollsman
B29227 10 010	Altimeter	Kollsman
B29227 10 016	Altimeter	Kollsman
B29534 01 004	Altimeter	Kollsman
B29534 04 001	Altimeter	Kollsman
B3007210004	Altimeter	Kollsman
B3668910009	Cabin Altimeter	Kollsman

B3668910015	Cabin Altimeter	Kollsman
B3733610006	Altimeter	Kollsman
B4155210002	Altimeter	Kollsman
B4420210002	Altimeter	Kollsman
B44202-10-015	Altimeter	Kollsman
B4515210002	Altimeter	Kollsman
B45152-10-002	Altimeter	Kollsman
B45152-10-003	Altimeter	Kollsman
B45152-10-004	Altimeter	Kollsman
B45152-10-005	Altimeter	Kollsman
B45152-10-007	Altimeter	Kollsman
B45152-10-009	Altimeter	Kollsman
B4515210011	Altimeter	Kollsman
B45152-10-011	Altimeter	Kollsman
B45152-10-013	Encoder Altimeter	Kollsman
B45152-10-019	Altimeter	Kollsman
B45152-10-042	Altimeter-Encoder	Kollsman
B4515210103	Altimeter	Kollsman
B45152-10-103	Altimeter	Kollsman
B45152-10-107	Altimeter	Kollsman
B45152-10-111	Altimeter	Kollsman
B45152-10-115	Altimeter	Kollsman
B45451-10-001	Altimeter	Kollsman
B45451-10-002	Altimeter	Kollsman
B45451-10-011	Altimeter	Kollsman
B45451-10-101	Altimeter	Kollsman
B45451-10-102	Altimeter	Kollsman
B45501-01-001	Altimeter	Kollsman

Primary Part Number	Nomenclature	Manufacture
B45501-01-002	Altimeter	Kollsman
B45501-10-001	Altimeter	Kollsman
B45501-10-002	Altimeter	Kollsman
B45501-10-101	Altimeter	Kollsman
B45501-10-102	Altimeter	Kollsman
B45521-10-001	Altimeter	Kollsman
B45521-10-002	Altimeter	Kollsman
B45521-10-101	Altimeter	Kollsman
B45521-10-102	Altimeter	Kollsman
B45531-10-001	Altimeter	Kollsman
B45531-10-002	Altimeter	Kollsman
B45531-10-101	Altimeter	Kollsman
B45531-10-102	Altimeter	Kollsman
BETA/4096	ATC Transponder	Genave
BETA/500	ATC Transponder	Genave
BETA/5000	ATC Transponder	Genave
C0001 81103	Altimeter	Astek
C0030-22102	Altimeter	Astek
C-11	Altimeter	Kollsman
C-12A	Altimeter	Kollsman

C14129BA	Altimeter	Thales
C14130AA	Altimeter	Thales
C-16	Altimeter	Kollsman
C266840 00 001	Altimeter	Kollsman
C2796000003	Altitude Controller	Kollsman
C2796000004	Altitude Controller	Kollsman
C2796000005	Altitude Controller	Kollsman
C28934-10-007	Altimeter	Kollsman
C2995100002	Altitude Controller	Kollsman
C30561 00 001	Altitude Controller	Kollsman
C30561 00 002	Altitude Controller	Kollsman
C30561 00 003	Altitude Controller	Kollsman
C4154210003	Altimeter	Kollsman
C45152-10-002	Altimeter	Kollsman
C45501-10-001	Altimeter	Kollsman
C45501-10-002	Altimeter	Kollsman
C45501-10-101	Altimeter	Kollsman
C45501-10-102	Altimeter	Kollsman
C45521-10-001	Altimeter	Kollsman
C45521-10-002	Altimeter	Kollsman
C45521-10-101	Altimeter	Kollsman
C45521-10-102	Altimeter	Kollsman
C-8	Altimeter	Kollsman
CA-530A	Altitude Hold	ARC

Primary Part Number	Nomenclature	Manufacture
CA-DP-10-ILB	Cabin Altimeter	Aerosonic
CC-310A	ATC Transponder	Cessna
CMC 459-136	Altimeter	Marconi
CP-I-AAU-3/A	Altimeter	Aerosonic
CP-I-AAU-3/A-12	Altimeter	Aerosonic
D0030-221-02	Altimeter	Astek
D120-P2-T	Altitude Encoder	Trans-Cal
D22061 04 004	Altimeter	Kollsman
D22061 04 010	Altimeter	Kollsman
D22061-04-004	Altimeter	Kollsman
D22061-04-010	Altimeter	Kollsman
D23727 10 004	Altimeter	Kollsman
D23727 10 005	Altimeter	Kollsman
D23727 10 006	Altimeter	Kollsman
D38410-00-201	Altimeter	Kollsman
D-6	Altimeter	Kollsman
D-7	Altimeter	Kollsman
D-8	Altimeter	Kollsman
DRI-55	Altitude Indicator	Collins
E.41-	Altimeter	IFR
E22061 04 016	Altimeter	Kollsman
EA-401A	Altimeter	Cessna
EA-801A	Altimeter	Cessna
F5186000100	Radar Altitude Indicator	Kollsman

G5186000100	Radar Altitude Indicator	Kollsman
H-1	Altimeter	Kollsman
H-2	Altimeter	Kollsman
H5186000100	Radar altitude Indicator	Kollsman
ID-1162/APN-159	Height Indicator	Stewart Warner
ID-1162A/APN-159	Height Indicator	Stewart Warner
ID-1162B/APN-159	Height Indicator	Stewart Warner
ID-1345/APN-171	Height Indicator	Honeywell
ID-1346/APN-171	Height Indicator	Honeywell
IFR 462	Altimeter	IFR
IFR 46-20	Altimeter	IFR
IFR 462I	Altimeter	IFR
IFR 462M	Altimeter	IFR
IU301-001	Altitude/Airspeed Indicator	Electric Auto-Lite Co
IU306-002	Altimeter	Electric Auto-Lite Co
JG1052AA01	Altitude Alert Indicator	Honeywell
JG1052AA02	Altitude Alert Indicator	Honeywell
JG1052AA03	Altitude Alert Indicator	Honeywell
JG1052AA04	Altitude Alert Indicator	Honeywell
JG1052AA05	Altitude Alert Indicator	Honeywell

Primary Part Number	Nomenclature	Manufacture
JG1052AA06	Altitude Alert Indicator	Honeywell
JG1052AA07	Altitude Alert Indicator	Honeywell
JG1052AA08	Altitude Alert Indicator	Honeywell
JG1052AB01	Altitude Alert Indicator	Honeywell
JG1052AB02	Altitude Alert Indicator	Honeywell
JG1052AB03	Altitude Alert Indicator	Honeywell
JG1052AB04	Altitude Alert Indicator	Honeywell
JG1052AC01	Altitude Alert Indicator	Honeywell
JG1052AC02	Altitude Alert Indicator	Honeywell
JG1052AC03	Altitude Alert Indicator	Honeywell
JG1052AC04	Altitude Alert Indicator	Honeywell
JG1052AC09	Altitude Alert Indicator	Honeywell
JG1052AK01	Altitude Alert Indicator	Honeywell
JG1052AP01	Altitude Alert Indicator	Honeywell
JG1052BC01	Altitude Alert Indicator	Honeywell
JG1052BD01	Altitude Alert Indicator	Honeywell
JG205DW	Height Indicator	Honeywell
JG206D1	Height Indicator	Honeywell
JG206D4	Height Indicator	Honeywell
K5186000100	Radar Altitude Indicator	Kollsman
KAA 1501K	Altimeter	Smith Industries
KAA 1502K	Altimeter	Smith Industries
KAA 1502L	Altimeter	Smith Industries
KAA 1502W	Altimeter	Smith Industries
KAA 1503K	Altimeter	Smith Industries
KAA 1504K	Altimeter	Smith Industries
KAA 1504L	Altimeter	Smith Industries
KAA 1504W	Altimeter	Smith Industries

KAA 1505K	Altimeter	Smith Industries
KAA 1505W	Altimeter	Smith Industries
KAA 1505W1	Altimeter	Smith Industries
KAA 1505W2	Altimeter	Smith Industries
KAA 1506K	Altimeter	Smith Industries
KAA 1506W	Altimeter	Smith Industries
KAA 1603K	Altimeter	Smith Industries
KAA 1603W	Altimeter	Smith Industries
KAA 1603W1	Altimeter	Smith Industries
KAA 1604K	Altimeter	Smith Industries
KAA 1604W	Altimeter	Smith Industries
KAA 1605W	Altimeter	Smith Industries
KAS297A	Altitude Selector	Bendix King
KAS297B	Altitude Selector	Bendix King
KAS297C	Altitude/Vertical Speed Select	Bendix King
KBA 125	Altimeter	Bendix King

Primary Part Number	Nomenclature	Manufacture
KDC 380	Air Data Computer	Bendix-King
KEA 130A	Altimeter	Bendix King
KEA 346	Altimeter	Bendix King
KEA129	Altimeter	Bendix King
KEA130	Altimeter	Bendix King
KEA130A	Altimeter	Bendix King
KEA346	Altimeter	Bendix King
KFS570B	ATC Transponder Control Unit	Bendix King
KI 250	Radar Altimeter Indicator	Bendix King
KI250	Radar Altimeter Indicator	Bendix King
KNI 416	Radar Altimeter Indicator	Honeywell
KO-671CLU4-035	Altimeter	Kollsman
KRA 405	Altimeter	Bendix King
KRA 405B	Radar Altimeter	Honeywell
KRA10	Radar Altimeter R/T	Bendix King
KRA10A	Radar Altimeter R/T	Bendix King
KSA 297	Altitude Selector	Bendix King
KT 76/78	Transponder	Bendix/King
KT 76C	ATCRBS Transponder	Honeywell
KT75	ATC Transponder	Bendix King
KT75R	ATC Transponder	Bendix King
KT76C	ATC Transponder	Bendix King
KT78	ATC Transponder	Bendix King
KT78A	Transponder	Bendix King
KT79	ATC Transponder	Bendix King
KTS B36689 10 015	Cabin Altitude	Kollsman
KXP750	ATC Transponder	Bendix King
KXP755	ATC Transponder	Bendix King
KXP756	ATC Transponder	Bendix King
L115	Altitude Encoder	Mitchell
L115-X	Altitude Encoder	Mitchell
L5186000100	Radar Altitude Indicator	Kollsman

M5186000100	Radar Altitude Indicator	Kollsman
MAC-117	Altimeter	Bendix King
MAC-118	Altimeter	Bendix King
N5186000100	Radar Altitude Indicator	Kollsman
P5186000100	Radar Altitude Indicator	Kollsman
PG10A	Altitude Controller	Honeywell
PG10A1	Altitude Controller	Honeywell
PG18A	Altitude Controller	Honeywell
PG18A1	Altitude Controller	Honeywell
PG51A1	Altitude Controller	Bendix King
PW/1606 Kaa/1	Altimeter	Smith Industries
R88A0350-050-000	Sensitive Altimeter	Kollsman

Primary Part Number	Nomenclature	Manufacture
RL/1101AM/MS/10	Altitude Alert System	Smith Industries
RL1350AM/MS/3	Altimeter	Smith Industries
RT-106A	Altitude Transponder	Cessna
RT-359A	Altitude Transponder	Cessna
RT-524A	Altitude Transponder	Cessna
RT667	ATC Transponder	Electric Auto-Lite Co
RT787	ATC Transponder	Electric Auto-Lite Co
RT887	ATC Transponder	Electric Auto-Lite Co
S-1313N1	Altimeter	Kollsman
SSD120	Altitude Encoder	Trans-Cal
SSD120-15	Altitude Encoder	Trans-Cal
SSD120-20	Altitude Encoder	Trans-Cal
SSD120-25	Altitude Encoder	Trans-Cal
SSD120-35	Altitude Encoder	Trans-Cal
SSD120-42	Altitude Encoder	Trans-Cal
SSD120-50	Altitude Encoder	Trans-Cal
SSD120-62	Altitude Encoder	Trans-Cal
SSD120-RS232C	Altitude Encoder	Trans-Cal
TDR90	ATC Transponder	Collins
TPR2060	ATC Transponder	Bendix King
TPR-640	ATC Transponder	Collins
TPR660	ATC Transponder	Bendix King
TR661A	ATC Transponder	Bendix King
TTU-229/E	Altimeter Test Set	Kollsman
UI-3000-0101	Cabin Altimeter	United Instruments
UI-3001-0101	Cabin Altimeter	United Instruments
UI-3002-0101	Cabin Altimeter	United Instruments
VSDL-0C403D	Altimeter	Ametek
WL/1101/AM/MS/1	Altimeter	Smith Industries
WL/1101AM/MS/1	Altitude Alert System	Smith Industries
WL/1101AM/MS/10	Altimeter	Smith Industries
WL/1101AM/MS/2	Altitude Alert System	Smith Industries
WL/1101AM/MS/3	Altimeter	Smith Industries
WL/1101AM/MS/4	Altimeter	Smith Industries
WL/1101AM/MS/7	Altimeter	Smith Industries
WL/1101AM/MS/8	Altimeter	Smith Industries

WL/1103/AM/MS/1	Altimeter	Smith Industries
WL/1103AM/MS	Altimeter	Smith Industries
WL/1103AM/MS/1	Altimeter	Smith Industries
WL/1103AM/MS/2	Altimeter	Smith Industries
WL/1103AM/MS/3	Altitude Alert System	Smith Industries
WL/1103AM/MS/4	Altimeter	Smith Industries
WL/1103AM/MS/9	Altimeter	Smith Industries
WL/1105AM/MS/2	Altitude Alert System	Smith Industries

Primary Part Number	Nomenclature	Manufacture
WL/1106AM/MS/2	Altimeter	Smith Industries
WL/1106AM/MS/5	Altimeter	Smith Industries
WL/1107AM/MS/1	Altitude Alert System	Smith Industries
WL/1107AM/MS/3	Altitude Alert System	Smith Industries
WL/1107AM-MS4	Altimeter	Smith Industries
WL/1107AM-MS5	Altimeter	Smith Industries
WL/1108AM/MS/1	Altimeter	Smith Industries
WL/1109AM/MS/3	Altimeter	Smith Industries
WL/1110AM/MS/1	Altimeter	Smith Industries
WL/1110AM/MS/2	Altimeter	Smith Industries
WL/1110AM/MS/3	Altimeter	Smith Industries
WL/1110AM/MS/4	Altimeter	Smith Industries
WL/1112AM/MS/1	Altimeter	Smith Industries
WL/1112AM/MS/2	Altimeter	Smith Industries
WL/1112AM/MS/3	Altimeter	Smith Industries
WL/1112AM/MS/4	Altimeter	Smith Industries
WL/1112AM/MS/5	Altimeter	Smith Industries
WL/1150AM/MS/1	Altimeter	Smith Industries
WL/1150AM/MS/2	Altimeter	Smith Industries
WL/1150AM/MS/4	Altimeter	Smith Industries
WL/1150AM/MS/5	Altimeter	Smith Industries
WL/1350AM/MS/2	Altimeter	Smith Industries
WL/1350AM/MS/4	Altimeter	Smith Industries
WL/1350AM/MS/5	Altimeter	Smith Industries
WL/1381AM/MS/1	Altimeter	Smith Industries
WL/1381AM/MS/2	Altimeter	Smith Industries
WL/1381AM/MS/3	Altimeter	Smith Industries
WL/1400M	Altimeter	Smith Industries
WL/1401AM/MS/1	Altimeter	Smith Industries
WL/1401AM/MS/4	Altimeter	Smith Industries
WL/1403AM/MS/1	Altimeter	Smith Industries
WL/1403AM/MS/2	Altimeter	Smith Industries
WL/1403AM/MS/3	Altimeter	Smith Industries
WL/1403AM/MS/4	Altimeter	Smith Industries
WL/1404AM/MS/2	Altimeter	Smith Industries
WL/1404AM/MS/3	Altimeter	Smith Industries
WL/1404AM/MS/4	Altimeter	Smith Industries
WL/1404AM/MS/5	Altimeter	Smith Industries
WL/1404AM/MS/6	Altimeter	Smith Industries
WL/1404AM/MS/7	Altimeter	Smith Industries

WL/1404AM/MS/8	Altimeter	Smith Industries
WL/1407AM/MS/1	Altimeter	Smith Industries
WL/1407AM/MS/2	Altimeter	Smith Industries
WL/1407AM/MS/3	Altimeter	Smith Industries

Primary Part Number	Nomenclature	Manufacture
WL/1407AM/MS/4	Altimeter	Smith Industries
WL/140AM/MS/2	Altimeter	Smith Industries
WL/140AM/MS/3	Altimeter	Smith Industries
WL/140AMMS/1	Altimeter	Smith Industries
WL/1801/AM2	Altimeter	Smith Industries
WL/1802/AM1	Altimeter	Smith Industries
WL/701AM/FA/1	Altimeter	Smith Industries
WL/701AM/FA/2	Altimeter	Smith Industries
WL/704AM/MS/1	Altimeter	Smith Industries
WL/704AM/MS/2	Altimeter	Smith Industries
WL/707AM/FA/1	Altimeter	Smith Industries
WL/707AM/FA/2	Altimeter	Smith Industries
WL/707AM/FA/4	Altimeter	Smith Industries
WL/710AM/MS/2	Altimeter	Smith Industries
WL/753AM/FA/1	Altimeter	Smith Industries
WL102AMS1	Altitude/Airspeed Indicator	Ametek/GE
WL102AMS2	Altitude/Airspeed Indicator	Ametek/GE
WL102AMS3	Altitude/Airspeed Indicator	Ametek/GE
WL102AMS4	Altitude/Airspeed Indicator	Ametek/GE
WL102AMS5	Altitude/Airspeed Indicator	Ametek/GE
WL102AMS6	Altitude/Airspeed Indicator	Ametek/GE
WL1484PGJA1	Cabin Differential Ind.	Smith Industries
WL701AM/FA/1	Altimeter	Smith Industries
WL701AM/FA/2	Altimeter	Smith Industries
WL704AM/FA/1	Altimeter	Smith Industries
WL704AM/FA/2	Altimeter	Smith Industries
WL704AM/MS/3	Altimeter	Smith Industries
WL707AM/FA/1	Altimeter	Smith Industries
WL707AM/FA/2	Altimeter	Smith Industries
WL707AM/FA/4	Altimeter	Smith Industries
WL708AM/FA/2	Altimeter	Smith Industries
WL710AM/MS/2	Altimeter	Smith Industries
WL753/FA/1	Altimeter	Smith Industries
12C220	Deicing Indicator	R C Allen
27B432	Deicing Indicator	AID
468100-0-1	Propeller De-Icer Timer	Bendix-Pacific
468100-1	Deicing Indicator	Bendix
96-384061-1,3	Deicing Indicator	AID
A-60060	Deicing Indicator	R C Allen
AW-1-7/8-16-AC	Deicing Indicator	US Gauge
AW-1-7/8-16-AC2	Deicing Indicator	US Gauge
AW-1-7/8-16-AC3	Deicing Indicator	US Gauge
AW-1-7/8-16-N	Deicing Indicator	US Gauge
AW2-43	Deicing Indicator	US Gauge

Primary Part Number	Nomenclature	Manufacture
C662503-0101	Deicing Indicator	R C Allen
C662503-0102	Deicing Indicator	R C Allen
C662503-0103	Deicing Indicator	R C Allen
C662503-0104	Deicing Indicator	R C Allen
C662503-0105	Deicing Indicator	R C Allen
C662503-0107	Deicing Indicator	R C Allen
C662503-0108	Deicing Indicator	R C Allen
C662503-0109	Deicing Indicator	R C Allen
C662503-0201	Deicing Indicator	R C Allen
CM2906-1	Deicing Indicator	R C Allen
EHU-15A/A	Temperature Indicator	Consolidated Airborn
S-2852-1	Deicing Indicator	R C Allen
T-38 Elec Sys	T-38 Elec Sys	ATOS
0227-102	Engine Analysis System	Mooney
100-476844-001	Engine Gas Generator Ind.	Canadian Marconi
169	Cluster Gage	Electric Auto-Lite Co
169AU	Cluster Gage	Electric Auto-Lite Co
18-1000-1	Engine Gage	R C Allen
18-1000-16	Engine Gage	R C Allen
18-1000-2	Engine Gage	R C Allen
18-1000-3	Engine Gage	R C Allen
18-1000-4	Engine Gage	R C Allen
18-1000-5	Engine Gage	R C Allen
18-1000-6	Engine Gage	R C Allen
18-1000-6AL	Engine Gage	R C Allen
18-1002	Engine Gage	R C Allen
18-1002-1	Engine Gage	R C Allen
18-1002-10	Engine Gage	R C Allen
18-1002-2	Engine Gage	R C Allen
18-1002-3	Engine Gage	R C Allen
18-1002-4	Engine Gage	R C Allen
18-1002-5	Engine Gage	R C Allen
18-1002-6	Engine Gage	R C Allen
18-1002-7	Engine Gage	R C Allen
18-1002-8	Engine Gage	R C Allen
18-1002-9	Engine Gage	R C Allen
18B1000	Engine Gage	R C Allen
18B331	Engine Gage	R C Allen
18B332	Engine Gage	R C Allen
18B452	Engine Gage	R C Allen
18C452	Engine Gage	R C Allen
18C452-1	Engine Gage	R C Allen
18C454	Engine Gage	R C Allen
18C454-01	Engine Gage	R C Allen
Primary Part Number	**Nomenclature**	**Manufacture**
18C454-02	Engine Gage	R C Allen
18C454-03	Engine Gage	R C Allen

18C454-04	Engine Gage	R C Allen
18C454-05	Engine Gage	R C Allen
18C454-06	Engine Gage	R C Allen
18P-1503-1	Engine Gage	AID
18P-1506	Engine Gage	R C Allen
195-1SN112	Engine Gage	Edison
195-1TN112	Engine Gage	Edison
195-7SN122	Engine Gage	Edison
1SP1503-1	Engine Gage	AID
1U305	Cluster Gage	Sigma Tek
1U378	Engine Gage	Sigma Tek
1U417-101-4	Engine Gage	Sigma Tek
22-804	Engine Gage	Electric Auto-Lite Co
273-21313	Engine Gage	Edison
273-7SN112	Engine Gage	Edison
34000	Engine Gage	Edison
34200	Engine Gage	Edison
34400	Engine Gage	Edison
35500	Engine Gage	Edison
473-90011	Engine Gage	Edison
49-2000	Cluster Gage	AID
550430	Engine Gage	AID
617234	Engine Analysis System	Sperry
669447	Engine Analysis System	Sperry
679660-108	Engine Analysis System	Sperry
679660-120	Engine Analysis System	Sperry
679660-144	Engine Analysis System	Sperry
679661-040	Engine Analysis System	Sperry
682081	Engine Analysis System	Sperry
804	Engine Gage	Electric Auto-Lite Co
8DJ339WAF1	Engine Gage	Ametek/GE
8DJ339WAG1	Engine Gage	Ametek/GE
8DJ339WAH1	Engine Gage	Ametek/GE
9001-3001	Cluster Gage	Insco
9001-3101	Cluster Gage	Insco
9910482-1	Engine Gage	R C Allen
A-21	Engine Gage	Edison
AN 5773-2	Engine Gage	Auto Lite
AN 5773-T2	Engine Gage	Edison
AN5773-1	Engine Gage	Auto Lite
AN5773-1A	Engine Gage	Edison
AN5773-2	Engine Gage	Edison

Primary Part Number	Nomenclature	Manufacture
AW-2 -3/4-19-AD	Engine Gage	US Gauge
B329-1	Engine Gage	R C Allen
B329-3	Engine Gage	R C Allen
B329-5	Engine Gage	R C Allen
B329-7	Engine Gage	R C Allen
B329-9	Engine Gage	R C Allen

C450	Engine Gage	R C Allen
C450-1	Engine Gage	R C Allen
C450-2	Engine Gage	R C Allen
C450A	Engine Gage	R C Allen
C450A-1	Engine Gage	R C Allen
C450A-2	Engine Gage	R C Allen
C450A-3	Engine Gage	R C Allen
IU378	Engine Gage	Electric Auto-Lite Co
PS50091	Engine Gage	AID
R88-G-1020	Engine Gage	Auto Lite
R88-G-1020-10	Engine Gage	Auto Lite
RCA272	Engine Gage	R C Allen
S231N001-1	Engine Gage	Ametek/GE
S231N001-13	Engine Gage	Boeing
1/2-2-81-200	Fuel Flow Transmitter	Foxboro
1/2-2-81-210	Fuel Flow Transmitter	Foxboro
1/2-2-81-217	Fuel Flow Transmitter	Ketema
1/2-2-81-301	Fuel Flow Transmitter	Ketema
1/2-2-81-302	Fuel Flow Transmitter	Ketema
1/2-2-81-303	Fuel Flow Transmitter	Ketema
1/2-2-81-306	Fuel Flow Transmitter	Ketema
10074-0101	Indicator	BF Goodrich
101059	Fuel Flow Indicator	Astronautics
101280	Fuel Flow Indicator	Astronautics
10-3065-273	Indicator	Honeywell
10-3065-276	Fuel Quantity Indicator	Honeywell
10-3065-277	Fuel Quantity Indicator	Honeywell
1-0525	Fuel Flow Transmitter	Foxboro
114ES224-1	Fuel Quantity Selector Switch	Gull
114ES224-4	Fuel Quantity Selector Switch	Gull
145ES025-1	Dual Fuel Flow Indicator	Boeing
150-022-002	Fuel Flow Transmitter	Gull
150-906-001	Fuel Flow Transmitter	Gull
150-906-002	Fuel Flow Transmitter	Gull
151-906-001	Fuel Flow Transmitter	Gull
151-906-002	Fuel Flow Transmitter	Gull
151-906-003	Fuel Flow Transmitter	Gull
151-906-010	Fuel Flow Transmitter	Gull

Primary Part Number	Nomenclature	Manufacture
151-915-001	Fuel Flow Transmitter	Gull
1558-041048	Fuel Flow Indicator	Kollsman
16501-1-B	Fuel Flow Amplifier	Pioneer Central
16501-1-C	Fuel Flow Amplifier	Pioneer Central
16501-2-C	Fuel Flow Amplifier	Pioneer Central
16502-1-A	Fuel Flow Amplifier	Pioneer Central
16502-1-D	Fuel Flow Amplifier	Pioneer Central
16502-2-B	Fuel Flow Amplifier	Pioneer Central
16502-2-C	Fuel Flow Amplifier	Pioneer Central
16511-1-A	Fuel Flow Amplifier	Pioneer Central

16511-1-B	Fuel Flow Amplifier	Pioneer Central
16512-1-A	Fuel Flow Amplifier	Pioneer Central
16545-1-A	Fuel Flow Indicator	Eclipse Pioneer
16545-1-B	Fuel Flow Indicator	Pioneer Central
16-562-51	Fuel Flow Transmitter	Parker Hannifin
185249	Fuel Flow Indicator	Weston
18-64927-1	Fuel Flow Indicator	Northrup
1880843-2A	Fuel Flow Indicator	Bendix
1966B041040	Fuel Flow Indicator	Kollsman
19A100	Fuel Flow Indicator	AID
19A300	Fuel Flow Transmitter	R C Allen
19A437	Fuel Flow Indicator	R C Allen
19R200	Fuel Flow Indicator	AID
1U028-003-10	Fuel Flow Indicator	Sigma Tek
1U028-003-9	Fuel Flow Indicator	Sigma Tek
1U028-004-14R	Fuel Flow Indicator	Sigma Tek
1U028-004-15R	Fuel Flow Indicator	Sigma Tek
1U028-004-16R	Fuel Flow Indicator	Sigma Tek
1U028-004-17R	Fuel Flow Indicator	Sigma Tek
1U028-004-18	Fuel Flow Indicator	Sigma Tek
1U028-004-19	Fuel Flow Indicator	Sigma Tek
1U028-004-21	Fuel Flow Indicator	Sigma Tek
1U028-004-27	Fuel Flow Indicator	Sigma Tek
1U028-004-28	Fuel Flow Indicator	Sigma Tek
1U028-004-3	Fuel Flow Indicator	Sigma Tek
1U028-004-30	Fuel Flow Indicator	Sigma Tek
1U028-004-32R	Fuel Flow Indicator	Sigma Tek
1U028-004-33R	Fuel Flow Indicator	Sigma Tek
1U028-004-39	Fuel Flow Indicator	Sigma Tek
1U028-004-42	Fuel Flow Indicator	Sigma Tek
1U028-004-6	Fuel Flow Indicator	Sigma Tek
1U028-005	Fuel Flow Indicator	Sigma Tek
1U028-104-1	Fuel Flow Indicator	Sigma Tek
1U028-104-11	Fuel Flow Indicator	Sigma Tek

Primary Part Number	Nomenclature	Manufacture
1U028-104-12R	Fuel Flow Indicator	Sigma Tek
1U028-104-13R	Fuel Flow Indicator	Sigma Tek
1U028-104-15R	Fuel Flow Indicator	Sigma Tek
1U028-104-16R	Fuel Flow Indicator	Sigma Tek
1U028-104-17R	Fuel Flow Indicator	Sigma Tek
1U028-104-18	Fuel Flow Indicator	Sigma Tek
1U028-104-35R	Fuel Flow Indicator	Sigma Tek
1U028-104-36R	Fuel Flow Indicator	Sigma Tek
1U028-104-37	Fuel Flow Indicator	Sigma Tek
1U028-104-43	Fuel Flow Indicator	Sigma Tek
1U028-104-5	Fuel Flow Indicator	Sigma Tek
1U028-204-29	Fuel Flow Indicator	Sigma Tek
1U028-204-8	Fuel Flow Indicator	Sigma Tek
20-225-01	Indicator	Smith Industries

203-014-001	Fuel Quantity Indicator	Gull
204-011-005	Fuel Flow Indicator	Gull
204-60931-1	Fuel Flow Indicator	AMETEK
21-1000	Fuel Flow/Manifold Pressure	R C Allen
21-1002	Fuel Flow/Manifold Pressure	R C Allen
21-1003	Fuel Flow/Manifold Pressure	R C Allen
21100-30C-150-A2	Fuel Flow Indicator	Eclipse Pioneer
21-1004	Fuel Flow/Manifold Pressure	R C Allen
21-1006	Fuel Flow/Manifold Pressure	R C Allen
21-1007	Fuel Flow/Manifold Pressure	R C Allen
218-913-001	Fuel Flow Indicator	Gull
21B300	Fuel Flow/Manifold Pressure	R C Allen
21B301	Fuel Flow/Manifold Pressure	R C Allen
21B302	Fuel Flow/Manifold Pressure	R C Allen
21-C357	Fuel Flow/Manifold Pressure	R C Allen
21C358	Fuel Flow/Manifold Pressure	R C Allen
21E100	Fuel Flow/Manifold Pressure	R C Allen
21E102	Fuel Flow/Manifold Pressure	R C Allen
21E200	Fuel Flow/Manifold Pressure	R C Allen
22-260-04-2	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-260-04-3	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-262-022-1	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-262-022-2	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-262-022-3	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-262-022-4	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-468-01-1	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-468-01-2	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-468-03	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-468-03-1	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-468-05	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
Primary Part Number	**Nomenclature**	**Manufacture**
22-468-05-C	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
22-468-08	Fuel Flow/Manifold Pressure	Electric Auto-Lite Co
2308130-7	Fuel Flow Indicator	Hickok
24100-30A-4-A2	Fuel Flow Transmitter	Eclipse Pioneer
25122	Fuel Flow Transmitter	Allied Signal
25514-B25A-3-A3	Fuel Flow Indicator	Bendix
266-025-001	Fuel Flow Indicator	Gull
266-025-002	Fuel Flow Indicator	Gull
2-662-51	Fuel Flow Transmitter	Parker Hannifin
267-917-001	Fuel Flow Indicator	Gull
267-917-002	Fuel Flow Indicator	Gull
267-917-003	Fuel Flow Indicator	Gull
267-917-004	Fuel Flow Indicator	Gull
267-937-001	Fuel Flow Indicator	Gull
267-978-001	Fuel Flow Indicator	Gull
267-978E01	Fuel Flow Indicator	Gull
267-978M01	Fuel Flow Indicator	Gull
267-978T01	Fuel Flow Indicator	Gull

267-987H01	Fuel Flow Indicator	Gull
271-001-001	Fuel Quantity Selector Switch	Gull
271-001-002	Fuel Quantity Selector Switch	Gull
27906-B16A-4-A1	Fuel Flow Indicator	HONEYWELL
3265013-0601	Fuel Flow Indicator	Ragen
3268011-0101	Fuel Flow Transmitter	Ragen
33-8007	Fuel Flow Transmitter	Garwin
33981-001	Fuel Flow Indicator	IDC
33981-002	Fuel Flow Indicator	IDC
35-380054-5	Fuel Flow/Manifold Pressure	AID
3571210-7002	Fuel Flow Indicator	HONEYWELL
3571213-7008	Indicator	Bendix
3571810-003	Fuel Flow Indicator	Bendix
36700-1A-1-A1	Fuel Flow Indicator	Pioneer Central
36700-1A-1-A3	Fuel Flow Indicator	Pioneer Central
36700-1A-1-B1	Fuel Flow Indicator	Pioneer Central
36700-1C-1-A3	Fuel Flow Indicator	Pioneer Central
36700-1D-1-B1	Fuel Flow Indicator	Pioneer Central
36701-2A-2-A1	Fuel Flow Indicator	Pioneer Central
36701-2A-2-B1	Fuel Flow Indicator	Pioneer Central
36702-1B-1-A1	Fuel Flow Indicator	Pioneer Central
36703-2B-2-A2	Fuel Flow Indicator	Pioneer Central
36703-3A-2-A1	Fuel Flow Indicator	Pioneer Central
36703-3A-2-B1	Fuel Flow Indicator	Pioneer Central
36704-4A-3-A1	Fuel Flow Indicator	Pioneer Central
36704-4A-3-A2	Fuel Flow Indicator	Pioneer Central

Primary Part Number	Nomenclature	Manufacture
36704-4A-3-B1	Fuel Flow Indicator	Pioneer Central
36705-8A-1-A4	Fuel Flow Indicator	Pioneer Central
36750-9A-4-A1	Fuel Flow Indicator	Pioneer Central
36750-9A-4-B1	Fuel Flow Indicator	Pioneer Central
37001-2A-2-A1	Fuel Flow Indicator	Eclipse Pioneer
393002-009	Fuel Flow Indicator	Simmonds
394300-1-1	Flow Divider	Garrett
394300-3-1	Flow Divider	Garrett
4013013-906	Fuel Flow Indicator	Sperry
4013013-907	Fuel Flow Indicator	Sperry
4013013-911	Fuel Flow Indicator	Sperry
4013013-912	Fuel Flow Indicator	Sperry
40-637-3	Fuel Flow Indicator	Ragen
40-637-4	Fuel Flow Indicator	Ragen
4305-7150L	Indicator	General Design
472015	Fuel Flow Transmitter	Simmonds
472016	Fuel Flow Compensator	Simmonds
50-380095	Fuel Flow Indicator	R C Allen
50-389027	Fuel Flow Indicator	AID
550-18013B-100	Fuel Flow Indicator	IDC
550-18013B-300	Fuel Flow Indicator	IDC
550-22719-003	Fuel Flow Indicator	IDC

550-22719-004	Fuel Flow Indicator	IDC
5709-0117	Fuel Flow Indicator	Insco
5710-1001	Fuel Flow Indicator	Insco
585-30560-001	Fuel Flow Indicator	IDC
585-30560-002	Fuel Flow Indicator	IDC
585-31650-001	Fuel Flow Indicator	IDC
585-31650-002	Fuel Flow Indicator	IDC
585-31650-003	Fuel Flow Indicator	IDC
585-31650-004	Fuel Flow Indicator	IDC
585-31652-001	Fuel Flow Indicator	IDC
585-31652-002	Fuel Flow Indicator	IDC
585-31652-011	Fuel Flow Indicator	IDC
585-31652-012	Fuel Flow Indicator	IDC
585-31653-003	Fuel Flow Indicator	IDC
585-31653-004	Fuel Flow Indicator	IDC
585-31653-013	Fuel Flow Indicator	IDC
585-31653-014	Fuel Flow Indicator	IDC
585-31654-002	Fuel Flow Indicator	IDC
585-31655-001	Fuel Flow Indicator	IDC
585-31655-002	Fuel Flow Indicator	IDC
585-31655-011	Fuel Flow Indicator	IDC
585-31655-012	Fuel Flow Indicator	IDC

Primary Part Number	Nomenclature	Manufacture
585-33980-001	Fuel Flow Indicator	IDC
585-33980-002	Fuel Flow Indicator	IDC
585-37803-001	Fuel Flow Indicator	IDC
585-37803-002	Fuel Flow Indicator	IDC
585-37804-001	Fuel Flow Indicator	IDC
585-37804-002	Fuel Flow Indicator	IDC
585-37804-011	Fuel Flow Indicator	IDC
585-37804-012	Fuel Flow Indicator	IDC
585-37804-101	Fuel Flow Indicator	IDC
585-37804-102	Fuel Flow Indicator	IDC
585-38704-002	Fuel Flow Indicator	IDC
58-71081H	Fuel Flow Indicator	Weston
5907-102A-20-B	Fuel Flow Indicator	Eclipse Pioneer
5907-104A-21-B	Fuel Flow Indicator	Eclipse Pioneer
5907-108A-20-B	Fuel Flow Indicator	Eclipse Pioneer
5907-56A-1-A	Fuel Flow Indicator	Eclipse Pioneer
5907-56A-2-A	Fuel Flow Indicator	Eclipse Pioneer
5907-59A-1-A	Fuel Flow Indicator	Eclipse Pioneer
5907-59A-1-B	Fuel Flow Indicator	Eclipse Pioneer
5907-59B-1-A	Fuel Flow Indicator	Eclipse Pioneer
5907-59B-1-B	Fuel Flow Indicator	Eclipse Pioneer
5907-70A-1-A	Fuel Flow Indicator	Eclipse Pioneer
5907-70A-2-A	Fuel Flow Indicator	Eclipse Pioneer
6007-38A-15-B	Fuel Flow Indicator	Eclipse Pioneer
6007-38A-20-B1	Fuel Flow Indicator	Eclipse Pioneer
6007-38A-21-B1	Fuel Flow Indicator	Eclipse Pioneer

6007-38A-7-B	Fuel Flow Indicator	Eclipse Pioneer
6007-38B-7-B	Fuel Flow Indicator	Eclipse Pioneer
6007-38C-1-B	Fuel Flow Indicator	Eclipse Pioneer
6007-38C-7-B	Fuel Flow Indicator	Eclipse Pioneer
6007-38E-31-B	Fuel Flow Indicator	Eclipse Pioneer
6007-40A-7-A	Fuel Flow Indicator	Eclipse Pioneer
6007-51A-14-A	Fuel Flow Indicator	Eclipse Pioneer
6007-51A-18-B	Fuel Flow Indicator	Eclipse Pioneer
6007-51A-22-A	Fuel Flow Indicator	Eclipse Pioneer
6007-51A-7-A	Fuel Flow Indicator	Eclipse Pioneer
6007-51A-7-B	Fuel Flow Indicator	Eclipse Pioneer
6007-51C-18-A	Fuel Flow Indicator	Eclipse Pioneer
6007-51C-20-A	Fuel Flow Indicator	Eclipse Pioneer
6007-51C-21-A	Fuel Flow Indicator	Eclipse Pioneer
6007-51C-27-B	Fuel Flow Indicator	Eclipse Pioneer
6007-51C-28-B	Fuel Flow Indicator	Eclipse Pioneer
6007-51C-56-B	Fuel Flow Indicator	Eclipse Pioneer
6007-51C-7-B	Fuel Flow Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
6007-51C-85-B	Fuel Flow Indicator	Eclipse Pioneer
6007-51D-7-A	Fuel Flow Indicator	Eclipse Pioneer
6007-51D-7-B	Fuel Flow Indicator	Eclipse Pioneer
6007-51E-36-B	Fuel Flow Indicator	Eclipse Pioneer
6007-51H-31-B	Fuel Flow Indicator	Eclipse Pioneer
6007-51J-32-B	Fuel Flow Indicator	Eclipse Pioneer
6007-69A-43-B	Fuel Flow Indicator	Eclipse Pioneer
6007-69B-44-B	Fuel Flow Indicator	Eclipse Pioneer
6007-70A-43-B1	Fuel Flow Indicator	Eclipse Pioneer
6007-70B-44-B1	Fuel Flow Indicator	Eclipse Pioneer
6007-80A-31-B	Fuel Flow Indicator	Eclipse Pioneer
6007-83B-31B	Fuel Flow Indicator	Eclipse Pioneer
6007-83B-32B	Fuel Flow Indicator	Eclipse Pioneer
6008-14A-4-A	Fuel Flow Indicator	Eclipse Pioneer
6040	Fuel Flow Indicator	United Instruments
6042	Fuel Flow Indicator	United Instruments
6060-0301	Fuel Flow Indicator	United Instruments
6200-B12C-1-A3	Fuel Flow Indicator	Eclipse Pioneer
6210	Fuel Flow Indicator	United Instruments
6220	Fuel Flow Indicator	United Instruments
6246-00105	Fuel Quantity Indicator	Rochester
6300-A15B-1-A2	Fuel Flow Indicator	Eclipse Pioneer
6300-B5A-14-A2	Fuel Flow Indicator	Eclipse Pioneer
6300-B5B-15-A2	Fuel Flow Indicator	Eclipse Pioneer
6311	Fuel Flow/Manifold Pressure	United Instruments
6311-H.88	Fuel Flow/Manifold Pressure	United Instruments
6312	Fuel Flow/Manifold Pressure	United Instruments
6313-H.78	Fuel Flow/Manifold Pressure	United Instruments
6314	Fuel Flow/Manifold Pressure	United Instruments
6315	Fuel Flow/Manifold Pressure	United Instruments

6331	Fuel Flow/Manifold Pressure	United Instruments
6331-H79	Fuel Flow/Manifold Pressure	United Instruments
6332	Fuel Flow/Manifold Pressure	United Instruments
6333	Fuel Flow/Manifold Pressure	United Instruments
651035-0107	Fuel Flow/Manifold Pressure	Aerosonic
651035-0112	Fuel Flow/Manifold Pressure	Aerosonic
651035-1113	Fuel Flow/Manifold Pressure	Aerosonic
6511	Fuel Flow Indicator	United Instruments
6511F.21	Fuel Flow Indicator	United Instruments
6531	Fuel Flow/Manifold Pressure	United Instruments
6533-1	Fuel Flow/Manifold Pressure	United Instruments
6533-1H.124	Fuel Flow/Manifold Pressure	United Instruments
6533-1H.130	Fuel Flow/Manifold Pressure	United Instruments
6533-1H.143	Fuel Flow/Manifold Pressure	United Instruments

Primary Part Number	Nomenclature	Manufacture
6533-1H.144	Fuel Flow/Manifold Pressure	United Instruments
6533-H.115	Fuel Flow/Manifold Pressure	United Instruments
6533-H.116	Fuel Flow/Manifold Pressure	United Instruments
6533-H.117	Fuel Flow/Manifold Pressure	United Instruments
6533-H.118	Fuel Flow/Manifold Pressure	United Instruments
6534-H.111	Fuel Flow/Manifold Pressure	United Instruments
6534-H.112	Fuel Flow/Manifold Pressure	United Instruments
6534-H.114	Fuel Flow/Manifold Pressure	United Instruments
6534-H.148	Fuel Flow/Manifold Pressure	United Instruments
65840-0106	Fuel Flow Indicator	Aerosonic
65840-0107	Fuel Flow Indicator	Aerosonic
65840-0114	Fuel Flow Indicator	Aerosonic
65840-0132	Fuel Flow Indicator	Aerosonic
65840-0133	Fuel Flow Indicator	Aerosonic
65840-0134	Fuel Flow Indicator	Aerosonic
65840-0135	Fuel Flow Indicator	Aerosonic
65840-0136	Fuel Flow Indicator	Aerosonic
65840-0137	Fuel Flow Indicator	Aerosonic
65840-0138	Fuel Flow Indicator	Aerosonic
65840-0147	Fuel Flow Indicator	Aerosonic
65840-0148	Fuel Flow Indicator	Aerosonic
65840-0154	Fuel Flow Indicator	Aerosonic
65840-0155	Fuel Flow Indicator	Aerosonic
65840-0157	Fuel Flow Indicator	Aerosonic
65840-0159	Fuel Flow Indicator	Aerosonic
65840-1115	Fuel Flow Indicator	Aerosonic
65840-1156	Fuel Flow Indicator	Aerosonic
65840-1158	Fuel Flow Indicator	Aerosonic
660063-503	Fuel Flow/Manifold Pressure	AID
66840-1138	Fuel Flow Indicator	Aerosonic
704173	Transmitter	Intertechnique
723-160-1	Fuel Flow Indicator	Intertechnique
723-160-2	Fuel Flow Indicator	Intertechnique
7507-4-A5-1	Fuel Flow Transmitter	Bendix

7609-37-H5-1	Pressure Transmitter	Bendix
7704-44-A12-1	Fuel Flow Transmitter	Eclipse Pioneer
790711	Transmitter	Intertechnique
8DJ107LWG1	Fuel Flow Indicator	Ametek/GE
8DJ121GAA1	Fuel Flow Indicator	Ametek/GE
8DJ121GAB1	Fuel Flow Indicator	Ametek/GE
8DJ121GAC1	Fuel Flow Indicator	Ametek/GE
8DJ121GAD1	Fuel Flow Indicator	Ametek/GE
8DJ121LWA1	Fuel Flow Indicator	Ametek/GE
8DJ121LWC1	Fuel Flow Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ125GAA1	Fuel Flow Indicator	Ametek/GE
8DJ125GAA2	Fuel Flow Indicator	Ametek/GE
8DJ125GAD2	Fuel Flow Indicator	Ametek/GE
8DJ125GAD3	Fuel Flow Indicator	Ametek/GE
8DJ125GAD4	Fuel Flow Indicator	Ametek/GE
8DJ125LAA2	Fuel Flow Indicator	Ametek/GE
8DJ125LAA3	Fuel Flow Indicator	Ametek/GE
8DJ125LAA4	Fuel Flow Indicator	Ametek/GE
8DJ125LAB2	Fuel Flow Indicator	Ametek/GE
8DJ125LAB3	Fuel Flow Indicator	Ametek/GE
8DJ125LAB4	Fuel Flow Indicator	Ametek/GE
8DJ125LAE4	Fuel Flow Indicator	Ametek/GE
8DJ125LWA1	Fuel Flow Indicator	Ametek/GE
8DJ125LWB2	Fuel Flow Indicator	Ametek/GE
8DJ125LWB3	Fuel Flow Indicator	Ametek/GE
8DJ125LWB4	Fuel Flow Indicator	Ametek/GE
8DJ125LWC2	Fuel Flow Indicator	Ametek/GE
8DJ125LWC3	Fuel Flow Indicator	Ametek/GE
8DJ125LWC4	Fuel Flow Indicator	Ametek/GE
8DJ125LWE2	Fuel Flow Indicator	Ametek/GE
8DJ125LWE3	Fuel Flow Indicator	Ametek/GE
8DJ125LWE4	Fuel Flow Indicator	Ametek/GE
8DJ125LWF2	Fuel Flow Indicator	Ametek/GE
8DJ125LWF3	Fuel Flow Indicator	Ametek/GE
8DJ125LWF4	Fuel Flow Indicator	Ametek/GE
8DJ125LWG1	Fuel Flow Indicator	Ametek/GE
8DJ125LWG2	Fuel Flow Indicator	Ametek/GE
8DJ125LWG3	Fuel Flow Indicator	Ametek/GE
8DJ125LWG4	Fuel Flow Indicator	Ametek/GE
8DJ125LWH1	Fuel Flow Indicator	Ametek/GE
8DJ125LWH2	Fuel Flow Indicator	Ametek/GE
8DJ125LWH3	Fuel Flow Indicator	Ametek/GE
8DJ125LWK2	Fuel Flow Indicator	Ametek/GE
8DJ125LWK3	Fuel Flow Indicator	Ametek/GE
8DJ125LWK4	Fuel Flow Indicator	Ametek/GE
8DJ125LWR3	Fuel Flow Indicator	Ametek/GE
8DJ125LWR4	Fuel Flow Indicator	Ametek/GE
8DJ125LWS3	Fuel Flow Indicator	Ametek/GE

8DJ125LWS4	Fuel Flow Indicator	Ametek/GE
8DJ125LWT3	Fuel Flow Indicator	Ametek/GE
8DJ125LWT4	Fuel Flow Indicator	Ametek/GE
8DJ125LWV3	Fuel Flow Indicator	Ametek/GE
8DJ125LWV4	Fuel Flow Indicator	Ametek/GE
8DJ125LWX3	Fuel Flow Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ125LWX4	Fuel Flow Indicator	Ametek/GE
8DJ125LWY3	Fuel Flow Indicator	Ametek/GE
8DJ125LWY4	Fuel Flow Indicator	Ametek/GE
8DJ125LXB3	Fuel Flow Indicator	Ametek/GE
8DJ125LXC3	Fuel Flow Indicator	Ametek/GE
8DJ125LXD4	Fuel Flow Indicator	Ametek/GE
8DJ125LXE4	Fuel Flow Indicator	Ametek/GE
8DJ125LXK3	Fuel Flow Indicator	Ametek/GE
8DJ125LXK4	Fuel Flow Indicator	Ametek/GE
8DJ125LXP3	Fuel Flow Indicator	Ametek/GE
8DJ125MWA4	Fuel Flow Indicator	Ametek/GE
8DJ125MWB4	Fuel Flow Indicator	Ametek/GE
8DJ125MWC4	Fuel Flow Indicator	Ametek/GE
8DJ125MWD4	Fuel Flow Indicator	Ametek/GE
8DJ130	Indicator	Ametek
8DJ130GAR1	Indicator	Ametek
8DJ135LAA1	Fuel Flow Indicator	Ametek/GE
8DJ135LWB1	Indicator	GE / Ametek
8DJ13WAA2	Fuel Flow Indicator	Ametek/GE
8DJ142GAC2	Fuel Flow Indicator	Ametek/GE
8DJ142GAD2	Fuel Flow Indicator	Ametek/GE
8DJ142GAH2	Fuel Flow Indicator	Ametek/GE
8DJ142GAT2	Fuel Flow Indicator	Ametek/GE
8DJ142GAX2	Fuel Flow Indicator	Ametek/GE
8DJ142GBB2	Fuel Flow Indicator	Ametek/GE
8DJ142GBC2	Fuel Flow Indicator	Ametek/GE
8DJ142GBD2	Fuel Flow Indicator	Ametek/GE
8DJ142GBG2	Fuel Flow Indicator	Ametek/GE
8DJ142GBL2	Fuel Flow Indicator	Ametek/GE
8DJ142LAA2	Fuel Flow Indicator	Ametek/GE
8DJ142LAD2	Fuel Flow Indicator	Ametek/GE
8DJ142LAH2	Fuel Flow Indicator	Ametek/GE
8DJ142LAS2	Fuel Flow Indicator	Ametek/GE
8DJ142LAT3	Fuel Flow Indicator	Ametek/GE
8DJ142LAV3	Fuel Flow Indicator	Ametek/GE
8DJ142LAX3	Fuel Flow Indicator	Ametek/GE
8DJ142LWA2	Fuel Flow Indicator	Ametek/GE
8DJ142LWB2	Fuel Flow Indicator	Ametek/GE
8DJ142LWE2	Fuel Flow Indicator	Ametek/GE
8DJ142LWH2	Fuel Flow Indicator	Ametek/GE
8DJ142LWM2	Fuel Flow Indicator	Ametek/GE
8DJ142LWN2	Fuel Flow Indicator	Ametek/GE

8DJ142LWS3	Fuel Flow Indicator	Ametek/GE
8DJ142LWT3	Fuel Flow Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ164LWA1	Fuel Flow Indicator	Ametek/GE
8DJ164LWA2	Fuel Flow Indicator	Ametek/GE
8DJ164LWG2	Fuel Flow Indicator	Ametek/GE
8DJ164LWM2	Fuel Flow Indicator	Ametek/GE
8DJ164LWN2	Fuel Flow Indicator	Ametek/GE
8DJ164LWP2	Fuel Flow Indicator	Ametek/GE
8DJ164LWR2	Fuel Flow Indicator	Ametek/GE
8DJ164LWS2	Fuel Flow Indicator	Ametek/GE
8DJ164LWT2	Fuel Flow Indicator	Ametek/GE
8DJ164LWT3	Fuel Flow Indicator	Ametek/GE
8DJ164LWV2	Fuel Flow Indicator	Ametek/GE
8DJ164LWX2	Fuel Flow Indicator	Ametek/GE
8DJ164LWX3	Fuel Flow Indicator	Ametek/GE
8DJ170LWA1	Fuel Flow Indicator	Ametek/GE
8DJ180LWA1	Fuel Flow Indicator	Ametek/GE
8DJ180LWD1	Fuel Flow Indicator	Ametek/GE
8DJ180LWE1	Fuel Flow Indicator	Ametek/GE
8DJ64GAA1	Fuel Flow Indicator	Ametek/GE
8DJ64GAF1	Fuel Flow Indicator	Ametek/GE
8DJ64GAN1	Fuel Flow Indicator	Ametek/GE
8DJ64GAS1	Fuel Flow Indicator	Ametek/GE
8DJ64GAT1	Fuel Flow Indicator	Ametek/GE
8DJ64GAX1	Fuel Flow Indicator	Ametek/GE
8DJ64GBA1	Fuel Flow Indicator	Ametek/GE
8DJ64GBC1	Fuel Flow Indicator	Ametek/GE
8DJ64GBH1	Fuel Flow Indicator	Ametek/GE
8DJ64GBW1	Fuel Flow Indicator	Ametek/GE
8DJ71GAB1	Fuel Flow Indicator	Ametek/GE
8DJ71GAK2	Fuel Flow Indicator	Ametek/GE
8DJ72GAB1	Fuel Flow Indicator	Ametek/GE
8DJ72GAD2	Fuel Flow Indicator	Ametek/GE
8DJ77LAC1	Fuel Flow Indicator	Ametek/GE
8DJ77LAC2	Fuel Flow Indicator	Ametek/GE
8DJ77LAD1	Fuel Flow Indicator	Ametek/GE
8DJ77LAD2	Fuel Flow Indicator	Ametek/GE
8DJ77LAE1	Fuel Flow Indicator	Ametek/GE
8DJ77LAE2	Fuel Flow Indicator	Ametek/GE
8DJ77LAF1	Fuel Flow Indicator	Ametek/GE
8DJ77LAF2	Fuel Flow Indicator	Ametek/GE
8DJ77LAM2	Fuel Flow Indicator	Ametek/GE
8DJ77LWB2	Fuel Flow Indicator	Ametek/GE
8DJ77LWE2	Fuel Flow Indicator	Ametek/GE
8DJ77LWF2	Fuel Flow Indicator	Ametek/GE
8DJ77LWH2	Fuel Flow Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture

8DJ77LWK2	Fuel Flow Indicator	Ametek/GE
8DJ88GAC1	Fuel Flow Indicator	Ametek/GE
8DJ88GAJ3	Fuel Flow Indicator	Ametek/GE
8DJ88LAB1	Fuel Flow Indicator	Ametek/GE
8DJ88LAB2	Fuel Flow Indicator	Ametek/GE
8DJ88LAB3	Fuel Flow Indicator	Ametek/GE
8DJ88LWB1	Fuel Flow Indicator	Ametek/GE
8DJ88LWC2	Fuel Flow Indicator	Ametek/GE
8DJ88LWC3	Fuel Flow Indicator	Ametek/GE
8DJ88LWD2	Fuel Flow Indicator	Ametek/GE
8DJ88LWD3	Fuel Flow Indicator	Ametek/GE
8DJ88LWE3	Fuel Flow Indicator	Ametek/GE
8DJ88LWF2	Fuel Flow Indicator	Ametek/GE
8DJ88LWF3	Fuel Flow Indicator	Ametek/GE
8DJ88LWG3	Fuel Flow Indicator	Ametek/GE
8DJ88LWH3	Fuel Flow Indicator	Ametek/GE
8DJ88LWK3	Fuel Flow Indicator	Ametek/GE
8DJ88LWM3	Fuel Flow Indicator	Ametek/GE
8DJ88LWN3	Fuel Flow Indicator	Ametek/GE
8DJ88LWS3	Fuel Flow Indicator	Ametek/GE
8DJ88LWX3	Fuel Flow Indicator	Ametek/GE
8DJ88LWY3	Fuel Flow Indicator	Ametek/GE
8DJ88LXA3	Fuel Flow Indicator	Ametek/GE
8DJ88LXC3	Fuel Flow Indicator	Ametek/GE
8DJ88LXV3	Fuel Flow Indicator	Ametek/GE
8DJ88LYF3	Fuel Flow Indicator	Ametek/GE
8DJ96LAC1	Fuel Flow Indicator	Ametek/GE
8DJ96LAD1	Fuel Flow Indicator	Ametek/GE
8DJ96LAF1	Fuel Flow Indicator	Ametek/GE
8DJ96LWA1	Fuel Flow Indicator	Ametek/GE
8DJ97GAA1	Fuel Flow Indicator	Ametek/GE
8DJ97GAC1	Fuel Flow Indicator	Ametek/GE
8DJ97LAA1	Fuel Flow Indicator	Ametek/GE
8KE24GAF1	Flow Meter Amplifier	Ametek/GE
8KE25GAC1	Flow Meter Amplifier	Ametek/GE
8KE25GAD1	Flow Meter Amplifier	Ametek/GE
8KE25GAE1	Flow Meter Amplifier	Ametek/GE
8KE25GAF1	Flow Meter Amplifier	Ametek/GE
8KE25GAN1	Flow Meter Amplifier	Ametek/GE
8KE5GAN1	Fuel Flow Amplifier	Ametek/GE
8TJ120GAA1	Fuel Flow Power Supply	Ametek/GE
8TJ120GAB2	Fuel Flow Power Supply	Ametek/GE
8TJ124GGA1	Fuel Flow Transmitter	Ametek/GE
8TJ124GGC1	Fuel Flow Transmitter	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8TJ124GGD1	Fuel Flow Transnitter	Ametek/GE
8TJ124GGL1	Fuel Flow Transmitter	Ametek/GE
8TJ124GGM1	Fuel Flow Transmitter	Ametek/GE
8TJ124GGN1	Fuel Flow Transmitter	Ametek/GE

8TJ124GGN2	Fuel Flow Transmitter	Ametek/GE
8TJ124GGN3	Fuel Flow Transmitter	Ametek/GE
8TJ124GGR1	Fuel Flow Transmitter	Ametek/GE
8TJ124GHG1	Fuel Flow Transmitter	Ametek/GE
8TJ126GAT2	Fuel Flow Transmitter	Ametek/GE
8TJ146AAP1	Oil Level Transmitter	Ametek/GE
8TJ167GHH1	Fuel Flow Transmitter	Ametek/GE
8TJ167GHM1	Fuel Flow Transmitter	Ametek/GE
8TJ167GHVI	Fuel Flow Transmitter	Ametek/GE
8TJ49GAA1	Fuel Flow Power Supply	Ametek/GE
8TJ49GAA2	Fuel Flow Power Supply	Ametek/GE
8TJ49GAA3	Fuel Flow Power Supply	Ametek/GE
8TJ49GAA4	Fuel Flow Power Supply	Ametek/GE
8TJ50GAB1	Fuel Flow Transmitter	Ametek/GE
8TJ50GAB3	Fuel Flow Transmitter	Ametek/GE
8TJ50GAS4	Fuel Flow Transmitter	Ametek/GE
8TJ50GAS5	Fuel Flow Transmitter	Ametek/GE
8TJ50GAY3	Fuel Flow Transmitter	Ametek/GE
8TJ50GBM5	Fuel Flow Transmitter	Ametek/GE
8TJ50GBX3	Fuel Flow Transmitter	Ametek/GE
8TJ50GBX4	Fuel Flow Transmitter	Ametek/GE
8TJ50GBZ3	Fuel Flow Transmitter	Ametek/GE
8TJ50GCA3	Fuel Flow Transmitter	Ametek/GE
8TJ50GCE3	Fuel Flow Transmitter	Ametek/GE
8TJ50GCE4	Fuel Flow Transmitter	Ametek/GE
8TJ51GAA1	Fuel Flow Power Supply	Ametek/GE
8TJ51GAA2	Fuel Flow Power Supply	Ametek/GE
8TJ51GAA4	Fuel Flow Power Supply	Ametek/GE
8TJ51GAA5	Fuel Flow Power Supply	Ametek/GE
8TJ51GBB5	Fuel Flow Power Supply	Ametek/GE
8TJ53GAA1	Fuel Flow Transmitter	Ametek/GE
8TJ53GAA2	Fuel Flow Transmitter	Ametek/GE
8TJ54GAD2	Fuel Flow Transmitter	Ametek/GE
8TJ54GAL2	Fuel Flow Transmitter	Ametek/GE
8TJ54GAM2	Fuel Flow Transmitter	Ametek/GE
8TJ59GAA1	Fuel Flow Transmitter	Ametek/GE
8TJ59GAA2	Fuel Flow Transmitter	Ametek/GE
8TJ59GAA3	Fuel Flow Transmitter	Ametek/GE
8TJ59GAB1	Fuel Flow Transmitter	Ametek/GE
8TJ59GAB2	Fuel Flow Transmitter	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8TJ59GAB3	Fuel Flow Transmitter	Ametek/GE
8TJ59GAD1	Fuel Flow Transmitter	Ametek/GE
8TJ59GAD2	Fuel Flow Transmitter	Ametek/GE
8TJ59GAF1	Fuel Flow Transmitter	Ametek/GE
8TJ59GAF2	Fuel Flow Transmitter	Ametek/GE
8TJ59GAF3	Fuel Flow Transmitter	Ametek/GE
8TJ59GAL2	Fuel Flow Transmitter	Ametek/GE
8TJ59GAM2	Fuel Flow Transmitter	Ametek/GE

8TJ59GAM3	Fuel Flow Transmitter	Ametek/GE
8TJ59GAM4	Fuel Flow Transmitter	Ametek/GE
8TJ59GAM5	Fuel Flow Transmitter	Ametek/GE
8TJ59GAR3	Fuel Flow Transmitter	Ametek/GE
8TJ59GAS2	Fuel Flow Transmitter	Ametek/GE
8TJ59GAT3	Fuel Flow Transmitter	Ametek/GE
8TJ59GAX3	Fuel Flow Transmitter	Ametek/GE
8TJ59GBB3	Fuel Flow Transmitter	Ametek/GE
8TJ59GBD3	Fuel Flow Transmitter	Ametek/GE
8TJ59GBE3	Fuel Flow Transmitter	Ametek/GE
8TJ59GCA1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCB1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCD1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCE1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCF1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCL1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCM1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCR1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCS1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCT1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCX1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCY1	Fuel Flow Transmitter	Ametek/GE
8TJ59GCZ1	Fuel Flow Transmitter	Ametek/GE
8TJ59GDR1	Fuel Flow Transmitter	Ametek/GE
8TJ59GEA1	Fuel Flow Transmitter	Ametek/GE
8TJ59GEB1	Fuel Flow Transmitter	Ametek/GE
8TJ59GED1	Fuel Flow Transmitter	Ametek/GE
8TJ59GEE1	Fuel Flow Transmitter	Ametek/GE
8TJ59GEF1	Fuel Flow Transmitter	Ametek/GE
8TJ59GEL1	Fuel Flow Transmitter	Ametek/GE
8TJ59GEM1	Fuel Flow Transmitter	Ametek/GE
8TJ59GER1	Fuel Flow Transmitter	Ametek/GE
8TJ59GES1	Fuel Flow Transmitter	Ametek/GE
8TJ59GET1	Fuel Flow Transmitter	Ametek/GE
8TJ59GEX1	Fuel Flow Transmitter	Ametek/GE
8TJ59GSB1	Fuel Flow Transmitter	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8TJ59GSC1	Fuel Flow Transmitter	Ametek/GE
8TJ59GSD1	Fuel Flow Transmitter	Ametek/GE
8TJ61GAB1	Fuel Flow Transmitter	Ametek/GE
8TJ61GAB2	Fuel Flow Transmitter	Ametek/GE
8TJ61GAB3	Fuel Flow Transmitter	Ametek/GE
8TJ61GAF1	Fuel Flow Transmitter	Ametek/GE
8TJ61GAF2	Fuel Flow Transmitter	Ametek/GE
8TJ61GAX2	Fuel Flow Transmitter	Ametek/GE
8TJ61GAX3	Fuel Flow Transmitter	Ametek/GE
8TJ61GBL	Fuel Flow Transmitter	Ametek/GE
8TJ61GBL3	Fuel Flow Transmitter	Ametek/GE
8TJ62GBA3	Fuel Flow Transmitter	Ametek/GE

8TJ62GBC3	Fuel Flow Transmitter	Ametek/GE
8TJ62GBK3	Fuel Flow Transmitter	Ametek/GE
8TJ62GBZ3	Fuel Flow Transmitter	Ametek/GE
8TJ62GCA3	Fuel Flow Transmitter	Ametek/GE
8TJ62GCA4	Fuel Flow Transmitter	Ametek/GE
8TJ64AAC2	Fuel Flow Transmitter	Ametek/GE
8TJ64GAC1	Fuel Flow Transmitter	Ametek/GE
8TJ64GAF1	Fuel Flow Transmitter	Ametek/GE
8TJ64GAH1	Fuel Flow Transmitter	Ametek/GE
8TJ64GAL1	Fuel Flow Transmitter	Ametek/GE
8TJ64GAV1	Fuel Flow Transmitter	Ametek/GE
8TJ64GBA1	Fuel Flow Transmitter	Ametek/GE
8TJ64GBD1	Fuel Flow Transmitter	Ametek/GE
8TJ64GBE1	Fuel Flow Transmitter	Ametek/GE
8TJ64GBK2	Fuel Flow Transmitter	Ametek/GE
8TJ64GBL2	Fuel Flow Transmitter	Ametek/GE
8TJ64GBM2	Fuel Flow Transmitter	Ametek/GE
8TJ64GBM3	Fuel Flow Transmitter	Ametek/GE
8TJ64GBN2	Fuel Flow Transmitter	Ametek/GE
8TJ64GBR2	Fuel Flow Transmitter	Ametek/GE
8TJ64GBS2	Fuel Flow Transmitter	Ametek/GE
8TJ64GBT2	Fuel Flow Transmitter	Ametek/GE
8TJ64GBW2	Fuel Flow Transmitter	Ametek/GE
8TJ64GBZ2	Fuel Flow Transmitter	Ametek/GE
8TJ64GCA2	Fuel Flow Transmitter	Ametek/GE
8TJ64GCC2	Fuel Flow Transmitter	Ametek/GE
8TJ64GCK2	Fuel Flow Transmitter	Ametek/GE
8TJ64GCM2	Fuel Flow Transmitter	Ametek/GE
8TJ64GCW2	Fuel Flow Transmitter	Ametek/GE
8TJ64GDM2	Fuel Flow Transmitter	Ametek/GE
8TJ64GDT2	Fuel Flow Transmitter	Ametek/GE
8TJ64GDZ3	Fuel Flow Transmitter	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8TJ80GAA1	Fuel Flow Power Supply	Ametek/GE
8TJ80GAA2	Fuel Flow Power Supply	Ametek/GE
8TJ85GAA1	Fuel Flow Transmitter	Ametek/GE
8TJ85GAB1	Fuel Flow Transmitter	Ametek/GE
8TJ85GAK1	Fuel Flow Transmitter	Ametek/GE
8TJ85GAK2	Fuel Flow Transmitter	Ametek/GE
8TJ85GAP1	Fuel Flow Transmitter	Ametek/GE
8TJ85GAS1	Fuel Flow Transmitter	Ametek/GE
8TJ85GAT1	Fuel Flow Transmitter	Ametek/GE
8TJ85GAV1	Fuel Flow Transmitter	Ametek/GE
8TJ85GAZ1	Fuel Flow Transmitter	Ametek/GE
8TJ85GAZ2	Fuel Flow Transmitter	Ametek/GE
8TJ85GBA1	Fuel Flow Transmitter	Ametek/GE
8TJ85GBA2	Fuel Flow Transmitter	Ametek/GE
8TJ85GCG2	Fuel Flow Transmitter	Ametek/GE
8TJ85GHA1	Fuel Flow Transmitter	Ametek/GE

8TJ85GHL1	Fuel Flow Transmitter	Ametek/GE
8TJ85GHM1	Fuel Flow Transmitter	Ametek/GE
8TJ85GHM2	Fuel Flow Transmitter	Ametek/GE
8TJ85GHX2	Fuel Flow Transmitter	Ametek/GE
8TJ85GHX3	Fuel Flow Transmitter	Ametek/GE
8TJ85GHY3	Fuel Flow Transmitter	Ametek/GE
8TJ85GJA2	Fuel Flow Transmitter	Ametek/GE
8TJ88GAC1	Fuel Flow Power Supply	Ametek/GE
8TJ88GAD1	Fuel Flow Power Supply	Ametek/GE
8TJ88GAD3	Fuel Flow Power Supply	Ametek/GE
8TJ88GAE1	Fuel Flow Power Supply	Ametek/GE
8TJ88GAF1	Fuel Flow Power Supply	Ametek/GE
8TJ88GAH3	Fuel Flow Power Supply	Ametek/GE
8TJ88GAN1	Fuel Flow Power Supply	Ametek/GE
8TJ88GAN3	Fuel Flow Power Supply	Ametek/GE
8TJ88GAN4	Fuel Flow Power Supply	Ametek/GE
8TJ88GAP1	Fuel Flow Power Supply	Ametek/GE
8TJ88GAP3	Fuel Flow Power Supply	Ametek/GE
8TJ88GAR1	Fuel Flow Power Supply	Ametek/GE
8TJ88GAR3	Fuel Flow Power Supply	Ametek/GE
8TJ88GAT1	Fuel Flow Power Supply	Ametek/GE
8TJ88GAV1	Fuel Flow Power Supply	Ametek/GE
8TJ88GAV3	Fuel Flow Power Supply	Ametek/GE
8TJ88GBC1	Fuel Flow Power Supply	Ametek/GE
8TJ88GBD1	Fuel Flow Power Supply	Ametek/GE
8TJ88GBD3	Fuel Flow Power Supply	Ametek/GE
8TJ88GBE1	Fuel Flow Power Supply	Ametek/GE
8TJ88GBF1	Fuel Flow Power Supply	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8TJ88GBN1	Fuel Flow Power Supply	Ametek/GE
8TJ88GBN3	Fuel Flow Power Supply	Ametek/GE
8TJ95GAA1	Fuel Flow Power Supply	Ametek/GE
8TJ95GAA2	Fuel Flow Power Supply	Ametek/GE
8TJ95GAA4	Fuel Flow Power Supply	Ametek/GE
8TJ95GAAY2	Fuel Flow Power Supply	Ametek/GE
8TJ95GAB1	Fuel Flow Power Supply	Ametek/GE
8TJ95GAB2	Fuel Flow Power Supply	Ametek/GE
8TJ95GAB3	Fuel Flow Power Supply	Ametek/GE
8TJ95GAB4	Fuel Flow Power Supply	Ametek/GE
8TJ95GAC4	Fuel Flow Power Supply	Ametek/GE
8TJ95GAD3	Fuel Flow Power Supply	Ametek/GE
8TJ95GBA2	Fuel Flow Power Supply	Ametek/GE
8TJ95GBAY3	Fuel Flow Power Supply	Ametek/GE
8TJ95GBB2	Fuel Flow Power Supply	Ametek/GE
90-380009-5	Fuel Flow Indicator	Gull
90-380009-7	Fuel Flow Transmitter	Gull
9054-3-A	Fuel Flow Transmitter	Eclipse Pioneer
9054-4-A	Fuel Flow Transmitter	Eclipse Pioneer
9054-5-A	Fuel Flow Transmitter	Eclipse Pioneer

9054-5-B	Fuel Flow Transmitter	Eclipse Pioneer
9054-7-A	Fuel Flow Transmitter	Eclipse Pioneer
9054-7-B	Fuel Flow Transmitter	Eclipse Pioneer
9057-10-A	Fuel Flow Transmitter	Eclipse Pioneer
9057-10-B1	Fuel Flow Transmitter	Pioneer Central
9057-9-A	Fuel Flow Transmitter	Eclipse Pioneer
9061-11-A	Fuel Flow Transmitter	Eclipse Pioneer
9061-11-B	Fuel Flow Transmitter	Eclipse Pioneer
9100-3-A	Fuel Flow Transmitter	Eclipse Pioneer
9100-3-B	Fuel Flow Transmitter	Eclipse Pioneer
9100-3-C3	Fuel Flow Transmitter	Bendix
9100-4-A	Fuel Flow Transmitter	Eclipse Pioneer
9100-4-B1	Fuel Flow Transmitter	Pioneer Central
9100-4-B1A	Fuel Flow Transmitter	Pioneer Central
9100-4-B2A	Fuel Flow Transmitter	Pioneer Central
9100-5-A	Fuel Flow Transmitter	Eclipse Pioneer
9100-5-A1	Fuel Flow Transmitter	Pioneer Central
9100-5-B	Fuel Flow Transmitter	Eclipse Pioneer
9100-5-B1A	Fuel Flow Transmitter	Pioneer Central
9100-7-A	Fuel Flow Transmitter	Eclipse Pioneer
9100-7-A1	Fuel Flow Transmitter	Pioneer Central
9100-7-A4	Fuel Flow Transmitter	Pioneer Central
9100-7-A4A	Fuel Flow Transmitter	Pioneer Central
9100-7-B	Fuel Flow Transmitter	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
9100-7-B2A	Fuel Flow Transmitter	Pioneer Central
9100-7-B3A	Fuel Flow Transmitter	Pioneer Central
9102-12-A	Fuel Flow Transmitter	Eclipse Pioneer
9102-12-B	Fuel Flow Transmitter	Eclipse Pioneer
9102-12-B2	Fuel Flow Transmitter	Pioneer Central
9102-12-B2A	Fuel Flow Transmitter	Pioneer Central
9102-12-B3A	Fuel Flow Transmitter	Pioneer Central
9102-12-C	Fuel Flow Transmitter	Eclipse Pioneer
9102-12-C1	Fuel Flow Transmitter	Pioneer Central
9104-12-A	Fuel Flow Transmitter	Eclipse Pioneer
9104-12-A1	Fuel Flow Transmitter	Pioneer Central
9104-12-A1A	Fuel Flow Transmitter	Pioneer Central
9104-12-A2	Fuel Flow Transmitter	Pioneer Central
9104-12-A2A	Fuel Flow Transmitter	Pioneer Central
9104-12-A4	Fuel Flow Transmitter	Pioneer Central
9104-12-A6A	Fuel Flow Transmitter	Pioneer Central
9105-10-B1A	Fuel Flow Transmitter	Pioneer Central
9105-12-A	Fuel Flow Transmitter	Eclipse Pioneer
9105-12-A1	Fuel Flow Transmitter	Pioneer Central
9105-12-A1A	Fuel Flow Transmitter	Pioneer Central
9106-12-A	Fuel Flow Transmitter	Eclipse Pioneer
9106-12-A1	Fuel Flow Transmitter	Pioneer Central
9106-12-B	Fuel Flow Transmitter	Eclipse Pioneer
9106-12-B1A	Fuel Flow Transmitter	Pioneer Central

9107-4-A1A	Fuel Flow Transmitter	Pioneer Central
9109-13-A1A	Fuel Flow Transmitter	Pioneer Central
9110-7-A1A	Fuel Flow Transmitter	Pioneer Central
9-112-01	Fuel Flow Transmitter	Eldec
9-112-02	Fuel Flow Transmitter	Eldec
9-112-03	Fuel Flow Transmitter	Eldec
9-112-05	Fuel Flow Transmitter	Eldec
9-112-06	Fuel Flow Transmitter	Eldec
9-112-11	Fuel Flow Transmitter	Eldec
9112-14-A1A	Fuel Flow Transmitter	Pioneer Central
9-114-02	Fuel Flow Transmitter	Eldec
9-114-05	Fuel Flow Transmitter	Eldec
9-114-06	Fuel Flow Transmitter	Eldec
9114-7-A1A	Fuel Flow Transmitter	Pioneer Central
9-115-10	Fuel Flow Electronics	Eldec
9-115-11	Fuel Flow Electronics	Eldec
9-115-13	Fuel Flow Electronics	Eldec
9-115-14	Fuel Flow Electronics	Eldec
9115-16-A1A	Fuel Flow Transmitter	Pioneer Central
9115-16-B1A	Fuel Flow Transmitter	Pioneer Central

Primary Part Number	Nomenclature	Manufacture
9115-16-C1A	Fuel Flow Transmitter	Pioneer Central
9115-16-D1	Fuel Flow Transmitter	Pioneer Central
9-115-18	Fuel Flow Electronics	Eldec
9-115-19	Fuel Flow Electronics	Eldec
9115-22-A1A	Fuel Flow Transmitter	Pioneer Central
9115-22-B1A	Fuel Flow Transmitter	Pioneer Central
9115-22-C1A	Fuel Flow Transmitter	Pioneer Central
9-115-29	Fuel Flow Indicator	Eldec
9116-19-A1A	Fuel Flow Transmitter	Pioneer Central
9117-16-A1	Fuel Flow Transmitter	Pioneer Central
9-118-03	Fuel Flow Indicator	Eldec
9-118-04	Fuel Flow Indicator	Eldec
9-118-12	Fuel Flow Indicator	Eldec
9-118-14	Fuel Flow Indicator	Eldec
9-118-15	Fuel Flow Indicator	Eldec
9-127-11	Fuel Flow Transmitter	Eldec
9-127-27	Fuel Flow Transmitter	Eldec
9-127-48	Fuel Flow Transmitter	Eldec
9-127-55	Fuel Flow Transmitter	Eldec
9-127-68	Fuel Flow Transmitter	Eldec
9-127-83	Fuel Flow Transmitter	Eldec
9133-25-B1	Fuel Flow Transmitter	Bendix
9133-54-A1	Fuel Flow Transmitter	Bendix
9133-54-B1	Fuel Flow Transmitter	Bendix
9133-84-B1	Fuel Flow Transmitter	Bendix
9136-4C1	Fuel Flow Transmitter	Bendix
9136-05-01	Fuel Flow Transmitter	Bendix
9136-5-A1	Fuel Flow Transmitter	Bendix

9136-5C1	Fuel Flow Transmitter	Bendix
9136-81C1	Fuel Flow Transmitter	Bendix
9-196-01	Fuel Flow Transmitter	Eldec
9-196-02	Fuel Flow Transmitter	Eldec
9-217-30	Fuel Flow Transmitter	Eldec
9-217-33	Fuel Flow Transmitter	Eldec
9-217-38	Fuel Flow Transmitter	Eldec
9-231-07	Fuel Flow Transmitter	Eldec
9-231-10	Fuel Flow Transmitter	Eldec
9-231-14	Transmitter	Crane / Eldec
9-328-01	Fuel Flow Indicator	Eldec
9-328-19	Fuel Flow Transmitter	Eldec
9-422-01	Fuel Flow Indicator	Eldec
9-464-40	Fuel Flow Indicator	Eldec
9-483-01	Fuel Flow Electronics	Eldec
9-483-02	Fuel Flow Electronics	Eldec

Primary Part Number	Nomenclature	Manufacture
96-380015-1	Fuel Flow Indicator	AID
96-380015-3	Fuel Flow Indicator	AID
96-380015-5	Fuel Flow Indicator	AID
96-380015-7	Fuel Flow Indicator	AID
9801-33-01	Fuel Flow Indicator	Edison
9807-18	Fuel Flow Indicator	Sunbeam
9807-20	Fuel Flow Indicator	Sunbeam
9807-21	Fuel Flow Indicator	Sunbeam
9813-77-03	Fuel Flow/Manifold Pressure	United Instruments
9912031-2	Fuel Flow Transmitters	Simmonds
9912031-3	Fuel Flow Compensator	Simmonds
9914095-9	Fuel Quantity Indicator	AMETEK
A-19	Fuel Flow Transmitter	Ametek/US Gauge
AW2824AM01	Fuel Flow Indicator	Ametek/US Gauge
B418	Fuel Flow Indicator	R C Allen
BH187K-4	Fuel Flow Indicator	Howell
C662037-0109	Fuel Flow/Manifold Pressure	United Instruments
CM2650L2	Fuel Flow Indicator	AID
CM3302-1	Fuel Flow Indicator	AID
DSF1549-10	Fuel Flow Indicator	Ragen
DSF1549-2	Fuel Flow Indicator	Consolidated Airborn
DSF1549-3	Fuel Flow Indicator	Ragen
DSF1549-4	Fuel Flow Indicator	Ragen
DSF1549-5	Fuel Flow Indicator	Ragen
EA1091A-2015	Tank Unit Assembly	Liquidometer
EA1091A-2024	Tank Unit Assembly	Liquidometer
EA1403	Fuel Flow Indicator	Sigma Tek
EFU-2/A	Fuel Flow Indicator	Sunbeam
EFU-20/A	Fuel Flow Indicator	Ametek/GE
F-2077-1500G-360	Fuel Flow Transmitter	Revere
F-2077-1500G-90	Fuel Flow Transmitter	Revere
H930-17	Fuel Flow Indicator	Howell

Primary Part Number	Nomenclature	Manufacture
H930-7	Fuel Flow Indicator	Howell
JG403A30	Indicator	Honeywell
JG403B1	Indicator	Honeywell
JG403B10	Indicator	Honeywell
JG403B11	Indicator	Honeywell
JG403B12	Indicator	Honeywell
JG403B13	Indicator	Honeywell
JG403B14	Indicator	Honeywell
JG403B15	Indicator	Honeywell
JG403B2	Indicator	Honeywell
JG403B3	Indicator	Honeywell
JG403B4	Indicator	Honeywell
JG403B5	Indicator	Honeywell
JG403B6	Indicator	Honeywell
JG403B7	Indicator	Honeywell
JG403B9	Indicator	Honeywell
KE-25	Fuel Flow Amplifier	Ametek/GE
MB-1	Fuel Flow Transmitter	Ametek/GE
MB-2	Fuel Flow Transmitter	Ametek/GE
MS 28005-1	Transmitter	US Gauge
MS28005-5	Transmitter	US Gauge
PS50031-17	Fuel Flow/Manifold Pressure	United Instruments
PS50031-18	Fuel Flow/Manifold Pressure	United Instruments
PS50031-20	Fuel Flow/Manifold Pressure	United Instruments
PS50031-21	Fuel Flow/Manifold Pressure	United Instruments
R5656-250AN	Fuel Flow Indicator	Hickok
R-862-D4	Fuel Flow Transmitter	Revere
S1395V3	Fuel Flow Indicator	Cessna
S1513N2	Fuel Flow Indicator	Standard Precision
SEL-C8B	Fuel Flow Indicator	AMETEK
SR-308-A	Fuel Flow Indicator	Ametek/US Gauge
SR-8A	Fuel Flow Indicator	Ametek/US Gauge
SRL-8A	Fuel Flow Indicator	Ametek/US Gauge
TFF 2905-11	Fuel Flow Transmitter	Ragen
TFF 2905-13	Fuel Flow Transmitter	Ragen
TFF 2905-16	Fuel Flow Transmitter	Ragen
TFF 2905-18	Fuel Flow Transmitter	Ragen
TFF 2905-19	Fuel Flow Transmitter	Ragen
TFF 2905-25	Fuel Flow Transmitter	Ragen
TFF 2905-6	Fuel Flow Transmitter	Ragen
TFF 2905-8	Fuel Flow Transmitter	Ragen
TFF 2905-9	Fuel Flow Transmitter	Ragen
TFF917-2	Fuel Flow Transmitter	Consolidated Airborn
TFF917-3	Fuel Flow Transmitter	Consolidated Airborn
TNS 512-231-1	Transmitter	Faure Herman
TNS 512-231-11	Transmitter	Faure Herman
TRK-56/A27J-1	Pressure Transmitter	Bendix
TRU-7/A	Fuel Flow Transmitter	Ametek/GE

TYPE J-7	Fuel Flow Transmitter	Norden Ketay
VSDL-0C408A	Fuel Flow Indicator	Ametek/US Gauge
VSDL-0C408D	Fuel Flow Indicator	Ametek/US Gauge
VSTLOC403C	Fuel Quantity Indicator	AMETEK
006-0025-01	Navigation Indicator	Bendix King
006-05029-0001	Navigation Indicator	Bendix King
006-0549-00	DME/GS Converter	Bendix King
0156	Gyro Power Supply	Hopkins

Primary Part Number	Nomenclature	Manufacture
060-0017-00	Indicator	Bendix-King
060-0017-01	Flight command Indicator	Honeywell/Bendix
060-0020-00	Flight Directional Indicator	Bendix King
060-0020-01	Flight Directional Indicator	Bendix King
060-0020-03	Flight Directional Indicator	Bendix King
060-0020-04	Flight Directional Indicator	Bendix King
060-0020-05	Flight Directional Indicator	Bendix King
060-0020-06	Flight Directional Indicator	Bendix King
060-0020-07	Flight Directional Indicator	Bendix King
060-0020-08	Flight Directional Indicator	Bendix King
060-0020-10	Flight Directional Indicator	Bendix King
060-0020-11	Flight Directional Indicator	Bendix King
060-0020-12	Flight Directional Indicator	Bendix King
060-0022-00	Directional Gyroscope	Honeywell
060-0024-00	Gyroscope	Bendix
066-01067-0000	VHF Nav. Receiver	Honeywell
066-01067-0001	VHF Nav. Receiver	Honeywell
066-01067-0002	VHF Nav. Receiver	Honeywell
066-01067-0004	VHF Nav/ Receiver	Honeywell
066-03046-0000	Pictorial Navigation Indicator	Honeywell
066-3011-02	Navigation Indicator	Bendix King
066-3045	Pictorial Navigation Indicator	Bendix King
066-3046-07	Pictorial Navigation Indicator	Bendix King
071-1053-04	Slaving Accessory	Bendix King
071-1242-00	Slaving Accessory	Bendix King
071-1283-25	Nav Control Unit	Honeywell/Bendix-Kir
0805-0000	C-8 Compass System	Sperry
1000	Radio Magnetic Indicator	ARC
1000188	Amplifier	Sperry
10061-1A-A1	Compass Indicator	Eclipse Pioneer
10061-1A-B1	Compass Indicator	Eclipse Pioneer
10061-1D-A1	Compass Indicator	Eclipse Pioneer
10061-1E-A1	Compass Indicator	Eclipse Pioneer
10061-1E-B1	Compass Indicator	Eclipse Pioneer
10061-1G-A1	Compass Indicator	Eclipse Pioneer
10061-1G-B1	Compass Indicator	Eclipse Pioneer
10061-1H-A1	Compass Indicator	Eclipse Pioneer
10061-1L-B1	Compass Indicator	Eclipse Pioneer
10061-1M-B1	Compass Indicator	Eclipse Pioneer
10061-1N-B1	Compass Indicator	Eclipse Pioneer

10061-1Q-B1	Compass Indicator	Eclipse Pioneer
10061-1Y-B1	Compass Indicator	Eclipse Pioneer
10062-1-A	Compass Indicator	Eclipse Pioneer
10062-1-B	Compass Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
100745-01	Yaw Damper	Lear Siegler
10078-1T-A1	Compass Indicator	Eclipse Pioneer
100903-01	Yaw Damper	Lear Siegler
10098-1AL-A1	Compass Indicator	Eclipse Pioneer
100990-01	Attitude Indicator	Lear Siegler
1010D0126	Vertical Displacement Gyro	TRC
101200	Bearing Distance Heading Ind	Astronautics
101240	Bearing Distance Heading Ind	Astronautics
101580	Bearing Distance Heading Ind	Astronautics
101617-01	Displacement/Rate Control	Lear Siegler
101700	Attitude Indicator	Astronautics
102200	Bearing Distance Heading Ind	Astronautics
102379	Attitude Indicator	Astronautics
1025-380005	Vertical Indicator	Beech
102550	Attitude Indicator	Astronautics
102590	Flight Director Computer	Astronautics
10263	Turn Coordinator	Brittian
102630	Attitude Indicator	Astronautics
1027D4544	Displacement Gyroscope	Sperry
10316	Turn Coordinator	Brittian
103900-01	Attitude Indicator	Lear Siegler
104-384022-1	Displacement Gyroscope	JET
104470	Bearing Distance Heading Ind	Astronautics
104820	Bearing Distance Heading Ind	Astronautics
105283-01	Gyroscope Amplifier	Lear Siegler
105283-02	Gyroscope Amplifier	Lear Siegler
105589-01	Roll And Pitch Control Ind	Lear Siegler
105713-01	Rool and Pitch Control	Lear Siegler
105716-01	Roll And Pitch Control Ind	Lear Siegler
105759-01	Attitude Indicator	Lear Siegler
105914-01	Roll And Pitch Control Ind	Lear Siegler
107062-01	Compass Amplifier	Lear Siegler
107063-01	Compass Gyroscope	Lear Siegler
107063-01-02	Compass Gyroscope	Lear Siegler
107064-01	Compass System Controller	Lear Siegler
107500	Attitude Indicator	Astronautics
1080F	Roll & Pitch Display Gyro	Lear Siegler
1080Y	Roll & Pitch Display Gyro	Lear Siegler
108590	Horizontal Situation Ind	Astronautics
109090	Attitude Indicator	Astronautics
109983-01	Attitude Indicator	Lear Siegler
11000	Rate Gyroscope	Condor Specific
110150-13	Horizontal Situation Ind	Astronautics
110150-15	Horizontal Situation Ind	Astronautics

Primary Part Number	Nomenclature	Manufacture
110150-17	Horizontal Situation Ind	Astronautics
110794-01	Gyroscope Amplifier	Lear Siegler
110794-02	Gyroscope Amplifier	Lear Siegler
111080	Horizontal Situation Ind	Astronautics
111302-5	Horizontal Situation Ind	Astronautics
111303-4	Attitude Indicator	Astronautics
11200	Course Indicator	Kearfott
112122-01	Rate Gyroscope	Lear Siegler
112375-30	Rate Gyroscope	Lear Siegler
112790	Attitude Indicator	Astronautics
112790-1	Attitude Indicator	Astronautics
112882-01	Gyroscope	Lear Siegler
113530	Attitude Indicator	Astronautics
11369-502	Pitch/Yaw Damper	Autonetics
11408-502	Pitch/Yaw Damper	Autonetics
11414-502	Pitch/Yaw Damper	Autonetics
114437-02	Flight Controller	Lear Siegler
114506-01	Yaw Damper	Lear Siegler
114756-01	Attitude Indicator	Lear Siegler
11484-302-3	Rate Gyroscope	Autonetics
11486-302-3	Pitch/Yaw Damper	Autonetics
11600	Rate Gyroscope	Condor Pacific
116595-01	Attitude Indicator	Lear Siegler
11700	Rate Gyroscope	Condor Pacific
117400	Horizontal Situation Ind	Astronautics
117410	Attitude Indicator	Astronautics
11807	Flight Controller	Brittian
11822-602	Pitch/Yaw Damper	Autonetics
11849-602	Pitch/Yaw Damper	Autonetics
118719-01	Displacement Gyroscope	Lear Siegler
118769-01	Attitude Indicator	Lear Siegler
118769-01-02	Attitude Indicator	Lear Siegler
11887-602	Pitch/Yaw Damper	Autonetics
118930-01	Attitude Indicator	Lear Siegler
118930-01-23	Attitude Indicator	Lear Siegler
118930-02-01	Gyroscope	Lear Siegler
119001-01	Displacement Gyroscope	Lear Siegler
119001-01-45	Displacement Gyroscope	Lear Siegler
119001-01-46	Displacement Gyroscope	Lear Siegler
119001-01-47	Roll & Pitch Display Gyro	Lear Siegler
119538-01	Rate Switching Gyro	Lear Siegler
119538-02	Rate Switching Gyro	Lear Siegler
119636-01	Yaw Damper	Lear Siegler
12001-1A-A1	Master Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
12001-1A-B1	Master Indicator	Eclipse Pioneer
12005-1A-A1	Master Indicator	Eclipse Pioneer

12005-1C-A1	Master Indicator	Eclipse Pioneer
12005-1D-A1	Master Indicator	Eclipse Pioneer
12005-1D-B1	Master Indicator	Eclipse Pioneer
12007	Directional Indicator	Eclipse Pioneer
12007-2A-A	Master Direction Indicator	Eclipse Pioneer
12008	Remote Compass Transmitter	Eclipse Pioneer
12008-1-a	Flux Detector	Eclipse Pioneer
12010	Directional Indicator	Eclipse Pioneer
12010-2B-A1	Master Direction Indicator	Eclipse Pioneer
12010-2B-C	Master Direction Indicator	Eclipse Pioneer
12010-2C-A1	Master Direction Indicator	Eclipse Pioneer
12010-2C-C	Master Direction Indicator	Eclipse Pioneer
12010-2C-F	Master Direction Indicator	Eclipse Pioneer
12010-2E-A1	Master Direction Indicator	Eclipse Pioneer
12011	Remote Compass Transmitter	Eclipse Pioneer
12011-1-A	Remote Compass Transmitter	Eclipse Pioneer
12013	Directional Indicator	Eclipse Pioneer
12013-2D-A1	Master Direction Indicator	Eclipse Pioneer
12013-2D-B	Master Direction Indicator	Eclipse Pioneer
12013-2G-B	Master Direction Indicator	Eclipse Pioneer
12013-2H-E	Master Direction Indicator	Eclipse Pioneer
12013-2H-L	Master Direction Indicator	Eclipse Pioneer
12013-5B-L1	Master Direction Indicator	Eclipse Pioneer
12020	Rate Gyroscope	Condor Pacific.
12040	Rate Gyroscope	Condor Pacific
121437-01	Rate Gyroscope	Lear Siegler
121672-01	Roll & Pitch Display Gyro	Lear Siegler
121672-01-15	Roll & Pitch Display Gyro	Lear Siegler
121672-01-16	Roll & Pitch Display Gyro	Lear Siegler
121672-01-17	Roll & Pitch Display Gyro	Lear Siegler
123161-01	Displacement/Rate Control	Lear Siegler
12340	Turn/Pitch Controller	Eclipse Pioneer
12340-1-A	Turn/Pitch Controller	Eclipse Pioneer
12340-1-B	Turn/Pitch Controller	Eclipse Pioneer
12340-1-C	Turn/Pitch Controller	Eclipse Pioneer
12341	Turn/Pitch Controller	Eclipse Pioneer
12341-1-A	Turn/Pitch Controller	Eclipse Pioneer
12341-1-B	Turn/Pitch Controller	Eclipse Pioneer
12341-1-C	Turn/Pitch Controller	Eclipse Pioneer
12349	Directional Gyro Indicator	Summers
1234T100-()	Turn and Slip Indicator	Mid Continent
123550-01	Gyroscope	Lear Siegler

Primary Part Number	Nomenclature	Manufacture
12400	Vertical Gyroscope Control	Eclipse Pioneer
12400-1A-A1	Vertical Gyroscope Control	Eclipse Pioneer
12401	Vertical Gyroscope Control	Eclipse Pioneer
12401-1A-A1	Vertical Gyroscope Control	Eclipse Pioneer
12401-1A-B1	Vertical Gyroscope Control	Eclipse Pioneer
12401-1A-E1	Vertical Gyroscope Control	Bendix

12401-1B-A1	Vertical Gyroscope Control	Eclipse Pioneer
12401-1B-B1	Vertical Gyroscope Control	Eclipse Pioneer
12401-1B-E1	Vertical Gyroscope Control	Eclipse Pioneer
12401-1B-J1	Vertical Gyroscope Control	Bendix
12401-1C-A1	Vertical Gyroscope Control	Bendix
12401-1C-C1	Vertical Gyroscope Control	Eclipse Pioneer
12401-1F-B2	Vertical Gyroscope Control	Eclipse Pioneer
12402	Vertical Gyroscope Control	Eclipse Pioneer
12402-1A-A1	Vertical Gyroscope Control	Eclipse Pioneer
12402-1A-B1	Vertical Gyroscope Control	Eclipse Pioneer
12402-1A-E1	Vertical Gyroscope Control	Eclipse Pioneer
12402-1B-A1	Vertical Gyroscope Control	Eclipse Pioneer
12402-1F-A1	Vertical Gyroscope Control	Eclipse Pioneer
12402-1F-B1	Vertical Gyroscope Control	Eclipse Pioneer
12402-1F-C1	Vertical Gyroscope Control	Eclipse Pioneer
12402-1F-E1	Vertical Gyroscope Control	Eclipse Pioneer
124215-01	Attitude Indicator	Lear Siegler
12422	Rate Gyroscope Control	Eclipse Pioneer
12422-1A-A1	Turn and Bank Indicator	Eclipse Pioneer
12422-1A-B1	Turn and Bank Indicator	Eclipse Pioneer
12422-1E-A1	Turn and Bank Indicator	Eclipse Pioneer
12422-1E-B1	Turn and Bank Indicator	Eclipse Pioneer
12423	Turn and Bank Indicator	Bendix
12423-1B-A1	Rate Gyroscope Control	Eclipse Pioneer
12423-1B-B1	Rate Gyroscope Control	Eclipse Pioneer
12423-1C-A1	Rate Gyroscope Control	Eclipse Pioneer
12423-1C-B1	Rate Gyroscope Control	Eclipse Pioneer
124623-( )	Roll & Pitch Display Gyro	Lear Siegler
124623-01	Roll & Pitch Display Gyro	Lear Siegler
124623-01-09	Roll & Pitch Display Gyro	Lear Siegler
124623-01-10	Roll & Pitch Display Gyro	Lear Siegler
124623-01-12	Roll & Pitch Display Gyro	Lear Siegler
124623-01-13	Roll & Pitch Display Gyro	Lear Siegler
124623-01-14	Roll & Pitch Display Gyro	Lear Siegler
124623-01-15	Roll & Pitch Display Gyro	Lear Siegler
124623-01-16	Roll & Pitch Display Gyro	Lear Siegler
124623-01-17	Roll & Pitch Display Gyro	Lear Siegler
124623-16	Roll & Pitch Display Gyro	Lear Siegler

Primary Part Number	Nomenclature	Manufacture
124623-17	Roll & Pitch Display Gyro	Lear Siegler
125062-01	Switching Rate Gyroscope	Lear Siegler
125780	Attitude Indicator	Astronautics
126164-01	Gyroscope	Lear Siegler
126164-01-15	Gyroscope	Lear Siegler
126165-01	Gyroscope	Lear Siegler
126165-01-15	Gyroscope	Lear Siegler
126370-10	Bearing Distance Heading Ind	Astronautics
126370-11	Bearing Distance Heading Ind	Astronautics
126460	HORIZONTAL SITUATION IND.	ASTRONAUTICS CORP

126615-01-22	Attitude Indicator	Lear Siegler
127117-01	Rate Gyroscope	Lear Siegler
127123-01	Attitude Indicator	Lear Siegler
128375-01	Attitude Indicator	Lear Siegler
128575-01	Gyroscope	Lear Siegler
129222	Horizontal Situation Ind	Astronautics
13060-01	Roll & Pitch Display Gyro	Lear Siegler
13060-01-06	Roll & Pitch Display Gyro	Lear Siegler
13060-01-07	Roll & Pitch Display Gyro	Lear Siegler
13060-10	Rate Gyroscope	Airesearch
131080-01	Attitude Indicator	Lear Siegler
131081-01	Gyroscope Amplifier	Lear Siegler
131400-01	Attitude Indicator	Lear Siegler
131440	Horizontal Situation Ind	Astronautics
13150	Rate Gyroscope	Condor Pacific
131941-01	Attitude Indicator	Lear Siegler
132637-01	Displacement Gyroscope	Lear Siegler
132750	Indicator	Astronautics
133696-01	Rate Gyroscope	Lear Siegler
134100-01	Yaw Damper	Lear Siegler
134107-01	Switching Rate Gyroscope	Lear Siegler
134338-02-01	Roll & Pitch Display Gyro	Lear Siegler
134338-02-03	Roll & Pitch Display Gyro	Lear Siegler
134363-01	Gyroscope	Lear Siegler
134364-01	Roll & Pitch Display Gyro	Lear Siegler
134383-01-22	Displacement Gyroscope	Lear Siegler
134383-01-23	Displacement Gyroscope	Lear Siegler
134383-01-24	Displacement Gyroscope	Lear Siegler
134383-01-25	Displacement Gyroscope	Lear Siegler
134383-01-26	Displacement Gyroscope	Lear Siegler
134553-01-02	Compass System Controller	Lear Siegler
134566-01	Roll & Pitch Display Gyro	Lear Siegler
134799-01-05	Attitude Indicator	Lear Siegler
134799-01-06	Attitude Indicator	Lear Siegler

Primary Part Number	Nomenclature	Manufacture
135070	Attitude Indicator	Lear Siegler
135441-01	Roll & Pitch Display Gyro	Lear Siegler
135441-01-07	Roll & Pitch Display Gyro	Lear Siegler
1357BX-4-01	Directional Gyroscope	Bendix King
136000-01-01	Attitude Indicator	Lear Siegler
136000-01-02	Attitude Indicator	Lear Siegler
136000-01-03	Attitude Indicator	Lear Siegler
136060-01	Roll & Pitch Display Gyro	Lear Siegler
136060-01-06	Roll & Pitch Display Gyro	Lear Siegler
136060-01-07	Roll & Pitch Display Gyro	Lear Siegler
136600-01-03	Attitude Indicator	Lear Siegler
136601-01-03	Gyroscope	Lear Siegler
136616-01-14	Displacement Gyroscope	Lear Siegler
136616-01-15	Displacement Gyroscope	Lear Siegler

136616-01-16	Displacement Gyroscope	Lear Siegler
136712-01-01	Attitude Indicator	Lear Siegler
136775-01-01	Roll & Pitch Display Gyro	Lear Siegler
136910-01-01	Attitude Indicator	Lear Siegler
137521-01-01	Attitude Indicator	Lear Siegler
137521-01-02	Attitude Indicator	Lear Siegler
137713-01-01	Attitude Indicator	Lear Siegler
1379901	Indicator	Astronautical
138093-01-01	Attitude Indicator	Lear Siegler
138093-01-02	Attitude Indicator	Lear Siegler
138094-01-01	Gyroscope	Lear Siegler
138094-01-02	Gyroscope	Lear Siegler
138474-01-01	Switching Rate Gyroscope	Lear Siegler
138816-01-01	Roll & Pitch Display Gyro	Lear Siegler
138994-01-02	Attitude Indicator	Lear Siegler
139000-01-01	Attitude Indicator	Lear Siegler
139000-01-02	Attitude Indicator	Lear Siegler
139000-02-01	Attitude Indicator	Lear Siegler
139001-01-01	Attitude Indicator	Lear Siegler
139001-01-02	Attitude Indicator	Lear Siegler
139001-01-03	Attitude Indicator	Lear Siegler
139001-01-04	Attitude Indicator	Lear Siegler
139100-01-01	Gyroscope	Lear Siegler
139100-02-01	Displacement Gyroscope	Lear Siegler
139137-01-01	Compass Controller	Lear Siegler
139137-02-01	Compass Controller	Lear Siegler
139400-01-01	Flight Director	Lear Siegler
1394T100 ( ) SERIES	Turn Coordinator	Mid Continent
1394T100 Series Z	Turn Coordinator	Mid Continent
1394T100-( ) RZ	Turn Coordinator	EGC

Primary Part Number	Nomenclature	Manufacture
1394T100-1	Turn Coordinator	EGC
1394T100-315R	Turn Coordinator	EGC
1394T100-315RE	Turn Coordinator	EGC
1394T100-317R	Turn Coordinator	EGC
1394T100-317RE	Turn Coordinator	EGC
1394T100-319RZ	Turn Coordinator	EGC
1394T100-320RZ	Turn Coordinator	EGC
1394T100-35R	Turn Coordinator	EGC
1394T100-35RE	Turn Coordinator	EGC
1394T100-37RZ	Turn Coordinator	EGC
1394T100-3ZB	Turn Coordinator	Mid Continent
1394T100-7Z	Turn Coordinator	Mid Continent
1394T100-7ZP	Turn Coordinator	Mid Continent
139602-01-01	Attitude Indicator	Lear Siegler
139800-01-01	Attitude Indicator	Lear Siegler
139987-01-01	Rate Gyroscope	Lear Siegler
140070-01-01	Displacement Gyroscope	Lear Siegler
140100-01-01	Attitude Indicator	Lear Siegler

140100-03-01	Attitude Indicator	Lear Siegler
140180-01-01	Switching Rate Gyroscope	Lear Siegler
140192	Course Indicator	Weston
140250-01-01	Displacement Gyroscope	Lear Siegler
140260-01-01	Displacement Gyroscope	Lear Siegler
140313	Course Indicator	Weston
140314	Course Indicator	Weston
140540-01-01	Switching Rate Gyroscope	Lear Siegler
140700	Course Indicator	Weston
14100-1-A	Gyroscope	Eclipse Pioneer
14113-2-A	Autopilot Control	Eclipse Pioneer
14113-2-B	Autopilot Control	Eclipse Pioneer
14113-2-F	Autopilot Control	Eclipse Pioneer
14125-1-A	Displacement Gyroscope	Sperry
14127-1-A	Vertical Gyroscope	Eclipse Pioneer
14128-3-A	Vertical Gyroscope	Bendix
14128-4-A	Vertical Gyroscope	Bendix
14128-4-B	Vertical Gyroscope	Bendix
141400-01-01	Attitude Indicator	Lear Siegler
141410-01-01	Switching Rate Gyroscope	Lear Siegler
14161-1A	Vertical Gyroscope	Eclipse Pioneer
14161-1B	Vertical Gyroscope	Eclipse Pioneer
141707-01-01	Attitude Director Indicator	Sperry
141900-01-01	Displacement Gyroscope	Lear Siegler
141900-01-2	Displacement Gyroscope	Lear Siegler
142348-01-02	Gyroscope Assembly	Teledyne

Primary Part Number	Nomenclature	Manufacture
142640-01-01	Attitude Indicator	Lear Siegler
142800-01-01	Gyroscope	Lear Siegler
143222-01-02	Attitude Indicator	Lear Siegler
143400-05-01	Attitude And Heading Reference	Lear Siegler
143400-05-02	Attitude And Heading Reference	Lear Siegler
143960-01	Attitude And Heading Reference	Lear Siegler
144700-01-01	Attitude Indicator	Lear Siegler
145974-01-03	Vertical Gyroscope	Lear Siegler
145974-03	Vertical Gyroscope	Lear Siegler
14600-1A-A1	Gyroscope	Eclipse Pioneer
14600-1A-B1	Gyroscope	Eclipse Pioneer
14601-1A-A1	Gyroscope	Eclipse Pioneer
14602-1J-A1	Gyroscope	Bendix
14602-1J-B1	Attitude Indicator	Bendix
14602-1J-C1	Gyroscope	Bendix
14602-1J-D1	Attitude Indicator	Eclipse Pioneer
14602-1J-E1	Attitude Indicator	Eclipse Pioneer
14602-1J-F1	Gyroscope	Bendix
14603	Gyroscopic Horizon Ind	Eclipse Pioneer
14605	Gyro Horizon Control	Eclipse Pioneer
14605-1P-A1	Gyro Horizon Control	Eclipse Pioneer
14607-1S-A1	Gyroscopic Horizon Ind	Bendix

14608-A	Gyroscopic Horizon Ind	Bendix
14609-1AW-C1	Gyroscopic Horizon Ind	Eclipse Pioneer
14609-1S-A1	Gyroscopic Horizon Ind	Eclipse Pioneer
14609-1S-B1	Gyroscopic Horizon Ind	Eclipse Pioneer
14609-1S-C1	Gyroscopic Horizon Ind	Eclipse Pioneer
14611-1Z-A1	Gyroscopic Horizon Ind	Eclipse Pioneer
14613-1AK-A2	Gyroscope	Bendix
14613-1AK-A3	Attitude Indicator	Eclipse Pioneer
14613-1AK-A4	Attitude Indicator	Bendix
14613-1AK-A5	Gyroscope	Bendix
14613-1AK-A6	Attitude Indicator	Eclipse Pioneer
14614-1AL-A1	Gyroscopic Horizon Ind	Eclipse Pioneer
14614-1AL-B1	Gyroscopic Horizon Ind	Eclipse Pioneer
14617-1AL-A1	Gyroscopic Horizon Ind	Eclipse Pioneer
14638	Displacement Gyroscope	Guidance Technology
146730-01-01	Attitude Indicator	Lear Siegler
146740-01-02	Attitude Indicator	Lear Siegler
146740-02-01	Attitude Indicator	Lear Siegler
147930-01-01	Gyroscope	Lear Siegler
148120-04-01	Attitude And Heading Reference	Lear Siegler
148120-05-01	Attitude And Heading Reference	Lear Siegler
148140-01-01	Attitude And Heading Reference	Lear Siegler

Primary Part Number	Nomenclature	Manufacture
148140-01-02	Attitude And Heading Reference	Lear Siegler
148260-01-01	Yaw Damper	Lear Siegler
148400-04-01	Displacement Gyroscope	Lear Siegler
148400-05-01	Displacement Gyroscope	Lear Siegler
148700-01-01	Attitude Indicator	Lear Siegler
148700-03-01	Attitude Indicator	Lear Siegler
148957-01-01	Displacement Gyroscope	Lear Siegler
149135-01-01	Attitude Indicator	Lear Siegler
149150-01-01	Attitude Indicator	Lear Siegler
149190-01-02	Attitude Indicator	Lear Siegler
149452-0101	Gyroscope	Lear Siegler
149500-01-01	Displacement Gyroscope	Lear Siegler
149900-01-02	Displacement Gyroscope	Lear Siegler
15001	Remote Compass Transmitter	Eclipse Pioneer
15001-1-A	Remote Compass Transmitter	Eclipse Pioneer
15001-1B	Remote Compass Transmitter	Eclipse Pioneer
15001-1-B	Remote Compass Transmitter	Eclipse Pioneer
15003	Flux Detector	Eclipse Pioneer
15003-1-B	Flux Detector	Eclipse Pioneer
15003-1-C	Flux Detector	Eclipse Pioneer
15003-1-C1	Flux Detector	Eclipse Pioneer
15003-1-D1	Flux Detector	Eclipse Pioneer
15003-1-G1	Flux Detector	Eclipse Pioneer
15005	Flux Detector	Eclipse Pioneer
15005-1-A1	Flux Detector	Eclipse Pioneer
15005-1-B1	Flux Detector	Eclipse Pioneer

15005-2-A1	Remote Compass Transmitter	Eclipse Pioneer
15005-2-B1	Remote Compass Transmitter	Eclipse Pioneer
15015-2-A1	Remote Compass Transmitter	Eclipse Pioneer
15015-2-A10	Remote Compass Transmitter	Eclipse Pioneer
15015-2-A4	Remote Compass Transmitter	Eclipse Pioneer
15017-2-A1	Remote Compass Transmitter	Eclipse Pioneer
15017-2-B1	Remote Compass Transmitter	Eclipse Pioneer
150557-01-01	Attitude Indicator	Lear Siegler
150557-01-01A	Attitude Indicator	Lear Siegler
150814-01-01	Rate Switching Gyroscope	Lear Siegler
1508992	Flight Director Computer	Sperry
1509589-901	Attitude Indicator	Sperry
15100-1C-A1	Pitch Trim Indicator	Eclipse Pioneer
15100-1H-A2	Pitch Trim Indicator	Eclipse Pioneer
151010-01-01	Displacement Gyroscope	Lear Siegler
1510698	Attitude Indicator	Sperry
15150	Slaving Control	Kearfott
15150-1	Slaving Control	Kearfott

Primary Part Number	Nomenclature	Manufacture
152017-01-01	Displacement Gyroscope	Lear Siegler
152560-01-01	Attitude Indicator	Lear Siegler
152913-01-01	Attitude Indicator	Lear Siegler
15300	Rate Gyroscope Control	Eclipse Pioneer
15300-1C-1-C1	Turn and Bank Indicator	Eclipse Pioneer
15300-1D-1-C1	Turn and Bank Indicator	Eclipse Pioneer
15300-1D-1-C2	Turn and Bank Indicator	Eclipse Pioneer
15300-1F-1-C1	Rate Gyroscope Control	Eclipse Pioneer
15300-1F-2-C1	Rate Gyroscope Control	Eclipse Pioneer
15300-1F-2-C2	Rate Gyroscope Control	Eclipse Pioneer
15300-1G-4-C2	Turn and Bank Indicator	Eclipse Pioneer
153003-02-01	Displacement Gyroscope	Lear Siegler
153248-01-01	Attitude Indicator	Lear Siegler
153681-01-01	Attitude Indicator	Lear Siegler
15482-1A1A	Electronic Control Amplifier	Bendix
156555-02-01	Displacement Gyroscope	Lear Siegler
156555-03-01	Displacement Gyroscope	Lear Siegler
156578-01-01	Attitude Indicator	Lear Siegler
156850-01-01	Sim Attitude Director Ind	Sperry
15700	Gyro Magnetic Compass System	Kearfott
15703-1-A	Turn/Pitch Controller	Eclipse Pioneer
15703-2-A	Turn/Pitch Controller	Eclipse Pioneer
15704	Turn/Pitch Controller	Eclipse Pioneer
15704-1-A1	Turn/Pitch Controller	Eclipse Pioneer
15704-1-A2	Turn/Pitch Controller	Eclipse Pioneer
15704-1-B1	Turn/Pitch Controller	Eclipse Pioneer
15704-1-B2	Turn/Pitch Controller	Eclipse Pioneer
15713-1-A	Turn/Pitch Controller	Eclipse Pioneer
15800-1-B	Gyroscope	Eclipse Pioneer
15800-1-F	Gyroscope	Eclipse Pioneer

15800-1-G	Gyroscope	Eclipse Pioneer
15800-2-C	Gyroscope	Eclipse Pioneer
15810	Directional Gyroscope	Kearfott
15810-1	Directional Gyroscope	Kearfott
15810-1-A	Gyroscope	Eclipse Pioneer
15816-2-A	Gyroscope	Eclipse Pioneer
15826-1-A	Rate Switching Gyro	Pioneer
15831-1-A	Gyroscope	Bendix
15831-2-A	Gyroscope	Bendix
15831-2-B	Gyroscope	Bendix
15832-2-B	Gyroscope	Bendix
15866-1A	Vertical Gyroscope	Bendix
15866-1B	Vertical Gyroscope	Bendix
15866-1C	Vertical Gyroscope	Bendix

Primary Part Number	Nomenclature	Manufacture
15866-1D	Vertical Gyroscope	Bendix
15866-2A	Vertical Gyroscope	Bendix
15866-2C	Vertical Gyroscope	Bendix
15866-2D	Vertical Gyroscope	Bendix
15866-3A	Vertical Gyroscope	Bendix
15866-3C	Vertical Gyroscope	Bendix
15868-1A	Rate Gyroscope	Bendix
15885-1B	Vertical Gyroscope	Bendix
15885-1C	Vertical Gyroscope	Bendix
15897-1A	Vertical Gyroscope	Bendix
15897-1C	Vertical Gyroscope	Bendix
15897-1D	Vertical Gyroscope	Bendix
15897-2D	Vertical Gyroscope	Bendix
15900	Master Indicator	Kearfott
15900-1	Master Indicator	Kearfott
15900-1M	Master Indicator	Kearfott
15900-2	Master Indicator	Kearfott
15900-3	Master Indicator	Kearfott
16000	Autopilot Amplifier	Kearfott
16002-1-B	Flight Director Computer	Eclipse Pioneer
16002-1-C	Flight Director Computer	Eclipse Pioneer
16002-4-C	Flight Director Computer	Eclipse Pioneer
161815-01-01	Attitude Indicator	Lear Siegler
1630U-4-03	Standby Compass	Kollsman
163447-03-01	Displacement Gyroscope	Lear Siegler
16400-2A-A1	Master Direction Indicator	Eclipse Pioneer
16400-2B-A1	Master Direction Indicator	Eclipse Pioneer
16400-2B-B1	Master Direction Indicator	Eclipse Pioneer
16404	Directional Indicator	Eclipse Pioneer
16404-1C-A1	Master Direction Indicator	Eclipse Pioneer
16404-1C-A3	Master Direction Indicator	Eclipse Pioneer
16540-2-A	Control Amplifier	Eclipse Pioneer
16540-2-B	Control Amplifier	Eclipse Pioneer
16556-1-A	ELECT. CNTRL. AMP.	Eclipse Pioneer

16556-1-B	ELECT. CNTRL. AMP.	Eclipse Pioneer
16561-1-A	Control Amplifier	Eclipse Pioneer
16561-1-B	Control Amplifier	Eclipse Pioneer
16561-1-C	Control Amplifier	Eclipse Pioneer
16562-1-A	Control Amplifier	Eclipse Pioneer
16562-1-B	Control Amplifier	Eclipse Pioneer
16562-1-C	Control Amplifier	Eclipse Pioneer
16800-1A-1A1	Directional Gyroscope	Eclipse Pioneer
1683	Rate Gyroscope Indicator	Brittian
1705	Turn and Slip Indicator	Bendix

Primary Part Number	Nomenclature	Manufacture
17100-1A-1A1	Directional Indicator	Eclipse Pioneer
17-115	Remote Compass Indicator	R C Allen
1713-1Y-A1	Turn and Bank Indicator	Eclipse Pioneer
1716	Turn and Slip Indicator	Bendix
1718-1A-A1	Turn and Bank Indicator	Bendix
1718-2S-A2	Turn and Bank Indicator	Eclipse Pioneer
1719-1AF-A1	Turn and Bank Indicator	Eclipse Pioneer
1719-1AN-A1	Turn and Bank Indicator	Eclipse Pioneer
1719-1AQ-A3	Turn and Bank Indicator	Eclipse Pioneer
1721-2U-A2	Turn and Bank Indicator	Eclipse Pioneer
1721-2Y-A2	Turn and Bank Indicator	Eclipse Pioneer
17221-1-A	Displacement Gyroscope	Eclipse Pioneer
17221-2A	Directional Gyroscope	Bendix
17221-2B	Directional Gyroscope	Bendix
1722-1BA-B1-1	Turn and Bank Indicator	Eclipse Pioneer
1722-1BC-B2-1	Turn and Bank Indicator	Eclipse Pioneer
1722-2AD-A2	Turn and Bank Indicator	Eclipse Pioneer
1722-2AD-B2	Turn and Bank Indicator	Eclipse Pioneer
1722-2AG-A2	Turn and Bank Indicator	Eclipse Pioneer
1722-2AG-B2	Turn and Bank Indicator	Eclipse Pioneer
1722-2AK-B2	Turn and Bank Indicator	Eclipse Pioneer
1722-2AL-B2	Turn and Bank Indicator	Eclipse Pioneer
1722-2V-A2	Turn and Bank Indicator	Eclipse Pioneer
17223-1A	Directional Control	Bendix
17223-1-A	Directional Gyroscope	Eclipse Pioneer
1723	Turn and Slip Indicator	Bendix
17238-1-A	Directional Gyroscope	Bendix
17238-1-B	Directional Gyroscope	Bendix
17238-2-A	Directional Gyroscope	Bendix
1725-1BD-A1-1	Gyroscope	Pioneer
17265-1A	Directional Gyroscope	Bendix
17265-2A	Directional Gyroscope	Bendix
1734-1BN-A1-2	Gyroscope	Pioneer
17502-1D-A1	Gyroscope	Bendix
17502-1D-B1	Gyroscope	Bendix
17502-1D-C2	Gyroscope	Bendix
177221-1-A	Compass Indicator	Eclipse Pioneer
1776167-2	Directional Gyroscope	Sperry

1776167-3	Directional Gyroscope	Sperry
1776365	Horizon Flight Director	Sperry
1777213	Gyrosyn Compass Indicator	Sperry
1777214	Gyrosyn Compass Indicator	Sperry
1777215	Gyrosyn Compass Indicator	Sperry
1778686	Gyrosyn Compass Indicator	Sperry

Primary Part Number	Nomenclature	Manufacture
1780582	Navigation Indicator	Sperry
1780959	Flight Director Computer	Sperry
178137-3	Rate Gyroscope	Sperry
1782137	Rate Gyroscope	Sperry
1782137-2	Rate Gyroscope	Sperry
1782137-3	Rate Gyroscope	Sperry
1782356-11	Vertical Gyroscope	Sperry
1782356-111	Vertical Gyroscope	Sperry
1782993	Gyrosyn Compass Indicator	Sperry
1783179	Flight Director Computer	Sperry
1783179-2	Flight Director Computer	Sperry
1783755	Gyrosyn Compass Indicator	Sperry
1783860	Navigation Indicator	Sperry
178389	Gyrosyn Compass Indicator	Sperry
1783993	Pictorial Deviation Indicator	Sperry
1784163	Gyroscope	Sperry
1784163-901	Attitude Indicator	Sperry
1784389	Gyrosyn Compass Indicator	Sperry
1784460-( )	Compass Indicator	Honeywell
1784460-655	Compass Indicator	Honeywell
178755	Gyrosyn Compass Indicator	Sperry
1788992	Flight Director Computer	Sperry
1801-1-A	Magnetic Compass	Pioneer
18-1039	Gyro Magnetic Compass System	Courter
1813-1-A	Magnetic Compass	Eclipse Pioneer
1818-1-A	Magnetic Compass	Eclipse Pioneer
1822-1-A	Magnetic Compass	Pioneer
1832-1-A	Magnetic Compass	Pioneer
1832-3-A	Magnetic Compass	Pioneer
1833-1-A	Magnetic Compass	Pioneer
1840-1-A	Standby Compass	Eclipse Pioneer
1840-2-A	Standby Compass	Eclipse Pioneer
1841-2-A	Standby Compass	Eclipse Pioneer
18506-1CA1	Attitude Indicator	Bendix
18506-1CB1	Attitude Indicator	Bendix
18506-1DA1	Attitude Indicator	Bendix
18506-1DB1	Attitude Indicator	Bendix
1880920	Gyroscopic Compass System	Sperry
18900-1-A	Gyro Stabilizer	Bendix
19005-1A	Displacement Gyroscope	Bendix
19005-1B	Displacement Gyroscope	Bendix
19005-1C	Displacement Gyroscope	Bendix

19005-2A	Displacement Gyroscope	Bendix
19005-2C	Displacement Gyroscope	Bendix

Primary Part Number	Nomenclature	Manufacture
1925756	Attitude Indicator	Bendix
1925756-1	Attitude Indicator	Bendix
1925756-2	Attitude Indicator	Bendix
1925757-1	Horizontal Situation Ind	Bendix
1925757-2	Horizontal Situation Ind	Bendix
19331-0	Directional Gyroscope	Sperry
19347-0	Directional Gyroscope	Sperry
19610-0	Directional Gyroscope	Sperry
1964106-5	Yaw Rate Gyro	Bendix
1964106-6	Yaw Rate Gyro	Bendix
1964391-1	Directional Gyroscope	Bendix
1976910-1	Attitude Indicator	Bendix
1976910-2	Attitude Gyro Indicator	Bendix
1976910-3	Gyroscope	Bendix
1978121-1	Vertical Gyroscope	Bendix
1978128-1	Attitude Gyro Indicator	Bendix
1978130-1	Attitude Indicator	Bendix
1978179-1	Attitude Gyro Indicator	Bendix
1978189-1	Attitude Gyro Indicator	Bendix
1990132-1	Electronic Control Amplifier	Bendix King
1990529-1	Gyroscope	Bendix
19911-1A	Vertical Gyroscope	Bendix
19911-1B	Vertical Gyroscope	Bendix
19911-1C	Vertical Gyroscope	Bendix
19911-2B	Vertical Gyroscope	Bendix
19911-2C	Vertical Gyroscope	Bendix
19911-3B	Vertical Gyroscope	Bendix
19911-3C	Vertical Gyroscope	Bendix
19911-4C	Vertical Gyroscope	Bendix
19913-1A	Vertical Gyroscope	Bendix
19913-1B	Vertical Gyroscope	Bendix
1B495	Flux Detector	Electric Auto-Lite Co
1C359	Gyroscope Amplifier	Mitchell
1C651	Yaw Damper	Mitchell
1C709	Pitch Trim System	Sigma Tek
1C709-1	Electronic Pitch Trim	Sigma Tek
1C709-2	Electronic Pitch Trim	Sigma Tek
1C709-3	Electronic Pitch Trim	Sigma Tek
1C709-4	Electronic Pitch Trim	Sigma Tek
1C709-5	Electronic Pitch Trim	Sigma Tek
1C709-6	Electronic Pitch Trim	Sigma Tek
1C709-7	Electronic Pitch Trim	Sigma Tek
1C709-8	Electronic Pitch Trim	Sigma Tek
1C709-9	Electronic Pitch Trim	Sigma Tek

Primary Part Number	Nomenclature	Manufacture

1C714	Slaving Amplifier	Sigma Tek
1C722	Slaving Amplifier	Sigma Tek
1C753-100	Yaw Damper	Century Flight System
1C753-200	Yaw Damper	Century Flight System
1C774	Mode Annunciator	Century Flight System
1D755	Gyro Slaving Amplifier	Mitchell
1U149-( )	Gyroscope	Sigma Tek
1U149-011	Gyroscope	Sigma Tek
1U149-012	Gyroscope	Sigma Tek
1U149-013	Gyroscope	Sigma Tek
1U149-014	Gyroscope	Sigma Tek
1U149-015	Gyroscope	Sigma Tek
1U149-016	Gyroscope	Sigma Tek
1U149-017	Gyroscope	Sigma Tek
1U149-018	Gyroscope	Sigma Tek
1U149-019	Gyroscope	Sigma Tek
1U149-020	Gyroscope	Sigma Tek
1U262- SERIES	Directional Gyroscope	Sigma Tek
1U262-006-45	Directional Gyroscope	Sigma Tek
1U262-006-64	Directional Gyroscope	Sigma Tek
1-U262-011	Directional Gyroscope	Sigma Tek
1-U262-012	Directional Gyroscope	Sigma Tek
1-U262-013	Directional Gyroscope	Sigma Tek
1-U262-014	Directional Gyroscope	Sigma Tek
1-U262-015	Directional Gyroscope	Sigma Tek
1-U262-016	Directional Gyroscope	Sigma Tek
1-U262-017	Directional Gyroscope	Sigma Tek
1-U262-018	Directional Gyroscope	Sigma Tek
1-U262-019	Directional Gyroscope	Sigma Tek
1-U262-020	Directional Gyroscope	Sigma Tek
1U262-031-1	Directional Gyroscope	Sigma Tek
1U262-032-2	Directional Gyroscope	Sigma Tek
1U262-033-13	Directional Gyroscope	Sigma Tek
1U262-033-3	Directional Gyroscope	Sigma Tek
1U262-033-5	Directional Gyroscope	Sigma Tek
1U262-034-4	Directional Gyroscope	Sigma Tek
1U262-034-6	Directional Gyroscope	Sigma Tek
1U262-035-7	Directional Gyroscope	Sigma Tek
1U262-036-8	Directional Gyroscope	Sigma Tek
1U262-037-9	Directional Gyroscope	Sigma Tek
1U262-038-10	Directional Gyroscope	Sigma Tek
1U262-039-11	Directional Gyroscope	Sigma Tek
1U262-040-12	Directional Gyroscope	Sigma Tek
1U275-001	Gyroscope	Sigma Tek

Primary Part Number	Nomenclature	Manufacture
1U295-004	Directional Gyroscope	Sigma Tek
1U295-006-5	Directional Gyroscope	Sigma Tek
1U295-010	Directional Gyroscope	Sigma Tek
1U295-010-11	Directional Gyroscope	Sigma Tek

1U301-001	Flight Monitor	Sigma Tek
1U367	Gyroscope	Sigma Tek
1u367-	Attitude Director	Sigmatek
1U367-002-2	Gyroscope	Sigma Tek
1U367-004-4	Gyroscope	Sigma Tek
1U367-006-6	Gyroscope	Sigma Tek
1U367-201-1	Gyroscope	Sigma Tek
1U367-202-2	Gyroscope	Sigma Tek
1U367-203-3	Gyroscope	Sigma Tek
1U367-204-17	Gyroscope	Sigma Tek
1U367-204-4	Gyroscope	Sigma Tek
1U367-205-5	Gyroscope	Sigma Tek
1U367-206-6	Gyroscope	Sigma Tek
1U367-207-13	Gyroscope	Sigma Tek
1U367-207-15	Gyroscope	Sigma Tek
1U367-207-16	Gyroscope	Sigma Tek
1U367-207-7	Gyroscope	Sigma Tek
1U367-207-8	Gyroscope	Sigma Tek
1U367-208-9	Gyroscope	Sigma Tek
1U367-209-10	Gyroscope	Sigma Tek
1U367-210-11	Gyroscope	Sigma Tek
1U367-210-12	Gyroscope	Sigma Tek
1U367-211-1	Gyroscope	Sigma Tek
1U367-212-2	Gyroscope	Sigma Tek
1U367-213-3	Gyroscope	Sigma Tek
1U367-214-4	Gyroscope	Sigma Tek
1U367-221-1	Gyroscope	Sigma Tek
1U367-221-3	Gyroscope	Sigma Tek
1U367-222-2	Gyroscope	Sigma Tek
1U367-222-4	Gyroscope	Sigma Tek
1U367-231-1	Gyroscope	Sigma Tek
1U367-232-2	Gyroscope	Sigma Tek
1U367-232-4	Gyroscope	Sigma Tek
1U367-233-3	Gyroscope	Sigma Tek
1U367-233-6	Gyroscope	Sigma Tek
1U367-234-5	Gyroscope	Sigma Tek
1U371-001-1	Flight Director	Sigma Tek
1U374- ( )	Gyroscope	Sigma Tek
1U407	Flight Director Indicator	Sigma Tek
1U407-001-1	Flight Director Indicator	Sigma Tek

Primary Part Number	Nomenclature	Manufacture
1U445-004-9	Horizontal Situation Ind	Sigma Tek
1Y149-016	Gyroscope	Sigma Tek
200 SERIES	Directional Gyroscope	AIM / CASTLEBERRY
20000-2	Displacement Gyroscope	Summers
20004A	Flight Controller	Bendix King
200-10	Directional Gyroscope	AIM
200-11	Directional Gyroscope	AIM
200-11AL	Directional Gyroscope	AIM

200-3	Directional Gyroscope	AIM
200-5	Directional Gyroscope	AIM
200-5C	Directional Gyroscope	AIM
200-6	Directional Gyroscope	AIM
200-9C3	Directional Gyroscope	AIM
200DCL(28)	Directional Gyroscope	AIM
200E	Directional Gyroscope	AIM
20100	Rate Gyroscope	Dynasciences
20110	Rate Gyroscope	Condor Pacific
204C946G1	Pitch Rate Gyroscope	Ametek/GE
204C957G1	Rate Gyroscope	Ametek/GE
204C957G2	Rate Gyroscope	Ametek/GE
204C957G3	Rate Gyroscope	Ametek/GE
205 SERIES	Directional Gyroscope	AIM
206-070-274-005	Turn and Slip Indicator	General Design
206-075-607-101	Attitude Indicator	General Design
209-075-365-101	Vertical Gyroscope	Lear Siegler
20B380	Turn and Slip Indicator	AIM
210-13A	Directional Gyroscope	AIM
210-6	Directional Gyroscope	AIM
213	Directional Gyroscope	AIM
214-075-220-1	Bearing Distance Heading Ind	Courter
214-075-244-001	Rate Gyroscope	General Design
21500A	Turn and Bank Indicator	Schwien
2171AD	Gyrsoscope Assembly	Teledyne
2179B	Gyroscope	Bendix
2181D-CF	Gyroscope	Bendix
21D0262-1	Indicator	Astronautical
21D0397-1	Indicator	Astronautical
223E320G5	Control Amplifier	Ametek/GE
223E378G4	Control Amplifier	Ametek/GE
229-0047-017	Vertical Gyroscope	Collins
229E950G1	Control Amplifier Assembly	Ametek/GE
229E950G3	Control Amplifier Assembly	Ametek/GE
23-0200-2	Gyro Power Supply	AID
23-1205-2B	Gyro Power Supply	AID

Primary Part Number	Nomenclature	Manufacture
231E927G2	Autopilot Coupler	Ametek/GE
23-330-01	Turn and Bank Indicator	Garwin
23407	Gyroscopic Directional Ind	Summers
23-477-001ANM	Turn and Bank Indicator	Garwin
23-477-010	Turn and Bank Indicator	Weston
23-477-07	Turn and Bank Indicator	Weston
23-477-07-A	Gyroscope	Weston
23-477-08	Turn and Bank Indicator	Weston
23-500- ( )	Gyroscope	Electric Auto-Lite Co
23-501- ( )	Gyroscope	Electric Auto-Lite Co
23-501-017	Gyroscope	Electric Auto-Lite Co
23-501-032	Gyroscope	Sigma Tek

23-501-033	Gyroscope	Sigma Tek
23-501-034	Gyroscope	Sigma Tek
23-501-035	Gyroscope	Sigma Tek
23-501-037	Gyroscope	Sigma Tek
23-501-038	Gyroscope	Sigma Tek
23-501-039	Gyroscope	Sigma Tek
23-501-040	Gyroscope	Sigma Tek
23-504-036	Gyroscope	Sigma Tek
23-573	Gyroscope	Weston
251	Horizon Reference Indicator	AIM
251 Series	Autopilot Horizon Indicator	AIM
251CF	Horizon Reference Indicator	AIM
251E	Horizon Reference Indicator	AIM
251ECF	Horizon Reference Indicator	AIM
254-1D	Directional Gyroscope	AIM
254-1E	Directional Gyroscope	AIM
254-1ED	Directional Gyroscope	AIM
254-1ES	Directional Gyroscope	AIM
254-1S	Directional Gyroscope	AIM
254-2	Directional Gyroscope	AIM
254-2E	Directional Gyroscope	AIM
254-92	Directional Gyroscope	AIM
2585113-9	Gyroscope	Sperry
2585297	Vertical Gyroscope	Sperry
2585302	Directional Gyroscope	Sperry
2585703-2	Slaving Amplifier	Sperry
2585801	Miniature Rate Gyro	Sperry
2586027	Mag Azimuth Detector	Sperry
2586028	Mag Azimuth Detector	Sperry
2586077-7	Directional Gyroscope	Sperry
2586137-1	Vertical Gyroscope	Sperry
2586137-6	Vertical Gyroscope	Sperry

Primary Part Number	Nomenclature	Manufacture
2586257-1	Magnetic Compensator	Sperry
2586257-3	Magnetic Compensator	Sperry
2586261-1	Digital Control Unit	Honeywell
2586261-2	Digital Control Unit	Honeywell
2586333-1	Directional Gyroscope	Honeywell
2586333-1F	Directional Gyroscope	Honeywell
2586333-2	Directional Gyroscope	Sperry
2586333-2F	Directional Gyroscope	Honeywell
2586333-3	Directional Gyroscope	Sperry
2586333-3E	Directional Gyroscope	Honeywell
2586333-3F	Directional Gyroscope	Honeywell
2586384-1	Amplifier	Sperry
2586384-2	Amplifier	Sperry
2587193-143	Directional Gyroscope	Honeywell
2587193-14X	Directional Gyroscope	Honeywell
2587193-2	Gyroscopic Compass System	Sperry

2587193-21	Gyroscope	Sperry
2587193-22	Gyroscopic Compass System	Sperry
2587193-23	Gyroscopic Compass System	Sperry
2587193-24	Gyroscopic Compass System	Sperry
2587193-25	Gyroscopic Compass System	Sperry
2587193-26	Gyroscopic Compass System	Sperry
2587193-27	Gyrosyn Compass	Sperry
2587193-3	Gyroscopic Compass System	Sperry
2587193-33	Gyroscope	Sperry
2587193-34	Gyrosyn Compass	Sperry
2587193-35	Gyrosyn Compass	Sperry
2587193-36	Gyroscopic Compass System	Sperry
2587193-4	Gyroscopic Compass System	Sperry
2587193-41	Gyrosyn Compass System	Sperry
2587193-42	Directional Gyroscope	Honeywell
2587193-43	Gyroscope	Honeywell
2587193-44	Directional Gyroscope	Honeywell
2587193-45	Directional Gyroscope	Honeywell
2587193-46	Directional Gyroscope	Honeywell
2587193-47	Directional Gyroscope	Honeywell
2587193-4X	Directional Gyroscope	Honeywell
2587193-5	Gyroscopic Compass System	Sperry
2587193-6	Gyroscopic Compass System	Sperry
2587193-7	Gyroscope	Sperry
2587317-( )	Compass Indicator	Honeywell
2587317-655	Compass Indicator	Honeywell
2587335-( )	Vertical Gyroscope	Sperry
2587451-2	Directional Gyroscope	Sperry

Primary Part Number	Nomenclature	Manufacture
2587451-3	Directional Gyroscope	Sperry
2588282-( )	Compass Indicator	Honeywell
2588302	Directional Gyroscope	Sperry
2588302-1	Directional Gyroscope	Sperry
2588302-10	Directional Gyroscope	Sperry
2588302-2	Directional Gyroscope	Sperry
2588302-3	Directional Gyroscope	Sperry
2588302-4	Directional Gyroscope	Sperry
2588302-5	Directional Gyroscope	Sperry
2588302-501	Directional Gyroscope	Sperry
2588302-6	Directional Gyroscope	Sperry
2588302-7	Directional Gyroscope	Sperry
2588302-8	Directional Gyroscope	Sperry
258830-5	Directional Gyroscope	Sperry
2588824-902	Radio Heading Indicator	Sperry
2588824-903	Radio Heading Indicator	Sperry
2588824-904	Radio Heading Indicator	Sperry
2589124-902	Miniature Rate Gyro	Honeywell
2589226-1	Amplifier	Sperry
2590625-901	Flight Controller	Sperry

2590930	Navigational Compass Set	Sperry
2591201-902	Compass Coupler	Sperry
2591201-912	Compass Coupler	Sperry
2591201-922	Compass Coupler	Sperry
2591202-902	Compass Controller	Sperry
2591202-905	Compass Controller	Sperry
2591202-912	Compass Controller	Sperry
2591411-144	Gyroscope	Sperry
2591411-244	Gyroscope	Sperry
2591411-245	Gyroscope	Sperry
2591411-264	Gyroscope	Sperry
2591411-265	Gyroscope	Sperry
2591411-400	Horizon Flt Director Ind	Sperry
2591411-401	Horizon Flt Director Ind	Sperry
2591411-402	Horizon Flt Director Ind	Sperry
2591411-403	Horizon Flt Director Ind	Sperry
2591411-404	Horizon Flt Director Ind	Sperry
2591411-405	Horizon Flt Director Ind	Sperry
2591411-406	Horizon Flt Director Ind	Sperry
2591411-407	Horizon Flt Director Ind	Sperry
2591411-440	Horizon Flt Director Ind	Sperry
2591411-441	Horizon Flt Director Ind	Sperry
2591411-442	Horizon Flt Director Ind	Sperry
2591411-443	Horizon Flt Director Ind	Sperry
Primary Part Number	**Nomenclature**	**Manufacture**
2591411-444	Gyroscope	Sperry
2591411-445	Horizon Flt Director Ind	Sperry
2591411-446	Horizon Flt Director Ind	Sperry
2591411-447	Horizon Flt Director Ind	Sperry
2591411-902	Gyroscope	Sperry
2591411-903	Gyroscope	Sperry
2591411-904	Gyroscope	Sperry
2591411-906	Gyroscope	Sperry
2591411-907	Gyroscope	Sperry
2591411-908	Gyroscope	Sperry
2591411-909	Gyroscope	Sperry
2591411-910	Gyroscope	Sperry
2592789-902	Electronic Control Amplifier	Sperry
2592920-444	Radio Deviation Indicator	Sperry
2592920-445	Radio Deviation Indicator	Sperry
2592920-901	Radio Deviation Indicator	Sperry
2592934-1	Directional Gyroscope	Sperry
2593379-1	Magnetic Compensator	Sperry
2593604-200	Flight Director Computer	Sperry
2593604-220	Flight Director Computer	Sperry
2593604-222	Flight Director Computer	Sperry
2593604-223	Flight Director Computer	Sperry
2593691	Gyroscope	Sperry
2593691-901	Gyroscope	Sperry

2593742-41	Vertical Gyroscope	Sperry
2593996-333	TARSYN	Sperry
2593996-444	TARSYN	Sperry
2593996-555	Gyroscope	Sperry
2594401-901	Directional Gyroscope	Sperry
2594860-901	Directional Gyroscope	Sperry
2594860-911	Directional Gyroscope	Sperry
26172	Gyroscopic Directional Ind	Summers
2690346-1	Rate Gyroscope	Texas Instruments
27-19133-1	Pitch Trim Indicator	Hickok
27-19133-5	Pitch Trim Indicator	Hickok
27360	Attitude Indicator	Summers
277700	Attitude Indicator	BVR Inc.
2800- ( )	Turn and Bank Indicator	General Design
2800-17	Turn and Bank Indicator	General Design
2800-18	Turn and Bank Indicator	General Design
2800-4245-4	Turn Coordinator	General Design
2800-4275-4	Turn Coordinator	General Design
2800-4530N13L	Turn and Slip Indicator	General Design
2800-4810N1	Turn and Bank Indicator	General Design

Primary Part Number	Nomenclature	Manufacture
2800-4810N3	Turn and Bank Indicator	General Design
2800-4810N4	Turn and Bank Indicator	General Design
2800-6845N1L	Turn and Slip Indicator	General Design
2800-7	Turn and Bank Indicator	General Design
2800-8	Turn and Bank Indicator	General Design
2800N7	Turn and Bank Indicator	General Design
289-1	Directional Gyroscope	AIM
289-1D	Directional Gyroscope	AIM
289-1E	Directional Gyroscope	AIM
289-1ED	Directional Gyroscope	AIM
289-1EDM	Directional Gyroscope	AIM
289-1ES	Directional Gyroscope	AIM
289-1ESM	Directional Gyroscope	AIM
289-1S	Directional Gyroscope	AIM
289-1SM	Directional Gyroscope	AIM
289-2D	Directional Gyroscope	AIM
289-2ED	Directional Gyroscope	AIM
289-2ES	Directional Gyroscope	AIM
289-2S	Directional Gyroscope	AIM
289-3D	Directional Gyroscope	AIM
289-3E	Directional Gyroscope	AIM
289-3ED	Directional Gyroscope	AIM
289-3ES	Directional Gyroscope	AIM
289-3S	Directional Gyroscope	AIM
289-4C3	Directional Gyroscope	AIM
289-4M	Directional Gyroscope	AIM
289-4M3	Directional Gyroscope	AIM
289-5C	Directional Gyroscope	AIM

289-5C3	Directional Gyroscope	AIM
289-5M	Directional Gyroscope	AIM
289-5M3	Directional Gyroscope	AIM
289-7	Directional Gyroscope	AIM
2901	Turn Coordinator	Brittian
2901-1	Turn Coordinator	Brittian
2902-2A-A	Drift Meter	Eclipse Pioneer
2902-2A-B	Drift Meter	Eclipse Pioneer
2902-2A-C	Drift Meter	Eclipse Pioneer
2903	Turn Coordinator	Brittian
2903-1	Turn Coordinator	Brittian
2905	Turn Coordinator	Brittian
2907	Turn Coordinator	Brittian
2909	Turn Coordinator	Brittian
2909-P	Turn Coordinator	Brittian
2910-2A-B	Drift Meter	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
2910-2A-C	Drift Meter	Eclipse Pioneer
2911	Turn Coordinator	Brittian
2911-P	Turn Coordinator	Brittian
2913	Turn Coordinator	Brittian
2913-2A-A	Drift Meter	Eclipse Pioneer
2913-2A-B	Drift Meter	Eclipse Pioneer
2914-2A-A	Drift Meter	Eclipse Pioneer
2914-2A-B	Drift Meter	Eclipse Pioneer
2914-2A-C	Drift Meter	Eclipse Pioneer
2915	Turn Coordinator	Brittian
2915-2A-A	Drift Meter	Eclipse Pioneer
2915-2A-B	Drift Meter	Eclipse Pioneer
2916-2A-A	Drift Meter	Eclipse Pioneer
2916-2A-B	Drift Meter	Eclipse Pioneer
2916-2A-C	Drift Meter	Eclipse Pioneer
2917	Turn Coordinator	Brittian
2917-2A-B	Drift Meter	Eclipse Pioneer
2919-2A-A	Drift Meter	Eclipse Pioneer
2919-2A-B	Drift Meter	Eclipse Pioneer
2921-2A-A	Drift Meter	Eclipse Pioneer
2922-2A-A	Drift Meter	Eclipse Pioneer
2923-2A-A	Drift Meter	Eclipse Pioneer
2924-2A-A	Drift Meter	Eclipse Pioneer
2926-2A-A	Drift Meter	Eclipse Pioneer
2928-2A-A	Drift Meter	Eclipse Pioneer
2929-2A-A	Drift Meter	Eclipse Pioneer
293-1	Directional Gyroscope	AIM
293-1D	Directional Gyroscope	AIM
293-1E	Directional Gyroscope	AIM
293-1ED	Directional Gyroscope	AIM
293-1ES	Directional Gyroscope	AIM
293-1S	Directional Gyroscope	AIM

2934-2D-A	Drift Meter	Eclipse Pioneer
2935-2D-A	Drift Meter	Eclipse Pioneer
2936-2D-A	Drift Meter	Eclipse Pioneer
2938-2E-A	Drift Meter	Eclipse Pioneer
2939-2E-A	Drift Meter	Eclipse Pioneer
2940-2E-A	Drift Meter	Eclipse Pioneer
2941-2E-A	Drift Meter	Eclipse Pioneer
2944-2E-A	Drift Meter	Eclipse Pioneer
2948-2E-A	Drift Meter	Eclipse Pioneer
2949-2E-A-27	Drift Meter	Eclipse Pioneer
2949-2E-A-33	Drift Meter	Eclipse Pioneer
2949-2E-A-48	Drift Meter	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
2949-2E-A-53	Drift Meter	Eclipse Pioneer
29520	Rate Gyroscope	ARC
297-1	Directional Gyroscope	AIM
297-1D	Directional Gyroscope	AIM
297-1E	Directional Gyroscope	AIM
297-1ED	Directional Gyroscope	AIM
297-1ES	Directional Gyroscope	AIM
297-1S	Directional Gyroscope	AIM
297-2D	Directional Gyroscope	AIM
297-2ED	Directional Gyroscope	AIM
297-2ES	Directional Gyroscope	AIM
297-2S	Directional Gyroscope	AIM
297-5	Directional Gyroscope	AIM
299-1	Directional Gyroscope	AIM
299-1D	Directional Gyroscope	AIM
299-1E	Directional Gyroscope	AIM
299-1ED	Directional Gyroscope	AIM
299-1ES	Directional Gyroscope	AIM
299-1S	Directional Gyroscope	AIM
29993	Attitude Indicator	Guidance Technology
300	Course Indicator	Cessna
300-1	Vertical Gyroscope	AIM
300-14EL	Horizon Reference Indicator	AIM
300-1BCF	Vertical Gyroscope	AIM
300-2	Horizon Reference Indicator	AIM
300-2 Series	Autopilot Horizon Indicator	AIM
300-2CF	Horizon Reference Indicator	AIM
300-3CFC	Vertical Gyroscope	AIM
300-7	Gyroscope	AIM
300-7 Series	Flight Director	BF Goodrich
300-7CF	Flight Director Horizon	AIM
300-7DC	Flight Director Horizon	AIM
300-9	Flight Director Horizon	AIM
300-9 Series	Flight Director Horizon	BF Goodrich
300-9C(8)	Horizon Gyro	AIM
300-9DC	Flight Director Horizon	AIM

Primary Part Number	Nomenclature	Manufacturer
300B	Horizon Reference Indicator	AIM
300B Series	Autopilot Horizon Indicator	AIM
301RGS/1	Miniature Rate Gyro	Smith Industries
301RGS/2	Miniature Rate Gyro	Smith Industries
301RGS/3	Miniature Rate Gyro	Smith Industries
301RGS/5	Miniature Rate Gyro	Smith Industries
301RGS/6	Miniature Rate Gyro	Smith Industries
302RGS/1	Miniature Rate Gyro	Smith Industries
302RGS/10	Miniature Rate Gyro	Smith Industries
302RGS/11	Miniature Rate Gyro	Smith Industries
302RGS/2	Miniature Rate Gyro	Smith Industries
302RGS/3	Miniature Rate Gyro	Smith Industries
302RGS/4	Miniature Rate Gyro	Smith Industries
302RGS/5	Miniature Rate Gyro	Smith Industries
302RGS/6	Miniature Rate Gyro	Smith Industries
302RGS/7	Miniature Rate Gyro	Smith Industries
302RGS/8	Miniature Rate Gyro	Smith Industries
302RGS/9	Miniature Rate Gyro	Smith Industries
303686	Turn Coordinator	Astronautics
303880	Turn Coordinator	Astronautics
303881	Turn Coordinator	Astronautics
303882	Turn Coordinator	Astronautics
303883	Turn Coordinator	Astronautics
303885	Turn Coordinator	Astronautics
303889	Turn Coordinator	Astronautics
304039-003	Turn Coordinator	Astronautics
304041	Turn Coordinator	Astronautics
304115-003	Turn Coordinator	Astronautics
304RGS/1	Miniature Rate Gyro	Smith Industries
304RGS/2	Miniature Rate Gyro	Smith Industries
305-2B	Attitude Gyroscope	AIM
305-SERIES	Gyroscope	BF Goodrich
306285-( )	Rate Gyroscope	Allied Signal
30-8049	Turn Coordinator	General Design
309RGS/1	Miniature Rate Gyro	Smith Industries
309RGS/2	Miniature Rate Gyro	Smith Industries
309RGS/3	Miniature Rate Gyro	Smith Industries
309RGS/4	Miniature Rate Gyro	Smith Industries
3100 SERIES	Radio Magnetic Indicator	Aeronetics
31100C	Directional Gyroscope	Aeronetics
31100S	Directional Gyroscope	Aeronetics
31101C	Directional Gyroscope	Aeritalia
31101P	Directional Gyroscope	Aeritalia
3115 SERIES	Radio Magnetic Indicator	Aeronetics
3117 SERIES	Radio Magnetic Indicator	Aeronetics
3125 SERIES	Radio Magnetic Indicator	Aeronetics
3127 SERIES	Radio Magnetic Indicator	Aeronetics
3137 SERIES	Radio Magnetic Indicator	Aeronetics

313RGS/1	Miniature Rate Gyro	Smith Industries
313RGS/2	Miniature Rate Gyro	Smith Industries
325A	Gyroscopic Directional Ind	Summers
325B	Gyroscopic Directional Ind	Summers

Primary Part Number	Nomenclature	Manufacture
325B-1	Gyroscopic Directional Ind	Summers
325RGS/2	Miniature Rate Gyro	Smith Industries
325RGS2	Gyro	GE
328A-3G	Slaving Accessory	Collins
329-7/( )	Flight Director Indicator	Collins
329A-3V	Horizon Reference Indicator	Collins
329B-3	Attitude Indicator	Collins
329B-7	Flight Director Indicator	Collins
329B-7/7()	Flight Director Indicator	Collins
329B-7/7(X)	Flight Director Indicator	Sperry
329B-7A	Flight Director Indicator	Collins
329B-7C	Flight Director Indicator	Collins
329B-7F	Flight Director Indicator	Collins
329B-7F1	Flight Director Indicator	Collins
329B-7G	Flight Director Indicator	Collins
329B-7J	Flight Director Indicator	Collins
329B-7K	Flight Director Indicator	Collins
329B-7M	Flight Director Indicator	Collins
329B-7R	Flight Director Indicator	Collins
329B-7R-1	Flight Director Indicator	Collins
329B-7R-2	Flight Director Indicator	Collins
329B-7R-3	Flight Director Indicator	Collins
329B-7R-4	Flight Director Indicator	Collins
329B-7R-5	Flight Director Indicator	Collins
329B-8G	Indicator	Collins
331A-3	Course Indicator	Collins
331A-3F	Course Indicator	Collins
331A-3G	Course Indicator	Collins
331A-6P	Course Indicator	Collins
331A-6R	Course Indicator	Collins
331A-8H	Horizontal Indicator	Collins
331C-4	Bearing Distance Heading Ind	Collins
331C-4A	Bearing Distance Heading Ind	Collins
331C-4E	Bearing Distance Heading Ind	Collins
331C-4F	Bearing Distance Heading Ind	Collins
332C-10	Radio Magnetic Indicator	Collins
332D-11	Vertical Gyroscope	Collins
332D11A	Vertical Reference	Collins
332D-11A	Vertical Gyroscope	Collins
332D11B	Vertical Reference	Collins
332D-11B	Vertical Gyroscope	Collins
332D-11T	Vertical Gyroscope	Collins
332D-11V	Vertical Gyroscope	Collins
332D-6	Vertical Gyroscope	Collins

Primary Part Number	Nomenclature	Manufacture
332D-6A	Vertical Gyroscope	Collins
3E+0	Directional Gyroscope	Collins
3E-2	Directional Gyroscope	Collins
3E-3	Directional Gyroscope	Collins
338276	Sim Attitude Director Ind	Sperry
338276-1	Sim Attitude Director Ind	Sperry
345A-7	Rate Gyroscope	Collins
345A-7 ()	Rate Gyroscope	Collins
345A-7A	Rate Gyroscope	Collins
345A-7B	Rate Gyroscope	Collins
34770-0014	Directional Gyroscope	ARC
34770-0028	Directional Gyroscope	ARC
34770-0114	Directional Gyroscope	ARC
34770-0128	Directional Gyroscope	ARC
350-382	Turn and Bank Indicator	R C Allen
350-383	Turn and Bank Indicator	R C Allen
35060-0114	Rate Gyroscope	General Design
35060-0128	Rate Gyroscope	General Design
350X-3	Directional Gyroscope	Collins
35900-1A-1-A-1	Compass Indicator	Eclipse Pioneer
35900-1A-1-B1	Compass Indicator	Eclipse Pioneer
35900-1-F	Comapss Signal Amplifier	Eclipse Pioneer
36100C	Horizon Gyroscope	Aeritalia
36101	Gyroscopic Horizon Ind	Aeritalia
36101C	Horizon Gyroscope	Aeritalia
36104-1H-8-A1	Radio Magnetic Indicator	Eclipse Pioneer
36104-1L-11-A1	Radio Magnetic Indicator	Eclipse Pioneer
36104-1L-11-A2	Radio Magnetic Indicator	Eclipse Pioneer
36105	Radio Magnetic Indicator	Eclipse Pioneer
369H90042-501	Directional Gyro Indicator	Hughes
3759029-6	Pitch Guidance Control Panel	Honeywell
3759078-6	Pitch Guidance Control Panel	Honeywell
3805D	Compass System Controller	Lear Siegler
3906	Turn and Bank Indicator	Bendix
3906-1M-A1	Turn and Bank Indicator	Pioneer
3907	Turn and Bank Indicator	Bendix
3911-1Q-A1-1	Turn and Slip Indicator	Eclipse Pioneer
3919	Turn and Slip Indicator	Bendix
3922	Turn and Slip Indicator	Bendix
392373	Sim Attitude Director Ind	Sperry
3924	Turn and Slip Indicator	Bendix
3924-1AG-B1-1	Turn and Slip Indicator	Bendix
3927	Turn and Slip Indicator	Bendix
3929	Turn and Slip Indicator	Bendix

Primary Part Number	Nomenclature	Manufacture
3932-1AG-A1-1	Turn and Slip Indicator	Bendix
3932-1AG-A4-1	Turn and Slip Indicator	Bendix

3935	Turn and Bank Indicator	General Design
398D-01-01	Directional Indicator	Kollsman
398F-01-01	Directional Indicator	Kollsman
399RGS/5	Miniature Rate Gyro	Smith Industries
400	Radio Magnetic Indicator	ARC
400 Series	Directional Gyroscope	AIM
4000	Directional Gyroscope	Sigma Tek
4000172-	Horizontal Situation Ind	Bendix
4000261-8502	Director/Horizon Indicator	Bendix
4000261-8505	Director/Horizon Indicator	Bendix
4000261-8506	Director/Horizon Indicator	Bendix
4000398-8101	Gyroscope	Honeywell
4000398-8103	Gyroscope	Honeywell
4000474-8503	Gyroscope	Honeywell
4000474-8504	Gyroscope	Honeywell
4000512-4101	Director Horizon Indicator	Bendix
4000512-4102	Director Horizon Indicator	Bendix
4000512-4103	Director Horizon Indicator	Bendix
4000512-4104	Director Horizon Indicator	Bendix
4000627-8101	Gyroscope	Bendix
4000627-8102	Gyroscope	Bendix
4000627-8103	Gyroscope	Bendix
4000627-8104	Gyroscope	Bendix
4000627-8105	Gyroscope	Bendix
4000627-8106	Gyroscope	Bendix
4000627-8107	Gyroscope	Bendix
4000627-8108	Gyroscope	Bendix
4000843	Flight Director Indicator	Bendix
4000869-3201	Gyroscope	Honeywell
4000869-3202	Gyroscope	Honeywell
4000874-8201	Directional Gyroscope	Bendix King
4000A	Directional Gyroscope	Garwin
4000A-1	Directional Gyroscope	Electric Auto-Lite Co
4000B	Directional Gyroscope	Garwin
4000B-1	Directional Gyroscope	Electric Auto-Lite Co
4000B-10	Directional Gyroscope	Electric Auto-Lite Co
4000B-12	Directional Gyroscope	Electric Auto-Lite Co
4000B-13	Directional Gyroscope	Electric Auto-Lite Co
4000B-14	Directional Gyroscope	Electric Auto-Lite Co
4000B-15	Directional Gyroscope	Electric Auto-Lite Co
4000B-16	Directional Gyroscope	Electric Auto-Lite Co
4000B-17	Directional Gyroscope	Electric Auto-Lite Co

Primary Part Number	Nomenclature	Manufacture
4000B-18	Directional Gyroscope	Electric Auto-Lite Co
4000B-19	Directional Gyroscope	Electric Auto-Lite Co
4000B-2	Directional Gyroscope	Electric Auto-Lite Co
4000B-20	Directional Gyroscope	Electric Auto-Lite Co
4000B-21	Directional Gyroscope	Electric Auto-Lite Co
4000B-22	Directional Gyroscope	Electric Auto-Lite Co

4000B-3	Directional Gyroscope	Electric Auto-Lite Co
4000B-30	Directional Gyro	Sigmatek
4000B-4	Directional Gyroscope	Electric Auto-Lite Co
4000B-5	Directional Gyroscope	Electric Auto-Lite Co
4000B-6	Directional Gyroscope	Electric Auto-Lite Co
4000B-7	Directional Gyroscope	Electric Auto-Lite Co
4000B-8	Directional Gyro	Sigmatek
4000B-9	Directional Gyroscope	Electric Auto-Lite Co
4000C	Directional Gyroscope	Electric Auto-Lite Co
4000C-1	Directional Gyroscope	Electric Auto-Lite Co
4000C-15	Directional Gyroscope	Electric Auto-Lite Co
4000C-16	Directional Gyroscope	Sigma Tek
4000C-17	Directional Gyroscope	Sigma Tek
4000C-2	Directional Gyroscope	Electric Auto-Lite Co
4000C-20	Directional Gyroscope	Electric Auto-Lite Co
4000C-3	Directional Gyroscope	Electric Auto-Lite Co
4000C-4	Directional Gyroscope	Electric Auto-Lite Co
4000C-5	Directional Gyroscope	Electric Auto-Lite Co
4000C-6	Directional Gyroscope	Electric Auto-Lite Co
4000C-7	Directional Gyroscope	Electric Auto-Lite Co
4000D	Directional Gyroscope	Garwin
4000D-1	Directional Gyroscope	Electric Auto-Lite Co
4000D-2	Directional Gyroscope	Electric Auto-Lite Co
4000D-3	Directional Gyroscope	Sigma Tek
4000D-4	Directional Gyroscope	Sigma Tek
4000D-5	Directional Gyroscope	Sigma Tek
4000D-6	Directional Gyroscope	Sigma Tek
4000D-7	Directional Gyroscope	Sigma Tek
4000G-503A	Directional Gyroscope	Sigma Tek
4000H	Directional Gyroscope	Sigma Tek
4000H-1	Directional Gyroscope	Sigma Tek
4000H-10	Directional Gyroscope	Sigma Tek
4000H-11	Directional Gyroscope	Sigma Tek
4000H-12	Directional Gyroscope	Sigma Tek
4000H-2	Directional Gyroscope	Sigma Tek
4000H-3	Directional Gyroscope	Sigma Tek
4000H-4	Directional Gyroscope	Sigma Tek
4000H-5	Directional Gyroscope	Sigma Tek
Primary Part Number	**Nomenclature**	**Manufacture**
4000H-6	Directional Gyroscope	Sigma Tek
4000H-7	Directional Gyroscope	Sigma Tek
4000H-8	Directional Gyroscope	Sigma Tek
4000H-9	Directional Gyroscope	Sigma Tek
4000HR-2	Directional Gyroscope	Sigma Tek
4000HR-5	Directional Gyroscope	Sigma Tek
4001808-901	Vertical Gyroscope	Sperry
4002531-454	Horizon Flt Director Ind	Sperry
4002963-404	Radio Magnetic Indicator	Honeywell
4002963-405	Radio Magnetic Indicator	Honeywell

4002963-444	Radio Magnetic Indicator	Honeywell
4002963-445	Radio Magnetic Indicator	Honeywell
4002963-454	Radio Magnetic Indicator	Honeywell
4002963-464	Radio Magnetic Indicator	Honeywell
4002963-901	Radio Magnetic Indicator	Honeywell
4002963-902	Radio Magnetic Indicator	Honeywell
4002963-903	Radio Magnetic Indicator	Honeywell
400305	Gyroscope	Lear Siegler
4003AF	Attitude Indicator	Lear Siegler
4003AU	Attitude Indicator	Lear Siegler
4004300-912	Attitude And Heading Reference	Sperry
4005AB	Attitude Indicator	Lear Siegler
4005W	Attitude Indicator	Lear Siegler
4007393-911	Autopilot Flight Director	Sperry
4007393-924	Integrated Flight Control Sys	Sperry
4010657-464	Gyroscope	Sperry
4010657-901	Gyroscope	Sperry
4012K	Attitude Indicator	Lear Siegler
4018369-902	Flight Director Computer	Sperry
4018369-903	Flight Director Computer	Sperry
4018369-906	Flight Director Computer	Sperry
401894	Gyro	Timex
4019190-3	Gyro Synchronizer	Sperry
4019286-901	Vertical Gyroscope	Sperry
4019286-902	Vertical Gyroscope	Sperry
4019286-903	Vertical Gyroscope	Sperry
4019286-VAR	Vertical Gyroscope	Honeywell
401RGU/FA/2	Rate Gyroscope	Smith Industries
4020501-1XX	Gyroscopic Horizon Ind	Sperry
4020501-2XX	Gyroscopic Horizon Ind	Sperry
4020501-3XX	Gyroscopic Horizon Ind	Sperry
4020501-4	Flight Director	Sperry
4020501-4XX	Gyroscopic Horizon Ind	Sperry
4020501-5XX	Gyroscopic Horizon Ind	Sperry

Primary Part Number	Nomenclature	Manufacture
4020531	Flight Director	Sperry
4020531-( )	Gyroscopic Horizon Ind	Sperry
4020547-901	Attitude Indicator	Sperry
4020547-904	Attitude Indicator	Sperry
4020547-905	Attitude Indicator	Sperry
4020547-906	Attitude Indicator	Sperry
4020547-907	Attitude Indicator	Sperry
4020547-908	Attitude Indicator	Sperry
4020550-901	Attitude Indicator	Sperry
4020553-901	Horizontal Situation Ind	Sperry
4020553-902	Horizontal Situation Ind	Sperry
4020553-903	Horizontal Situation Ind	Sperry
4020553-904	Horizontal Situation Ind	Sperry
4020576-901	Rate Gyroscope	Sperry

4020577-3	Directional Gyroscope	Honeywell
4020577-6	Directional Gyroscope	Honeywell
4020577-8	Directional Gyroscope	Honeywell
4020936-901	Gyroscope	Sperry
4020936-902	Gyroscope	Sperry
4020936-903	Gyroscope	Sperry
4021541	Gyroscopic Horizon Ind	Sperry
402211-100	Gyroscopic Horizon Ind	Sperry
4022211-100	Gyroscopic Horizon Ind	Sperry
4025782-901	Horizontal Situation Ind	Sperry
4025782-902	Horizontal Situation Ind	Sperry
4025782-903	Horizontal Situation Ind	Sperry
4025782-904	Horizontal Situation Ind	Sperry
4025782-906	Horizontal Situation Ind	Sperry
4025782-907	Horizontal Situation Ind	Sperry
4025782-908	Horizontal Situation Ind	Sperry
4025782-909	Horizontal Situation Ind	Sperry
4026667-901	Yaw Rate Gyro	Sperry
403-1	Directional Gyroscope	Honeywell
4034242-901	Flt. Guid. Cntrl Panel	Honeywell
4034242-902	Flt. Guid. Cntrl Panel	Honeywell
4034242-903	Flt. Guid. Cntrl Panel	Honeywell
4034242-904	Flt. Guid. Cntrl Panel	Honeywell
4034242-906	Flt. Guid. Cntrl Panel	Honeywell
4034242-911	Flt. Guid. Cntrl Panel	Honeywell
4034242-913	Flt. Guid. Cntrl Panel	Honeywell
4034242-921	Flt. Guid. Cntrl Panel	Honeywell
4034242-922	Flt. Guid. Cntrl Panel	Honeywell
4034242-932	Flt. Guid. Cntrl Panel	Honeywell
4034242-942	Flt. Guid. Cntrl Panel	Honeywell

Primary Part Number	Nomenclature	Manufacture
4034242-952	Flt. Guid. Cntrl Panel	Honeywell
4034242-962	Flt. Guid. Cntrl Panel	Honeywell
4034242-972	Flt. Guid. Cntrl Panel	Honeywell
4034559-901	Distance Bearing Indicator	Honeywell
4034559-902	Distance Bearing Indicator	Honeywell
4034559-908	Distance Bearing Indicator	Honeywell
4034559-909	Distance Bearing Indicator	Honeywell
4034559-910	Distance Bearing Indicator	Honeywell
4038930-901	Horizontal Situation Ind	Sperry
4038930-902	Horizontal Situation Ind	Sperry
4038930-903	Horizontal Situation Ind	Sperry
4038930-904	Horizontal Situation Ind	Sperry
4038930-906	Horizontal Situation Ind	Sperry
40760-0104	Directional Gyroscope	AIM
4078369-902	Flight Director Computer	Sperry
4099B	Turn and Bank Indicator	Bendix
4145A	Attitude Indicator	Lear Siegler
41600	Horizontal Situation Ind	AIM

41750-0201	Directional Gyroscope	AIM
418854-01	Gyroscope	Lear Siegler
42090	Attitude Indicator	Guidance Technology
421155-1	Vertical Gyroscope	Kearfott
421155-2	Vertical Gyroscope	Kearfott
421156-1	Directional Gyroscope	Kearfott
42281	Displacement Gyroscope	Guidance Technology
423257-2	Gyroscope	Kearfott
423305-1	Vertical Gyroscope	Kearfott
424-1	Directional Gyroscope	AIM
424-1D	Directional Gyroscope	AIM
424-1E	Directional Gyroscope	AIM
424-1ED	Directional Gyroscope	AIM
424-1ES	Directional Gyroscope	AIM
424-1S	Directional Gyroscope	AIM
424-2D	Directional Gyroscope	AIM
424-2ED	Directional Gyroscope	AIM
424-2ES	Directional Gyroscope	AIM
424-2S	Directional Gyroscope	AIM
4245-4	Turn Coordinator	General Design
42520	Displacement Gyroscope	Guidance Technology
42565	Displacement Gyroscope	Guidance Technology
42660	Displacement Gyroscope	Guidance Technology
4275-4	Turn Coordinator	General Design
42-903	Gyroscopic Horizon	Sfena
42-903BDV5	Gyroscopic Horizon	Sfena
Primary Part Number	**Nomenclature**	**Manufacture**
42-904	Gyroscopic Horizon	Sfena
4300 ( )	Attitude Gyroscope	General Design
4300-311	Indicator	Mid-Continent
4300-312	Gyroscope	Mid Continent
4300-6980L	Artificial Horizon	General Design
4300-7205-3	Gyroscope	General Design
4300-8220L	Artificial Horizon	General Design
4300-XXX	Attitude Indicator	Mid Continent
43020	Displacement Gyroscope	Guidance Technology
4305	Directional Gyroscope	General Design
4305-7150-3	Directional Gyroscope	General Design
43550	Gyroscope Displacement	Guidance Technology
43550-1	Gyroscope Displacement	Guidance Technology
43550-2	Gyroscope Displacement	Guidance Technology
44125	Gyroscope Displacement	Guidance Technology
44524	Gyroscope Displacement	Guidance Technology
44525	Gyroscope Displacement	Guidance Technology
4460	Turn and Bank Indicator	General Design
4530N1	Turn and Bank Indicator	General Design
4530NI	Turn and Bank Indicator	General Design
453ON1	Turn and Bank Indicator	General Design
454-00158-000	Vertical Gyroscope	Sfena

458572	Rate Gyroscope	Hamilton Standard
46060-1	Displacement Gyroscope	Sperry
46060-3	Displacement Gyroscope	Sperry
46060-4	Displacement Gyroscope	Sperry
4715 ( )	Directional Gyroscope	General Design
471794-2	Compass System Controller	Texas Instruments
471881-1	Displacement Gyroscope	Texas Instruments
482225	Sim Attitude Director Ind	Sperry
4825	Attitude Gyroscope	General Design
490134	Sim Attitude Director Ind	Sperry
500 SERIES	Gyroscope	AIM
5000-2	Gyroscope	Electric Auto-Lite Co
50003-1	Displacement Gyroscope	Flightline Systems
5000A	Gyroscope	Garwin
5000A-1	Gyroscope	Electric Auto-Lite Co
5000A-2	Gyroscope	Electric Auto-Lite Co
5000B	Gyroscope	Garwin
5000B-1	Gyroscope	Sigma Tek
5000B-10	Gyroscope	Electric Auto-Lite Co
5000B-11	Gyroscope	Electric Auto-Lite Co
5000B-12	Gyroscope	Electric Auto-Lite Co
5000B-13	Gyroscope	Electric Auto-Lite Co

Primary Part Number	Nomenclature	Manufacture
5000B-14	Gyroscope	Electric Auto-Lite Co
5000B-15	Gyroscope	Electric Auto-Lite Co
5000B-17	Gyroscope	Electric Auto-Lite Co
5000B-18	Gyroscope	Electric Auto-Lite Co
5000B-19	Gyroscope	Electric Auto-Lite Co
5000B-2	Gyroscope	Electric Auto-Lite Co
5000B-20	Gyroscope	Electric Auto-Lite Co
5000B-21	Gyroscope	Electric Auto-Lite Co
5000B-22	Gyroscope	Electric Auto-Lite Co
5000B-24	Gyroscope	Electric Auto-Lite Co
5000B-25	Gyroscope	Electric Auto-Lite Co
5000B-26	Gyroscope	Electric Auto-Lite Co
5000B-28	Gyroscope	Electric Auto-Lite Co
5000B-3	Gyroscope	Electric Auto-Lite Co
5000B-36	Gyroscope	Sigma Tek
5000B-38	Gyroscope	Sigma Tek
5000B-4	Gyroscope	Electric Auto-Lite Co
5000B-40	Gyroscope	Sigma Tek
5000B-41	Gyroscope	Sigma Tek
5000B-5	Gyroscope	Electric Auto-Lite Co
5000B-67	Gyroscope	Electric Auto-Lite Co
5000B-7	Gyroscope	Electric Auto-Lite Co
5000B-72	Horizon Gyro	Sigma Tek
5000B-75	Gyroscope	Electro Auto-light co
5000B-8	Gyroscope	Electric Auto-Lite Co
5000B-9	Gyroscope	Electric Auto-Lite Co

5000C	Gyroscope	Electric Auto-Lite Co
5000C-1	Gyroscope	Electric Auto-Lite Co
5000D	Gyroscope	Garwin
5000D-1	Gyroscope	Electric Auto-Lite Co
5000E	Gyroscope	Garwin
5E+2	Gyroscope	Electric Auto-Lite Co
5E-07	Gyroscope	Electric Auto-Lite Co
5E-08	Gyroscope	Electric Auto-Lite Co
5E-10	Gyroscope	Electric Auto-Lite Co
5E+1	Gyroscope	Electric Auto-Lite Co
5000-E3	Gyroscope	Electric Auto-Lite Co
5E+0	Gyroscope	Electric Auto-Lite Co
5E-1	Gyroscope	Electric Auto-Lite Co
5E-2	Gyroscope	Electric Auto-Lite Co
5E-4	Gyroscope	Electric Auto-Lite Co
5E-5	Gyroscope	Electric Auto-Lite Co
5E-6	Gyroscope	Electric Auto-Lite Co
5000F	Gyroscope	Sigma Tek

Primary Part Number	Nomenclature	Manufacture
5000F-1	Gyroscope	Electric Auto-Lite Co
5000F-10	Gyroscope	Electric Auto-Lite Co
5000F-11	Gyroscope	Electric Auto-Lite Co
5000F-12	Gyroscope	Electric Auto-Lite Co
5000F-2	Gyroscope	Electric Auto-Lite Co
5000F-3	Gyroscope	Electric Auto-Lite Co
5000F-5	Gyroscope	Electric Auto-Lite Co
5000F-6	Gyroscope	Electric Auto-Lite Co
5000F-7	Gyroscope	Electric Auto-Lite Co
5000F-8	Gyroscope	Electric Auto-Lite Co
5000F-9	Gyroscope	Electric Auto-Lite Co
5000G	Gyroscope	Electric Auto-Lite Co
5000H	Gyroscope	Electric Auto-Lite Co
5000J	Gyroscope	Electric Auto-Lite Co
5000K	Gyroscope	Electric Auto-Lite Co
5000L	Gyroscope	Electric Auto-Lite Co
5000L-4	Gyroscope	Electric Auto-Lite Co
5000L-8	Gyroscope	Electric Auto-Lite Co
5000M	Gyroscope	Sigma Tek
50015	Directional Gyroscope	Flightline Systems
50015-1	Directional Gyroscope	Flightline Systems
500CF	Horizon Reference Indicator	AIM
500CFK	Horizon Reference Indicator	AIM
500DC	Horizon Reference Indicator	AIM
500DCD	Horizon Reference Indicator	AIM
500DCF	Horizon Reference Indicator	AIM
500DCFL	Horizon Reference Indicator	AIM
500E	Horizon Reference Indicator	AIM
500EB	Horizon Reference Indicator	AIM
500ECF	Horizon Reference Indicator	AIM

500ED	Horizon Reference Indicator	AIM
500EDC	Horizon Reference Indicator	AIM
500EDK	Horizon Reference Indicator	AIM
500K	Horizon Reference Indicator	AIM
501-1005-01	Vertical Gyroscope	JET
501-1006-()	Vertisyn	BF Goodrich
501-1022-01	Gyroscope	JET
501-1027-01	Rate Gyroscope Indicator	JET
501-1027-02	Rate Gyroscope Indicator	JET
501-1032-01	Vertical Gyroscope	JET
501-1033 SERIES	Rate Gyroscope	JET
501-1036-( )	Attitude Indicator	JET
501-1036-01	Gyroscope	JET
501-1036-02	Gyroscope	JET

Primary Part Number	Nomenclature	Manufacture
501-1036-03	Gyroscope	JET
501-1036-04	Gyroscope	JET
501-1036-05	Gyroscope	JET
501-1036-06	Gyroscope	JET
501-1036-07	Gyroscope	JET
501-1049-01	Gyroscope	JET
501-1049-51	Gyroscope	JET
501-1063-01	Gyroscope	JET
501-1063-02	Gyroscope	JET
501-1063-03	Gyroscope	JET
501-1063-04	Gyroscope	JET
501-1063-05	Gyroscope	JET
501-1063-06	Gyroscope	JET
501-1063-07	Gyroscope	JET
501-1063-08	Gyroscope	JET
501-1077-01	Attitude Indicator	JET
501-1078-01	Gyroscope	JET
501-1078-02	Gyroscope	JET
501-1078-03	Gyroscope	JET
501-1078-04	Gyroscope	JET
501-1078-05	Gyroscope	JET
501-1078-06	Gyroscope	JET
501-1078-07	Gyroscope	JET
501-1078-08	Gyroscope	JET
501-1078-09	Gyroscope	JET
501-1078-10	Gyroscope	JET
501-1078-11	Gyroscope	JET
501-1078-12	Gyroscope	JET
501-1078-13	Gyroscope	JET
501-1086-01	Vertical Gyroscope	JET
501-1096-01	Vertical Gyroscope	JET
501-1098-01	Vertical Gyroscope	JET
501-1099-02	Attitude Indicator	JET
501-1100-01	Attitude Indicator	JET

501-1102-01	Rate Gyroscope	JET
501-1105-( )	Gyroscope	JET
501-1105-01	Attitude Indicator	L3 Communications
501-1105-02	Attitude Indicator	L3 Communications
501-1105-03	Attitude Indicator	L3 Communications
501-1105-04	Attitude Indicator	L3 Communications
501-1105-05	Attitude Indicator	L3 Communications
501-1105-06	Attitude Indicator	L3 Communications
501-1105-07	Attitude Indicator	L3 Communications
501-1105-08	Attitude Indicator	L3 Communications

Primary Part Number	Nomenclature	Manufacture
501-1105-09	Attitude Indicator	L3 Communications
501-1105-10	Attitude Indicator	L3 Communications
501-1105-11	Attitude Indicator	L3 Communications
501-1113-01	Displacement Gyroscope	JET
501-1114-01	Displacement Gyroscope	JET
501-1114-02	Displacement Gyroscope	JET
501-1116-01	Displacement Gyroscope	JET
501-1116-02	Displacement Gyroscope	JET
501-1121-01	Displacement Gyroscope	JET
501-1131-01	Attitude Indicator	JET
501-1131-02	Attitude Indicator	JET
501-1149-01	Directional Gyroscope	JET
501-1150-01	Displacement Gyroscope	JET
501-1150-02	Displacement Gyroscope	JET
501-1152-01	Attitude Indicator	JET
501-1153-01	Attitude Indicator	JET
501-1160-01	Displacement Gyroscope	JET
501-1162-01	Directisyn	JET
501-1162-02	Directisyn	JET
501-1169 SERIES	Rate Gyroscope	JET
501-1195-01	Gyroscope	JET
501-1197-( )	Attitude Indicator	JET
501-1197-02	Attitude Indicator	L3 Communications
501-1197-03	Attitude Indicator	L3 Communications
501-1197-04	Attitude Indicator	L3 Communications
501-1197-05	Attitude Indicator	L3 Communications
501-1197-06	Attitude Indicator	L3 Communications
501-1197-07	Attitude Indicator	L3 Communications
501-1197-08	Attitude Indicator	L3 Communications
501-1197-09	Attitude Indicator	L3 Communications
501-1197-10	Attitude Indicator	L3 Communications
501-1197-11	Attitude Indicator	L3 Communications
501-1197-12	Attitude Indicator	L3 Communications
501-1197-14	Attitude Indicator	L3 Communications
501-1197-15	Attitude Indicator	L3 Communications
501-1197-16	Attitude Indicator	L3 Communications
501-1197-17	Attitude Indicator	L3 Communications
501-1197-18	Attitude Indicator	L3 Communications

Primary Part Number	Nomenclature	Manufacturer
501-1197-19	Attitude Indicator	L3 Communications
501-1197-22	Attitude Indicator	L3 Communications
501-1197-23	Attitude Indicator	L3 Communications
501-1197-24	Attitude Indicator	L3 Communications
501-1197-25	Attitude Indicator	L3 Communications
501-1197-26	Attitude Indicator	L3 Communications
501-1197-27	Attitude Indicator	L3 Communications
501-1197-28	Attitude Indicator	L3 Communications
501-1197-29	Attitude Indicator	L3 Communications
501-1197-31	Attitude Indicator	L3 Communications
501-1197-32	Attitude Indicator	L3 Communications
501-1197-33	Attitude Indicator	L3 Communications
501-1204-01	Displacement Gyroscope	JET
501-1204-1-01	Displacement Gyroscope	JET
501-1209-01	Displacement Gyroscope	JET
501-1210-01	Displacement Gyroscope	JET
501-1224-01	Displacement Gyroscope	JET
501-1224-02	Displacement Gyroscope	JET
501-1239-51	Indicator	Jet
501-1251-01	Attitude Indicator	JET
501-1251-02	Attitude Indicator	JET
501-1255-01	Displacement Gyroscope	JET
501-1267-01	Attitude Indicator	JET
501-1277-01	Attitude Indicator	JET
501-1292-01	Attitude Indicator	JET
501-1294-01	Attitude Indicator	JET
501-1295-( )	Attitude Indicator	JET
501-1296-( )	Attitude Indicator	JET
501-1296-03	Attitude Indicator	L3 Communications
501-1412-( )	Attitude Indicator	JET
501-1453-01	Displacement Gyroscope	JET
501-1455-( )	Attitude Indicator	JET
502-1018-03	Directional Gyroscope	JET
50320	Rate Gyroscope	ARC
50-380023-1	Turn and Bank Indicator	AID
50-380024	Turn and Bank Indicator	Beechcraft
504-0001-921	Horizon Reference Indicator	AIM
504-0001-922	Horizon Gyro	AIM
504-0006-914	Horizon Reference Indicator	AIM
504-0006-954	Horizon Reference Indicator	AIM
504-0017-()	Gyroscope	L3 Communications
504-0017-901	Gyroscope	L3 Communications
504-0017-902	Gyroscope	AIM
504-0017-903	Gyroscope	L3 Communications
504-0017-905	Gyroscope	L3 Communications
504-0017-907	Gyroscope	L3 Communications
504-0017-909	Gyroscope	L3 Communications
504-0017-910	Gyroscope	L3 Communications

504-0017-911	Gyroscope	L3 Communications
504-0017-912	Gyroscope	L3 Communications

Primary Part Number	Nomenclature	Manufacture
504-0017-913	Gyroscope	L3 Communications
504-0017-914	Gyroscope	L3 Communications
504-0017-916	Gyroscope	L3 Communications
504-0017-917	Gyroscope	L3 Communications
504-0017-918	Gyroscope	L3 Communications
504-0017-921	Gyroscope	L3 Communications
504-0017-922	Gyroscope	L3 Communications
504-0017-923	Gyroscope	L3 Communications
504-0017-924	Gyroscope	L3 Communications
504-0017-925	Gyroscope	L3 Communications
504-0017-926	Gyroscope	L3 Communications
504-0017-928	Gyroscope	L3 Communications
504-0017-930	Gyroscope	L3 Communications
504-0017-931	Gyroscope	L3 Communications
504-0017-932	Gyroscope	L3 Communications
504-0017-933	Gyroscope	L3 Communications
504-0017-934	Gyroscope	L3 Communications
504-0022-901	Attitude Indicator	AIM
504-0024-()	Gyroscope	L3 Communications
504-0024-901	Gyroscope	L3 Communications
504-0024-902	Gyroscope	L3 Communications
504-0024-903	Gyroscope	L3 Communications
504-0024-904	Gyroscope	L3 Communications
504-0024-905	Gyroscope	L3 Communications
504-0024-906	Gyroscope	L3 Communications
504-0024-907	Gyroscope	L3 Communications
504-0027-901	Flight Director	JET
504-0028-()	Gyroscope	L3 Communications
504-0028-901	Gyroscope	L3 Communications
504-0028-902	Gyroscope	L3 Communications
504-0028-903	Gyroscope	L3 Communications
504-0028-904	Gyroscope	L3 Communications
504-0028-905	Gyroscope	L3 Communications
504-0028-906	Gyroscope	L3 Communications
504-0028-907	Gyroscope	L3 Communications
504-0028-908	Gyroscope	L3 Communications
504-0028-909	Gyroscope	L3 Communications
504-0028-910	Gyroscope	L3 Communications
504-0028-911	Gyroscope	L3 Communications
504-0028-912	Gyroscope	L3 Communications
504-0028-913	Gyroscope	L3 Communications
504-0028-914	Gyroscope	L3 Communications
504-0030-()	Gyroscope	L3 Communications
504-0030-909	Gyroscope	L3 Communications

Primary Part Number	Nomenclature	Manufacture

504-0030-910	Gyroscope	L3 Communications
504-0030-911	Gyroscope	L3 Communications
504-0030-912	Gyroscope	L3 Communications
504-0030-913	Gyroscope	L3 Communications
504-0030-914	Gyroscope	L3 Communications
504-0030-915	Gyroscope	L3 Communications
504-0030-916	Gyroscope	L3 Communications
504-0030-918	Gyroscope	L3 Communications
504-0030-919	Gyroscope	L3 Communications
504-0030-920	Gyroscope	L3 Communications
504-0031-()	Gyroscope	L3 Communications
504-0031-901	Gyroscope	L3 Communications
504-0031-902	Gyroscope	L3 Communications
504-0031-903	Gyroscope	L3 Communications
504-0031-904	Gyroscope	L3 Communications
504-0031-906	Gyroscope	L3 Communications
504-0031-907	Gyroscope	L3 Communications
504-0031-908	Gyroscope	L3 Communications
504-0031-909	Gyroscope	L3 Communications
504-0031-910	Gyroscope	L3 Communications
504-0031-911	Gyroscope	L3 Communications
504-0031-912	Gyroscope	L3 Communications
504-0031-913	Gyroscope	L3 Communications
504-0031-914	Gyroscope	L3 Communications
504-0031-915	Gyroscope	L3 Communications
504-0031-916	Gyroscope	L3 Communications
504-0031-917	Gyroscope	L3 Communications
504-0032-902	Attitude Gyroscope	AIM
504-0032-904	Attitude Gyroscope	AIM
504-0032-906	Attitude Gyroscope	AIM
504-0032-911	Attitude Gyroscope	AIM
504-0032-912	Attitude Gyroscope	AIM
504-0032-916	Attitude Gyroscope	AIM
504-0032-917	Attitude Gyroscope	AIM
504-0033-921	Gyroscope	BF Goodrich
504-0033-922	Gyroscope	BF Goodrich
504-0033-923	Gyroscope	BF Goodrich
504-0033-924	Gyroscope	BF Goodrich
504-0033-925	Gyroscope	BF Goodrich
504-0033-926	Gyroscope	BF Goodrich
504-0033-927	Gyroscope	BF Goodrich
504-0033-928	Gyroscope	BF Goodrich
504-0033-929	Gyroscope	BF Goodrich
504-0033-930	Gyroscope	BF Goodrich

Primary Part Number	Nomenclature	Manufacture
504-0033-931	Gyroscope	BF Goodrich
504-0033-932	Gyroscope	BF Goodrich
504-0033-933	Gyroscope	BF Goodrich
504-0033-934	Gyroscope	BF Goodrich

504-0035-9()	Attitude Indicator	BF Goodrich
504-0035-901	Attitude Indicator	L3 Communications
504-0035-902	Attitude Indicator	L3 Communications
504-0035-903	Attitude Indicator	L3 Communications
504-0035-904	Attitude Indicator	L3 Communications
504-0035-905	Attitude Indicator	L3 Communications
504-0035-906	Attitude Indicator	L3 Communications
504-0035-907	Attitude Indicator	L3 Communications
504-0035-908	Attitude Indicator	L3 Communications
504-0035-909	Attitude Indicator	L3 Communications
504-0035-910	Attitude Indicator	L3 Communications
504-0035-911	Attitude Indicator	L3 Communications
504-0035-912	Attitude Indicator	L3 Communications
504-0035-913	Attitude Indicator	L3 Communications
504-0035-914	Attitude Indicator	L3 Communications
504-0035-915	Attitude Indicator	L3 Communications
504-0035-916	Attitude Indicator	L3 Communications
504-0035-917	Attitude Indicator	L3 Communications
504-0035-918	Attitude Indicator	L3 Communications
504-0035-921	Attitude Indicator	L3 Communications
504-0035-922	Attitude Indicator	L3 Communications
504-0035-923	Attitude Indicator	L3 Communications
504-0035-924	Attitude Indicator	L3 Communications
504-0035-925	Attitude Indicator	L3 Communications
504-0035-926	Attitude Indicator	L3 Communications
504-0037-()	Gyroscope	L3 Communications
504-0037-901	Gyroscope	L3 Communications
504-0037-902	Gyroscope	L3 Communications
504-0037-903	Gyroscope	L3 Communications
504-0037-904	Gyroscope	L3 Communications
504-0037-905	Gyroscope	L3 Communications
504-0038-()	Gyroscope	L3 Communications
504-0038-901	Gyroscope	L3 Communications
504-0038-902	Gyroscope	L3 Communications
504-0038-903	Gyroscope	L3 Communications
504-0038-904	Gyroscope	L3 Communications
504-0038-905	Gyroscope	L3 Communications
504-0038-906	Gyroscope	L3 Communications
504-0038-907	Gyroscope	L3 Communications
504-0038-908	Gyroscope	L3 Communications

Primary Part Number	Nomenclature	Manufacture
504-0038-909	Gyroscope	L3 Communications
504-0038-910	Gyroscope	L3 Communications
504-0038-911	Gyroscope	L3 Communications
504-0038-913	Gyroscope	L3 Communications
504-0038-914	Gyroscope	L3 Communications
504-0041-()	Gyroscope	L3 Communications
504-0041-901	Gyroscope	L3 Communications
504-0041-902	Gyroscope	L3 Communications

504-0042-()	Gyroscope	L3 Communications
504-0042-901	Gyroscope	L3 Communications
504-0042-902	Gyroscope	L3 Communications
504-0042-903	Gyroscope	L3 Communications
504-0042-904	Gyroscope	L3 Communications
504-0042-905	Gyroscope	L3 Communications
504-0043-()	Gyroscope	L3 Communications
504-0043-901	Gyroscope	L3 Communications
504-0044-()	Gyroscope	L3 Communications
504-0044-901	Gyroscope	L3 Communications
504-0045-()	Gyroscope	L3 Communications
504-0045-901	Gyroscope	L3 Communications
504-0045-902	Gyroscope	L3 Communications
504-0045-903	Gyroscope	L3 Communications
504-0045-904	Gyroscope	L3 Communications
504-0046-()	Gyroscope	L3 Communications
504-0048-()	Gyroscope	L3 Communications
504-0048-901	Gyroscope	L3 Communications
504-0048-902	Gyroscope	L3 Communications
504-0048-903	Gyroscope	L3 Communications
504-0051-()	Gyroscope	L3 Communications
504-0051-901	Gyroscope	L3 Communications
504-0052-()	Gyroscope	L3 Communications
504-0052-901	Gyroscope	L3 Communications
504-0053-()	Gyroscope	L3 Communications
504-0053-901	Gyroscope	L3 Communications
504-0057-()	Gyroscope	L3 Communications
504-0057-901	Gyroscope	L3 Communications
504-0110-( )	Attitude Indicator	L3 Communications
504-0111-()	Attitude Indicator	L3 Communications
505-0010-902	Directional Gyroscope	AIM
505-0017-904	Directional Gyroscope	AIM
505-0023-913	Directional Gyroscope	AIM
505-0031-()	Directional Gyroscope	AIM
505-0031-901	Directional Gyroscope	JET
505-0031-902	Directional Gyroscope	JET

Primary Part Number	Nomenclature	Manufacture
505-0031-903	Directional Gyroscope	JET
505-0031-904	Directional Gyroscope	JET
505-0031-905	Directional Gyroscope	JET
505-0031-906	Directional Gyroscope	JET
505-0031-907	Directional Gyroscope	JET
505-0031-908	Directional Gyroscope	JET
505-0031-909	Directional Gyroscope	JET
505-0031-910	Directional Gyroscope	JET
505-0031-911	Directional Gyroscope	JET
505-0031-912	Directional Gyroscope	JET
505-0031-916	Directional Gyroscope	JET
505-0031-926	Directional Gyroscope	JET

505-0031-927	Directional Gyroscope	JET
505-0031-928	Directional Gyroscope	JET
505-0031-929	Directional Gyroscope	JET
505-0031-930	Directional Gyroscope	JET
505-0031-931	Directional Gyroscope	JET
505650-3	Azimuth Indicator	Bendix
506-0021-901	Horizontal Situation Ind	AIM
507-0020-901	Turn Coordinator	Castleberry
510 SERIES	Gyroscope	AIM
510-1078-01	Roll & Pitch Display Gyro	JET
51-1533-51	Indicator	Jet
515E100	Displacement Gyroscope	ICSD
520-() SERIES	Attitude Indicator	AIM
5-2000-()	Gyroscope	AIM
520-8100-001	Directional Gyroscope	Aeronetics
520-8130-003	Horizontal Situation Ind	Aeronetics
522-1513-005	Directional Gyroscope	Collins
522-1936-004	Compass Slave Indicator	Collins
522-1936-014	Compass Slave Indicator	Collins
522-1936-024	Compass Slave Indicator	Collins
522-1936-036	Compass Slave Indicator	Collins
522-1936-044	Compass Slave Indicator	Collins
522-1936-045	Compass Slave Indicator	Collins
522-1936-046	Compass Slave Indicator	Collins
522-1936-047	Compass Slave Indicator	Collins
522-1936-048	Compass Slave Indicator	Collins
522-1936-049	Compass Slave Indicator	Collins
522-2377-003	Beraing Distance Haeding	Collins
522-2411-003	Horizontal Situation Ind	Collins
522-2576-00P	Vertical Reference	Collins
522-2638-( )	Course Indicator	Collins
522-2644-011	slaving Accessory	Collins

Primary Part Number	Nomenclature	Manufacture
522-2782-004	Course Indicator	Collins
522-2782-014	Course Indicator	Collins
522-2782-024	Course Indicator	Collins
522-2782-034	Course Indicator	Collins
522-3241-000	Directional Gyroscope	Collins
522-3875-001	Course Indicator	Collins
522-3985-001	Vertical Gyroscope	Collins
522-4279-000	Course Indicator	Collins
522-4529-001	Indicator	Collins
523-0759314	Turn Rate Sensor	Collins
523-0771836	Magnetic Compass System	Collins
523-0771837	Magnetic Compass System	Collins
523-0771838	Magnetic Compass System	Collins
523-0771839	Magnetic Compass System	Collins
523-0771841	Directional Gyroscope	Collins
523-0771842	Directional Gyroscope	Collins

523-0771843	Directional Gyroscope	Collins
523-0771844	Directional Gyroscope	Collins
523-0772729	Rate Gyroscope	Collins
523-0772752	Magnetic Compass System	Collins
523-0774771	Magnetic Compass System	Collins
523-0775950	Directional Gyroscope	Collins
52C77	Flight Director	Sigma Tek
52C77-2	Flight Director	Sigma Tek
52C77-3	Flight Director	Sigma Tek
52D136	Horizontal Situation Ind	Sigma Tek
52D137	Horizontal Situation Ind	Sigma Tek
52D167	Artificial Horizon	Sigma Tek
52D167M	Artificial Horizon	Sigma Tek
52D178	Flight Director	Sigma Tek
52D54	Directional Gyroscope	Edo Aire
52D60	Turn and Bank Indicator	Sigma Tek
52D66	Horizon Gyroscope	Sigma Tek
52D67	Horizon Gyroscope	Sigma Tek
52D69	Turn and Bank Indicator	Mitchell
52D75	Turn and Bank Indicator	Mitchell
52D75-3	Turn and Bank Indicator	Sigma Tek
52D75-4	Turn and Bank Indicator	Sigma Tek
534E975G2	Autopilot Coupler	Ametek/GE
5400	Turn Coordinator	General Design
5-4000-01	Vertical Gyroscope Indicator	JET
5-4000-02	Vertical Gyroscope Indicator	JET
5-4000-04	Vertical Gyroscope Indicator	JET
5-4000-05	Vertical Gyroscope Indicator	JET

Primary Part Number	Nomenclature	Manufacture
5-4000-06	Vertical Gyroscope Indicator	JET
5-4000-08	Vertical Gyroscope Indicator	JET
5-4000-10	Vertical Gyroscope Indicator	JET
5-4000-11	Vertical Gyroscope Indicator	JET
5400-1 & 2	Turn Coordinator	General Design
5400-7295-1	Turn Coordinator	General Design
5400-7295-2	Turn Coordinator	General Design
5400-7295-3	Turn Coordinator	General Design
5400-7295-4	Turn Coordinator	General Design
5400-7425-1	Turn Coordinator	General Design
5400-7425-2	Turn Coordinator	General Design
5400-7425-3	Turn Coordinator	General Design
5400-7425-4	Turn Coordinator	General Design
540-2	Gyroscope	Bendix King
549E725G4	Autopilot Coupler	Ametek/GE
552-1513-005	Directional Gyroscope	Collins
552-3985-001	Gyroscope	Collins
553800	Attitude And Heading Reference	Pioneer
554214-1	Displacement Gyroscope	Texas Instruments
5550-7485N3	Turn and Bank Indicator	General Design

5550-7485N4	Turn and Bank Indicator	General Design
5550-8340N1L	Turn and Slip Indicator	General Design
5550-8340N3L	Turn and Slip Indicator	General Design
5550-8340N5L	Turn and Slip Indicator	General Design
5560-7615N3	Turn and Slip Indicator	General Design
5560-7615N4	Turn and Slip Indicator	General Design
5560-8165N1L	Turn and Bank Indicator	General Design
5560-850N7L	Turn and Slip Indicator	General Design
5560N1	Turn and Bank Indicator	General Design
5735-1	Directional Gyro Horizon	Garwin
58057-11	Compass	Honeywell
58057-112	Compass	Sagem
58057-12	Compass	Sagem
58057-13	Compass	Ragem
58057-32	Compass	Ragem
58057-4	Compass	Sagem
58057-41	Compass	Ragem
58057-82	Compass	Ragem
58057-85	Compass	Sagem
58-380094-9	Turn Coordinator	Mid Continent
5920	Compass Indicator	Eclipse Pioneer
600000	Drift Meter	Friden
600005	Drift Meter	Friden
600-009-900	Turn Coordinator	Brittian

Primary Part Number	Nomenclature	Manufacture
600010	Drift Meter	Friden
600015	Drift Meter	Friden
600020	Drift Meter	Friden
600025	Drift Meter	Friden
600030	Drift Meter	Friden
600035	Drift Meter	Friden
600040	Drift Meter	Friden
600045	Drift Meter	Friden
600050	Drift Meter	Friden
600055	Drift Meter	Friden
600748	Roll And Pitch Control	Sperry
60-130	Turn Coordinator	Astronautics
601696-100	Roll and Pitch Control	Sperry
601696-106	Roll And Pitch Control	Sperry
601969-106	Roll and Pitch Control	Sperry
604390B	Control Amplifier	Sperry
605210-21	Flight Director	Sperry
608335-106	Vertical Gyroscope Control	Sperry
608336-106	Vertical Gyroscope Control	Sperry
608588-2	Gyroscopic Horizon Ind	Sperry
608588-23	Vertical Gyroscope	Sperry
608588-6	Horizon Indicator	Sperry
608588-63	Vertical Gyroscope	Sperry
608778	Vertical Gyroscope Control	Sperry

608778-106	Vertical Gyroscope Control	Sperry
608816-1	Amplifier	Sperry
608816-2	Amplifier	Sperry
608853	Amplifier	Sperry
610782-105	Vertical Gyroscope Control	Sperry
610818	Auto Approach Control	Sperry
613260-1	Directional Gyroscope	Sperry
613260-2	Directional Gyroscope	Sperry
613937	Gyroscopic Horizon Ind	Sperry
614569	Compass Indicator	Sperry
615035	Amplifier	Sperry
615039	Vertical Gyroscope	Sperry
615857	Horizon Indicator	Sperry
617908	Directional Gyroscope	Sperry
617926-1	Vertical Gyroscope	Sperry
618287	Directional Gyroscope	Sperry
620359	Flux Detector	Sperry
622-0181-001	Rate Gyroscope	Collins
622-0181-002	Rate Gyroscope	Collins
622-0181-003	Rate Gyroscope	Collins

Primary Part Number	Nomenclature	Manufacture
622-0213-001	Flight Director	Collins
622-0835-001	Flight Director Indicator	Collins
622-0835-002	Flight Director Indicator	Collins
622-0836-001	Flight Director Indicator	Collins
622-0836-002	Flight Director Indicator	Collins
622-0836-003	Flight Director Indicator	Collins
622-0837-001	Flight Director Indicator	Collins
622-0837-002	Flight Director Indicator	Collins
622-0837-003	Flight Director Indicator	Collins
622-0855-001	Flight Director Indicator	Collins
622-0855-002	Flight Director Indicator	Collins
622-0856-001	Flight Director Indicator	Collins
622-0856-002	Flight Director Indicator	Collins
622-3343-001	Attitude Indicator	Collins
622-3343-002	Attitude Indicator	Collins
622-3344-002	Attitude Indicator	Collins
622-3374-002	Attitude Indicator	Collins
622-3594-019	Indicator	Collins
622-4424-001	Vertical Gyroscope	Collins
622-4488-001	Vertical Gyroscope	Collins
622-4565-001	Vertical Gyroscope	Collins
622-4565-002	Vertical Gyroscope	Collins
622-5812-001	Flux Detector	Collins
622-5812-002	Flux Detector	Collins
622-5812-003	Flux Detector	Collins
622-5812-004	Flux Detector	Collins
622-5812-005	Flux Detector	Collins
622-5812-006	Flux Detector	Collins

622-6136-001	Directional Gyroscope	Collins
622-6136-002	Directional Gyroscope	Collins
622-7194-201	Navigation Reveiver	Collins
622-8154-001	Flux Detector	Collins
622-8154-002	Flux Detector	Collins
634-4005-001	Rotor	Collins
6405	Turn Coordinator	S-TEC
6405-14L	Turn Coordinator	S-TEC
6406-14L	Directional Gyroscope	S-TEC
6407-( )	Turn Coordinator	S-TEC
64-30000	Gyroscopic Horizon Ind	Ferranti
643-S	Horizon Reference Indicator	AIM
64585-303	Rate Gyroscope	Northrup
646040	Gyroscopic Horizon Ind	Sperry
646050	Directional Gyro Indicator	Sperry
646050-AJ	Directional Gyro Indicator	Sperry

Primary Part Number	Nomenclature	Manufacture
646050-H	Directional Gyro Indicator	Sperry
647910	Directional Gyro Indicator	Sperry
647910-C	Directional Gyro Indicator	Sperry
647910-R	Directional Gyro Indicator	Sperry
648012	Autopilot	Sperry
649742	Directional Gyro Indicator	Sperry
652191	Directional Gyro Indicator	Sperry
652833-12	Horizon Indicator	Sperry
652833-22	Gyroscopic Horizon Ind	Sperry
653278	Compass Amplifier	Sperry
653290	Directional Gyro Indicator	Sperry
6534	Attitude Indicator	Sunbeam
653822	Amplifier	Sperry
653894-6BA	Directional Gyro Indicator	Sperry
654514-11	Vertical Indicator	Sperry
654514-21	Vertical Indicator	Sperry
654704	Gyroscopic Horizon Ind	Sperry
654744-2	Gyroscopic Horizon Ind	Sperry
654744-23	Gyroscopic Horizon Ind	Sperry
654744-4	Gyroscopic Horizon Ind	Sperry
654744-43	Vertical Gyroscope	Sperry
654744-6	Vertical Gyroscope	Sperry
654744-63	Vertical Gyroscope	Sperry
654776-12	Horizon Indicator	Sperry
65491-01816-101	Indicator	Astronautical
656518	Vertical Gyroscope Control	Sperry
656518B	Vertical Gyroscope Control	Sperry
656519	Directional Gyroscope	Sperry
656537	Amplifier	Sperry
656537-B	Amplifier	Sperry
656541	Automatic Flight System	Sperry
656557	Directional Gyro Indicator	Sperry

656767	Magnetic Flux Compensator	Sperry
656768	Gyroscopic Horizon Ind	Sperry
657069	Directional Gyro Indicator	Sperry
658527	Automatic Flight System	Sperry
658870	Gyroscope	Sperry
659591	Gyroscopic Horizon Ind	Sperry
659810	Attitude Gyro Indicator	Sperry
65D30721	Sim Attitude Director Ind	Sperry
6610-613-5476	Switching Rate Gyroscope	Lear Siegler
661204	Amplifier	Sperry
661207	Flight Controller	Sperry
661208	Flight Controller	Sperry

Primary Part Number	Nomenclature	Manufacture
6615-336-3129	Directional Gyroscope	Kearfott
6615-555-3962	Switching Rate Gyroscope	Lear Siegler
661560	Directional Gyro Indicator	Sperry
6615-618-9297	Switching Rate Gyroscope	Lear Siegler
6615-618-9800	Rate Switching Gyro	Pioneer
6615-631-1034	Rate Gyroscope	Lear Siegler
661633	Automatic Flight System	Sperry
661953	Amplifier	Sperry
661961	Attitude Gyro Indicator	Sperry
662611	Turn Controller	Sperry
663632	Amplifier	Sperry
663634	Amplifier	Sperry
664106-2	Compass Indicator	Sperry
664127	Attitude Gyro Indicator	Sperry
664159	Flight Controller	Sperry
664255	Compass Indicator	Sperry
664416-111	Autopilot Control	Sperry
664416-211	Autopilot Control	Sperry
664698	Amplifier	Sperry
664911	Gyroscope	Sperry
665265-2	Compass Indicator	Sperry
665266	Compass Amplifier	Sperry
665928	Automatic Flight System	Sperry
665930-113	Autopilot Control	Sperry
665930-121	Autopilot Control	Sperry
665930-211	Autopilot Control	Sperry
667833-21	Flight Director Indicator	Sperry
667834	Flight Director Computer	Sperry
667857	Vertical Gyroscope Control	Sperry
669339	Directional Gyroscope	Sperry
669386-2	Turn Controller	Sperry
669602-21	Heading Selector	Sperry
669923	Gyroscopic Horizon Ind	Sperry
669923-22	Gyroscopic Horizon Ind	Sperry
669926-2	Compass Indicator	Sperry
669926-6	Compass Indicator	Sperry

670176	Gyroscopic Horizon Ind	Sperry
671032	Gyroscopic Horizon Ind	Sperry
672670-2	Heading Selector	Sperry
672671	Auto Approach Control	Sperry
672740	Horizon Indicator	Sperry
673147	Compass Indicator	Sperry
673192	Horizon Indicator	Sperry
673230	Flight Command Indicator	Sperry

Primary Part Number	Nomenclature	Manufacture
673230-21	Flight Controller	Sperry
673239	Flight Controller	Sperry
673300	Flight Controller	Sperry
673391	Gyroscopic Horizon Ind	Sperry
673447	Directional Gyro Control	Sperry
673613-10	Amplifier	Sperry
673613-2	Amplifier	Sperry
673613-3	Amplifier	Sperry
673613-4	Amplifier	Sperry
673613-5	Amplifier	Sperry
673613-6	Amplifier	Sperry
673613-8	Amplifier	Sperry
674090	Directional Gyroscope	Sperry
674174	Directional Gyro Indicator	Sperry
678601	Gyroscopic Horizon Ind	Sperry
6803-4000-2	Azimuth-Range Indicator	Sperry
682440	Compass Amplifier	Sperry
682441-1	Compass Controller	Sperry
683063	Heading Selector	Sperry
683100	Auto Approach Control	Sperry
684535	Compass Amplifier	Sperry
685861	Flight Controller	Sperry
686524	Coordinator Control	Sperry
686531	Gyroscopic Horizon Ind	Sperry
687D835G17	Automatic Flight System	Ametek/GE
687D835G19	Automatic Flight System	Ametek/GE
689022	Vertical Gyroscope Control	Sperry
689022B	Vertical Gyroscope Control	Sperry
689024	Vertical Gyroscope Control	Sperry
68S59	Flight Director Computer	Electric Auto-Lite Co
6980L	Attitude Indicator	General Design
698588-6	Gyroscopic Horizon Ind	Sperry
7000-1A-1-A2	Azimuth Indicator	Eclipse Pioneer
7000-1A-1-A4	Azimuth Indicator	Eclipse Pioneer
7000466-901	Attitude Indicator	Sperry
7000466-902	Attitude Indicator	Sperry
7000466-903	Attitude Indicator	Sperry
7000466-904	Attitude Indicator	Sperry
7000466-905	Attitude Indicator	Sperry
7000466-906	Attitude Indicator	Sperry

7000466-907	Attitude Indicator	Sperry
7000466-908	Attitude Indicator	Sperry
7000466-909	Attitude Indicator	Sperry
7000466-910	Attitude Indicator	Sperry

Primary Part Number	Nomenclature	Manufacture
7000466-911	Attitude Indicator	Sperry
7000466-912	Attitude Indicator	Sperry
7000466-913	Attitude Indicator	Sperry
7000466-914	Attitude Indicator	Sperry
7000466-915	Attitude Indicator	Sperry
7000466-916	Attitude Indicator	Sperry
7000466-917	Attitude Indicator	Sperry
7000466-918	Attitude Indicator	Sperry
7000466-920	Attitude Indicator	Sperry
7000466-925	Attitude Indicator	Sperry
7000466-926	Attitude Indicator	Honeywell
7000466-935	Attitude Indicator	Sperry
7000466-936	Attitude Indicator	Sperry
7000466-945	Attitude Indicator	Sperry
7000466-946	Attitude Indicator	Honeywell
7000466-950	Attitude Indicator	Sperry
7000466-951	Attitude Indicator	Sperry
7000466-953	Attitude Indicator	Sperry
7000466-955	Attitude Indicator	Sperry
7000466-957	Attitude Indicator	Sperry
7000466-959	Attitude Indicator	Sperry
7000466-961	Attitude Indicator	Sperry
7000466-966	Attitude Indicator	Honeywell
7000466-986	Attitude Indicator	Honeywell
7000469-901	Horizontal Situation Ind	Sperry
7000469-902	Horizontal Situation Ind	Sperry
7000469-903	Horizontal Situation Ind	Sperry
7000469-905	Horizontal Situation Ind	Sperry
7000469-906	Horizontal Situation Ind	Sperry
7000469-907	Horizontal Situation Ind	Sperry
7000469-908	Horizontal Situation Ind	Sperry
7000469-909	Horizontal Situation Ind	Sperry
7000469-910	Horizontal Situation Ind	Sperry
7000469-911	Horizontal Situation Ind	Sperry
7000469-912	Horizontal Situation Ind	Sperry
7000469-913	Horizontal Situation Ind	Sperry
7000469-914	Horizontal Situation Ind	Sperry
7000469-915	Horizontal Situation Ind	Sperry
7000469-916	Horizontal Situation Ind	Sperry
7000469-917	Horizontal Situation Ind	Sperry
7000469-918	Horizontal Situation Ind	Sperry
7000469-919	Horizontal Situation Ind	Sperry
7000469-920	Horizontal Situation Ind	Sperry
7000469-921	Horizontal Situation Ind	Sperry

Primary Part Number	Nomenclature	Manufacture
7000469-922	Horizontal Situation Ind	Sperry
7000469-923	Horizontal Situation Ind	Sperry
7000469-924	Horizontal Situation Ind	Sperry
7000622-901	Vertical Gyroscope	Sperry
7000622-902	Vertical Gyroscope	Honeywell
7000788-XXX	Gyroscopic Horizon Ind	Sperry
7000836-( )	Attitude Director Indicator	Sperry
7000850-571	Attitude Indicator	Sperry
7001179-901	Horizontal Situation Ind	Honeywell
7001179-902	Horizontal Situation Ind	Honeywell
7001179-903	Horizontal Situation Ind	Honeywell
7001179-904	Horizontal Situation Ind	Honeywell
7001179-905	Horizontal Situation Ind	Honeywell
7001179-906	Horizontal Situation Ind	Honeywell
7001179-907	Horizontal Situation Ind	Honeywell
7001179-908	Horizontal Situation Ind	Honeywell
7001179-909	Horizontal Situation Ind	Honeywell
7001179-910	Horizontal Situation Ind	Honeywell
7001179-911	Horizontal Situation Ind	Honeywell
7001179-912	Horizontal Situation Ind	Honeywell
7001179-913	Horizontal Situation Ind	Honeywell
7001179-914	Horizontal Situation Ind	Honeywell
7001179-915	Horizontal Situation Ind	Honeywell
7001179-916	Horizontal Situation Ind	Honeywell
7001179-951	Horizontal Situation Ind	Honeywell
7001179-952	Horizontal Situation Ind	Honeywell
7001179-953	Horizontal Situation Ind	Honeywell
7001179-954	Horizontal Situation Ind	Honeywell
7001179-955	Horizontal Situation Ind	Honeywell
7001179-956	Horizontal Situation Ind	Honeywell
7001179-957	Horizontal Situation Ind	Honeywell
7001179-958	Horizontal Situation Ind	Honeywell
7001179-959	Horizontal Situation Ind	Honeywell
7001179-960	Horizontal Situation Ind	Honeywell
7001179-961	Horizontal Situation Ind	Honeywell
7001179-962	Horizontal Situation Ind	Honeywell
7001179-963	Horizontal Situation Ind	Honeywell
7001179-964	Horizontal Situation Ind	Honeywell
7001179-965	Horizontal Situation Ind	Honeywell
7001179-966	Horizontal Situation Ind	Honeywell
7001179-971	Horizontal Situation Ind	Honeywell
7001179-972	Horizontal Situation Ind	Honeywell
7001179-975	Horizontal Situation Ind	Honeywell
7001179-976	Horizontal Situation Ind	Honeywell

Primary Part Number	Nomenclature	Manufacture
7001182-901	Attitude Indicator	Sperry
7001182-902	Attitude Indicator	Sperry

7001182-903	Attitude Indicator	Sperry
7001182-904	Attitude Indicator	Sperry
7001182-905	Attitude Indicator	Sperry
7001182-906	Attitude Indicator	Sperry
7001182-907	Attitude Indicator	Sperry
7001182-908	Attitude Indicator	Sperry
7001182-909	Attitude Indicator	Sperry
7001182-910	Attitude Indicator	Sperry
7001182-911	Attitude Indicator	Sperry
7001182-912	Attitude Indicator	Sperry
7001182-913	Attitude Indicator	Sperry
7001182-914	Attitude Indicator	Sperry
7001182-915	Attitude Indicator	Sperry
7001182-916	Attitude Indicator	Sperry
7001182-917	Attitude Indicator	Sperry
7001182-918	Attitude Indicator	Collins
7001182-919	Attitude Indicator	Sperry
700179-952	Horizontal Situation Ind	Honeywell
700179-965	Horizontal Situation Ind	Honeywell
7001A	Displacement Gyroscope	Lear Siegler
700-2	Horizon Reference Indicator	AIM
700-2 Series	Autopilot Horizon Indicator	AIM
7002493-901	Horizontal Situation Ind	Sperry
7002493-902	Horizontal Situation Ind	Sperry
7002493-903	Horizontal Situation Ind	Sperry
7002493-904	Horizontal Situation Ind	Sperry
7002493-905	Horizontal Situation Ind	Sperry
7002493-906	Horizontal Situation Ind	Sperry
7002493-907	Horizontal Situation Ind	Sperry
7002493-908	Horizontal Situation Ind	Sperry
7002493-909	Horizontal Situation Ind	Sperry
7002493-910	Horizontal Situation Ind	Sperry
7002493-911	Horizontal Situation Ind	Sperry
7002493-912	Horizontal Situation Ind	Sperry
7002C	Displacement Gyroscope	Lear Siegler
700-2CF	Horizon Reference Indicator	AIM
700-3	Horizon Reference Indicator	AIM
700-3 Series	Autopilot Horizon Indicator	AIM
7003879-925	Autopilot Controller	Honeywell
7003897-901	PC-400 Autopilot Controller	Honeywell
700-3CF	Horizon Reference Indicator	AIM
700-4CF	Gyroscope	AIM

Primary Part Number	Nomenclature	Manufacture
700-5CF	Attitude Gyro Indicator	Electric Auto-Lite Co
705-15V10	Gyroscopic Horizon Ind	Sfena
705-15V1M1	Gyroscopic Horizon Ind	Sfena
705-15V3	Gyroscopic Horizon Ind	Sfena
705-15V4	Gyroscopic Horizon Ind	Sfena
705-15V9	Gyroscopic Horizon Ind	Sfena

705-19	Gyroscopic Horizon Ind	Sfena
705-7	Gyroscopic Horizon Ind	Sfena
705-7V4M1	Gyroscopic Horizon Ind	Sfena
705-7V9	Gyroscopic Horizon Ind	Sextant
705-7V91M1	Gyroscopic Horizon Ind	Sextant
705-7V9M1	Gyroscopic Horizon Ind	Sextant
71004-0109	Turn and Slip Indicator	Aerosonic
7125-1	Rate Gyroscope	General Design
7125-2	Rate Gyroscope	General Design
716537	Sim Attitude Director Ind	Sperry
7202-1A-1-A2	Course Indicator	Eclipse Pioneer
7202-1A-4-B1	Course Indicator	Eclipse Pioneer
7202-1A-4-C1	Course Indicator	Eclipse Pioneer
7204-1A-4-A1	Course Indicator	Eclipse Pioneer
7204-1A-4-D1	Course Indicator	Eclipse Pioneer
722-5140-002	Rate Gyroscope	Collins
722696-1	Sim Attitude Director Ind	Sperry
72-73B-74P	Slaving Amplifier	IFR
7301-1B-2-A1	Radio Converter Indicator	Eclipse Pioneer
7301-1C-3-A1	Radio Converter Indicator	Eclipse Pioneer
7301-1C-3-B1	Radio Converter Indicator	Eclipse Pioneer
743-001	Autopilot Control	Varo Inc.
743-001-1	Autopilot Control	Varo Inc.
74806-01	Gyroscope Amplifier	Lear Siegler
750-9800	Autopilot Control	Cook
76-212	Course Indicator	Ford
772-5140-001	Rate Gyroscope	Collins
772-5140-002	Rate Gyro	Collins
772-5370-001	Course Indicator	Collins
777-1026-001	Horizontal Situation Ind	Collins
777-1026-002	Horizontal Situation Ind	Collins
777-1026-003	Horizontal Situation Ind	Collins
777-1026-004	Horizontal Situation Ind	Collins
777-1026-005	Horizontal Situation Ind	Collins
777-1026-006	Horizontal Situation Ind	Collins
777-1034-001	Rate Gyroscope	Collins
777-1224-001	Indicator	Collins
777-1555-001	Directional Gyroscope	Collins

Primary Part Number	Nomenclature	Manufacture
777-1555-002	Directional Gyroscope	Collins
777-1556-001	Compass Amplifier	Collins
777-1556-002	Compass Amplifier	Collins
787-6380-001	Directional Gyroscope	Collins
787-6385-001	Course Indicator	Collins
787-6385-005	Indicator	Collins
7902-1C-4-A1	Range Indicator	Eclipse Pioneer
7902-1E-5-A1	Range Indicator	Eclipse Pioneer
7902-1E-5-A2	Range Indicator	Eclipse Pioneer
7902-1E-5-A3	Range Indicator	Eclipse Pioneer

7905-1G-7-B1	Range Indicator	Eclipse Pioneer
792-6091-001	Horizontal Situation Ind	Collins
792-6355-001	Flight Director Indicator	Collins
792-6355-002	Flight Director Indicator	Collins
792-6355-003	Flight Director Indicator	Collins
792-6355-004	Flight Director Indicator	Collins
792-6356-002	Course Indicator	Collins
792-6357-001	Attitude Indicator	Collins
792-6357-002	Attitude Indicator	Collins
792-6357-003	Attitude Indicator	Collins
792-6357-005	Attitude Indicator	Collins
792-6357-006	Attitude Indicator	Collins
792-6357-007	Attitude Indicator	Collins
792-6694-001	Vertical Gyroscope	Collins
792-6694-002	Vertical Reference	Collins
792-6694-004	Vertical Reference	Collins
797-6694-002	Vertical Gyroscope	Collins
8.043.003	Directional Gyroscope	Aeritalia
8.043.008.1	Directional Gyroscope	Aeritalia
8.048.003	Horizon Gyroscope	Aeritalia
8.048.008.1	Horizon Gyroscope	Aeritalia
8.143.900	Directional Gyroscope	Aeritalia
8.143.900.1	Directional Gyroscope	Aeritalia
8.143.900.2	Directional Gyroscope	Aeritalia
8.143.900.3	Directional Gyroscope	Aeritalia
8.143.900.4	Directional Gyroscope	Aeritalia
8.148.001	Gyroscopic Horizon Ind	Aeritalia
8.148.002	Gyroscopic Horizon Ind	Aeritalia
8.148.003	Gyroscopic Horizon Ind	Aeritalia
8.148.004	Gyroscopic Horizon Ind	Aeritalia
8.249.001	Attitude Gyroscope	Aeritalia
8.249.006	Attitude Gyroscope	Aeritalia
8.249.007	Attitude Gyroscope	Aeritalia
8.249.009	Attitude Gyroscope	Aeritalia

Primary Part Number	Nomenclature	Manufacture
8.249.050	Attitude Gyroscope	Aeritalia
8.249.086	Attitude Gyroscope	Aeritalia
8.249.087	Horizon Gyroscope	Aeritalia
8.249.095	Attitude Gyroscope	Aeritalia
800 Series	Directional Gyroscope	AIM
803-2	Gyroscope	Sfena
803V21	Gyroscope	Sfena
803V24	Gyroscope	Sfena
8100	Directional Gyroscope	Aeronetics
8130	Horizontal Situation Ind	Aeronetics
814B	Standby Compass	Kollsman
814B-02	Standby Compass	Kollsman
814BN-5-02	Standby Compass	Kollsman
814BN-8-02	Standby Compass	Kollsman

818	Radio Magnetic Indicator	Borg
819	Radio Converter Indicator	Borg
8220L	Attitude Indicator	General Design
822-1193-001	Flux Detector	Collins
82455-01	Gyroscope Amplifier	Lear Siegler
841A	Autopilot	Cessna
853D915G1	Rate Gyroscope	Ametek/GE
853D915G2	Gyroscope	Ametek/GE
86156	Sim Attitude Director Ind	Sperry
888	Glide Indicator	Weston
8DJ205LAE1	Vertical Indicator	Ametek/GE
8DJ206LAE1	Vertical Indicator	Ametek/GE
8DJ207LAE1	Vertical Indicator	Ametek/GE
8DJ30AA1	G-2 Compass	Ametek/GE
8KC1AC	Directional Gyro Turn Ind	Ametek/GE
8KC1AC2	Directional Gyro Indicator	Ametek/GE
8KC1AD	Directional Gyro Turn Ind	Ametek/GE
8KC1AD2	Directional Gyro Indicator	Ametek/GE
8KC2AC	Directional Gyro Turn Ind	Ametek/GE
8KC2AC2	Directional Gyro Indicator	Ametek/GE
8KD1AB2	Master Direction Indicator	Ametek/GE
8KD1AB3	Master Direction Indicator	Ametek/GE
8KD1AC4	Master Direction Indicator	Ametek/GE
8KD1AD5	Master Direction Indicator	Ametek/GE
8KD1AE5	Master Direction Indicator	Ametek/GE
8KD1AE6	Master Direction Indicator	Ametek/GE
8KD1AK5	Master Direction Indicator	Ametek/GE
8KD1Ak6	Master Direction Indicator	Ametek/GE
8KD1AL5	Master Direction Indicator	Ametek/GE
8KD1AL6	Master Direction Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8KD1AL7	Master Direction Indicator	Ametek/GE
8KD1AM7	Directional Indicator	Ametek/GE
8KD1AN7	Master Direction Indicator	Ametek/GE
8KD3AA2	Directional Gyroscope	Ametek/GE
8KD3AC2	Directional Gyroscope	Ametek/GE
8KD3AC3	Directional Gyroscope	Ametek/GE
8KD3AD2	Directional Gyroscope	Ametek/GE
8KD6AA2	Directional Gyro Indicator	Ametek/GE
8KD6AaB2	Directional Gyro Indicator	Ametek/GE
8KD6AB2	Directional Gyro Indicator	Ametek/GE
8KD6AD2	Directional Gyro Indicator	Ametek/GE
8KD6AE2,-3	Directional Gyro Indicator	Ametek/GE
8KD9AF2	Displacement Gyroscope	Ametek/GE
8KD9AF3	Displacement Gyroscope	Ametek/GE
8KD9AF4	Displacement Gyroscope	Ametek/GE
8KD9AF5	Displacement Gyroscope	Ametek/GE
8KD9AF6	Displacement Gyroscope	Ametek/GE
8KE1AC2	Compass Amplifier	Ametek/GE

8KE1AC3	Compass Amplifier	Ametek/GE
8KE1AC4	Compass Amplifier	Ametek/GE
8KE1AC4A	Compass Amplifier	Ametek/GE
8KE1AE2	Compass Amplifier	Ametek/GE
8KE63AV2	Electronic Control Amplifier	Ametek/GE
8KE63AZ2	Electronic Control Amplifier	Ametek/GE
8KE65AF2	Compass System Controller	Ametek/GE
8KE65AG2	Compass Controller	Ametek/GE
8KE65AH2	Compass Controller	Ametek/GE
8KE65BG2	Compass Controller	Ametek/GE
8KE65BJ2	Compass Controller	Ametek/GE
8KE65BK2	Compass Controller	Ametek/GE
8KJ3AA2	Remote Compass Transmitter	Ametek/GE
8KJ4AE2	Remote Compass Transmitter	Ametek/GE
8KJ4AE4	Remote Compass Transmitter	Ametek/GE
9000	Turn Coordinator	United Instruments
9000 Series	Turn Coordinator	United Instruments
9000C	Vertical Gyroscope	Lear Siegler
9002A	Displacement Gyroscope	Lear Siegler
9002B1	Displacement Gyroscope	Lear Siegler
9010-N.14	Turn Coordinator	United Instruments
903BD	Gyroscopic Horizon	Sfena
903BDV21	Gyroscopic Horizon	Sfena
903BDV4	Gyroscopic Horizon	Sfena
903BDV5	Gyroscopic Horizon	Sfena
904	Gyroscopic Horizon	Sfena
Primary Part Number	**Nomenclature**	**Manufacture**
9100	Turn Coordinator	United Instruments
9100 Series	Turn Coordinator	United Instruments
913B257G1	Control Gyro	Ametek/GE
92160-01	Attitude Indicator	Lear Siegler
94923-01	Flight Controller	Lear Siegler
9500	Turn and Slip Indicator	United Instruments
9500 Series	Turn and Slip Indicator	United Instruments
9500A	Turn and Slip Indicator	United Instruments
9500B	Turn and Slip Indicator	United Instruments
9501	Turn and Slip Indicator	United Instruments
9501A	Turn and Slip Indicator	United Instruments
9501B	Turn and Slip Indicator	United Instruments
9502	Turn and Slip Indicator	United Instruments
9502A	Turn and Slip Indicator	United Instruments
9502B	Turn and Slip Indicator	United Instruments
9550	Turn and Slip Indicator	United Instruments
9550 Series	Turn and Slip Indicator	United Instruments
9550A	Turn and Slip Indicator	United Instruments
9550B	Turn and Slip Indicator	United Instruments
9551	Turn and Slip Indicator	United Instruments
9551A	Turn and Slip Indicator	United Instruments
9551B	Turn and Slip Indicator	United Instruments

9552	Turn and Slip Indicator	United Instruments
9552A	Turn and Slip Indicator	United Instruments
9552B	Turn and Slip Indicator	United Instruments
9560 (series)	Turn and Slip Indicator	United Instruments
9561	Turn and Slip Indicator	United Instruments
9562	Turn and Slip Indicator	United Instruments
9616-13	Bearing Distance Heading Ind	Sunbeam
9616-13-03	Bearing Distance Heading Ind	Sunbeam
96245-04	Artificial Horizon	TACTAIR
965-0046-007	Go-Around Attitude Subsytem Co	Sundstrand
976M	Directional Gyroscope	TACTAIR
976M-1	Directional Gyroscope	TACTAIR
981-18-01	Attitude Indicator	Edison
9813-06	Bearing Distance Heading Ind	John Oster
9813-07	Bearing Distance Heading Ind	Sunbeam
9813-13	Bearing Distance Heading Ind	Sunbeam
9813-1301	Bearing Distance Heading Ind	Sunbeam
9819-08	Attitude Indicator	Sunbeam
9819-58-03	Attitude Indicator	Edison
9819-68-01	Sim Attitude Director Ind	Sperry
9819-97-01	Sim Attitude Director Ind	Sperry
989-10-01	Standby Compass	Kollsman

Primary Part Number	Nomenclature	Manufacture
9914188-3	Horizon Indicator	Hickok
99-384044-()	Pitch Trim Indicator	R C Allen
9KD1AM7	Master Direction Indicator	Ametek/GE
A/A42G-11	Vertical Gyroscope Control	Sperry
A1050	Turn and Slip Indicator	R C Allen
A-11	Turn and Bank Indicator	Eclipse Pioneer
A-12	Turn and Bank Indicator	Eclipse Pioneer
A-12D	Vertical Gyroscope Control	Sperry
A1600	Turn and Bank Indicator	R C Allen
A1605	Turn and Slip Indicator	R C Allen
A1615	Turn and Slip Indicator	R C Allen
A1620	Turn and Slip Indicator	R C Allen
A1620-03	Turn and Slip Indicator	R C Allen
A-2	Vertical Indicator	Sperry
A2060	Rate Gyroscope	R C Allen
A2200	Turn and Slip Indicator	Kelly
A2460	Rate Gyroscope	R C Allen
A2475-2	Turn and Bank Indicator	R C Allen
A24G-42	Displacement Gyroscope	Bendix
A24G-5	Displacement Gyroscope	Bendix
A2550-1	Turn and Slip Indicator	Kelly
A2562-01	Turn and Slip Indicator	Kelly
A2850-1	Rate Gyroscope	R C Allen
A2850-5	Rate Gyroscope	R C Allen
A2850B-1	Rate Gyroscope	R C Allen
A-3	Autopilot	Sperry

A-3A	Autopilot	Sperry
A-5	Autopilot	Sperry
A5920	Turn and Bank Indicator	R C Allen
A5930	Turn and Bank Indicator	R C Allen
A-780	Directional Gyroscope	TACTAIR
A-8	Turn and Bank Indicator	Eclipse Pioneer
AD113	Directional Gyroscope	Sperry
AD122	Vertical Gyroscope Control	Sperry
AD-884A	Autopilot Adapter	Bendix
ADI-330	Attitude Indicator	BF Goodrich
ADI-84	Indicator	Collins
ADI-85	Attitude Indicator	Collins
AF-295A	Autopilot	Cessna
AF-394A	Cessna 300 Navomatic Autopilot	Cessna
AF-395A	NAV-O-MATIC Autopilot	Cessna
AF-420A	Autopilot	Cessna
AF-512A	NAV-O-MATIC 200	Cessna
AF-512B	NAV-O-MATIC 300	Cessna

Primary Part Number	Nomenclature	Manufacture
AF-512C	NAV-O-MATIC 300	Cessna
AF-512D	NAV-O-MATIC 300	Cessna
AF-520A	NAV-O-MATIC 400	Cessna
AF-520B	NAV-O-MATIC 400	Cessna
AF-520C	NAV-O-MATIC 400	Cessna
AF530A	Autopilot	Cessna
AF-550A	NAV-O-MATIC Autopilot	Cessna
AH08-0105-1	Artificial Horizon	Humphrey
AI-297	Attitude Indicator	OMI
AI-803M/R	Attitude Indicator	JET
AI-803M/W	Attitude Indicator	JET
AI-804-( )	Attitude Indicator	JET
AI-904	Attitude Indicator	JET
AI-904 ( )	Attitude Indicator	JET
AIM 300	Horizon Reference Indicator	AID
AIM 400	Directional Gyroscope	AIM
AIM 400 SERIES	Directional Gyroscope	AIM
AIM 505 ( ) SERIES	Gyroscope	AIM
AIM 520 ( )	Gyroscope	BF Goodrich
AIM 800	Directional Gyroscope	AIM
Aim TS200-4	Turn and Slip Indicator	AIM
AIM251	Autopilot Horizon Indicator	BF Goodrich
AIM251(8°)	Autopilot Horizon Indicator	BF Goodrich
AIM251CF	Autopilot Horizon Indicator	BF Goodrich
AIM251CF(8°)	Autopilot Horizon Indicator	BF Goodrich
AIM300-2	Autopilot Horizon Indicator	BF Goodrich
AIM300-2(8°)	Autopilot Horizon Indicator	BF Goodrich
AIM300-2CF	Autopilot Horizon Indicator	BF Goodrich
AIM300-2CF(8°)	Autopilot Horizon Indicator	BF Goodrich
AIM300B	Autopilot Horizon Indicator	BF Goodrich

AIM700-2	Autopilot Horizon Indicator	BF Goodrich
AIM700-2CF	Autopilot Horizon Indicator	BF Goodrich
AIM700-2CF(8°)	Autopilot Horizon Indicator	BF Goodrich
AIM700-3	Autopilot Horizon Indicator	BF Goodrich
AIM700-3CF	Autopilot Horizon Indicator	BF Goodrich
AIM700-3CF(8°)	Autopilot Horizon Indicator	BF Goodrich
AK319	Automatic Flight System	Electric Auto-Lite Co
AK411	Automatic Flight System	Electric Auto-Lite Co
AK448	Century IV Autopilot	Electric Auto-Lite Co
AK448FD	Century IV Flight Director	Electric Auto-Lite Co
AK490	Century IIB Autopilot	Electric Auto-Lite Co
AM-3209/ASN	Electronic Control Amplifier	Sperry
AN/ASN-43	Directional Gyroscope Displace	Sperry
AN/ASN-50	Attitude Indicator	Pioneer

Primary Part Number	Nomenclature	Manufacture
AN/ASN-73	Attitude And Heading Reference	Lear Siegler
AN01-190EB-2	Directional Gyroscope	Ametek/GE
AN05-45BA-2	Autopilot	Jack & Heintz
AN-5730-1	Magnetic Compass	Pioneer
AN5730-2	Compass Indicator	Eclipse Pioneer
AN5730-2A	Compass Indicator	Eclipse Pioneer
AN5730-3	Compass Indicator	Eclipse Pioneer
AN5730-6	Magnetic Compass	Eclipse Pioneer
AN5732-1	Magnetic Compass	Pioneer
AN5735-1	Directional Gyroscope	Sperry
AN5735-1A	Directional Gyro Indicator	Sperry
AN5736-1A	Gyroscopic Horizon Ind	Sperry
AN5736L1A	Gyroscope	Sperry
AN5738-1	Astro Compass	SPERTI
AN5756-1	Compass Indicator	Eclipse Pioneer
AN5756-2	Compass Indicator	Eclipse Pioneer
AN5766-1	Magnetic Compass	Airpath
AN5766-2	Magnetic Compass	Airpath
AN5766-3	Magnetic Compass	Airpath
AN5766-4	Magnetic Compass	Airpath
AN5766-T3	Magnetic Compass	Airpath
ANS-20	Directional Gyroscope	ANS
ANS-30	Directional Gyroscope	ANS
ANS-31A	Area Navigation System	Collins
ANS-31C	Area Navigation System	Collins
ANS-35	Area Navigation System	Collins
ANS-351	Area Navigation Computer	Collins
AP118-A1	Gyroscope	Bendix
AP125-A1	Gyroscope	Bendix
AP97-A1	Gyroscope	Bendix
AQU-13A/A	HORIZONTAL SITUATION IND.	ASTRONAUTICS CORP
AQU-2/A	Horizontal Situation Ind	Collins
ARU-12/A	Attitude Indicator	Astronautics
ARU-13/A	Attitude Indicator	Lear Siegler

ARU-18/A	Attitude Indicator	Lear Siegler
ARU-20/A	Attitude Indicator	Lear Siegler
ARU-2B/A	Attitude Indicator	Lear Siegler
ARU-3/A	Turn and Slip Indicator	Kelly
ARU-4/A	Attitude Indicator	Lear Siegler
ARU-55/A	Indicator	Jet
ARU-60/A	Indicator	Jet
ASN-75	Directional Gyroscope	Sperry
ASN-89(V)	Directional Gyroscope	Sperry
B-11	Autopilot	Brittian

Primary Part Number	Nomenclature	Manufacture
B-1278	Directional Gyroscope	TACTAIR
B-16	Magnetic Compass	Airpath
B24670 00 002	Erection Amplifier	Kollsman
B2888-01	Rate Gyroscope	R C Allen
B2888-02	Rate Gyroscope	R C Allen
B2C	LEVEL-MATIC Autopilot	Brittian
B3083910006	Radio Magnetic Indicator	Bendix King
B381	Turn and Bank Indicator	Beechcraft
B4	Flight Controller	Brittian
B4A	Turn and Bank Indicator	Schwien
B4A-A	Turn and Bank Indicator	Schwien
B4A-B	Turn and Bank Indicator	Schwien
B4-B	Turn and Bank Indicator	Schwien
B4B-A	Turn and Bank Indicator	Schwien
B4B-B	Turn and Bank Indicator	Schwien
B4B-D	Turn and Bank Indicator	Schwien
B4B-E	Turn and Bank Indicator	Schwien
B4B-F	Turn and Bank Indicator	Schwien
B4B-K	Turn and Bank Indicator	Schwien
B4B-L	Turn and Bank Indicator	Schwien
B4B-M	Turn and Bank Indicator	Schwien
B4B-N	Turn and Bank Indicator	Schwien
B4B-P	Turn and Bank Indicator	Schwien
B4B-T	Turn and Bank Indicator	Schwien
B-5P	Flight Controller	Brittian
B-650	Directional Gyroscope	TACTAIR
B-677	Directional Gyroscope	TACTAIR
B-7	Flight Controller	Brittian
BDI-36	Bearing Distance Heading Ind	Collins
BG 174 Series	Autopilot Computer	Bendix King
BG 274 Series	Autopilot Computer	Bendix King
BG 374 Series	Autopilot Computer	Bendix King
BG174B2	Autopilot Computer	Bendix King
BG174C1	Autopilot Computer	Bendix King
BG174C2	Autopilot Computer	Bendix King
BG174D1	Autopilot Computer	Bendix King
BG174D2	Autopilot Computer	Bendix King
BG274B2	Autopilot Computer	Bendix King

Primary Part Number	Nomenclature	Manufacture
BG274C1	Autopilot Computer	Bendix King
BG274C2	Autopilot Computer	Bendix King
BG274D1	Autopilot Computer	Bendix King
BG274D2	Autopilot Computer	Bendix King
BG374C1	Autopilot Computer	Bendix King
BG374C3	Autopilot Computer	Bendix King
BG374C4	Autopilot Computer	Bendix King
BG374D1	Autopilot Computer	Bendix King
BG374D2	Autopilot Computer	Bendix King
BG374D3	Autopilot Computer	Bendix King
BG374D4	Autopilot Computer	Bendix King
BH187L-7	Autotak Indicator	Howell
BSS	LEVEL-MATIC Autopilot	Brittian
B-VII	Flight Controller	Brittian
B-VIII	Flight Controller	Brittian
C-1	Turn and Bank Indicator	Eclipse Pioneer
C-11B	Compass System	Sperry
C-12	Compass System	Sperry
C128569	Horizon Indicator	Hickok
C-14A	Gyroscope	Sperry
C-14B	Directional Gyroscope	Sperry
C166221ZA01	Integrated Standby Instrument	Thales
C2300-DL4	Magnetic Compass	Airpath
C-2984/AJB-3A	Compass System Controller	Lear Siegler
C-2A	Gyrosyn Compass System	Sperry
C-4	Gyrosyn Compass System	Sperry
C-4A	Gyrosyn Compass System	Sperry
C-4B	Gyrosyn Compass System	Sperry
C-5C	Directional Gyroscope	Sperry
C-5H	Pilot Standby Compass	Ametek/GE
C661003-0506	Turn Coordinator	Mid Continent
C661075-0106	Directional Gyroscope	AIM
CD-14D	Directional Gyroscope	Sperry
CENTURY I	Autopilot	Electric Auto-Lite Co
CENTURY IV	Flight Director	Electric Auto-Lite Co
CG 117/517	Flight Controller	Bendix King
CG 136	Heading Selector	Bendix King
CG 515	Flight Controller	Bendix King
CG 515 Series	Flight Controller	Bendix King
CG117B1	Flight Controller	Bendix King
CG117B2	Flight Controller	Bendix King
CG117B3	Flight Controller	Bendix King
CG136A1	Heading Selector	Bendix King
CG136B1	Heading Selector	Bendix King
CG217B1	Flight Controller	Bendix King
CG217B2	Flight Controller	Bendix King
CG217B3	Flight Controller	Bendix King
CG317B1	Flight Controller	Bendix King

CG317B2	Flight Controller	Bendix King
CG317B4	Flight Controller	Bendix King

Primary Part Number	Nomenclature	Manufacture
CG317D1	Flight Controller	Bendix King
CG317D2	Flight Controller	Bendix King
CG417A1	Flight Controller	Bendix King
CG417A2	Flight Controller	Bendix King
CG417B1	Flight Controller	Bendix King
CG417B2	Flight Controller	Bendix King
CG417G1	Flight Controller	Bendix King
CG417G2	Flight Controller	Bendix King
CG515A1	Flight Controller	Bendix King
CG515A2	Flight Controller	Bendix King
CG515B1	Flight Controller	Bendix King
CG515B2	Flight Controller	Bendix King
CG515C1	Flight Controller	Bendix King
CG515C2	Flight Controller	Bendix King
CG515D1	Flight Controller	Bendix King
CG515D2	Flight Controller	Bendix King
CG515K1	Flight Controller	Bendix King
CG515K2	Flight Controller	Bendix King
CIA 251 Series	Autopilot Horizon Indicator	BF Goodrich
CIA 300 Series	Autopilot Horizon Indicator	BF Goodrich
CIA 700 Series	Autopilot Horizon Indicator	BF Goodrich
CM-1	Remote Caging Control	Eclipse Pioneer
CM-2	Remote Caging Control	Eclipse Pioneer
CN-1072/AJN	Flux Detector	Bendix
CN-1141	Directional Gyroscope	Sperry
CN-1169/A	Displacement Gyroscope	Guidance Technology
CN-1251	Directional Gyroscope	Sperry
CN-1314/A	Vertical Gyroscope	Lear Siegler
CN-1314A/A	Displacement Gyroscope	Flightline Systems
CN-1314B/A	Displacement Gyroscope	Lear Siegler
CN-1466/ASN-129	Displacement Gyroscope	Lear Siegler
CN-1497	Displacement Gyroscope	Lear Siegler
CN-1497/A	Displacement Gyroscope	JET
CN-1497A	Vertical Gyroscope	Lear Siegler
CN-1525/ASN-134	Displacement Gyroscope	Lear Siegler
CN-1552A/A	Rate Gyroscope	Condor Pacific
CN-1564A/A	Rate Gyroscope	Condor Pacific
CN-601/ASW-12(V)	Displacement Gyroscope	Sperry
CN-601/ASW-12(V0	Displacement Gyroscope	Sperry
CN-601A/ASW-12(V)	Displacement Gyroscope	Sperry
CN-811A/ASN	Vertical Gyroscope	Lear Siegler
CN-811B/ASN	Displacement Gyroscope	JET
CN-811D/ASN	Displacement Gyroscope	Guidance Technology
CN-811E/ASN	Displacement Gyroscope	TRC

Primary Part Number	Nomenclature	Manufacture

CN-998(B)	Directional Gyroscope	Sperry
CN-998-ASN-43	Directional Gyroscope	Sperry
CN-998B/ASN-43	Directional Gyroscope Displace	Sperry
CPN 622-0181-001	Rate Gyroscope	Collins
CPN 622-0181-002	Rate Gyroscope	Collins
CPN 622-0181-003	Rate Gyroscope	Collins
CPN 722-5140-001	Rate Gyroscope	Collins
CPN 722-5140-002	Rate Gyroscope	Collins
CPN 777-1034-001	Rate Gyroscope	Collins
CPU-4/A	Flight Director Computer	Collins
CQ-1	Caging Switch Box	Eclipse Pioneer
CQ-2	Caging Switch Box	Eclipse Pioneer
D1000	Course Indicator	Rainier
D-1468	Directional Gyroscope	TACTAIR
D-321	Directional Gyroscope	TACTAIR
D-323	Artificial Horizon	TACTAIR
DG 1009	Pitch Trim Electronics	Bendix King
DG 1010	Pitch Trim Electronics	Bendix King
DG 114	Attitude Reference Coupler	Bendix King
DG04-0109-1	Directional Gyroscope	Humphrey
DG1009	Electric Pitch-Trim Adapter	Bendix King
DG1010	Electric Pitch-Trim Adapter	Bendix King
DG114A1	Attitude Reference Coupler	Bendix King
DG312	Directional Gyroscope Displace	Sperry
DG-360A	Horizontal Situation Ind	Century Flight System
DG-882A	Directional Gyroscope	Bendix
DGS-65	Directional Gyroscope	Collins
DH-841C	Director Horizon Indicator	Bendix
DH-841V	Horizon Indicator	Bendix King
DH-861A	Horizon Indicator	Bendix King
DHC60167-1	Vertical Gyroscope	Bendix
DME-40	DME Indicator	Collins
DME-451	DME Indicator	Collins
DP43A1	Signal Modifier Monitor	Allied
DP64A1	Signal Modifier Monitor	Allied
DP87A1	Signal Modifier Monitor	Allied
DP91A1	Signal Modifier Monitor	Allied
DSA274	Attitude Indicator	Consolidated Airborn
DSA274-1	Attitude Indicator	Consolidated Airborn
DSA274-2	Attitude Indicator	Consolidated Airborn
DSA274-4	Attitude Indicator	Consolidated Airborn
DSB-357	Bearing Distance Heading Ind	Consolidated Airborn
E14355	Attitude Indicator	Collins
E25-8034-2	Attitude Indicator	Lear Siegler

Primary Part Number	Nomenclature	Manufacture
E-4	Autopilot	Sperry
E5165001400	Bearing Distance Heading Ind	Kollsman
EB-17-A1	Caging Relay	Eclipse Pioneer
EB-17-A2	Caging Relay	Eclipse Pioneer

EB-2	Caging Relay	Eclipse Pioneer
EFIS-85A-2A	EFIS	Collins
EFS 40/50	EFIS	Bendix King
EG105A	Control Amplifier	Honeywell
EG105A-2	Control Amplifier	Honeywell
EG65A	Control Amplifier	Honeywell
EG65A3	ELECT.CNTRL AMP.	Honeywell
EG66A	Control Amplifier	Honeywell
EH6650	Sim Attitude Director Ind	Sperry
EH6690	Sim Attitude Director Ind	Sperry
F51650011400	Bearing Distance Heading Ind	Kollsman
FCS810	Flight Controller	Bendix King
FCS-810	Flight Controller	Bendix
FD-108X	Integrated Flight System	Collins
FD-108Y	Integrated Flight System	Collins
FD-108Z	Integrated Flight System	Collins
FD-112A	Flight Director	Collins
FD-112V	Flight Director	Collins
FDU-3000	Flux Detector	Collins
FDU-70	Flux Detector	Collins
FDU-70A	Flux Detector	Collins
FH15G/2	Gyroscopic Horizon Ind	Ferranti
FIS-84	Flight Instrument System	Collins
FPA-80	Flight Profile Advisory	Collins
FSSC 88-C-800	Magnetic Compass	Pioneer
FX-833A	Flux Detector	Bendix
G-112A	Directional Gyroscope	ARC
G-20-A	Directional Gyroscope	AIM
G-20-B	Directional Gyroscope	AIM
G300	Turn and Slip Indicator	EGC
G300A	Turn Coordinator	General Design
G4000	Turn and Bank Indicator	R C Allen
G4003	Turn and Slip Indicator	R C Allen
G504A	Directional Gyroscope	Electric Auto-Lite Co
G515A	Rate Gyroscope	ARC
G517A	Rate Gyroscope	ARC
G-840A	Gyro Computer	Cessna
GG 205	Turn and Bank Indicator	Bendix King
GG 301	Vertical Gyroscope	Bendix King
GG 302	Directional Gyroscope	Bendix King

Primary Part Number	Nomenclature	Manufacture
GG202C1	Directional Gyroscope	Cessna
GG205A1	Turn and Bank Indicator	Bendix King
GG205A3	Turn and Bank Indicator	Bendix King
GG205A4	Turn and Bank Indicator	Bendix King
GG205A5	Turn and Bank Indicator	Bendix King
GG205B4	Turn and Bank Indicator	Bendix King
GG205C1	Turn and Bank Indicator	Bendix King
GG205C2	Turn and Bank Indicator	Bendix King

GG205C4	Turn and Bank Indicator	Bendix King
GG2479AA01	Rate Gyroscope	Honeywell
GG2479AB01	Rate Gyroscope	Honeywell
GG2479AB03	Rate Gyroscope	Honeywell
GG301A1	Gyroscope	Honeywell
GG301A2	Gyroscope	Honeywell
GG301B1	Gyroscope	Bendix King
GG301B2	Gyroscope	Bendix King
GG301-BCF2	Vertical Gyroscope	Bendix King
GG301C1	Gyroscope	Bendix King
GG301C2	Gyroscope	Honeywell
GG301P2	Gyroscope	Bendix King
GG302A1	Gyroscope	Bendix King
GG302B1	Gyroscope	Bendix King
GG302C1	Gyroscope	Bendix King
GG48A	Displacement Gyroscope	Honeywell
GG48A1	Displacement Gyroscope	Honeywell
GG79A1	Rate Gyroscope	Honeywell
GG79A2	Rate Gyroscope	Honeywell
GG79A3	Rate Gyroscope	Honeywell
GG79A4	Rate Gyroscope	Honeywell
GG79A5	Rate Gyroscope	Honeywell
GG79A6	Rate Gyroscope	Honeywell
GH02E-3BL	Attitude Gyroscope	Falcon
GH-14	Gyroscopic Horizon Ind	Sperry
GH-14A	Flight Director	Sperry
GH-14B	Flight Director	Sperry
GI106A	Indicator	Mid-Continent
GNC 250XL	GPS	Garmin
GR06-0102-1	Directional Gyroscope	Humphrey
GR06-0102-2	Directional Gyroscope	Humphrey
H14	Autopilot	Bendix King
H-14	Autopilot System	Bendix King
H140ABM2	Gyroscopic Horizon Ind	Thales
H140ACM2	Gyroscopic Horizon Ind	Sfena
H140ADM2	Gyroscopic Horizon Ind	Sfena

Primary Part Number	Nomenclature	Manufacture
H140AMM	Gyroscopic Horizon Ind	Sfena
H140ARM2	Gyroscopic Horizon Ind	Sfena
H140ASM	Gyroscopic Horizon Ind	Sfena
H140ATM2	Gyroscopic Horizon Ind	Sfena
H140AUM2	Gyroscopic Horizon Ind	Sfena
H140BAM2	Gyroscopic Horizon Ind	Sfena
H140BHM2	Gyroscopic Horizon Ind	Sfena
H140BKM	Gyroscopic Horizon Ind	Sfena
H140BLM	Gyroscopic Horizon Ind	Sfena
H140CAM1	Gyroscope	Sfena
H140CJM1	Gyroscope	Sfena
H140CLM1	Gyroscopic Horizon Ind	Sfena

H140CPM1	Gyroscopic Horizon Ind	Sfena
H140CQM3	Gyroscope	Sfena
H140CRM1	Gyroscopic Horizon Ind	Sfena
H140CSM1	Gyroscopic Horizon Ind	Sfena
H140CWM	Gyroscopic Horizon Ind	Sfena
H140DCM	Gyroscopic Horizon Ind	Sfena
H140JBM	Gyroscopic Horizon Ind	Sfena
H140JDM	Gyroscopic Horizon Ind	Sfena
H140JDM1	Gyroscopic Horizon Ind	Sfena
H140JJM1	Gyroscopic Horizon Ind	Sfena
H140JKM1	Gyroscope	Sfena
H140JLM	Gyroscopic Horizon Ind	Sfena
H140JSM	Gyroscopic Horizon Ind	Sfena
H140JTM1	Gyroscopic Horizon Ind	Sfena
H140JUM2	Gyroscopic Horizon Ind	Sfena
H140JVM2	Gyroscopic Horizon Ind	Sfena
H140JWM1	Gyroscopic Horizon Ind	Sfena
H140JYM1	Gyroscopic Horizon Ind	Sfena
H140KAM	Gyroscopic Horizon Ind	Sfena
H140KBM	Gyroscopic Horizon Ind	Sfena
H140KDM	Gyroscopic Horizon Ind	Sfena
H140KRM	Gyroscopic Horizon Ind	Sfena
H150AKM1	Attitude Indicator	Sfena
H221	Horizon Gyroscope	Thales
H221AGM	Horizon Gyroscope	Thales
H221AHM	Horizon Gyroscope	Thales
H221ALM	Horizon Gyroscope	Thales
H221AMM	Horizon Gyroscope	Thales
H221ANM	Horizon Gyroscope	Thales
H221APM	Horizon Gyroscope	Thales
H221ARM	Horizon Gyroscope	Thales
H221AUM	Horizon Gyroscope	Thales

Primary Part Number	Nomenclature	Manufacture
H221AVM	Horizon Gyroscope	Thales
H221AWM	Horizon Gyroscope	Thales
H221BDM	Horizon Gyroscope	Thalesa
H221BFM	Horizon Gyroscope	Thales
H221BLM	Horizon Gyroscope	Thales
H221BPM	Horizon Gyroscope	Horizon Gyroscope
H221EAM	Horizon Gyroscope	Horizon Gyroscope
H-3	Gyroscopic Horizon Ind	Sperry
H321AAM1	Gyroscopic Horizon Ind	Sfena
H321ABM1	Gyroscopic Horizon Ind	Sfena
H321ACM1	Gyroscopic Horizon Ind	Sfena
H321AFM1	Gyroscopic Horizon Ind	Sfena
H321AGM	Gyroscopic Horizon Ind	Sfena
H321AGM1	Gyroscopic Horizon Ind	Sfena
H321AKM1	Gyroscopic Horizon Ind	Sfena
H321ALM1	Gyroscopic Horizon Ind	Sfena

H321AMM1	Gyroscopic Horizon Ind	Sfena
H321ANM1	Gyroscopic Horizon Ind	Sfena
H321AQM1	Gyroscopic Horizon Ind	Sfena
H321ASM1	Gyroscopic Horizon Ind	Sfena
H321AYM1	Gyroscopic Horizon Ind	Sfena
H321AZM1	Gyroscopic Horizon Ind	Sfena
H321BAM1	Gyroscopic Horizon Ind	Sfena
H321BDM1	Gyroscopic Horizon Ind	Sfena
H321BEM2	Gyroscopic Horizon Ind	Sfena
H321BFM2	Gyroscopic Horizon Ind	Sfena
H321BGM	Gyroscopic Horizon Ind	Sfena
H321BGM1	Gyroscopic Horizon Ind	Sfena
H321BHM1	Gyroscopic Horizon Ind	Sfena
H321BHM2	Gyroscopic Horizon Ind	Sfena
H321BKM	Gyroscopic Horizon Ind	Thales
H321BNM	Gyroscopic Horizon Ind	Sfena
H321BTM	Gyroscopic Horizon Ind	Sfena
H321BVM	Gyroscopic Horizon Ind	Sfena
H321BVM1	Gyroscopic Horizon Ind	Sfena
H321BWM	Gyroscope Horizon	Thales
H321CBM	Gyroscopic Horizon Ind	Thales
H321CCM	Gyroscopic Horizon Ind	Thales
H321CEM	Gyroscopic Horizon Ind	Thales
H321CJM	Gyroscopic Horizon Ind	Thales
H321CMM	Gyroscopic Horizon Ind	Thales
H321CZM	Gyroscopic Horizon Ind	Thales
H321DAM	Gyroscopic Horizon Ind	Thales
H321DBM	Gyroscopic Horizon Ind	Thales

Primary Part Number	Nomenclature	Manufacture
H321EEM	Gyroscopic Horizon Ind	Thales
H321EFM	Gyroscopic Horizon Ind	Thales
H321EHM	Gyroscopic Horizon Ind	Thales
H321ERM	Gyroscopic Horizon Ind	Thales
H321FAM	Gyroscopic Horizon Ind	Thales
H321FBM	Gyroscopic Horizon Ind	Thales
H321FCM	Gyroscopic Horizon Ind	Thales
H341ADM1	Gyroscopic Horizon Ind	Sfena
H341ADM2	Gyroscopic Horizon Ind	Sfena
H341AGM	Gyroscopic Horizon Ind	Sfena
H341AGM1	Gyroscopic Horizon Ind	Sfena
H341AMM1	Gyroscopic Horizon Ind	Sfena
H341ANM1	Gyroscopic Horizon Ind	Sextant
H341ARM	Gyroscopic Horizon Ind	Sfena
H341AZM	Gyroscopic Horizon Ind	Sfena
H-5	Gyroscopic Horizon Ind	Sperry
H-5A	Gyroscopic Horizon Ind	Sperry
H-6A	Gyroscopic Horizon Ind	Sperry
H-6B	Gyroscopic Horizon Ind	Sperry
H901-254	Autotak Indiicator	Howell

H901-264	Autotak Indicator	Howell
H901-265	Autotak Indicator	Howell
HSD-830	Horizontal Situation Ind	Bendix
HSD-880	Horizontal Situation Ind	Bendix
HSI 610	Horizontal Situation Ind	AIM
HSI 610-1	Horizontal Situation Ind	AIM
HSI610	Horizontal Situation Ind	Aviation Instrument
HZ-3	Horizon Flt Director Ind	Sperry
IC709	Pitch Trim Amplifier	Electric Auto-Lite Co
ID-1351E/A	Radio Magnetic Indicator	BVR Inc.
ID-1760/APN-194(V)	Indicator	Honywell
ID-2178/ASQ	Bearing Distance Heading Ind	Astronautics
ID-2278A/A	Indicator	Astronautics
ID-250/ARN	Radio Magnetic Indicator	Aeronetics
ID-250A/ARN	Radio Magnetic Indicator	Borg
ID-387/ARN	Course Indicator	Pioneer
ID-389/ASN-6	Lat/Long Indicator	Ford
ID-663/U	Bearing Distance Heading Ind	John Oster
ID-998/ASN	Radio Magnetic Indicator	Sperry
IF-550A	Autopilot	Cessna
IN-380A	Course Indicator	Cessna
IN-380AC	Course Indicator	Cessna
IN-381A	Course Indicator	Cessna
IN-381AC	Course Indicator	Cessna

Primary Part Number	Nomenclature	Manufacture
IN-382AC	Course Indicator	Cessna
IN-383AC	Course Indicator	Cessna
IN-480AC	Course Indicator	Cessna
IN-481AC	Course Indicator	Cessna
IN-482AC	Course Indicator	Cessna
IN-483AC	Course Indicator	Cessna
IN-803A	Radio Magnetic Indicator	Cessna
IN-8130	Horizontal Situation Ind	Aeronetics
IN830A	Horizontal Situation Ind	AIM
IN-831A	Horizontal Situation Ind	Bendix
IN-881A	Horizontal Situation Ind	Bendix
IND-30	Indicator	Collins
IND-31	Indicator	Collins
IND-31C	Indicator	Collins
IND-350	Indicator	Collins
IND-350A	Indicator	Collins
IND-351	Indicator	Collins
IND-351A	Indicator	Collins
IND-351C	Indicator	Collins
IND-351D	Indicator	Collins
IND-42 ()	Indicator	Collins
IU265-006-4	Directional Gyroscope	Electric Auto-Lite Co
IU275-001	Turn and Bank Indicator	Electric Auto-Lite Co
IU295-A1	Directional Gyroscope	Electric Auto-Lite Co

IU367-004-4	Gyroscope	Electric Auto-Lite Co
IU367-006-2	Attitude Indicator	Electric Auto-Lite Co
IU367-201-1	Horizon Gyroscope	Electric Auto-Lite Co
IU376-002-2	Attitude Indicator	Electric Auto-Lite Co
IU407	Flight Director Indicator	Electric Auto-Lite Co
IU445	Horizontal Situation Ind	Electric Auto-Lite Co
J-1	Autopilot	Jack & Heintz
J-2	Compass Indicator	Sperry
J-2 SYSTEM	Magnetic Compass	Sperry
J-3	Gyroscope	Sperry
J-4	Compass Indicator	Eclipse Pioneer
J5BM1	Rate Gyroscope	Sextant
J5BM2	Rate Gyroscope	Sextant
J-8	Attitude Indicator	Eclipse Pioneer
JF7044A-55	Vertical Gyroscope	Honeywell
JF7044A-57	Vertical Gyroscope	Honeywell
JG1061AA01	Indicator	Honeywell
JG7044A1	Vertical Gyroscope	Honeywell
JG7044A16	Vertical Gyroscope	Honeywell
JG7044A17	Vertical Gyroscope	Honeywell
Primary Part Number	**Nomenclature**	**Manufacture**
JG7044A2	Vertical Gyroscope	Honeywell
JG7044A25	Vertical Gyroscope	Honeywell
JG7044A3	Vertical Gyroscope	Honeywell
JG7044A37	Vertical Gyroscope	Honeywell
JG7044A38	Vertical Gyroscope	Honeywell
JG7044A39	Vertical Gyroscope	Honeywell
JG7044A4	Vertical Gyroscope	Honeywell
JG7044A40	Vertical Gyroscope	Honeywell
JG7044A-40	Vertical Gyroscope	Honeywell
JG7044A45	Vertical Gyroscope	Honeywell
JG7044A55	Vertical Gyroscope	Honeywell
JG7044A-55	Vertical Gyroscope	Honeywell
JG7044A-57	Vertical Gyroscope	Honeywell
JG7044E	Yaw/Roll Gyro	Honeywell
JG7044F	Yaw/Roll Gyro	Honeywell
JG7044M	Yaw/Roll Gyro	Honeywell
JG7044N	Yaw/Roll Gyro	Honeywell
JH5500	Directional Gyroscope	Jack & Heintz
JH6500-A	Gyroscopic Horizon Ind	Jack & Heintz
K3385-02	Horizon Gyroscope	R C Allen
K3995-01	Horizon Gyroscope	R C Allen
K3995-02	Horizon Gyroscope	R C Allen
K3995-03	Horizon Gyroscope	R C Allen
K5048-01	Horizon Gyroscope	R C Allen
K5048-02	Horizon Gyroscope	R C Allen
K5048-03	Horizon Gyroscope	R C Allen
K5048-04	Horizon Gyroscope	R C Allen
K5750-01	Horizon Gyroscope	R C Allen

KA 117	Pitch Trim Adaptor	Bendix King
KA 120	DME/GS Converter	Bendix King
KA47	DME Code Converter	Bendix King
KA51A	Slaving Accessory	Bendix King
KA52	Autopilot Adapter	Bendix King
KA57	Autopilot Adapter	Bendix King
KAH-460	Gyroscope	Bendix King
KAP-150H	Helicopter Autopilot	Bendix King
KC 291	Yaw Controller	Bendix King
KC 295	Flight Controller	Bendix King
KC 296	Yaw Controller	Bendix King
KC295	Flight Controller	Bendix King
KC296	Flight Controller	Bendix King
KCA0101C	Standby Compass	Smith Industries
KCA0101W	Standby Compass	Smith Industries
KCA0102C	Standby Compass	Smith Industries

Primary Part Number	Nomenclature	Manufacture
KCA0102W	Standby Compass	Smith Industries
KCA0104W	Standby Compass	Smith Industries
KCA0106W	Standby Compass	Smith Industries
KCA010W	Standby Compass	Smith Industries
KCI 310A	Flight Command Indicator	Bendix King
KCS 305	Compass System	Bendix King
KCS 55	Pictorial Navigation System	Bendix King
KCS 55A	Pictorial Navigation System	Bendix King
KCS55	Pictorial Navigation Indicator	Bendix King
KCS55A	Pictorial Navigation Indicator	Bendix King
KCU561	Digital Control Unit	Bendix King
KCU565	Digital Control Unit	Bendix King
KCU565A	Digital Control Unit	Bendix King
KCU578	Digital Control Unit	Bendix King
KCU582	Digital Control Unit	Bendix King
KCU591	Digital Control Unit	Bendix King
KDD693	DME Range Converter	Bendix King
KDI571	DME Indicator	Bendix King
KDI572	DME Indicator	Bendix King
KDI573	DME Indicator	Bendix King
KDI574	DME Indicator	Bendix King
KDM700	DME Indicator	Bendix King
KDM700A	DME Indicator	Bendix King
KDM705	DME Indicator	Bendix King
KDM705A	DME Indicator	Bendix King
KDM706	DME Indicator	Bendix King
KDM706A	DME Indicator	Bendix King
KFC250	Flight Controller	Bendix King
KFC275	Flight Controller	Bendix King
KFC325	Flight Controller	Bendix King
KFC400	Flight Controller	Bendix King
KFS560	Navigation Control Unit	Bendix King

KG 102	Directional Gyroscope	Bendix King
KG 102A	Directional Gyroscope	Bendix King
KG 107	Gyroscope	Bendix King
KG 253	Horizon Gyroscope	Bendix King
KG 257	Gyroscope	Bendix King
KG 259	Horizon Gyroscope	Bendix King
KG102A	Directional Gyroscope	Bendix King
KG107	Directional Gyroscope	Bendix King
KG-253	Horizon Gyroscope	Bendix King
KG257	Gyroscope	Bendix King
KGS 100	Navigation System	Bendix King
KGS 305	Horizon Gyroscope	Bendix King

Primary Part Number	Nomenclature	Manufacture
KI 202	Navigation Indicator	Bendix King
KI 229	Radio Magnetic Indicator	Bendix King
KI 254	Gyroscope	Bendix King
KI 255	Flight Director Indicator	Bendix King
KI 256	Flight Command Indicator	Bendix King
KI 258	Horizon Gyroscope	Bendix King
KI 261	Distance Measuring Ind	Bendix King
KI 525A	Navigation Indicator	Bendix King
KI203	Navigation Indicator	Bendix King
KI204	Navigation Indicator	Bendix King
KI206	Navigation Indicator	Bendix King
KI207	Navigation Indicator	Bendix King
KI208	Navigation Indicator	Bendix King
KI226	Radio Magnetic Indicator	Bendix King
KI229	Radio Magnetic Indicator	Bendix King
KI256	Gyroscope	Bendix King
KI258	Horizon Gyroscope	Bendix King
KI525	Pictorial Navigation System	Bendix King
KI525A	Pictorial Navigation Indicator	Bendix King
KLN 900	GPS	Bendix King
KMT 110	Flux Detector	Bendix King
KMT112	Flux Detector	Bendix King
KN60	DME Indicator	Bendix King
KN60B	DME Indicator	Bendix King
KN60C	DME Indicator	Bendix King
KN61	Distance Measuring Ind	Bendix King
KN62	Distance Measuring Equiptment	Bendix King
KN62A	Distance Measuring Equiptment	Bendix King
KN64	Distance Measuring Equiptment	Bendix King
KN74	Area Navigation Computer	Bendix King
KNI 520	Navigation Indicator	Bendix King
KNI 521	Navigation Indicator	Bendix King
KNI 582	Radio Magnetic Indicator	Bendix King
KNI-510	Course Indicator	Bendix King
KNI581	Radio Magnetic Indicator	Bendix King
KNI582	Radio Magnetic Indicator	Bendix King

KNS80	Digital Area Nav System	Bendix King
KPI 550	Pictorial Navigation Indicator	Bendix King
KPI 550A	Pictorial Navigation Indicator	Bendix King
KPI 551	Pictorial Navigation Indicator	Bendix King
KPI 551A	Pictorial Navigation Indicator	Bendix King
KPI 552	Navigation Indicator	Bendix King
KPI 553	Pictorial Navigation Indicator	Bendix King
KPI 553A	Pictorial Navigation Indicator	Bendix King

Primary Part Number	Nomenclature	Manufacture
KPI 553B	Navigation Indicator	Bendix King
KPI-550A	Course Indicator	Bendix King
KPI-551	Navigation Indicator	Bendix King
KPI-551A	Navigation Indicator	Bendix King
KPI-553	Navigation Indicator	Bendix King
KPI-553B	Navigation Indicator	Bendix King
KRG 330	Rate Gyroscope	Bendix King
KRG 331	Rate Gyroscope	Bendix King
KRG 332	Rate Gyroscope	Bendix King
KRG-330	Rate Gyroscope	Bendix King
KRG-331	Rate Gyroscope	Bendix King
KSC305	Directional Gyroscope	Bendix King
KSG 105	Pictorial Navigation Indicator	Bendix King
KTS 152	Gyroscope	Bendix King
KVG 350	Vertical Gyroscope	Bendix King
L2	Autopilot	Lear Siegler
LT-3062A	Autopilot	Lear Siegler
LT-3086	Autopilot	Lear Siegler
LT4020	Attitude Heading Pressure Ref	Lear Siegler
LT5118-01-01	Gyroscope Test Set	Lear Siegler
M2A	Pathfinder	Astronautics
M3500-1	Turn and Slip Indicator	R C Allen
M3500-10	Turn and Slip Indicator	R C Allen
M3500-11	Turn and Slip Indicator	R C Allen
M3500-12	Turn and Slip Indicator	R C Allen
M3500-2	Turn and Slip Indicator	R C Allen
M3500-3	Turn and Slip Indicator	R C Allen
M3500-4	Turn and Slip Indicator	R C Allen
M3500-5	Turn and Slip Indicator	R C Allen
M3500-6	Turn and Slip Indicator	R C Allen
M3500-7	Turn and Slip Indicator	R C Allen
M3500-8	Turn and Slip Indicator	R C Allen
M3500-9	Turn and Slip Indicator	R C Allen
M3514-07	Turn and Slip Indicator	R C Allen
M3540-1	Turn and Slip Indicator	Kelly
M3540-3	Turn and Slip Indicator	R C Allen
M3540-4	Turn and Slip Indicator	R C Allen
M3540-5	Turn and Slip Indicator	R C Allen
M3540-6	Turn and Slip Indicator	R C Allen
M3540-7	Turn and Slip Indicator	R C Allen

M3562-01	Turn and Slip Indicator	Kelly
M3637	Turn and Slip Indicator	R C Allen
M5000-08	Turn and Slip Indicator	R C Allen
MA-1	Compass Controlled Directional	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
MC-1	Gyroscope	R C Allen
MD200-2xx series	Course Deviation Indicator	Mid Continent
MF-2	Attitude Indicator	Eclipse Pioneer
MIL-G-49266(CR)	Displacement Gyroscope	Military Specification
MIL-G-49267(CR)	Displacement Gyroscope	Military Specification
MIL-G-81620A	Gyroscope	Sperry
MM-1	Roll And Pitch Control	Eclipse Pioneer
MNI-300	Low Approach Indicator	Honeywell
MODEL 888	Glide Indicator	Weston
Model C-2	Gyrosyn Compass System	Sperry
Model C-2A	Gyrosyn Compass System	Sperry
Model RCA 10	Directional Gyroscope	Kelly
MS28024-3A	Mil Specs	AID
MS28041-1A	Turn and Slip Indicator	Military Specification
NSD-360	Navigation Situation Display	Century Flight System
NSD-360A	Navigation Situation Display	Century Flight System
P1	Pathfinder	Astronautics
P1-TC()	Turn Coordinator	Astronautics
P2	Pathfinder	Astronautics
P-2	Autopilot	Astronautics
P2A	Flight Controller	Astronautics
P2A-M2A	Autopilot	Astronautics
P3	Pathfinder	Astronautics
P3A	Pathfinder	Astronautics
P3A-M3A	Autopilot	Astronautics
P3B	Turn and Slip Indicator	Astronautics
P3B-M3B	Autopilot	Astronautics
P3-TC	Turn Coordinator	Astronautics
PB20N	Auto Flight Control System	Bendix
PN-101	Pictorial Navigation System	Collins
PS50030-3-5	Turn Coordinator	Mid Continent
RCA 26BK	Gyroscope	R C Allen
RCA 26C	Gyroscope	R C Allen
RCA 26CM	Gyroscope	R C Allen
RCA10	Directional Gyroscope	R C Allen
RCA10-1	Directional Gyroscope	R C Allen
RCA10-2	Directional Gyroscope	R C Allen
RCA10-3	Directional Gyroscope	R C Allen
RCA10-4	Directional Gyroscope	R C Allen
RCA10-J4980-01	Directional Gyroscope	Kelly
RCA11	Directional Gyroscope	R C Allen
RCA11A	Directional Gyroscope	R C Allen
RCA11A-1	Directional Gyroscope	R C Allen
RCA11A-10	Directional Gyroscope	R C Allen

Primary Part Number	Nomenclature	Manufacture
RCA11A-11	Directional Gyroscope	R C Allen
RCA11A-2	Directional Gyroscope	R C Allen
RCA11A-3	Directional Gyroscope	R C Allen
RCA11A-4	Directional Gyroscope	R C Allen
RCA11A-8	Directional Gyroscope	R C Allen
RCA11A-9	Directional Gyroscope	R C Allen
RCA11D-2	Directional Gyroscope	R C Allen
RCA11D-3	Directional Gyroscope	R C Allen
RCA11D-4	Directional Gyroscope	R C Allen
RCA11D-5	Directional Gyroscope	R C Allen
RCA12	Turn and Bank Indicator	R C Allen
RCA12F65	Directional Gyroscope	R C Allen
RCA12P61	Directional Gyroscope	R C Allen
RCA12P64	Directional Gyroscope	R C Allen
RCA12R22M	Directional Gyroscope	R C Allen
RCA12R65	Directional Gyroscope	R C Allen
RCA12W2	Directional Gyroscope	R C Allen
RCA15	Directional Gyroscope	R C Allen
RCA15A-1	Directional Gyroscope	R C Allen
RCA15AK	Directional Gyroscope	R C Allen
RCA15B-1	Directional Gyroscope	R C Allen
RCA15BK	Directional Gyroscope	R C Allen
RCA15BK-1	Directional Gyroscope	R C Allen
RCA15BK-2	Directional Gyroscope	R C Allen
RCA15C	Directional Gyroscope	R C Allen
RCA15CM	Directional Gyroscope	R C Allen
RCA15CM-1	Directional Gyroscope	R C Allen
RCA2	Turn and Bank Indicator	R C Allen
RCA20	Gyroscope	R C Allen
RCA21	Gyroscope	R C Allen
RCA21-12	Horizon Gyroscope	R C Allen
RCA21-13	Horizon Gyroscope	R C Allen
RCA21-14	Horizon Gyroscope	R C Allen
RCA21-15	Horizon Gyroscope	R C Allen
RCA21-16	Horizon Gyroscope	R C Allen
RCA21-17	Horizon Gyroscope	R C Allen
RCA21-21	Horizon Gyroscope	R C Allen
RCA21-22	Horizon Gyroscope	R C Allen
RCA21-23	Horizon Gyroscope	R C Allen
RCA21-24	Horizon Gyroscope	R C Allen
RCA22-1	Horizon Gyroscope	R C Allen
RCA22-10	Gyroscopic Horizon Ind	R C Allen
RCA22-11	Horizon Gyroscope	R C Allen
RCA22-12	Horizon Gyroscope	R C Allen

Primary Part Number	Nomenclature	Manufacture
RCA22-13	Horizon Gyroscope	R C Allen
RCA22-14	Horizon Gyroscope	R C Allen

RCA22-15	Horizon Gyroscope	R C Allen
RCA22-16	Horizon Gyroscope	R C Allen
RCA22-17	Horizon Gyroscope	R C Allen
RCA22-18	Horizon Gyroscope	R C Allen
RCA22-19	Horizon Gyroscope	R C Allen
RCA22-2	Horizon Gyroscope	R C Allen
RCA22-20	Horizon Gyroscope	R C Allen
RCA22-24	Horizon Gyroscope	R C Allen
RCA22-25	Gyroscopic Horizon Ind	R C Allen
RCA22-29	Gyroscopic Horizon Ind	R C Allen
RCA22-3	Horizon Gyroscope	R C Allen
RCA22-30	Gyroscopic Horizon Ind	R C Allen
RCA22-31	Gyroscopic Horizon Ind	R C Allen
RCA22-32	Gyroscopic Horizon Ind	R C Allen
RCA22-33	Gyroscopic Horizon Ind	R C Allen
RCA22-34	Gyroscopic Horizon Ind	R C Allen
RCA22-35	Gyroscopic Horizon Ind	R C Allen
RCA22-36	Gyroscopic Horizon Ind	R C Allen
RCA22-37	Gyroscopic Horizon Ind	R C Allen
RCA22-40	Horizon Gyroscope	R C Allen
RCA22-42	Horizon Gyroscope	R C Allen
RCA22-5	Gyroscopic Horizon Ind	R C Allen
RCA22-6	Horizon Gyroscope	R C Allen
RCA22-7	Horizon Gyroscope	R C Allen
RCA22-8	Gyroscopic Horizon Ind	R C Allen
RCA22-9	Horizon Gyroscope	R C Allen
RCA25	Gyroscope	R C Allen
RCA25A-1	Gyroscope	R C Allen
RCA25B-1	Gyroscope	R C Allen
RCA26	Gyroscope	R C Allen
RCA26AK-1	Attitude Gyroscope	R C Allen
RCA26AK-2	Attitude Gyroscope	R C Allen
RCA26AK-3	Attitude Gyroscope	R C Allen
RCA26AK-4	Attitude Gyroscope	R C Allen
RCA26AK-6	Attitude Gyroscope	R C Allen
RCA26BK-1	Attitude Gyroscope	R C Allen
RCA26BK-10	Attitude Gyroscope	R C Allen
RCA26BK-12	Attitude Gyroscope	R C Allen
RCA26BK-16	Attitude Gyroscope	R C Allen
RCA26BK-18	Attitude Gyroscope	R C Allen
RCA26BK-2	Attitude Gyroscope	R C Allen
RCA26BK-20	Attitude Gyroscope	R C Allen

Primary Part Number	Nomenclature	Manufacture
RCA26BK-21	Attitude Gyroscope	R C Allen
RCA26BK-3	Attitude Gyroscope	R C Allen
RCA26BK-31	Attitude Gyroscope	R C Allen
RCA26BK-34	Attitude Gyroscope	R C Allen
RCA26BK-4	Attitude Gyroscope	R C Allen
RCA26BK-6	Attitude Gyroscope	R C Allen

RCA26BK-7	Attitude Gyroscope	R C Allen
RCA26BK-8	Attitude Gyroscope	R C Allen
RCA26BK-9	Attitude Gyroscope	R C Allen
RCA26C-5	Attitude Gyroscope	R C Allen
RCA26C-7	Attitude Gyroscope	R C Allen
RCA26C-8	Attitude Gyroscope	R C Allen
RCA26C-9	Attitude Gyroscope	R C Allen
RCA26CM-1	Attitude Gyroscope	R C Allen
RCA26CM-2	Attitude Gyroscope	R C Allen
RCA26CM-3	Attitude Gyroscope	R C Allen
RCA26CM-4	Attitude Gyroscope	R C Allen
RCA26CM-5	Attitude Gyroscope	R C Allen
RCA26CM-6	Attitude Gyroscope	R C Allen
RCA28	Directional Gyroscope	R C Allen
RCA28F65	Directional Gyroscope	R C Allen
RCA28P61	Directional Gyroscope	R C Allen
RCA28P64	Directional Gyroscope	R C Allen
RCA28R22M	Directional Gyroscope	R C Allen
RCA28R65	Directional Gyroscope	R C Allen
RCA28W2	Directional Gyroscope	R C Allen
RCA2W	Turn and Bank Indicator	R C Allen
RCA56	Turn and Bank Indicator	R C Allen
RCA80-1	Turn and Bank Indicator	R C Allen
RCA80-2	Turn and Bank Indicator	R C Allen
RCA82A	Turn and Bank Indicator	R C Allen
RCA83A	Turn and Bank Indicator	R C Allen
RCA90-1	Gyroscope	R C Allen
RCA90-2	Rate Switching Gyroscope	R C Allen
RD-44	Radio Deviation Indicator	Sperry
RD-444	Radio Deviation Indicator	Sperry
RD-445	Radio Deviation Indicator	Sperry
RD-550	Horizontal Situation Ind	Honeywell
RD-550A	Horizontal Situation Ind	Honeywell
RD-550B	Horizontal Situation Ind	Honeywell
RD-550R	Horizontal Situation Ind	Honeywell
RG-122	Miniature Rate Gyro	Sperry
RH-600	Radio Heading	Sperry
RI-106	Horizontal Situation Ind	Sperry

Primary Part Number	Nomenclature	Manufacture
RI-206	Horizontal Situation Ind	Sperry
RMI-30	Radio Magnetic Indicator	Collins
RMI-36	Radio Magnetic Indicator	Collins
S-1	Directional Gyroscope	Sperry
S-2	Compass Indicator	Sperry
S231T110-6	Attitude Indicator	Sfena
S-3	Directional Gyro Control	Sperry
S-3A	Directional Gyro Control	Sperry
S-3B	Directional Gyro Control	Sperry
SBK16	Displacement Gyroscope	Bendix

SBK-16/A24G-42	Displacement Gyroscope	Bendix
SBU-21/A	Displacement Gyroscope	Lear Siegler
SBU-23/A	Displacement Gyroscope	Lear Siegler
SC-883A	Slaving Control	Bendix
SES-194	Sim Attitude Director Ind	Sperry
SG-100	Gyroscopic Compass System	IFR
SG-200T	Gyroscopic Compass System	IFR
SG-500	Gyroscopic Compass System	IFR
SG-500C	Slaved	IFR
SG-500P	Gyroscopic Compass System	IFR
SG-831A	Navigation Situation Display	Bendix King
SG-832B	Gyroscope	Bendix King
SHZ-212	Integrated Flight Control Sys	Sperry
SHZ-212-3	Integrated Flight Control Sys	Sperry
Sp-5400	Turn and Bank Indicator	Standard Precision
SP-7576	Directional Gyroscope	Standard Precision
SP-7577	Directional Gyroscope	Standard Precision
SP-7581	Gyroscope	Standard Precision
SP-7582	Gyroscope	Standard Precision
SP-7600	Directional Gyroscope	Standard Precision
SP-7700	Gyroscope	Standard Precision
SPZ-900	Flight Controller	Sperry
T-1	Artificial Horizon	TACTAIR
T-100812C	Amplifier	Sperry
T-2	Artificial Horizon	TACTAIR
T2106-1A-A	Vertical Gyroscope	Kearfott
T2106-1A-B	Vertical Gyroscope	Kearfott
T2107-1A-A	Vertical Gyroscope	Kearfott
T2108-1A-A	Vertical Gyroscope	Kearfott
T2108-1A-B	Vertical Gyroscope	Kearfott
T2108-2A-B	Vertical Gyroscope	Kearfott
T-3	Artificial Horizon	TACTAIR
T307950	Rate Gyroscope	Sperry
T321638	Vertical Gyroscope	Sperry

Primary Part Number	Nomenclature	Manufacture
T321787	Vertical Gyroscope	Sperry
T3837-02	Rate Switching Gyro	R C Allen
T4040-2	Rate Switching Gyro	R C Allen
T4040-3	Switching Rate Gyroscope	R C Allen
T5800-01	Rate Switching Gyroscope	R C Allen
T5800-02	Rate Switching Gyroscope	R C Allen
T8605-11N	Azimuth Range Indicator	Kearfott
T8605-22N	Azimuth Range Indicator	Kearfott
T-95100	Gyroscopic Horizon Ind	Sperry
T-95450	Gyroscopic Horizon Ind	Sperry
T-95590	Gyroscopic Horizon Ind	Sperry
T-95640	Gyroscopic Horizon Ind	Sperry
TC100 GYRO	Turn Coordinator	Brittian
TC100(12)	Turn Coordinator	Brittian

TC100(24)	Turn Coordinator	Brittian
TC-120	Turn Coordinator	AIM
TC-120 Series	Turn Coordinator	AIM
TC-M()	Turn Coordinator	Astronautics
TRU-2A/2	Gyroscope	Honeywell
TRU-2A/A	Rate Gyroscope	R C Allen
TS 200-2	Turn and Slip Indicator	AIM
TS 200-3B	Turn and Slip Indicator	AIM
TS200-2	Turn and Slip Indicator	AIM
TS200-2A	Turn and Slip Indicator	AIM
TS200-2B	Turn and Slip Indicator	AIM
TS200-3	Turn and Slip Indicator	AIM
TS200-3A	Turn and Slip Indicator	AIM
TS200-3B	Turn and Slip Indicator	AIM
TS200-4	Turn and Slip Indicator	AIM
TS300	Turn and Slip Indicator	AIM
TS300 Series	Turn and Slip Indicator	AIM
TS300-1	Turn and Slip Indicator	AIM
TS300-1A	Turn and Slip Indicator	AIM
TS300-2	Turn and Slip Indicator	AIM
TS300-2A	Turn and Slip Indicator	AIM
TS300-2B	Turn and Slip Indicator	AIM
Type A-2	Compass Amplifier	Sperry
Type A-3	Autopilot	Sperry
Type C-12	Gyroscopic Compass System	Sperry
Type N-1	Directional Gyroscope System	Kearfott
VG-14A	Vertical Gyroscope	Honeywell
VG-203D	Vertical Gyroscope	Sperry
VG-203M	Vertical Gyroscope	Sperry
VG-204	Vertical Gyroscope	JET

Primary Part Number	Nomenclature	Manufacture
VG-204AA	Displacement Gyroscope	JET
VG-204AB	Displacement Gyroscope	JET
VG-204AC	Displacement Gyroscope	JET
VG-204L	Displacement Gyroscope	JET
VG-204V	Displacement Gyroscope	JET
VG-204Z	Displacement Gyroscope	JET
VG-206D	Gyroscope	L3 Communications
VG-208	Displacement Gyroscope	JET
VG-301	Vertical Indicator	JET
VIR-432	Navigation Receiver	Collins
VN-202	Vertisyn	JET
VNS 41A	Navigation System	Bendix King
X740723-1	Gyroscopic Horizon Ind	Eclipse Pioneer
XE768416-1	Turn/Pitch Controller	Eclipse Pioneer
1356-512457	Accumulator Assembly	Parker Hannifin
1356-512465	Accumulator Assembly	Parker Hannifin
1356-512471	Accumulator Assembly	Parker Hannifin
1356-512473	Accumulator Assembly	Parker Hannifin

1356-512475	Accumulator Assembly	Parker Hannifin
1356-542107	Accumulator Assembly	Parker Hannifin
1356-542838	Accumulator Assembly	Parker Hannifin
1356-542839	Accumulator Assembly	Parker Hannifin
1356-542897	Accumulator Assembly	Parker Hannifin
1356-542899	Accumulator Assembly	Parker Hannifin
1356-542901	Accumulator Assembly	Parker Hannifin
1356-542903	Accumulator Assembly	Parker Hannifin
1356-542905	Accumulator Assembly	Parker Hannifin
1356-552235	Accumulator Assembly	Parker Hannifin
1356-552237	Accumulator Assembly	Parker Hannifin
215-009-001	Hydraulic Break Indicator	Parker
010-906-001	Fuel Quantity Tank Unit	Gull
014-901-001	Fuel Quantity Tank Unit	Gull
014-901-002	Fuel Quantity Tank Unit	Gull
014-901-004	Fuel Quantity Tank Unit	Gull
014-901-008	Fuel Quantity Tank Unit	Gull
014-901-010	Fuel Quantity Tank Unit	Gull
014-901-012	Fuel Quantity Tank Unit	Gull
014-901-013	Fuel Quantity Tank Unit	Gull
014-901-015	Fuel Quantity Tank Unit	Gull
014-901-016	Fuel Quantity Tank Unit	Gull
014-901-017	Fuel Quantity Tank Unit	Gull
014-922-001	Fuel Quantity Tank Unit	Gull
014-922-002	Fuel Quantity Tank Unit	Gull
014-922-003	Fuel Quantity Tank Unit	Gull

Primary Part Number	Nomenclature	Manufacture
014-922-004	Fuel Quantity Tank Unit	Gull
014-922-005	Fuel Quantity Tank Unit	Gull
014-922-006	Fuel Quantity Tank Unit	Gull
014-922-007	Fuel Quantity Tank Unit	Gull
014-923-001	Fuel Quantity Tank Unit	Gull
014-923-002	Fuel Quantity Tank Unit	Gull
014-924-002	Fuel Quantity Tank Unit	Gull
014-924-004	Fuel Quantity Tank Unit	Gull
014-924-005	Fuel Quantity Tank Unit	Gull
014-939-001	Fuel Quantity Tank Unit	Gull
0201KTU10	Fuel Quantity Tank Unit	Smith Industries
0201KTU11	Fuel Quantity Tank Unit	Smith Industries
0201KTU12	Fuel Quantity Tank Unit	Smith Industries
0201KTU13	Fuel Quantity Tank Unit	Smith Industries
0201KTU14	Fuel Quantity Tank Unit	Smith Industries
0201KTU15	Fuel Quantity Tank Unit	Smith Industries
0201KTU16	Fuel Quantity Tank Unit	Smith Industries
0201KTU17	Fuel Quantity Tank Unit	Smith Industries
0201KTU18	Fuel Quantity Tank Unit	Smith Industries
0201KTU19	Fuel Quantity Tank Unit	Smith Industries
0201KTU20	Fuel Quantity Tank Unit	Smith Industries
0201KTU21	Fuel Quantity Tank Unit	Smith Industries

0201KTU22	Fuel Quantity Tank Unit	Smith Industries
0201KTU23	Fuel Quantity Tank Unit	Smith Industries
0201KTU24	Fuel Quantity Tank Unit	Smith Industries
0201KTU25	Fuel Quantity Tank Unit	Smith Industries
0201KTU29	Fuel Quantity Tank Unit	Smith Industries
0201KTU3	Fuel Quantity Tank Unit	Smith Industries
0201KTU30	Fuel Quantity Tank Unit	Smith Industries
0201KTU31	Fuel Quantity Tank Unit	Smith Industries
0201KTU32	Fuel Quantity Tank Unit	Smith Industries
0201KTU33	Fuel Quantity Tank Unit	Smith Industries
0201KTU34	Fuel Quantity Tank Unit	Smith Industries
0201KTU35	Fuel Quantity Tank Unit	Smith Industries
0201KTU4	Fuel Quantity Tank Unit	Smith Industries
0201KTU5	Fuel Quantity Tank Unit	Smith Industries
0201KTU6	Fuel Quantity Tank Unit	Smith Industries
0201KTU7	Fuel Quantity Tank Unit	Smith Industries
0201KTU8	Fuel Quantity Tank Unit	Smith Industries
0201KTU9	Fuel Quantity Tank Unit	Smith Industries
0204KID-01	Fuel Quantity Indicator	Smith Industries
0204KID-02	Fuel Quantity Indicator	Smith Industries
0205KID-01	Fuel Quantity Indicator	Smith Industries
0205KID-02	Fuel Quantity Indicator	Smith Industries

Primary Part Number	Nomenclature	Manufacture
0206KID-01	Fuel Quantity Indicator	Smith Industries
0206KID-02	Fuel Quantity Indicator	Smith Industries
020-904-003	Fuel Quantity Tank Unit	Gull
020-904-004	Fuel Quantity Tank Unit	Gull
020-917-001	Fuel Quantity Tank Unit	Gull
020-917-002	Fuel Quantity Tank Unit	Gull
020-917-003	Fuel Quantity Tank Unit	Gull
020-917-004	Fuel Quantity Tank Unit	Gull
020-917-005	Fuel Quantity Tank Unit	Gull
020-917-006	Fuel Quantity Tank Unit	Gull
020-924-002	FUEL QTY. TANK UNIT	GULL
020-924-003	FUEL QTY. TANK UNIT	GULL
020-924-004	FUEL QTY. TANK UNIT	Gull
021-031-001	Fuel Quantity Tank Unit	Gull Airborne
028-025-001	Fuel Quantity Indicator	Gull
066-1070-00	Distance Measuring System	Honeywell
066-1070-01	Distance Measuring System	Honeywell
100030	Fuel Quantity Tank Unit	Consolidated Airborn
10031-0000-01	Indicator	BF Goodrich
10037-1000-0151	Fuel Quantity Indicator	BF Goodrich
10037-1000-0152	Fuel Quantity Indicator	BF Goodrich
10037-1000-0153	Fuel Quantity Indicator	BF Goodrich
10037-1000-0154	Fuel Quantity Indicator	BF Goodrich
10037-1000-0155	Fuel Quantity Indicator	BF Goodrich
10037-1000-0156	Fuel Quantity Indicator	BF Goodrich
10037-1000-0157	Fuel Quantity Indicator	BF Goodrich

10037-1000-0158	Fuel Quantity Indicator	BF Goodrich
10037-1000-0159	Fuel Quantity Indicator	BF Goodrich
10037-1000-0160	Fuel Quantity Indicator	BF Goodrich
10037-1000-0161	Fuel Quantity Indicator	BF Goodrich
10037-1000-0162	Fuel Quantity Indicator	BF Goodrich
10037-1000-0163	Fuel Quantity Indicator	BF Goodrich
10037-1000-0164	Fuel Quantity Indicator	BF Goodrich
10037-1000-0165	Fuel Quantity Indicator	BF Goodrich
10037-1000-0166	Fuel Quantity Indicator	BF Goodrich
100-380006-101	Fuel Quantity Tank Unit	Gull
100-380006-11	Fuel Quantity Tank Unit	Beechcraft
100-380006-13	Fuel Quantity Tank Unit	Gull
100-380006-181	Fuel Quantity Tank Unit	Gull
100-380006-35	Fuel Quantity Tank Unit	Gull
100-380006-37	Fuel Quantity Tank Unit	Gull
100-380006-41	Fuel Quantity Tank Unit	Gull
100-380006-43	Fuel Quantity Tank Unit	Gull
100-380006-49	Fuel Quantity Tank Unit	Gull

Primary Part Number	Nomenclature	Manufacture
100-380006-55	Fuel Quantity Tank Unit	Gull
100-380006-57	Fuel Quantity Tank Unit	Gull
100-380006-67	Fuel Quantity Tank Unit	Gull
100-380006-69	Fuel Quantity Tank Unit	Gull
100-380006-7	Fuel Quantity Tank Unit	Gull
100-380006-71	Fuel Quantity Tank Unit	Gull
100-380006-73	Fuel Quantity Tank Unit	Gull
100-380006-75	Fuel Quantity Tank Unit	Gull
100-380006-77	Fuel Quantity Tank Unit	Gull
100-380006-79	Fuel Quantity Tank Unit	Gull
100-380006-81	Fuel Quantity Tank Unit	Gull
100-380006-83	Fuel Quantity Tank Unit	Gull
100-380006-85	Fuel Quantity Tank Unit	Gull
100-380006-97	Fuel Quantity Tank Unit	Gull
10038-3000-0101	Fuel Quantity Totalizer	Simmonds
10040-5000-0101	Indicator	Simmonds
100-476845-001	Fuel Quantity Indicator	Canadian Marconi
10051-000-01	Indicator	BF Goodrich
10066-0000-01	LIQUID QUANTITY INDICATOR	BFGoodrich
101-384189-3	Fuel Quantity Indicator	Gull
10150-1-A	Densiometer Indicator	Pioneer
104-389001-11	Fuel Quantity Indicator	Gull
10-60520-37	Liquid Quantity	Goodrich
10-60520-43	Liquid Quantity	Goodrich
10-60722-11	Transmitter	BF Goodrich
10-60722-13	Indicator	BF Goodrich
10-60722-8	Indicator	BF Goodrich
10-61219-1	Liquid Quantity	Goodrich
10-61219-112	Fuel Quantity Indicator	Ametek/GE
10-61219-114	Liquid Quantity	Goodrich

10-61219-201	Liquid Quantity	Goodrich
10-61219-314	Liquid Quantity	Goodrich
111482	Fuel Quantity Indicator	Weston
114.063	Fuel Quantity Indicator	Kratos
114.063-1	Fuel Quantity Indicator	Kratos
114-380034-9	Fuel Quantity Indicator	Gull
114-389001-9	Fuel Quantity Tank Unit	Gull
115.080-3	Hydraulic Quantity Indicator	Kratos
115.095	Hydraulic Reservoir Ind	Kratos
1160-8	Liquid Qxygen Qty Indicator	Penn Airborne
1353-1B-168-A	Liquid Quantity Transmitter	Eclipse Pioneer
1353-1B-A	Liquid Quantity Transmitter	Eclipse Pioneer
1353-6E-A	Liquid Quantity Transmitter	Eclipse Pioneer
1353A	Liquid Quantity Transmitter	Pioneer
Primary Part Number	**Nomenclature**	**Manufacture**
1354A	Liquid Quantity Transmitter	Pioneer
1355-4C-A	Liquid Quantity Transmitter	Eclipse Pioneer
1355-6J-A	Liquid Quantity Transmitter	Eclipse Pioneer
1355A	Liquid Quantity Transmitter	Pioneer
1356-2C-90-A	Liquid Quantity Transmitter	Eclipse Pioneer
1356A	Liquid Quantity Transmitter	Pioneer
1616-013-71	Fuel Qty Ind. Simulator	Avien
1616-018-95	Fuel Qty Ind. Simulator	Avien
1616-022-100	Fuel Qty Ind. Simulator	Avien
1616-022-129	Fuel Qty Ind. Simulator	Avien
1616-04-113	Fuel Qty Ind. Simulator	Avien
1616-04-67	Fuel Qty Ind. Simulator	Avien
1616-05-68	Fuel Qty Ind. Simulator	Avien
162-012-434	Fuel Quantity Indicator	Avien
162-015-121	Fuel Quantity Indicator	Avien
162-015-263	Fuel Quantity Indicator	Avien
162-015-264	Fuel Quantity Indicator	Avien
162-024-200	Fuel Quantity Indicator	Avien
162-024-201	Fuel Quantity Indicator	Avien
162-024-202	Fuel Quantity Indicator	Avien
162-024-203	Fuel Quantity Indicator	Avien
162-024-204	Fuel Quantity Indicator	Avien
162-035-243	Fuel Quantity Indicator	Avien
162-039-126	Fuel Quantity Indicator	Avien
162-039-127	Fuel Quantity Indicator	Avien
162-039-128	Fuel Quantity Indicator	Avien
162-040-250	Fuel Quantity Indicator	Avien
162-040-251	Fuel Quantity Indicator	Avien
162-040-253	Fuel Quantity Indicator	Avien
162-043-157	Fuel Quantity Indicator	Avien
162-043-158	Fuel Quantity Indicator	Avien
162-043-159	Fuel Quantity Indicator	Avien
162-043-160	Fuel Quantity Indicator	Avien
162-043-161	Fuel Quantity Indicator	Avien

162-044-156	Fuel Quantity Indicator	Avien
162-050-272	Fuel Quantity Indicator	Avien
162-066-265	Fuel Quantity Indicator	Avien
162-079-496	Fuel Quantity Indicator	Avien
162-084-249	Fuel Quantity Indicator	Avien
162-09-120	Fuel Quantity Indicator	Avien
162-09-124	Fuel Quantity Indicator	Avien
162-09-125	Fuel Quantity Indicator	Avien
162-09-140	Fuel Quantity Indicator	Avien
162-09-144	Fuel Quantity Indicator	Avien

Primary Part Number	Nomenclature	Manufacture
162-09-145	Fuel Quantity Indicator	Avien
162-09-146	Fuel Quantity Indicator	Avien
162-09-147	Fuel Quantity Indicator	Avien
162-09-148	Fuel Quantity Indicator	Avien
162-09-149	Fuel Quantity Indicator	Avien
162-09-162	Fuel Quantity Indicator	Avien
162-09-169	Fuel Quantity Indicator	Avien
162-09-17	Fuel Quantity Indicator	Avien
162-09-170	Fuel Quantity Indicator	Avien
162-09-221	Fuel Quantity Indicator	Avien
162-09-225	Fuel Quantity Indicator	Avien
162-09-810	Fuel Quantity Indicator	Avien
162-09-99	Fuel Quantity Indicator	Avien
164-010	Fuel Quantity Amplifier	Avien
164-010-2	Fuel Quantity Amplifier	Avien
164-010-3	Fuel Quantity Amplifier	Avien
164-010B	Fuel Quantity Amplifier	Avien
164-010C	Fuel Quantity Amplifier	Avien
164-012	Fuel Quantity Amplifier	Avien
164-012B	Fuel Quantity Amplifier	Avien
164-012C	Fuel Quantity Amplifier	Avien
164-035	Fuel Quantity Amplifier	Avien
164-035C	Fuel Quantity Amplifier	Avien
164-035E	Fuel Quantity Amplifier	Avien
164-035I	Fuel Quantity Amplifier	Avien
164-1	Liquid Qxygen Qty Indicator	Penn Airborne
165-010-192	Fuel Quantity Tank Unit	Avien
165-012-252	Fuel Quantity Tank Unit	Avien
165-012-255	Fuel Quantity Tank Unit	Avien
165-012-331	Fuel Quantity Tank Unit	Avien
165-013-253	Fuel Quantity Tank Unit	Avien
165-013-254	Fuel Quantity Tank Unit	Avien
165-013-256	Fuel Quantity Tank Unit	Avien
165-013-332	Fuel Quantity Tank Unit	Avien
165-022-1160	Fuel Quantity Tank Unit	Avien
165-022-222	Fuel Quantity Tank Unit	Avien
165-022-228	Fuel Quantity Tank Unit	Avien
165-022-318	Fuel Quantity Tank Unit	Avien

165-022-320	Fuel Quantity Tank Unit	Avien
165-022-429	Fuel Quantity Tank Unit	Avien
165-022-431	Fuel Quantity Tank Unit	Avien
165-022-432	Fuel Quantity Tank Unit	Avien
165-023-1161	Fuel Quantity Tank Unit	Avien
165-023-223	Fuel Quantity Tank Unit	Avien

Primary Part Number	Nomenclature	Manufacture
165-023-224	Fuel Quantity Tank Unit	Avien
165-023-225	Fuel Quantity Tank Unit	Avien
165-023-226	Fuel Quantity Tank Unit	Avien
165-023-315	Fuel Quantity Tank Unit	Avien
165-023-317	Fuel Quantity Tank Unit	Avien
165-023-319	Fuel Quantity Tank Unit	Avien
165-040-436	Fuel Quantity Tank Unit	Avien
165-040-438	Fuel Quantity Tank Unit	Avien
165-040-442	Fuel Quantity Tank Unit	Avien
165-040-444	Fuel Quantity Tank Unit	Avien
165-040-446	Fuel Quantity Tank Unit	Avien
165-045-324	Fuel Quantity Tank Unit	Avien
165-045-480	Fuel Quantity Tank Unit	Avien
165-045-482	Fuel Quantity Tank Unit	Avien
165-045-484	Fuel Quantity Tank Unit	Avien
165-045-645	Fuel Quantity Tank Unit	Avien
165-045-647	Fuel Quantity Tank Unit	Avien
165-045-651	Fuel Quantity Tank Unit	Avien
165-045-859	Fuel Quantity Tank Unit	Avien
165-046-323	Fuel Quantity Tank Unit	Avien
165-046-462	Fuel Quantity Tank Unit	Avien
165-046-481	Fuel Quantity Tank Unit	Avien
165-046-483	Fuel Quantity Tank Unit	Avien
165-046-485	Fuel Quantity Tank Unit	Avien
165-046-648	Fuel Quantity Tank Unit	Avien
165-046-649	Fuel Quantity Tank Unit	Avien
165-046-650	Fuel Quantity Tank Unit	Avien
165-051-179	Fuel Quantity Tank Unit	Avien
165-051-181	Fuel Quantity Tank Unit	Avien
165-051-182	Fuel Quantity Tank Unit	Avien
165-051-183	Fuel Quantity Tank Unit	Avien
165-051-184	Fuel Quantity Tank Unit	Avien
165-051-186	Fuel Quantity Tank Unit	Avien
165-051-321	Fuel Quantity Tank Unit	Avien
165-051-322	Fuel Quantity Tank Unit	Avien
165-052-180	Fuel Quantity Tank Unit	Avien
165-052-185	Fuel Quantity Tank Unit	Avien
165-059-456	Fuel Quantity Tank Unit	Avien
165-059-457	Fuel Quantity Tank Unit	Avien
165-059-458	Fuel Quantity Tank Unit	Avien
165-059-991	Fuel Quantity Tank Unit	Avien
165-059-992	Fuel Quantity Tank Unit	Avien

165-060-460	Fuel Quantity Tank Unit	Avien
165-063-459	Fuel Quantity Tank Unit	Avien

Primary Part Number	Nomenclature	Manufacture
165-075-707	Fuel Quantity Tank Unit	Avien
165-075-708	Fuel Quantity Tank Unit	Avien
165-075-711	Fuel Quantity Tank Unit	Avien
165-075-712	Fuel Quantity Tank Unit	Avien
165-075-719	Fuel Quantity Tank Unit	Avien
165-076-709	Fuel Quantity Tank Unit	Avien
165-076-714	Fuel Quantity Tank Unit	Avien
165-076-715	Fuel Quantity Tank Unit	Avien
165-076-721	Fuel Quantity Tank Unit	Avien
165-076-723	Fuel Quantity Tank Unit	Avien
165-076-725	Fuel Quantity Tank Unit	Avien
165-088-621	Fuel Quantity Tank Unit	Avien
165-089-629	Fuel Quantity Tank Unit	Avien
165-089-631	Fuel Quantity Tank Unit	Avien
166-01-11	Fuel Quantity Indicator	Avien
166-02	Fuel Quantity Indicator	Avien
169AB-910-27	Fuel Quantity Indicator	Sigma Tek
169AC-910-6L	Fuel Quantity Indicator	Sigma Tek
169AC-910-6L-1	Fuel Quantity Indicator	Sigma Tek
169AE-910-42L	Fuel Quantity Indicator	Sigma Tek
169AM-910-3	Fuel Quantity Indicator	Sigma Tek
169AM-910-4	Fuel Quantity Indicator	Sigma Tek
169AR-910-20	Fuel Quantity Indicator	Sigma Tek
169AR-910-21	Fuel Quantity Indicator	Sigma Tek
169B-910-23L	Fuel Quantity Indicator	Sigma Tek
169B-910-6L	Fuel Quantity Indicator	Sigma Tek
169C-910-10	Fuel Quantity Indicator	Sigma Tek
169C-910-10L	Fuel Quantity Indicator	Sigma Tek
169C-910-28L	Fuel Quantity Indicator	Sigma Tek
169C-910-28L-1	Fuel Quantity Indicator	Sigma Tek
169C-910-9	Fuel Quantity Indicator	Sigma Tek
169C-910-9L	Fuel Quantity Indicator	Sigma Tek
169D-910-10	Fuel Quantity Indicator	Sigma Tek
169D-910-10L	Fuel Quantity Indicator	Sigma Tek
169D-910-9	Fuel Quantity Indicator	Sigma Tek
169D-910-9L	Fuel Quantity Indicator	Sigma Tek
169P-910-22L	Fuel Quantity Indicator	Sigma Tek
169P-910-22L1	Fuel Quantity Indicator	Sigma Tek
169Q-910-20	Fuel Quantity Indicator	Sigma Tek
169Q-910-21	Fuel Quantity Indicator	Sigma Tek
19B434	Fuel Quantity Indicator	AID
200-003-001	Fuel Quantity Indicator	Gull
200-003-002	Fuel Quantity Indicator	Gull
200-007-005	Hydraulic Fluid Qty. Ind.	Gull

Primary Part Number	Nomenclature	Manufacture

200-007-005-1	Hydraulic Fluid Qty. Ind.	Gull
200-007-006	Hydraulic Fluid Qty. Ind.	Gull
200-007-007	Hydraulic Fluid Qty. Ind.	Gull
200-007-008	Hydraulic Fluid Qty. Ind.	Gull
200-007-009	Hydraulic Fluid Qty. Ind.	Gull
200-007-010	Hydraulic Fluid Qty. Ind.	Gull
200-020-001	Fuel Quantity Indicator	Gull
200-037-002A	Fuel Quantity Indicator	Gull
200-037-005	Fuel Quantity Indicator	Gull
200-060-001	Fuel Quantity Indicator	Gull
200-078-001	Fuel Quantity Indicator	Gull
200-099-001	Hydraulic Quantity Indicator	Gull
200-099-002	Hydraulic Quantity Indicator	Gull
200-099-003	Hydraulic Quantity Indicator	Gull
200-099-004	Hydraulic Quantity Indicator	Gull
200-099-005	Hydraulic Quantity Indicator	Gull
200-099-006	Hydraulic Quantity Indicator	Gull
20025-0000-0101	Fuel Quantity Tank Unit	Simmonds
20025-0000-0102	Fuel Quantity Tank Unit	Simmonds
20025-0000-0103	Fuel Quantity Tank Unit	Simmonds
20025-0000-0104	Fuel Quantity Tank Unit	Simmonds
20025-0000-0105	Fuel Quantity Tank Unit	Simmonds
20025-0000-0106	Fuel Quantity Tank Unit	Simmonds
200-913-001	Fuel Quantity Indicator	Gull
200-913T01	Fuel Quantity Indicator	Gull
200-914-001	Fuel Quantity Indicator	Gull
202-001-001	Fuel Quantity Indicator	Gull
202-001T01	Fuel Quantity Indicator	Gull
203-003-001	Fuel Quantity Indicator	Gull
203-003-002	Fuel Quantity Indicator	Gull
203-021-003	Fuel Quantity Indicator	Gull
203-021-003M	Fuel Quantity Indicator	Gull
203-021T03	Fuel Quantity Indicator	Gull
204-013-004	Fuel Quantity Indicator	Gull
205-002-001	Fuel Totalizer	Gull
205-002-002	Fuel Quantity Totalizer	Gull
205-019-001	Fuel Quantity Totalizer	Gull
206-001-001	Fuel Quantity Indicator	Gull
206-001-001R	Fuel Quantity Indicator	Gull
206-001-001W	Fuel Quantity Indicator	Gull
206-001-002	Fuel Quantity Indicator	Gull
206-001-002R	Fuel Quantity Indicator	Gull
206-001-002W	Fuel Quantity Indicator	Gull
206-001-003	Fuel Quantity Indicator	Gull

Primary Part Number	Nomenclature	Manufacture
206-001-003R	Fuel Quantity Indicator	Gull
206-001-003W	Fuel Quantity Indicator	Gull
206-001-004	Fuel Quantity Indicator	Gull
206-001-004R	Fuel Quantity Indicator	Gull

206-001-004W	Fuel Quantity Indicator	Gull
206-075-189-1	Fuel Quantity Indicator	Insco
211-009-005	Pylon Refuel Indicator	Gull
21585	Fuel Tank Valve Ind	Airtron
217-003-001	Fuel Quantity Indicator	Gull
217-003-002	Fuel Quantity Indicator	Gull
217-003-003	Fuel Quantity Indicator	Gull
217-003-009	Fuel Quantity Indicator	Gull
217-003-011	Fuel Quantity Indicator	Gull
217-003-012	Fuel Quantity Indicator	Gull
217-003-016	Fuel Quantity Indicator	Gull
217-003-103	Fuel Quantity Indicator	Gull
217-003-103M	Fuel Quantity Indicator	Gull
217-003-109	Fuel Quantity Indicator	Gull
217-003-109M	Fuel Quantity Indicator	Gull
217-003-111	Fuel Quantity Indicator	Gull
217-003-111M	Fuel Quantity Indicator	Gull
217-003-112	Fuel Quantity Indicator	Gull
217-003-112M	Fuel Quantity Indicator	Gull
217-003-116	Fuel Quantity Indicator	Gull
217-003-116M	Fuel Quantity Indicator	Gull
218-912-001	Fuel Quantity Indicator	Gull
219-003-001	Fuel Quantity Indicator	Gull
219-003-002	Fuel Quantity Indicator	Gull
219-003-003	Fuel Quantity Indicator	Gull
22001-2-C1-3	MAG.SKYDROL TRNSM.	Eclipse Pioneer
22-162-011A	Fuel Quantity Indicator	Garwin
22-164-012	Fuel Quantity Indicator	AID
22-164-044	Fuel Quantity Indicator	AID
224-08-20	Fuel Quantity Amplifier	Avien
2307-02-01	Fuel Quantity Indicator	Ametek/GE
2307-04-01	Fuel Quantity Indicator	Ametek/GE
2307-04-02	Fuel Quantity Indicator	Smith Industries
2307-04-03	Fuel Quantity Indicator	Smith Industries
2307-06-01	Fuel Quantity Indicator	Smith Industries
2307-06-02	Fuel Quantity Indicator	Smith Industries
2307-06-03	Fuel Quantity Indicator	Smith Industries
2307-07-01	Fuel Quantity Indicator	Smith Industries
2307-07-02	Fuel Quantity Indicator	Smith Industries
2307-07-03	Fuel Quantity Indicator	Smith Industries
Primary Part Number	**Nomenclature**	**Manufacture**
2307-08-01	Fuel Quantity Indicator	Smith Industries
2307-08-02	Fuel Quantity Indicator	Smith Industries
2307-08-03	Fuel Quantity Indicator	Smith Industries
2307-09-01	Fuel Quantity Indicator	Smith Industries
2307-09-02	Fuel Quantity Indicator	Smith Industries
2307-09-03	Fuel Quantity Indicator	Smith Industries
2307-10-01	Fuel Quantity Indicator	Smith Industries
2307-10-02	Fuel Quantity Indicator	Smith Industries

2307-10-03	Fuel Quantity Indicator	Smith Industries
2426-55A-A2	Liquid Qxygen Qty Indicator	Pioneer
2426-55B-A2	Liquid Qxygen Qty Indicator	Pioneer
2426-55B-B2	Liquid Qxygen Qty Indicator	Pioneer
2426-56A-B3	Liquid Qxygen Qty Indicator	Pioneer
2426-56B-A3	Liquid Qxygen Qty Indicator	Pioneer
253685	Quantity Indicator	Weston
267-901-001	Fuel Quantity Indicator	Gull
267-901-003	Fuel Quantity Indicator	Gull
267-901-004	Fuel Quantity Indicator	Gull
267-925-001	Fuel Quantity Indicator	Gull
267-935-001	Fuel Quantity Indicator	Gull
267-959-000	Fuel Quantity Indicator	Gull
267-959-001	Fuel Quantity Indicator	Gull
267-959-002	Fuel Quantity Indicator	Gull
267-959-003	Fuel Quantity Indicator	Gull
267-966-004	Oil Quantity Indicator	Gull
27-19144-5	Water Injection Indicator	Hickok
27-19144-7	Water Injection Indicator	Hickok
276-968-004	Oil Quantity Indicator	Gull
302-902-004	Indicator	Gull
302-904-001	Fuel Quantity Indicator	Gull
308-002-001	Fuel Quantity Indicator	Gull
308-002-002	Fuel Quantity Indicator	Gull
308-003-003	Fuel Quantity Indicator	Gull
308-003-005	Fuel Quantity Indicator	Gull
308-003-007	Fuel Quantity Indicator	Gull
308-003-008	Fuel Quantity Indicator	Gull
308-904-001	Fuel Quantity Indicator	Gull
31654-001	Fuel Quantity Indicator	IDC
31654-002	Fuel Quantity Indicator	IDC
3265005-0101	Totalizer	Litton
3265009-0201	Totalizer	Litton
3581320-2001	Fuel Quantity Indicator	Allied Signal/ Honeyw
360-012-003	Fuel Quantity Power Supply	Gull
360-913-004	Intermediate Device	Gull

Primary Part Number	Nomenclature	Manufacture
360-916-004	Fuel Quantity Indicator	Gull
360-926-001	Signal Conditioner	Gull
360-927-001	Intermediate Device	Gull
360-956-001	Signal Conditioner	Gull
360-984-001	Signal Conditioner	Gull
361-012-001	Fuel Quantity Indicator	Gull
361-016-001	Fuel Quantity Indicator	Gull
371-2	Fuel Quantity Indicator	Consolidated Airborn
37-13-2000-291	Fuel Quantity Tank Unit	Simmonds
37-13-2000-292	Fuel Quantity Tank Unit	Simmonds
37-13-2000-293	Fuel Quantity Tank Unit	Simmonds
37-13-2000-481	Fuel Quantity Tank Unit	Simmonds

37-13-2000-482	Fuel Quantity Tank Unit	Simmonds
37-1-7300-29	Adjustment Box	Simmonds
37211-383	Fuel Quantity Tank Unit	Simmonds
37211-385	Fuel Quantity Tank Unit	Simmonds
37211-479	Fuel Quantity Tank Unit	Simmonds
37212-291	Fuel Quantity Tank Unit	Simmonds
37212-292	Fuel Quantity Tank Unit	Simmonds
37212-293	Fuel Quantity Tank Unit	Simmonds
37212-345	Fuel Quantity Tank Unit	Simmonds
37212-351	Fuel Quantity Tank Unit	Simmonds
37212-360	Fuel Quantity Tank Unit	Simmonds
37212-362	Fuel Quantity Tank Unit	Simmonds
37212-388	Fuel Quantity Tank Unit	Simmonds
37212-389	Fuel Quantity Tank Unit	Simmonds
37212-42	Fuel Quantity Tank Unit	Simmonds
37212-44	Fuel Quantity Tank Unit	Simmonds
37212-47	Fuel Quantity Tank Unit	Simmonds
37212-476	Fuel Quantity Tank Unit	Simmonds
37212-48	Fuel Quantity Tank Unit	Simmonds
37212-481	Fuel Quantity Tank Unit	Simmonds
37212-482	Fuel Quantity Tank Unit	Simmonds
37212-502	Fuel Quantity Tank Unit	Simmonds
37212-62	Fuel Quantity Tank Unit	Simmonds
37212-63	Fuel Quantity Tank Unit	Simmonds
37212-64	Fuel Quantity Tank Unit	Simmonds
37212-65	Fuel Quantity Tank Unit	Simmonds
37212-68	Fuel Quantity Tank Unit	Simmonds
37212-69	Fuel Quantity Tank Unit	Simmonds
37213-472	Fuel Quantity Tank Unit	Simmonds
37214-300	Fuel Quantity Tank Unit	Simmonds
37214-393	Fuel Quantity Tank Unit	Simmonds
37214-449	Fuel Quantity Tank Unit	Simmonds

Primary Part Number	Nomenclature	Manufacture
37221-384	Fuel Quantity Tank Unit	Simmonds
37221-477	Fuel Quantity Tank Unit	Simmonds
37221-478	Fuel Quantity Tank Unit	Simmonds
37222-346	Fuel Quantity Tank Unit	Simmonds
37222-43	Fuel Quantity Tank Unit	Simmonds
37223-474	Fuel Quantity Tank Unit	Simmonds
37224-450	Fuel Quantity Tank Unit	Simmonds
37224-473	Fuel Quantity Tank Unit	Simmonds
37242-347	Fuel Quantity Tank Unit	Simmonds
37242-350	Fuel Quantity Tank Unit	Simmonds
37242-361	Fuel Quantity Tank Unit	Simmonds
37244-299	Fuel Quantity Tank Unit	Simmonds
37260-494	Fuel Quantity Tank Unit	Simmonds
37260-75	Fuel Quantity Tank Unit	Simmonds
37-2-7600-6	Adjustment Box	Simmonds
37-2-7600-7	Adjustment Box	Simmonds

37-2-7600-96	Adjustment Box	Simmonds
37-2-7600-97	Adjustment Box	Simmonds
37300	Fuel Quantity Power Supply	Simmonds
37-3-2000-42	Fuel Quantity Tank Unit	Simmonds
37-3-2000-44	Fuel Quantity Tank Unit	Simmonds
37-3-2000-47	Fuel Quantity Tank Unit	Simmonds
37-3-2000-48	Fuel Quantity Tank Unit	Simmonds
37-3-2000-502	Fuel Quantity Tank Unit	Simmonds
37-3-2000-62	Fuel Quantity Tank Unit	Simmonds
37-3-2000-63	Fuel Quantity Tank Unit	Simmonds
37-3-2000-64	Fuel Quantity Tank Unit	Simmonds
37-3-2000-65	Fuel Quantity Tank Unit	Simmonds
37-3-2000-68	Fuel Quantity Tank Unit	Simmonds
37-3-2000-69	Fuel Quantity Tank Unit	Simmonds
37323	Fuel Quantity Power Supply	Simmonds
37-3-2400-256	Fuel Quantity Tank Unit	Simmonds
37-3-4100-61	Fuel Quantity Indicator	Simmonds
37-3-4100-62	Fuel Quantity Indicator	Simmonds
37402-129	Fuel Quantity Indicator	Simmonds
37402-147	Fuel Quantity Indicator	Simmonds
37403-	Fuel Quantity Indicator	Simmonds
37403-137	Fuel Quantity Indicator	Simmonds
37403-141	Fuel Quantity Indicator	Simmonds
37403-141B	Fuel Quantity Indicator	Simmonds
37403-162	Fuel Quantity Indicator	Simmonds
37403-215	Fuel Quantity Indicator	Simmonds
37404-	Fuel Quantity Indicator	Simmonds
37404-127	Fuel Quantity Indicator	Simmonds

Primary Part Number	Nomenclature	Manufacture
37404-128	Fuel Quantity Indicator	Simmonds
37404-138	Fuel Quantity Indicator	Simmonds
37404-142	Fuel Quantity Indicator	Simmonds
37404-144	Fuel Quantity Indicator	Simmonds
37404-155	Fuel Quantity Indicator	Simmonds
37404-174	Fuel Quantity Indicator	Simmonds
37404-210	Fuel Quantity Indicator	Simmonds
37413-	Fuel Quantity Indicator	Simmonds
37413-158	Fuel Quantity Indicator	Simmonds
37413-159	Fuel Quantity Indicator	Simmonds
37413-203A	Fuel Quantity Indicator	Simmonds
37413-220	Fuel Quantity Indicator	Simmonds
37414-	Fuel Quantity Indicator	Simmonds
37414-142	Fuel Quantity Indicator	Simmonds
37414-174	Fuel Quantity Indicator	Simmonds
37415-	Fuel Quantity Indicator	Simmonds
37415-227	Fuel Quantity Indicator	Simmonds
37415-228	Fuel Quantity Indicator	Simmonds
37415-229	Fuel Quantity Indicator	Simmonds
37415-230	Fuel Quantity Indicator	Simmonds

37415-231	Fuel Quantity Indicator	Simmonds
37415-280	Fuel Quantity Indicator	Simmonds
37-4-4100-61	Fuel Quantity Indicator	Simmonds
37-5-2300-2	Fuel Quantity Tank Unit	Simmonds
37-61-2000-254	Fuel Quantity Tank Unit	Simmonds
37-62-2400-255	Fuel Quantity Tank Unit	Simmonds
37-6-2400-10	Fuel Quantity Tank Unit	Avien
37-6-2400-11	Fuel Quantity Tank Unit	Avien
37-6-2400-12	Fuel Quantity Tank Unit	Avien
37711-84	Adjustment Box	Simmonds
37720-55	Adjustment Box	Simmonds
37720-60	Adjustment Box	Simmonds
37720-62	Adjustment Box	Simmonds
37720-65	Adjustment Box	Simmonds
37730-52	Adjustment Box	Simmonds
37730-76	Adjustment Box	Simmonds
37730-95	Adjustment Box	Simmonds
37-8-2000-43	Fuel Quantity Tank Unit	Simmonds
37-8-2400-258	Fuel Quantity Tank Unit	Simmonds
37-8-2500-257	Fuel Quantity Tank Unit	Simmonds
380807-001	Fuel Quantity Indicator	Simmonds
380807-002	Fuel Quantity Indicator	Simmonds
380807-004	Fuel Quantity Indicator	Simmonds
380807-005	Fuel Quantity Indicator	Simmonds

Primary Part Number	Nomenclature	Manufacture
381001-A0178	Fuel Quantity Tank Unit	Simmonds
381001-E0004	Fuel Quantity Tank Unit	Simmonds
381001-E0005	Fuel Quantity Tank Unit	Simmonds
381001-E0007	Fuel Quantity Tank Unit	Simmonds
381001-E0008	Fuel Quantity Tank Unit	Simmonds
381001-E0010	Fuel Quantity Tank Unit	Simmonds
381001-E0011	Fuel Quantity Tank Unit	Simmonds
381001-E0016	Fuel Quantity Tank Unit	Simmonds
381001-E0017	Fuel Quantity Tank Unit	Simmonds
381001-E0018	Fuel Quantity Tank Unit	Simmonds
381001-E0019	Fuel Quantity Tank Unit	Simmonds
381001-E0020	Fuel Quantity Tank Unit	Simmonds
381001-E0021	Fuel Quantity Tank Unit	Simmonds
381001-E0022	Fuel Quantity Tank Unit	Simmonds
381001-E0023	Fuel Quantity Tank Unit	Simmonds
381001-E0024	Fuel Quantity Tank Unit	Simmonds
381001-E0064	Fuel Quantity Tank Unit	Simmonds
381001-E0558	Fuel Quantity Tank Unit	Simmonds
381001-EO169	Fuel Quantity Tank Unit	Simmonds
381001-F0012	Fuel Quantity Tank Unit	Simmonds
381001-G0077	Fuel Quantity Tank Unit	Simmonds
381001-G0078	Fuel Quantity Tank Unit	Simmonds
381001-G0108	Fuel Quantity Tank Unit	Simmonds
381001-G0158	Fuel Quantity Tank Unit	Simmonds

381001-G0174	Fuel Quantity Tank Unit	Simmonds
381001-H0082	Fuel Quantity Tank Unit	Simmonds
381001-H0157	Fuel Quantity Tank Unit	Simmonds
381001-H0171	Fuel Quantity Tank Unit	Simmonds
381001-H0175	Fuel Quantity Tank Unit	Simmonds
381001-L0190	Fuel Quantity Tank Unit	Simmonds
381003-E0025	Fuel Quantity Tank Unit	Simmonds
381003-E0518	Fuel Quantity Tank Unit	Simmonds
381003-G0080	Fuel Quantity Tank Unit	Simmonds
381003-G0109	Fuel Quantity Tank Unit	Simmonds
381003-G0138	Fuel Quantity Tank Unit	Simmonds
381003-G0155	Fuel Quantity Tank Unit	Simmonds
381003-G0156	Fuel Quantity Tank Unit	Simmonds
381003-G0170	Fuel Quantity Tank Unit	Simmonds
381003-G0176	Fuel Quantity Tank Unit	Simmonds
381003-G0218	Fuel Quantity Tank Unit	Simmonds
381003-G0219	Fuel Quantity Tank Unit	Simmonds
381003-G0271	Fuel Quantity Tank Unit	Simmonds
381003-G0306	Fuel Quantity Tank Unit	Simmonds
381003-G0307	Fuel Quantity Tank Unit	Simmonds

Primary Part Number	Nomenclature	Manufacture
381003-H0083	Fuel Quantity Tank Unit	Simmonds
381003-H0172	Fuel Quantity Tank Unit	Simmonds
381003-H0173	Fuel Quantity Tank Unit	Simmonds
381003-H0177	Fuel Quantity Tank Unit	Simmonds
381003-H0273	Fuel Quantity Tank Unit	Simmonds
381006-A0063	Fuel Quantity Tank Unit	Simmonds
381006-A0179	Fuel Quantity Tank Unit	Simmonds
381006-A0180	Fuel Quantity Tank Unit	Simmonds
381006-A0181	Fuel Quantity Tank Unit	Simmonds
381006-A0182	Fuel Quantity Tank Unit	Simmonds
381006-A0183	Fuel Quantity Tank Unit	Simmonds
381006-A0184	Fuel Quantity Tank Unit	Simmonds
381006-A0185	Fuel Quantity Tank Unit	Simmonds
381006-A0186	Fuel Quantity Tank Unit	Simmonds
381006-A0187	Fuel Quantity Tank Unit	Simmonds
381006-A0188	Fuel Quantity Tank Unit	Simmonds
381006-A0189	Fuel Quantity Tank Unit	Simmonds
381006-A0192	Fuel Quantity Tank Unit	Simmonds
381006-A0301	Fuel Quantity Tank Unit	Simmonds
381006-A0302	Fuel Quantity Tank Unit	Simmonds
381006-A0303	Fuel Quantity Tank Unit	Simmonds
381027-G0217	Fuel Quantity Tank Unit	Simmonds
381027-G0272	Fuel Quantity Tank Unit	Simmonds
381027-G0287	Fuel Quantity Tank Unit	Simmonds
381027-G0300	Fuel Quantity Tank Unit	Simmonds
381051-31789	Fuel Quantity Tank Unit	Simmonds
381051-31791	Fuel Quantity Tank Unit	Simmonds
381051-31792	Fuel Quantity Tank Unit	Simmonds

381051-31793	Fuel Quantity Tank Unit	Simmonds
381051-31795	Fuel Quantity Tank Unit	Simmonds
381051-31796	Fuel Quantity Tank Unit	Simmonds
381051-31798	Fuel Quantity Tank Unit	Simmonds
381051-31949	Fuel Quantity Tank Unit	Simmonds
381052-01-	Fuel Quantity Tank Unit	Simmonds
381052-31794	Fuel Quantity Tank Unit	Simmonds
381052-31797	Fuel Quantity Tank Unit	Simmonds
381052-31950	Fuel Quantity Tank Unit	Simmonds
382000	Amplifier	Simmonds
382000-1	Amplifier	Simmonds
382002-022	Amplifier	Simmonds
382002-6	Amplifier	Simmonds
382011	Amplifier	Simmonds
382012	Bridge Amplifier	Simmonds
382012-001	Bridge Amplifier	Simmonds

Primary Part Number	Nomenclature	Manufacture
382022-001	Amplifier	Simmonds
382022-005	Amplifier	Simmonds
382022-006	Amplifier	Simmonds
383000-061	Fuel Quantity Indicator	Simmonds
383000-075	Fuel Quantity Indicator	Simmonds
383000-086	Fuel Quantity Indicator	Simmonds
383000-090	Fuel Quantity Indicator	Simmonds
383000-128	Fuel Quantity Indicator	Simmonds
383000-129	Fuel Quantity Indicator	Simmonds
383000-B035	Fuel Quantity Indicator	Simmonds
383000-B036	Fuel Quantity Indicator	Simmonds
383000-B076	Fuel Quantity Indicator	Simmonds
383000-B077	Fuel Quantity Indicator	Simmonds
383000-B078	Fuel Quantity Indicator	Simmonds
383000-B079	Fuel Quantity Indicator	Simmonds
383000-B080	Fuel Quantity Indicator	Simmonds
383000-B081	Fuel Quantity Indicator	Simmonds
383000-B085	Fuel Quantity Indicator	Simmonds
383000-B101	Fuel Quantity Indicator	Simmonds
383000-B130	Fuel Quantity Indicator	Simmonds
383000-B180	Fuel Quantity Indicator	Simmonds
383000-B182	Fuel Quantity Indicator	Simmonds
383000-B183	Fuel Quantity Indicator	Simmonds
383000-B186	Fuel Quantity Indicator	Simmonds
383000-G105	Fuel Quantity Indicator	Simmonds
383000-J107	Fuel Quantity Indicator	Simmonds
383000-J108	Fuel Quantity Indicator	Simmonds
383000-J109	Fuel Quantity Indicator	Simmonds
383000-J110	Fuel Quantity Indicator	Simmonds
383000-J111	Fuel Quantity Indicator	Simmonds
383000-J112	Fuel Quantity Indicator	Simmonds
383000-K140	Fuel Quantity Indicator	Simmonds

383000-M114	Fuel Quantity Indicator	Simmonds
383000-M148	Fuel Quantity Indicator	Simmonds
383000-M149	Fuel Quantity Indicator	Simmonds
383000-S139	Fuel Quantity Indicator	Simmonds
383004-A191	Fuel Quantity Indicator	Simmonds
383011-24209	Fuel Quantity Indicator	Simmonds
383011-28489	Fuel Quantity Indicator	Simmonds
383011-A191	Fuel Quantity Indicator	Simmonds
383020-01558	Fuel Quantity Indicator	Simmonds
383020-A272	Fuel Quantity Indicator	Simmonds
383020-A273	Fuel Quantity Indicator	Simmonds
383020-A275	Fuel Quantity Indicator	Simmonds

Primary Part Number	Nomenclature	Manufacture
383021-04559	Fuel Quantity Indicator	Simmonds
383021-D276	Fuel Quantity Indicator	Simmonds
383060-01490	Fuel Quantity Indicator	Simmonds
384059-B003	Capacitance Unit	Simmonds
385000	Bridge Cal. Assy	Simmonds
385000-1	Bridge Cal. Assy	Simmonds
385000-2	Bridge Cal. Assy	Simmonds
385001	Bridge Cal. Assy	Simmonds
385001-4	Bridge Cal. Assy	Simmonds
386005	Fuel Quantity Indicator	Simmonds
386007	Fuel Quantity Indicator	Simmonds
386008	Fuel Quantity Indicator	Simmonds
386016-013	Fuel Quantity Indicator	Simmonds
386016-G001	Fuel Quantity Indicator	Simmonds
391007-01951	Fuel Quantity Tank Unit	Simmonds
391007-01952	Fuel Quantity Tank Unit	Simmonds
391007-31951	Fuel Quantity Tank Unit	Simmonds
391007-31952	Fuel Quantity Tank Unit	Simmonds
391041-009	Liquid Quantity	Goodrich
391041-020	Liquid Quantity	Goodrich
391041-021	Liquid Quantity	Goodrich
391041-022	Liquid Quantity	Goodrich
391041-024	Liquid Quantity	Goodrich
391041-025	Liquid Quantity	Goodrich
391041-05007	Liquid Quantity	Goodrich
391041-06008	Liquid Quantity	Goodrich
391057-036	Fuel Quantity Tank Unit	Simmonds
391057-037	Fuel Quantity Tank Unit	Simmonds
391057-038	Fuel Quantity Tank Unit	Simmonds
391057-040	Fuel Quantity Tank Unit	Simmonds
391063-002	Fuel Quantity Tank Unit	Simmonds
391080-08096	Liquid Quantity Transmitter	Simmonds
391088-002	Transmitter	Simmonds
391088-003	Transmitter	Simmonds
391088-004	Transmitter	Simmonds
391088-005	Transmitter	Simmonds

391088-006	Transmitter	Simmonds
393000-01703	Liquid Quantity Indicator	Simmonds
393000-01704	Liquid Quantity Indicator	Simmonds
393002-007	Fuel Quantity Indicator	Simmonds
393-003	Fuel Quantity Indicator	Simmonds
393003-013	Fuel Quantity Indicator	Simmonds
393003-014	Fuel Quantity Indicator	Simmonds
393004-01409	Fuel Quantity Indicator	Simmonds

Primary Part Number	Nomenclature	Manufacture
393004-01491	Fuel Quantity Indicator	Simmonds
393004-01539	Fuel Quantity Indicator	Simmonds
393004-01648	Fuel Quantity Indicator	Simmonds
393004-01685	Fuel Quantity Indicator	Simmonds
393004-01699	Fuel Quantity Indicator	Simmonds
393004-01862	Fuel Quantity Indicator	Simmonds
393004-01970	Fuel Quantity Indicator	Simmonds
393004-050	Fuel Quantity Indicator	Simmonds
393004-060	Fuel Quantity Indicator	Simmonds
393004-061	Fuel Quantity Indicator	Simmonds
393004-093	Fuel Quantity Indicator	Simmonds
393004-10827	Fuel Quantity Indicator	Simmonds
393004-29821	Indicator	Simmonds
393004-29997	Indicator	Simmonds
393007-07869	Fuel Quantity Indicator	Simmonds
393007-07870	Fuel Quantity Indicator	Simmonds
393008-035	Fuel Quantity Indicator	Simmonds
393008-036	Fuel Quantity Indicator	Simmonds
393008-037	Fuel Quantity Indicator	Simmonds
393008-040	Fuel Quantity Indicator	Simmonds
393008-042	Fuel Quantity Indicator	Simmonds
393008-046	Fuel Quantity Indicator	Simmonds
393008-047	Fuel Quantity Indicator	Simmonds
393008-056	Fuel Quantity Indicator	Simmonds
393008-064	Fuel Quantity Indicator	Simmonds
393008-074	Fuel Quantity Indicator	Simmonds
393008-075	Indicator	Simmonds Precision
393008-07600	Fuel Quantity Indicator	Simmonds
393008-078	Fuel Quantity Indicator	Simmonds
393008-07973	Fuel Quantity Indicator	Simmonds
393008-082	Fuel Quantity Indicator	Simmonds
393020-003	LIQUID QUANTITY INDICATOR	BFGoodrich
393020-012	LIQUID QUANTITY INDICATOR	BFGoodrich
393020-01789	LIQUID QUANTITY INDICATOR	BFGoodrich
393026-001	Fuel Quantity Indicator	Simmonds
393026-01837	Fuel Quantity Indicator	Simmonds
393026-01838	Fuel Quantity Indicator	Simmonds
393026-01840	Fuel Quantity Indicator	Simmonds
393026-01841	Fuel Quantity Indicator	Simmonds
393026-01880	Fuel Quantity Indicator	Simmonds

393026-03235	Fuel Quantity Indicator	Simmonds
393026-03236	Fuel Quantity Indicator	Simmonds
393026-03334	Fuel Quantity Indicator	Simmonds
393026-03335	Fuel Quantity Indicator	Simmonds

Primary Part Number	Nomenclature	Manufacture
393026-03508	Fuel Quantity Indicator	Simmonds
393026-03569	Fuel Quantity Indicator	Simmonds
393026-036	Fuel Quantity Indicator	Simmonds
393026-037	Fuel Quantity Indicator	Simmonds
393026-038	Fuel Quantity Indicator	Simmonds
393026-039	Fuel Quantity Indicator	Simmonds
393026-040	Fuel Quantity Indicator	Simmonds
393026-042	Fuel Quantity Indicator	Simmonds
393026-04237	Fuel Quantity Indicator	Simmonds
393026-043	Fuel Quantity Indicator	Simmonds
393026-04337	Fuel Quantity Indicator	Simmonds
393026-044	Fuel Quantity Indicator	Simmonds
393026-04510	Fuel Quantity Indicator	Simmonds
393026-04568	Fuel Quantity Indicator	Simmonds
393026-053	Fuel Quantity Indicator	Simmonds
393026-054	Fuel Quantity Indicator	Simmonds
393026-064	Fuel Quantity Indicator	Simmonds
393026-071	Fuel Quantity Indicator	Simmonds
393026-072	Fuel Quantity Indicator	Simmonds
393026-076	Fuel Quantity Indicator	Simmonds
393026-077	Fuel Quantity Indicator	Simmonds
393026-079	Fuel Quantity Indicator	Simmonds
393026-080	Fuel Quantity Indicator	Simmonds
393026-081	Fuel Quantity Indicator	Simmonds
393026-082	Fuel Quantity Indicator	Simmonds
393026-083	Fuel Quantity Indicator	Simmonds
393026-084	Fuel Quantity Indicator	Simmonds
393026-085	Fuel Quantity Indicator	Simmonds
393026-086	Fuel Quantity Indicator	Simmonds
393026-087	Fuel Quantity Indicator	Simmonds
393026-088	Fuel Quantity Indicator	Simmonds
393026-089	Fuel Quantity Indicator	Simmonds
393026-090	Fuel Quantity Indicator	Simmonds
393026-091	Fuel Quantity Indicator	Simmonds
393026-092	Fuel Quantity Indicator	Simmonds
393026-093	Fuel Quantity Indicator	Simmonds
393026-094	Fuel Quantity Indicator	Simmonds
393026-095	Fuel Quantity Indicator	Simmonds
393026-096	Fuel Quantity Indicator	Simmonds
393027-002	Fuel Quantity Indicator	Simmonds
393027-003	Fuel Quantity Indicator	Simmonds
393027-007	Fuel Quantity Indicator	Simmonds
393027-009	Fuel Quantity Indicator	Simmonds
393027-010	Fuel Quantity Indicator	Simmonds

Primary Part Number	Nomenclature	Manufacture
393027-012	Fuel Quantity Indicator	Simmonds
393027-04378	Fuel Quantity Indicator	Simmonds
393029-01412	Fuel Quantity Indicator	Simmonds
393043-003	Fuel Quantity Indicator	Simmonds
393043-01718	Fuel Quantity Indicator	Simmonds
393081-103	Fuel Quantity Totalizer	Simmonds
393081-105	Fuel Quantity Totalizer	Simmonds
393081-107	Fuel Quantity Totalizer	Simmonds
393081-109	Fuel Quantity Totalizer	Simmonds
393081-111	Fuel Quantity Totalizer	Simmonds
393081-113	Fuel Quantity Totalizer	Simmonds
393081-115	Fuel Quantity Totalizer	Simmonds
393084-024	Fuel Quantity Indicator	Simmonds
393084-025	Fuel Quantity Indicator	Simmonds
393084-026	Fuel Quantity Indicator	Simmonds
393084-031	Fuel Quantity Indicator	Simmonds
393084-036	Fuel Quantity Indicator	Simmonds
393084-04359	Liquid Quantity Indicator	Simmonds
393084-04408	Liquid Quantity Indicator	Simmonds
393084-04596	Liquid Quantity Indicator	Simmonds
393084-052	Liquid Oxygen Quantity Gage	Simmonds Precision
393084-054	Fuel Quantity Indicator	Simmonds
393084-11358	Liquid Qxygen Qty Indicator	Simmonds
393084-11426	Liquid Oxygen Quantity Gage	Simmonds Precision
393084-11881	Liquid Qxygen Qty Indicator	Simmonds
393084-11882	Liquid Qxygen Qty Indicator	Simmonds
393084-16648	Fuel Quantity Indicator	Simmonds
393084-22488	Fuel Quantity Indicator	Simmonds
393084-22825	Fuel Quantity Indicator	Simmonds
393085-43708	Fuel Quantity Indicator	Simmonds
393090-101	Fuel Quantity Indicator	Simmonds
393090-109	Fuel Quantity Indicator	Simmonds
393090-111	Fuel Quantity Indicator	Simmonds
393090-113	Fuel Quantity Indicator	Simmonds
393090-115	Fuel Quantity Indicator	Simmonds
393090-117	Fuel Quantity Indicator	Simmonds
393097-02819	Indicator	Simmonds
441713	Fuel Quantity Indicator	Honeywell
451778	Fuel Quantity Indicator	Honeywell
472144-005	Fuel Quantity Indicator	Simmonds
490211	Fuel Quantity Indicator	AID
50-389031	Fuel Quantity Indicator	AID
50-389031-1	Fuel Quantity Indicator	AID
5-1211	Fuel Quantity Indicator	Rochester

Primary Part Number	Nomenclature	Manufacture
522223	Potable Water Qty Indicator	Weston
555-1305	Water Level Switch	Cook

5707-3002	Fuel Quantity Indicator	Insco
585-31654-001	Fuel Quantity Indicator	IDC
585-37470-001	Fuel Used Indicator	Kollsman
585-37470-002	Fuel Used Indicator	Kollsman
585-37470-003	Fuel Used Indicator	Kollsman
585-37470-004	Fuel Used Indicator	Kollsman
585-37470-011	Fuel Used Indicator	Kollsman
585-37470-012	Fuel Used Indicator	Kollsman
5-90372	Fuel Quantity Indicator	Rochester
5907-43A-1-A	Hydraulic Quantity Indicator	Eclipse Pioneer
5907-43A-1-B	Hydraulic Quantity Indicator	Eclipse Pioneer
5907-43B-1-A	Hydraulic Quantity Indicator	Eclipse Pioneer
5907-43B-1-B	Hydraulic Quantity Indicator	Eclipse Pioneer
5907-44A-1-A	Hydraulic Quantity Indicator	Eclipse Pioneer
5907-44B-1-A	Hydraulic Quantity Indicator	Eclipse Pioneer
5907-44B-1-B	Hydraulic Quantity Indicator	Eclipse Pioneer
6007-32A-11-A	Liquid Quantity Indicator	Eclipse Pioneer
6007-33A-10-A	Liquid Quantity Indicator	Eclipse Pioneer
6007-34A-11-A	Liquid Quantity Indicator	Eclipse Pioneer
6007-58A-15-A	Liquid Quantity Indicator	Eclipse Pioneer
6007-58A-15-B	Liquid Quantity Indicator	Eclipse Pioneer
6007-58A-56-B	Liquid Quantity Indicator	Eclipse Pioneer
6007-58C-36-B1	Liquid Quantity Indicator	Eclipse Pioneer
6007-59B-7-B	Liquid Quantity Indicator	Eclipse Pioneer
6007-60B-7-A	Liquid Quantity Indicator	Eclipse Pioneer
6007-60B-7-B	Liquid Quantity Indicator	Eclipse Pioneer
6007-61A-7-A	Liquid Quantity Indicator	Eclipse Pioneer
6007-61B-7-B	Liquid Quantity Indicator	Eclipse Pioneer
6007-61C-55-B	Liquid Quantity Indicator	Eclipse Pioneer
60B92017-23	Fuel Quantity Indicator	Ametek/GE
60B92017-29	Fuel Quantity Indicator	Ametek/GE
6150-1-A6	Liquid Level Transmitter	Eclipse Pioneer
6150-1-C6	Liquid Level Transmitter	Eclipse Pioneer
6150-3-A4	Liquid Level Transmitter	Eclipse Pioneer
6150-3-B4	Liquid Level Transmitter	Eclipse Pioneer
6150-3-C4	Liquid Level Transmitter	Eclipse Pioneer
6150-4-C1	Liquid Level Transmitter	Eclipse Pioneer
6246-00052	Fuel Quantity Indicator	Rochester
6246-00053	Fuel Quantity Indicator	Rochester
6246-00474	Fuel Quantity Indicator	Rochester
640281-105	Fuel Quantity Indicator	Rochester
640281-107	Fuel Quantity Indicator	Rochester

Primary Part Number	Nomenclature	Manufacture
664-1	Liquid Qxygen Qty Indicator	Penn Airborne
664-2	Liquid Qxygen Qty Indicator	Penn Airborne
664-2HEA	Liquid Qxygen Qty Indicator	Penn Airborne
697749-5	Indicator	Simmonds
70408	Fuel Quantity Indicator	Honeywell
70901-21801-103	Fuel Quantity Indicator	Natec Electronic

78-109-1	Adaptor	Ragen
80807-003	Fuel Quantity Indicator	Simmonds
81-101-1	Fuel Quantity Indicator	Ragen
81-101-2	Fuel Quantity Indicator	Ragen
81-175-2	Fuel Quantity Indicator	Ragen
81-208-1	Fuel Quantity Indicator	Ragen
8DJ11LAC	Liquid Quantity Indicator	Ametek/GE
8DJ11LAD	Liquid Quantity Indicator	Ametek/GE
8DJ11LAE	Liquid Quantity Indicator	Ametek/GE
8DJ11LAL	Liquid Quantity Indicator	Ametek/GE
8DJ11LAN	Liquid Quantity Indicator	Ametek/GE
8DJ11LAT	Liquid Quantity Indicator	Ametek/GE
8DJ11LAV	Liquid Quantity Indicator	Ametek/GE
8DJ11LWK	Liquid Quantity Indicator	Ametek/GE
8DJ11LXM	Liquid Quantity Indicator	Ametek/GE
8DJ12LAE	Liquid Quantity Indicator	Ametek/GE
8DJ12LAF	Liquid Quantity Indicator	Ametek/GE
8DJ12LXA	Liquid Quantity Indicator	Ametek/GE
8DJ12LXE	Liquid Quantity Indicator	Ametek/GE
8DJ130LAC1	Oil Quantity Indicator	Ametek/GE
8DJ130LWA1	Oil Quantity Indicator	Ametek/GE
8DJ130LWS1	Oil Quantity Indicator	Ametek/GE
8DJ130LWX1	Oil Quantity Indicator	Ametek/GE
8DJ142LAT4	Fuel Quantity Indicator	Ametek/GE
8DJ142LAV4	Fuel Quantity Indicator	Ametek/GE
8DJ142LWS4	Fuel Quantity Indicator	Ametek/GE
8DJ142LXF4	Fuel Quantity Indicator	Ametek/GE
8DJ171LWA3	Fuel Quantity Indicator	Ametek/GE
8DJ171LWD3	Fuel Quantity Indicator	Ametek/GE
8DJ171WA2	Fuel Quantity Indicator	Ametek/GE
8DJ171WD2	Fuel Quantity Indicator	Ametek/GE
8DJ173LWA1	Oil Quantity Indicator	Ametek/GE
8DJ173LWC1	Oil Quantity Indicator	Ametek/GE
8DJ173LWD1	Oil Quantity Indicator	Ametek/GE
8DJ1LAL	Liquid Quantity Indicator	Ametek/GE
8DJ1LAM	Liquid Quantity Indicator	Ametek/GE
8DJ1LAR	Liquid Quantity Indicator	Ametek/GE
8DJ1LAS	Liquid Quantity Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ20AAC	Liquid Quantity Indicator	Ametek/GE
8DJ20AAD	Liquid Quantity Indicator	Ametek/GE
8DJ20AAE	Liquid Quantity Indicator	Ametek/GE
8DJ20AAV	Liquid Quantity Indicator	Ametek/GE
8DJ20AAZ	Liquid Quantity Indicator	Ametek/GE
8DJ20ABK	Liquid Quantity Indicator	Ametek/GE
8DJ20ACD	Liquid Quantity Indicator	Ametek/GE
8DJ20ACS	Liquid Quantity Indicator	Ametek/GE
8DJ20ACY	Liquid Quantity Indicator	Ametek/GE
8DJ20ADC	Liquid Quantity Indicator	Ametek/GE

8DJ20ADD	Liquid Quantity Indicator	Ametek/GE
8DJ20ADE	Liquid Quantity Indicator	Ametek/GE
8DJ20ADF	Liquid Quantity Indicator	Ametek/GE
8DJ20ADH	Liquid Quantity Indicator	Ametek/GE
8DJ20ADK	Liquid Quantity Indicator	Ametek/GE
8DJ20ADR	Liquid Quantity Indicator	Ametek/GE
8DJ20ADS	Liquid Quantity Indicator	Ametek/GE
8DJ20ADX	Liquid Quantity Indicator	Ametek/GE
8DJ20ADY	Liquid Quantity Indicator	Ametek/GE
8DJ20AFA	Liquid Quantity Indicator	Ametek/GE
8DJ20AFB	Liquid Quantity Indicator	Ametek/GE
8DJ20AFD4	Liquid Quantity Indicator	Ametek/GE
8DJ20AFM	Liquid Quantity Indicator	Ametek/GE
8DJ20AFW	Liquid Quantity Indicator	Ametek/GE
8DJ20AFX	Liquid Quantity Indicator	Ametek/GE
8DJ20AFY	Liquid Quantity Indicator	Ametek/GE
8DJ20AGE	Fuel Quantity Indicator	Ametek/GE
8DJ20AGE50	Liquid Quantity Indicator	Ametek/GE
8DJ21AAB	Liquid Quantity Indicator	Ametek/GE
8DJ21AAF	Liquid Quantity Indicator	Ametek/GE
8DJ21AAN	Liquid Quantity Indicator	Ametek/GE
8DJ21ABY	Liquid Quantity Indicator	Ametek/GE
8DJ21ABZ	Liquid Quantity Indicator	Ametek/GE
8DJ21ACN	Liquid Quantity Indicator	Ametek/GE
8DJ21ACW	Liquid Quantity Indicator	Ametek/GE
8DJ21ACZ	Liquid Quantity Indicator	Ametek/GE
8DJ21ADE	Liquid Quantity Indicator	Ametek/GE
8DJ21ADH	Liquid Quantity Indicator	Ametek/GE
8DJ21ADR	Liquid Quantity Indicator	Ametek/GE
8DJ21ADY3	Liquid Quantity Indicator	Ametek/GE
8DJ21AEF3	Liquid Quantity Indicator	Ametek/GE
8DJ21AEL3	Liquid Quantity Indicator	Ametek/GE
8DJ2LAE	Liquid Quantity Indicator	Ametek/GE
8DJ2LAF	Liquid Quantity Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ2LAL	Liquid Quantity Indicator	Ametek/GE
8DJ2LAR	Liquid Quantity Indicator	Ametek/GE
8DJ2LAT	Liquid Quantity Indicator	Ametek/GE
8DJ2LAY	Liquid Quantity Indicator	Ametek/GE
8DJ2LAZ	Liquid Quantity Indicator	Ametek/GE
8DJ2LBA	Liquid Quantity Indicator	Ametek/GE
8DJ2LBF	Liquid Quantity Indicator	Ametek/GE
8DJ2OAEY	Liquid Quantity Indicator	Ametek/GE
8DJ2OAFV	Liquid Quantity Indicator	Ametek/GE
8DJ2Y6	Liquid Quantity Indicator	Ametek/GE
8DJ3EAF	Liquid Quantity Indicator	Ametek/GE
8DJ3GAE50	Liquid Quantity Indicator	Ametek/GE
8DJ3GAF-Y53	Liquid Quantity Indicator	Ametek/GE
8DJ3LAL	Liquid Quantity Indicator	Ametek/GE

8DJ3LAR	Liquid Quantity Indicator	Ametek/GE
8DJ3LAS	Liquid Quantity Indicator	Ametek/GE
8DJ3LAV	Liquid Quantity Indicator	Ametek/GE
8DJ4LWA	Liquid Quantity Indicator	Ametek/GE
8DJ4PAS	Liquid Quantity Indicator	Ametek/GE
8DJ4PCS	Liquid Quantity Indicator	Ametek/GE
8DJ4PCT	Liquid Quantity Indicator	Ametek/GE
8DJ4PCZ	Liquid Quantity Indicator	Ametek/GE
8DJ4PDF	Liquid Quantity Indicator	Ametek/GE
8DJ54GAE1	Liquid Quantity Indicator	Ametek/GE
8DJ54GAF1	Liquid Quantity Indicator	Ametek/GE
8J173LWE1	Oil Quantity Indicator	Ametek/GE
8TJ13LAE	Liquid Quantity Transmitter	Ametek/GE
8TJ13LAF	Liquid Quantity Transmitter	Ametek/GE
8TJ13LAH	Liquid Quantity Transmitter	Ametek/GE
8TJ13LAK	Liquid Quantity Transmitter	Ametek/GE
8TJ13LBE	Liquid Quantity Transmitter	Ametek/GE
8TJ13LBF	Liquid Quantity Transmitter	Ametek/GE
8TJ13LCY	Liquid Quantity Transmitter	Ametek/GE
8TJ13LCZ	Liquid Quantity Transmitter	Ametek/GE
8TJ13LDA	Liquid Quantity Transmitter	Ametek/GE
8TJ13LDB	Liquid Quantity Transmitter	Ametek/GE
8TJ13LDK	Liquid Quantity Transmitter	Ametek/GE
8TJ13LDL	Liquid Quantity Transmitter	Ametek/GE
8TJ13LDN	Liquid Quantity Transmitter	Ametek/GE
8TJ13LDR	Liquid Quantity Transmitter	Ametek/GE
8TJ13LDZ	Liquid Quantity Transmitter	Ametek/GE
8TJ13LEA	Liquid Quantity Transmitter	Ametek/GE
8TJ13LEB	Liquid Quantity Transmitter	Ametek/GE
8TJ13LED	Liquid Quantity Transmitter	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8TJ13LEE	Liquid Quantity Transmitter	Ametek/GE
8TJ13LEF	Liquid Quantity Transmitter	Ametek/GE
8TJ13LEH	Liquid Quantity Transmitter	Ametek/GE
8TJ13LEM	Liquid Quantity Transmitter	Ametek/GE
8TJ13LET	Liquid Quantity Transmitter	Ametek/GE
8TJ13LEV	Liquid Quantity Transmitter	Ametek/GE
8TJ13LEW	Liquid Quantity Transmitter	Ametek/GE
8TJ13LEX	Liquid Quantity Transmitter	Ametek/GE
8TJ13LEY	Liquid Quantity Transmitter	Ametek/GE
8TJ13LFB	Liquid Quantity Transmitter	Ametek/GE
8TJ13LFC	Liquid Quantity Transmitter	Ametek/GE
8TJ13LFD	Liquid Quantity Transmitter	Ametek/GE
8TJ13LFH	Liquid Quantity Transmitter	Ametek/GE
8TJ13LFK	Liquid Quantity Transmitter	Ametek/GE
8TJ13LFL	Liquid Quantity Transmitter	Ametek/GE
8TJ13LFR	Liquid Quantity Transmitter	Ametek/GE
8TJ13LJM43	Liquid Quantity Transmitter	Ametek/GE
8TJ13LWAH	Liquid Quantity Transmitter	Ametek/GE

8TJ13LWAK	Liquid Quantity Transmitter	Ametek/GE
8TJ13LWT	Liquid Quantity Transmitter	Ametek/GE
8TJ13LWV	Liquid Quantity Transmitter	Ametek/GE
8TJ13LWZ	Liquid Quantity Transmitter	Ametek/GE
8TJ13LXN	Liquid Quantity Transmitter	Ametek/GE
8TJ13LXR	Liquid Quantity Transmitter	Ametek/GE
8TJ13LXS	Liquid Quantity Transmitter	Ametek/GE
8TJ13LY9	Liquid Quantity Transmitter	Ametek/GE
8TJ17AAA	Liquid Quantity Transmitter	Ametek/GE
8TJ17AAB	Liquid Quantity Transmitter	Ametek/GE
8TJ17AAM	Liquid Quantity Transmitter	Ametek/GE
8TJ17AAN	Liquid Quantity Transmitter	Ametek/GE
8TJ17ABH	Liquid Quantity Transmitter	Ametek/GE
8TJ17ABK	Liquid Quantity Transmitter	Ametek/GE
8TJ17ACF	Liquid Quantity Transmitter	Ametek/GE
8TJ17ACX	Liquid Quantity Transmitter	Ametek/GE
8TJ17ACY	Liquid Quantity Transmitter	Ametek/GE
8TJ17ACZ	Liquid Quantity Transmitter	Ametek/GE
8TJ17ADC	Liquid Quantity Transmitter	Ametek/GE
8TJ17ADL	Liquid Quantity Transmitter	Ametek/GE
8TJ17ADM	Liquid Quantity Transmitter	Ametek/GE
8TJ17AEL	Liquid Quantity Transmitter	Ametek/GE
8TJ17AEM	Liquid Quantity Transmitter	Ametek/GE
8TJ17AFH	Liquid Quantity Transmitter	Ametek/GE
8TJ17AFK	Liquid Quantity Transmitter	Ametek/GE
8TJ17AGE	Liquid Quantity Transmitter	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8TJ17AGN	Liquid Quantity Transmitter	Ametek/GE
8TJ17AGR	Liquid Quantity Transmitter	Ametek/GE
8TJ17AGX	Liquid Quantity Transmitter	Ametek/GE
8TJ17AGZ	Liquid Quantity Transmitter	Ametek/GE
8TJ17AHF	Liquid Quantity Transmitter	Ametek/GE
8TJ17AHN	Liquid Quantity Transmitter	Ametek/GE
8TJ17AHS	Liquid Quantity Transmitter	Ametek/GE
8TJ17AJZ	Liquid Quantity Transmitter	Ametek/GE
8TJ17ANN3	Liquid Quantity Transmitter	Ametek/GE
8TJ18LAD	Liquid Quantity Transmitter	Ametek/GE
8TJ18LAT8	Liquid Quantity Transmitter	Ametek/GE
8TJ18LAY8	Liquid Level Transmitter	Ametek/GE
8TJ18LAY9	Liquid Quantity Transmitter	Ametek/GE
8TJ18LBK11	Liquid Quantity Transmitter	Ametek/GE
8TJ92GAA2	Liquid Quantity Transmitter	Ametek/GE
8TJ92GAD2	Liquid Quantity Transmitter	Ametek/GE
8TJ99GAF1	Liquid Quantity Transmitter	Ametek/GE
8TJ99GAF2	Liquid Quantity Transmitter	Ametek/GE
8TJ99GAT1	Liquid Quantity Transmitter	Ametek/GE
8TJ99GAT2	Liquid Quantity Transmitter	Ametek/GE
8TJ99GBD1	Liquid Quantity Transmitter	Ametek/GE
8TJ99GBD2	Liquid Quantity Transmitter	Ametek/GE

8TJ99GBH1	Liquid Quantity Transmitter	Ametek/GE
8TJ99GBM2	Liquid Quantity Transmitter	Ametek/GE
8TJ9PET	Liquid Quantity Transmitter	Ametek/GE
9-114-04	Fuel Used Indicator	Eldec
9-116-01	Fuel Used Indicator	Eldec
9-116-02	Fuel Used Indicator	Eldec
96-384005-3	Fuel Quantity Indicator	AID
9910082-1	Fuel Quantity Indicator	Consolidated Airborn
9910082-14	FUEL QTY. TANK UNIT	Cessna
9910082-17	FUEL QTY. TANK UNIT	Cessna
9910082-2	Fuel Quantity Indicator	Cessna
9910082-310Q	Fuel Quantity Indicator	Cessna
9910082-340	Fuel Quantity Indicator	Cessna
9910082-402B	Fuel Quantity Indicator	Cessna
9910082-414	Fuel Quantity Indicator	Cessna
9910082-421	Fuel Quantity Indicator	Cessna
9910082-421C	Fuel Quantity Indicator	Cessna
9910082-441	Fuel Quantity Indicator	Gull
9910082-8	FUEL QTY. TANK UNIT	Cessna
99C015	Indicator	SigmaTek
9A-1036-2	Liquid Qxygen Qty Indicator	Penn Airborne
9A-1040	Liquid Qxygen Qty Indicator	Penn Airborne

Primary Part Number	Nomenclature	Manufacture
9A225	Liquid Qxygen Qty Indicator	Penn Airborne
9A-225	Liquid Qxygen Qty Indicator	Penn Airborne
9A-360	Liquid Qxygen Qty Indicator	Penn Airborne
9A-360HEA	Liquid Qxygen Qty Indicator	Penn Airborne
9A-4HEA	Liquid Qxygen Qty Indicator	Penn Airborne
AC-134A5-4	Adjustment Panel	Liquidometer
B118-101	Fuel Quantity Indicator	Simmonds
B118-124	Fuel Quantity Indicator	Liquidometer
B118-125	Fuel Quantity Indicator	Simmonds
B118-126	Fuel Quantity Indicator	Liquidometer
B118-138	Liquid Quantity Indicator	Simmonds
B118-143	Fuel Quantity Indicator	Liquidometer
B118-144	Fuel Quantity Indicator	Liquidometer
B118-145	Fuel Quantity Indicator	Simmonds
B118-156	Fuel Quantity Indicator	Simmonds
B118-161	Liquid Quantity Indicator	Simmonds
B118-249	Fuel Quantity Indicator	Simmonds
B118-261	Indicator Control Unit	Simmonds
B118-262	Indicator Control Unit	Simmonds
B118-312	Fuel Quantity Indicator	Simmonds
B118-312W	Fuel Quantity Indicator	Simmonds
B118-312XW	Fuel Quantity Indicator	Simmonds
B118-313	Fuel Quantity Indicator	Simmonds
B118-313W	Fuel Quantity Indicator	Simmonds
B118-313XW	Fuel Quantity Indicator	Simmonds
B118-314	Fuel Quantity Indicator	Simmonds

B118-314W	Fuel Quantity Indicator	Simmonds
B118-314XW	Fuel Quantity Indicator	Simmonds
B118-315	Fuel Quantity Indicator	Simmonds
B118-315W	Fuel Quantity Indicator	Simmonds
B118-315XW	Fuel Quantity Indicator	Simmonds
B118-316	Fuel Quantity Indicator	Simmonds
B118-316W	Fuel Quantity Indicator	Simmonds
B118-316XW	Fuel Quantity Indicator	Simmonds
B118-317	Fuel Quantity Indicator	Simmonds
B118-324	Fuel Quantity Indicator	Simmonds
B118-324W	Fuel Quantity Indicator	Simmonds
B118-324XW	Fuel Quantity Indicator	Simmonds
B118-336	Fuel Quantity Indicator	Simmonds
B118-337	Fuel Quantity Indicator	Simmonds
B118-338	Fuel Quantity Indicator	Simmonds
B118-339	Fuel Quantity Indicator	Simmonds
B118-3-3W	Fuel Quantity Indicator Main	Simmonds
B118-340	Fuel Quantity Indicator	Simmonds

Primary Part Number	Nomenclature	Manufacture
B118-341	Fuel Quantity Indicator	Simmonds
B118-342	Fuel Quantity Indicator	Simmonds
B118-356	Fuel Quantity Indicator	Simmonds
B118-357	Fuel Quantity Indicator	Simmonds
B118-58	Fuel Quantity Indicator	Liquidometer
B118-59	Fuel Quantity Indicator	Liquidometer
B118-60	Fuel Quantity Indicator	Liquidometer
B118-61	Fuel Quantity Indicator	Liquidometer
B118-62	Fuel Quantity Indicator	Liquidometer
B118-63	Fuel Quantity Indicator	Liquidometer
B118-64	Fuel Quantity Indicator	Liquidometer
B118-65	Fuel Quantity Indicator	Liquidometer
B118-66	Fuel Quantity Indicator	Liquidometer
B118-67	Fuel Quantity Indicator	Liquidometer
B118-68	Fuel Quantity Indicator	Simmonds
B118-69	Fuel Quantity Indicator	Simmonds
B118-70	Fuel Quantity Indicator	Simmonds
B118-71	Fuel Quantity Indicator	Simmonds
B118-72	Fuel Quantity Indicator	Simmonds
B118-75	Fuel Quantity Indicator	Simmonds
B118-95	Fuel Quantity Indicator	Liquidometer
B118-97	Fuel Quantity Indicator	Liquidometer
B118C-28M	Fuel Quantity Tank Unit	Liquidometer
B118C-28M1	Fuel Quantity Tank Unit	Liquidometer
B118C-29M	Fuel Quantity Tank Unit	Liquidometer
B118C-29M1	Fuel Quantity Tank Unit	Liquidometer
B118C-30M	Fuel Quantity Tank Unit	Liquidometer
B118C-31M	Fuel Quantity Tank Unit	Liquidometer
B118C-32M	Fuel Quantity Tank Unit	Liquidometer
B118C-33M	Fuel Quantity Tank Unit	Liquidometer

B118C-34M	Fuel Quantity Tank Unit	Liquidometer
B118C-35M	Fuel Quantity Tank Unit	Liquidometer
B118C-35M1	Fuel Quantity Tank Unit	Liquidometer
B118C-38	Fuel Quantity Power Supply	Liquidometer
B118E-26	Fuel Quantity Indicator	Liquidometer
B118E-98	Fuel Quantity Power Supply	Liquidometer
B1239-3646	Fuel Quantity Tank Unit	Simmonds
B1559-1	Hydraulic Quantity Indicator	Simmonds
B175-21W	Fuel Quantity Indicator	BF Goodrich
B175-22W	Fuel Quantity Indicator	BF Goodrich
B175-24W	Fuel Quantity Indicator	BF Goodrich
B175-25W	Fuel Quantity Indicator	BF Goodrich
B202-10-2	Fuselage Fuel Indicator	Simmonds
B202-10-3	Fuselage Fuel Indicator	Simmonds

Primary Part Number	Nomenclature	Manufacture
B222-42	Fuel Quantity Indicator	Simmonds
B222A-9	Fuel Quantity Indicator	Simmonds
B222A-9A	Fuel Quantity Indicator	Simmonds
B353-13	Liquid Quantity Indicator	Liquidometer
B353-14	Liquid Quantity Indicator	Liquidometer
B518-313	Fuel Quantity Indicator	Simmonds
B711-1	Liquid Quantity Indicator	BF Goodrich
B711-3	Liquid Quantity Indicator	Simmonds
B711-4	Liquid Quantity Indicator	Simmonds
B711-5	Liquid Quantity Indicator	Simmonds
B711-6	Liquid Quantity Indicator	Simmonds
B712-1	Liquid Quantity Indicator	Simmonds
B712-2	Liquid Quantity Indicator	Simmonds
B712-4	Liquid Quantity Indicator	Simmonds
BH112J	Jet Cal Analyzer	Howell
BH112JA	Jet Cal Analyzer	Howell
CM2646	Fuel Quantity Indicator	AID
CM2646-1	Fuel Quantity Indicator	AID
CM2646-2	Fuel Quantity Indicator	AID
CM2646-3	Fuel Quantity Indicator	AID
CM2696-1	Fuel Quantity Indicator	AID
CMF1167	Fuel Quantity Control Monitor	Consolidated Airborn
CMF776-10	Fuel Quantity Control Monitor	Consolidated Airborn
CMF776-3	Fuel Quantity Control Monitor	Consolidated Airborn
CMF776-4	Fuel Quantity Control Monitor	Consolidated Airborn
CMF776-5	Fuel Quantity Control Monitor	Consolidated Airborn
D3347-2-13	Liquid Quantity Indicator	Stewart Warner
DDL-OC119A	Fuel Quntity Indicator	Ametek/GE
DG33A	Compensator	Honeywell
DG33A-1	Compensator	Honeywell
DG33A-1A	Compensator	Honeywell
DG33A-9	Compensator	Honeywell
DJ-1	Liquid Quantity Indicator	Ametek/GE
DJ-11	Liquid Quantity Indicator	Ametek/GE

DJ-12	Liquid Quantity Indicator	Ametek/GE
DJ-13	Liquid Quantity Transmitter	Ametek/GE
DJ-17	Liquid Quantity Transmitter	Ametek/GE
DJ-18	Liquid Quantity Transmitter	Ametek/GE
DJ-2	Liquid Quantity Indicator	Ametek/GE
DJ-20	Liquid Quantity Indicator	Ametek/GE
DJ-21	Liquid Quantity Indicator	Ametek/GE
DJ-3	Liquid Quantity Indicator	Ametek/GE
DJ-4	Liquid Quantity Indicator	Ametek/GE
DSF 1906	Fuel Quantity Indicator	Consolidated Airborn

Primary Part Number	Nomenclature	Manufacture
DSF 698-2	Fuel Quantity Indicator	Consolidated Airborn
DSF 929	Fuel Quantity Indicator	Consolidated Airborn
DSF1158	Fuel Quantity Indicator	Consolidated Airborn
DSF-1580	Fuel Quantity Indicator	Consolidated Airborn
DSF365	Fuel Quantity Indicator	Consolidated Airborn
DSF419	Fuel Quantity Indicator	Consolidated Airborn
DSF-684-1	Fuel Quantity Tank Unit	Consolidated Airborn
DSF859-1	Fuel Quantity Indicator	Consolidated Airborn
EA100AN-10	Fuel Quantity Indicator	Liquidometer
EA100AN-11	Fuel Quantity Indicator	Liquidometer
EA100AN-110	Fuel Quantity Indicator	Liquidometer
EA100AN-12	Fuel Quantity Indicator	Liquidometer
EA100AN-13	Fuel Quantity Indicator	Liquidometer
EA100AN-133H	Fuel Quantity Indicator	Liquidometer
EA100AN-17	Fuel Quantity Indicator	Liquidometer
EA100AN-30	Fuel Quantity Indicator	Liquidometer
EA100AN-35	Fuel Quantity Indicator	Liquidometer
EA100AN-36	Fuel Quantity Indicator	Liquidometer
EA100AN-37	Fuel Quantity Indicator	Liquidometer
EA100AN-38	Fuel Quantity Indicator	Liquidometer
EA100AN-39	Fuel Quantity Indicator	Liquidometer
EA100AN-40	Fuel Quantity Indicator	Liquidometer
EA100AN-41	Fuel Quantity Indicator	Liquidometer
EA100AN-52	Fuel Quantity Indicator	Liquidometer
EA100AN-53	Fuel Quantity Indicator	Liquidometer
EA100AN-56	Fuel Quantity Indicator	Liquidometer
EA100AN-57	Fuel Quantity Indicator	Liquidometer
EA100AN-62	Fuel Quantity Indicator	Liquidometer
EA100AN-63	Fuel Quantity Indicator	Liquidometer
EA100AN-66	Fuel Quantity Indicator	Liquidometer
EA100AN-68	Fuel Quantity Indicator	Liquidometer
EA100AN-70	Fuel Quantity Indicator	Liquidometer
EA100AN-74	Fuel Quantity Indicator	Liquidometer
EA100AN-75	Fuel Quantity Indicator	Liquidometer
EA100AN-76	Fuel Quantity Indicator	Liquidometer
EA100AN-93	Fuel Quantity Indicator	Liquidometer
EA100AN-98H	Fuel Quantity Indicator	Liquidometer
EA100ANH-103	Fuel Quantity Indicator	Liquidometer

EA100ANH-104	Fuel Quantity Indicator	Liquidometer
EA100ANH-105	Fuel Quantity Indicator	Liquidometer
EA100ANH-107	Fuel Quantity Indicator	Liquidometer
EA100ANH-126	Fuel Quantity Indicator	Liquidometer
EA100ANH-144	Fuel Quantity Indicator	Liquidometer
EA100ANH-146	Fuel Quantity Indicator	Liquidometer

Primary Part Number	Nomenclature	Manufacture
EA100ANH-17	Fuel Quantity Indicator	Liquidometer
EA100ANH-76	Fuel Quantity Indicator	Liquidometer
EA100ANH-87	Fuel Quantity Indicator	Liquidometer
EA100ANH-88	Fuel Quantity Indicator	Liquidometer
EA100ANH-89	Fuel Quantity Indicator	Liquidometer
EA100ANH-92	Fuel Quantity Indicator	Liquidometer
EA100ANH-94	Fuel Quantity Indicator	Liquidometer
EA100ANH-97	Fuel Quantity Indicator	Liquidometer
EA-101A	Indicator	Liquidometer
EA101AN-107	Fuel Quantity Indicator	Liquidometer
EA101AN-89	Fuel Quantity Indicator	Liquidometer
EA102AN-10	Fuel Quantity Indicator	Liquidometer
EA102AN-27	Fuel Quantity Indicator	Liquidometer
EA102AN-29	Fuel Quantity Indicator	Liquidometer
EA102AN-44	Fuel Quantity Indicator	Liquidometer
EA102AN-54	Fuel Quantity Indicator	Liquidometer
EA102AN-65	Fuel Quantity Indicator	Liquidometer
EA102AN-82	Fuel Quantity Indicator	Liquidometer
EA102AN-83	Fuel Quantity Indicator	Liquidometer
EA102ANH-116	Fuel Quantity Indicator	Liquidometer
EA1030-792	Fuel Quantity Tank Unit	Liquidometer
EA1030-792M	Fuel Quantity Tank Unit	Liquidometer
EA1030-793	Fuel Quantity Tank Unit	Liquidometer
EA1030-793M	Fuel Quantity Tank Unit	Liquidometer
EA1030-794	Fuel Quantity Tank Unit	Liquidometer
EA1030-794M	Fuel Quantity Tank Unit	Liquidometer
EA1030-795	Fuel Quantity Tank Unit	Liquidometer
EA1030-795M	Fuel Quantity Tank Unit	Liquidometer
EA1030-796	Fuel Quantity Tank Unit	Liquidometer
EA1030-796M	Fuel Quantity Tank Unit	Liquidometer
EA1030-797	Fuel Quantity Tank Unit	Liquidometer
EA1030-797M	Fuel Quantity Tank Unit	Liquidometer
EA1060-1520	Fuel Quantity Tank Unit	Liquidometer
EA1060A-872	Fuel Quantity Tank Unit	Liquidometer
EA1060A-872A	Fuel Quantity Tank Unit	Liquidometer
EA1060AW-1362AB	Fuel Quantity Tank Unit	Liquidometer
EA1060B-818A	Fuel Quantity Tank Unit	Liquidometer
EA1060B-819A	Fuel Quantity Tank Unit	Liquidometer
EA1060B-820A	Fuel Quantity Tank Unit	Liquidometer
EA1060B-822A	Fuel Quantity Tank Unit	Liquidometer
EA1060B-823A	Fuel Quantity Tank Unit	Liquidometer
EA1060B-870	Fuel Quantity Tank Unit	Liquidometer

EA1060B-871	Fuel Quantity Tank Unit	Liquidometer
EA1060B-874	Fuel Quantity Tank Unit	Liquidometer

Primary Part Number	Nomenclature	Manufacture
EA1060B-875	Fuel Quantity Tank Unit	Liquidometer
EA1060W-1362A	Fuel Quantity Tank Unit	Liquidometer
EA1060W-821A	Fuel Quantity Tank Unit	Liquidometer
EA1060W-821AB	Fuel Quantity Tank Unit	Liquidometer
EA1060W-873	Fuel Quantity Tank Unit	Liquidometer
EA1060W-873A	Fuel Quantity Tank Unit	Liquidometer
EA1060W-873AB	Fuel Quantity Tank Unit	Liquidometer
EA1061B-817A	Fuel Quantity Tank Unit	Liquidometer
EA1061B-824A	Fuel Quantity Tank Unit	Liquidometer
EA1061B-869	Fuel Quantity Tank Unit	Liquidometer
EA1061B-876	Fuel Quantity Tank Unit	Liquidometer
EA1062A-997A	Fuel Quantity Tank Unit	Liquidometer
EA1062A-998A	Fuel Quantity Tank Unit	Liquidometer
EA1065A-2406	Water Quantity Tank Unit	Simmonds
EA1065A-2721	Water Quantity Tank Unit	Simmonds
EA1065A-2745	Water Quantity Tank Unit	Simmonds
EA1065AW-1827	Oil Quantity Tank Unit	Liquidometer
EA1065AW-1894	Fuel Quantity Tank Unit	Liquidometer
EA1065AW-2315	Fuel Quantity Tank Unit	Simmonds
EA1068A-2313	Engine Oil Quantity Trans.	Liquidometer
EA1068A-2352	Engine Oil Quantity Trans.	Liquidometer
EA1093A-3544	Liquid Quantity Transmitter	Simmonds
EA1093A-3679	Liquid Quantity Transmitter	Simmonds
EA124AN-10	Fuel Quantity Indicator	Liquidometer
EA124AN-100	Fuel Quantity Indicator	Liquidometer
EA124AN-103	Fuel Quantity Indicator	Liquidometer
EA124AN-105	Fuel Quantity Indicator	Liquidometer
EA124AN-105A	Fuel Quantity Indicator	Liquidometer
EA124AN-108	Fuel Quantity Indicator	Liquidometer
EA124AN-11	Fuel Quantity Indicator	Liquidometer
EA124AN-110	Fuel Quantity Indicator	Liquidometer
EA124AN-111	Fuel Quantity Indicator	Liquidometer
EA124AN-112	Fuel Quantity Indicator	Liquidometer
EA124AN-115	Fuel Quantity Indicator	Liquidometer
EA124AN-29	Fuel Quantity Indicator	Liquidometer
EA124AN-40	Fuel Quantity Indicator	Liquidometer
EA124AN-74	Fuel Quantity Indicator	Liquidometer
EA124AN-83	Fuel Quantity Indicator	Liquidometer
EA124AN-93	Fuel Quantity Indicator	Liquidometer
EA124AN-P47	Fuel Quantity Indicator	Liquidometer
EA133AN-1	Fuel Quantity Indicator	Liquidometer
EA148AN-1	Fuel Quantity Indicator	Liquidometer
EA148AN-11	Fuel Quantity Indicator	Liquidometer
EA148AN-12	Fuel Quantity Indicator	Liquidometer

Primary Part Number	Nomenclature	Manufacture

EA148AN-13	Fuel Quantity Indicator	Liquidometer
EA148AN-16	Fuel Quantity Indicator	Liquidometer
EA148AN-36	Fuel Quantity Indicator	Liquidometer
EA148AN-40	Fuel Quantity Indicator	Liquidometer
EA148AN-42	Fuel Quantity Indicator	Liquidometer
EA148AN-43	Fuel Quantity Indicator	Liquidometer
EA148AN-46	Fuel Quantity Indicator	Liquidometer
EA148AN-47	Fuel Quantity Indicator	Liquidometer
EA148AN-51	Fuel Quantity Indicator	Liquidometer
EA148AN-71	Fuel Quantity Indicator	Liquidometer
EA148ANH-102H	Liquid Quantity Indicator	Liquidometer
EA148ANH-95H	Liquid Quantity Indicator	Liquidometer
EA148ANW-45	Fuel Quantity Indicator	Liquidometer
EA-15	Fuel Quantity Tank Unit	Liquidometer
EA150AN-13	Fuel Quantity Indicator	Liquidometer
EA150AN-14	Fuel Quantity Indicator	Liquidometer
EA150AN-15	Fuel Quantity Indicator	Liquidometer
EA150AN-31	Fuel Quantity Indicator	Liquidometer
EA150AN-32	Fuel Quantity Indicator	Liquidometer
EA150AN-48	Fuel Quantity Indicator	Liquidometer
EA150AN-49	Fuel Quantity Indicator	Liquidometer
EA150AN-54	Fuel Quantity Indicator	Liquidometer
EA150AN-55	Fuel Quantity Indicator	Liquidometer
EA150AN-56	Fuel Quantity Indicator	Liquidometer
EA150AN-58	Fuel Quantity Indicator	Liquidometer
EA150AN-60	Fuel Quantity Indicator	Liquidometer
EA15-219949	Fuel Quantity Tank Unit	Liquidometer
EA15-6-26076	Fuel Quantity Tank Unit	Liquidometer
EA15A-1407	Fuel Quantity Tank Unit	Liquidometer
EA15A-628039A	Fuel Quantity Tank Unit	Liquidometer
EA15B-628026	Fuel Quantity Tank Unit	Liquidometer
EA-16	Fuel Quantity Tank Unit	Liquidometer
EA1611-515	Fuel Quantity Tank Unit	Liquidometer
EA1612-18R-9714	Fuel Quantity Tank Unit	Liquidometer
EA1612-18R-9715	Fuel Quantity Tank Unit	Liquidometer
EA16-168159	Fuel Quantity Tank Unit	Liquidometer
EA16-168159-1	Fuel Quantity Tank Unit	Liquidometer
EA-17	Fuel Quantity Tank Unit	Liquidometer
EA-177	Fuel Quantity Tank Unit	Liquidometer
EA184-491	Fuel Quantity Tank Unit	Liquidometer
EA184W-492	Fuel Quantity Tank Unit	Liquidometer
EA18B-621	Fuel Quantity Tank Unit	Liquidometer
EA18B-692	Fuel Quantity Tank Unit	Liquidometer
EA18B-692M	Fuel Quantity Tank Unit	Liquidometer

Primary Part Number	Nomenclature	Manufacture
EA190W-586	Fuel Quantity Tank Unit	Liquidometer
EA228-10	Fuel Quantity Tank Unit	Liquidometer
EA228B-11	Fuel Quantity Tank Unit	Liquidometer
EA2520	Fuel Quantity Indicator	Cessna

EA2521	Fuel Quantity Indicator	Electric Auto-Lite Co
EA-2550	Fuel Quantity Indicator	Electric Auto-Lite Co
EA2551	Fuel Quantity Indicator	Cessna
EA303AN-1	Fuel Quantity Indicator	Liquidometer
EA303AN-3	Fuel Quantity Indicator	Liquidometer
EA31-1047	Fuel Quantity Indicator	Liquidometer
EA31-150	Fuel Quantity Indicator	Liquidometer
EA31-337-1FF	Fuel Quantity Indicator	Liquidometer
EA31-337-1RF	Fuel Quantity Indicator	Liquidometer
EA343	Fuel Quantity Indicator	Liquidometer
EA-35	Fuel Quantity Indicator	Liquidometer
EA-36	Fuel Quantity Indicator	Liquidometer
EA378A-545M	Fuel Quantity Tank Unit	Liquidometer
EA378A-546M	Fuel Quantity Tank Unit	Liquidometer
EA379A-1440	Fuel Quantity Tank Unit	Liquidometer
EA379A-547AM	Fuel Quantity Tank Unit	Liquidometer
EA379AC-547AM	Fuel Quantity Tank Unit	Liquidometer
EA379AC-547M	Fuel Quantity Tank Unit	Liquidometer
EA380-548AM	Fuel Quantity Tank Unit	Liquidometer
EA380-548M	Fuel Quantity Tank Unit	Liquidometer
EA380C-1441	Fuel Quantity Tank Unit	Liquidometer
EA380C-548ABM	Fuel Quantity Tank Unit	Liquidometer
EA380C-548AM	Fuel Quantity Tank Unit	Liquidometer
EA381-549AM	Fuel Quantity Tank Unit	Liquidometer
EA381-549M	Fuel Quantity Tank Unit	Liquidometer
EA-47008	Fuel Quantity Indicator	Liquidometer
EA470-3518	Fuel Quantity Tank Unit	Liquidometer
EA470-3587	Fuel Quantity Tank Unit	Liquidometer
EA470-3588	Fuel Quantity Tank Unit	Liquidometer
EA470B3519	Fuel Quantity Tank Unit	Liquidometer
EA470B3588	Fuel Quantity Tank Unit	Liquidometer
EA502C-608	Fuel Quantity Tank Unit	Liquidometer
EA502C-608A	Fuel Quantity Tank Unit	Liquidometer
EA503-729	Fuel Quantity Tank Unit	Liquidometer
EA515-320	Fuel Quantity Tank Unit	Liquidometer
EA515-544	Fuel Quantity Tank Unit	Liquidometer
EA515-677	Fuel Quantity Tank Unit	Liquidometer
EA515A-670	Fuel Quantity Tank Unit	Liquidometer
EA515AC-509L	Fuel Quantity Tank Unit	Liquidometer
EA515AC-509R	Fuel Quantity Tank Unit	Liquidometer

Primary Part Number	Nomenclature	Manufacture
EA515B-607	Fuel Quantity Tank Unit	Liquidometer
EA515B-695	Fuel Quantity Tank Unit	Liquidometer
EA515W-648	Fuel Quantity Tank Unit	Liquidometer
EA515WC-647	Fuel Quantity Tank Unit	Liquidometer
EA524A-309	Fuel Quantity Tank Unit	Liquidometer
EA528A-738	Fuel Quantity Tank Unit	Liquidometer
EA528AW-737	Fuel Quantity Tank Unit	Liquidometer
EA529BC-310	Fuel Quantity Tank Unit	Liquidometer

EA533-665	Fuel Quantity Tank Unit	Liquidometer
EA565-444	Fuel Quantity Tank Unit	Liquidometer
EA565-791	Fuel Quantity Tank Unit	Liquidometer
EA565A-766L	Fuel Quantity Tank Unit	Liquidometer
EA565A-766R	Fuel Quantity Tank Unit	Liquidometer
EA565A-767	Fuel Quantity Tank Unit	Liquidometer
EA565A-768	Fuel Quantity Tank Unit	Liquidometer
EA565AC-550	Fuel Quantity Tank Unit	Liquidometer
EA565AC-551	Fuel Quantity Tank Unit	Liquidometer
EA565AC-552L	Fuel Quantity Tank Unit	Liquidometer
EA565AC-552R	Fuel Quantity Tank Unit	Liquidometer
EA565B-446	Fuel Quantity Tank Unit	Liquidometer
EA565BC-446	Fuel Quantity Tank Unit	Liquidometer
EA565BP-447	Fuel Quantity Tank Unit	Liquidometer
EA565C-245	Fuel Quantity Tank Unit	Liquidometer
EA565C-443	Fuel Quantity Tank Unit	Liquidometer
EA565C-445	Fuel Quantity Tank Unit	Liquidometer
EA565P-414	Fuel Quantity Tank Unit	Liquidometer
EA565P-676	Fuel Quantity Tank Unit	Liquidometer
EA565P-991	Fuel Quantity Tank Unit	Liquidometer
EA565PC-442	Fuel Quantity Tank Unit	Liquidometer
EA565W-1311	Fuel Quantity Tank Unit	Liquidometer
EA565W-1339	Fuel Quantity Tank Unit	Liquidometer
EA565W-1345	Fuel Quantity Tank Unit	Liquidometer
EA565W-269	Fuel Quantity Tank Unit	Liquidometer
EA565W-553	Fuel Quantity Tank Unit	Liquidometer
EA565WP-675	Fuel Quantity Tank Unit	Liquidometer
EA584-786	Fuel Quantity Tank Unit	Liquidometer
EA584A-1361	Fuel Quantity Tank Unit	Liquidometer
EA584A-681	Fuel Quantity Tank Unit	Liquidometer
EA584A-787	Fuel Quantity Tank Unit	Liquidometer
EA584A-815L	Fuel Quantity Tank Unit	Liquidometer
EA584A-815R	Fuel Quantity Tank Unit	Liquidometer
EA584A-852L	Fuel Quantity Tank Unit	Liquidometer
EA584A-852R	Fuel Quantity Tank Unit	Liquidometer
EA584AC-752L	Fuel Quantity Tank Unit	Liquidometer

Primary Part Number	Nomenclature	Manufacture
EA584AC-752R	Fuel Quantity Tank Unit	Liquidometer
EA584BC-540	Fuel Quantity Tank Unit	Liquidometer
EA584BC-540R	Fuel Quantity Tank Unit	Liquidometer
EA584BC-827	Fuel Quantity Tank Unit	Liquidometer
EA585A-694L	Fuel Quantity Tank Unit	Liquidometer
EA585A-694R	Fuel Quantity Tank Unit	Liquidometer
EA588AP-639	Fuel Quantity Tank Unit	Liquidometer
EA589DP-640	Fuel Quantity Tank Unit	Liquidometer
EA58BC-764	Fuel Quantity Tank Unit	Liquidometer
EA590A-478	Fuel Quantity Tank Unit	Liquidometer
EA590A-479	Fuel Quantity Tank Unit	Liquidometer
EA590A-480L	Fuel Quantity Tank Unit	Liquidometer

EA590A-480R	Fuel Quantity Tank Unit	Liquidometer
EA590P-611	Fuel Quantity Tank Unit	Liquidometer
EA591B-539	Fuel Quantity Tank Unit	Liquidometer
EA592A-328	Fuel Quantity Tank Unit	Liquidometer
EA592A-594	Fuel Quantity Tank Unit	Liquidometer
EA65-4222324	Fuel Quantity Tank Unit	Liquidometer
EA-65AWC	Fuel Quantity Tank Unit	Liquidometer
EA65W-613	Fuel Quantity Tank Unit	Liquidometer
EA711ANH-1	Fuel Quantity Indicator	Liquidometer
EA711-C-5	Fuel Quantity Indicator	Liquidometer
EA711-M-1	Fuel Quantity Indicator	Liquidometer
EA727K-1	Fuel Quantity Indicator	Liquidometer
EA727K-2	Fuel Quantity Indicator	Liquidometer
EA727K-3	Fuel Quantity Indicator	Liquidometer
EA727KA-4	Fuel Quantity Indicator	Liquidometer
EA727KA-6	Fuel Quantity Indicator	Liquidometer
EA727KA-7	Fuel Quantity Indicator	Liquidometer
EA727M-18	Fuel Quantity Indicator	Liquidometer
EA730D-811	Fuel Quantity Indicator	Liquidometer
EA730D-812	Fuel Quantity Indicator	Liquidometer
EA730D-842A	Fuel Quantity Indicator	Liquidometer
EA730D-843A	Fuel Quantity Indicator	Liquidometer
EA730D-845A	Fuel Quantity Indicator	Liquidometer
EA730D-846A	Fuel Quantity Indicator	Liquidometer
EA730D-847A	Fuel Quantity Indicator	Liquidometer
EA737AA-1	Fuel Quantity Indicator	Liquidometer
EA737AA-2	Fuel Quantity Indicator	Liquidometer
EA737BB-1A	Fuel Quantity Indicator	Liquidometer
EA755AA-1	Fuel Quantity Indicator	Liquidometer
EA755AA-14	Fuel Quantity Indicator	Liquidometer
EA755AA-1S-16	Fuel Quantity Indicator	Liquidometer
EA755AA-2	Fuel Quantity Indicator	Liquidometer

Primary Part Number	Nomenclature	Manufacture
EA755AA-4	Fuel Quantity Indicator	Liquidometer
EA755AA-6	Fuel Quantity Indicator	Liquidometer
EA764-920	Fuel Quantity Indicator	Liquidometer
EA768-853	Fuel Quantity Indicator	Liquidometer
EA768-854	Fuel Quantity Indicator	Liquidometer
EA768-855	Fuel Quantity Indicator	Liquidometer
EA768-974	Fuel Quantity Indicator	Liquidometer
EA768A-1367AB	Fuel Quantity Tank Unit	Liquidometer
EA7722856	Fuel Quantity Indicator	Honeywell
EA774-1080	Fuel Quantity Indicator	Liquidometer
EA774-1081	Fuel Quantity Indicator	Liquidometer
EA774-1082	Fuel Quantity Indicator	Liquidometer
EA774-961	Fuel Quantity Indicator	Liquidometer
EA774-993	Fuel Quantity Indicator	Liquidometer
EA796JJB-1421	Fuel Quantity Indicator	Liquidometer
EA799KJN-1422	Fuel Quantity Indicator	Liquidometer

EA821-798	Fuel Quantity Tank Unit	Liquidometer
EA828-799	Fuel Quantity Tank Unit	Liquidometer
EA84AW-307	Fuel Quantity Tank Unit	Liquidometer
EA84AW-308	Fuel Quantity Tank Unit	Liquidometer
EA84AW-396L	Fuel Quantity Tank Unit	Liquidometer
EA84AW-396R	Fuel Quantity Tank Unit	Liquidometer
EA84AW-397	Fuel Quantity Tank Unit	Liquidometer
EA85A-574	Fuel Quantity Tank Unit	Liquidometer
EA85A-742	Fuel Quantity Tank Unit	Liquidometer
EA85-P47A	Fuel Quantity Tank Unit	Liquidometer
EA85W-622	Fuel Quantity Tank Unit	Liquidometer
EA85W-702	Fuel Quantity Tank Unit	Liquidometer
EA85WC-943	Fuel Quantity Tank Unit	Liquidometer
EA85WC-943A	Fuel Quantity Tank Unit	Liquidometer
EA910CC-18	Fuel Quantity Amplifier	Liquidometer
EA960B-1224	Fuel Quantity Indicator	Liquidometer
EA960B-1225	Fuel Quantity Indicator	Liquidometer
EA960C-1223	Fuel Quantity Indicator	Liquidometer
EA961A-1221	Fuel Quantity Indicator	Liquidometer
EA961A-1222	Fuel Quantity Indicator	Liquidometer
EG5A	Fuel Quantity Power Supply	Honeywell
EG5A-1	Fuel Quantity Power Supply	Honeywell
EG5A-10	Fuel Quantity Power Supply	Honeywell
EG5A-11	Fuel Quantity Power Supply	Honeywell
EG5A-12	Fuel Quantity Power Supply	Honeywell
EG5A-2	Fuel Quantity Power Supply	Honeywell
EG5A-3	Fuel Quantity Power Supply	Honeywell
EG5A-4	Fuel Quantity Power Supply	Honeywell

Primary Part Number	Nomenclature	Manufacture
EG5A-5	Fuel Quantity Power Supply	Honeywell
EG5A-6	Fuel Quantity Power Supply	Honeywell
EG5A-7	Fuel Quantity Power Supply	Honeywell
EG5A-8	Fuel Quantity Power Supply	Honeywell
EG5A-9	Fuel Quantity Power Supply	Honeywell
EG5B	Fuel Quantity Power Supply	Honeywell
EG5B-1	Fuel Quantity Power Supply	Honeywell
EG5B-2	Fuel Quantity Power Supply	Honeywell
EG5B-3	Fuel Quantity Power Supply	Honeywell
EG5B-4	Fuel Quantity Power Supply	Honeywell
EG5B-5	Fuel Quantity Power Supply	Honeywell
EG5B-6	Fuel Quantity Power Supply	Honeywell
FG120A	Fuel Quantity Tank Unit	Honeywell
FG120A-10	Fuel Quantity Tank Unit	Honeywell
FG120A-11	Fuel Quantity Tank Unit	Honeywell
FG120A-12	Fuel Quantity Tank Unit	Honeywell
FG120A-19	Fuel Quantity Tank Unit	Honeywell
FG120C	Fuel Quantity Tank Unit	Honeywell
FG120C-17	Fuel Quantity Tank Unit	Honeywell
FG120C-18	Fuel Quantity Tank Unit	Honeywell

FG120C-22	Fuel Quantity Tank Unit	Honeywell
FG120C-23	Fuel Quantity Tank Unit	Honeywell
FG1A-1	Compensator	Honeywell
FG1A-4	Compensator	Honeywell
FG220A100	Tank Unit	Honeywell
FG220A101	Tank Unit	Honeywell
FG220A102	Tank Unit	Honeywell
FG220A103	Tank Unit	Honeywell
FG220A104	Tank Unit	Honeywell
FG220A105	Tank Unit	Honeywell
FG220A106	Tank Unit	Honeywell
FG220A107	Tank Unit	Honeywell
FG220A108	Tank Unit	Honeywell
FG220A109	Tank Unit	Honeywell
FG220A110	Tank Unit	Honeywell
FG220A111	Tank Unit	Honeywell
FG220A112	Tank Unit	Honeywell
FG220A113	Tank Unit	Honeywell
FG220A114	Tank Unit	Honeywell
FG220A115	Tank Unit	Honeywell
FG220A155	Tank Unit	Honeywell
FG220A156	Tank Unit	Honeywell
FG220A175	Tank Unit	Honeywell
FG220A176	Tank Unit	Honeywell

Primary Part Number	Nomenclature	Manufacture
FG220A177	Tank Unit	Honeywell
FG220A178	Tank Unit	Honeywell
FG220A179	Tank Unit	Honeywell
FG220A192	Tank Unit	Honeywell
FG220A193	Tank Unit	Honeywell
FG220A194	Tank Unit	Honeywell
FG220A195	Tank Unit	Honeywell
FG220A196	Tank Unit	Honeywell
FG220A197	Tank Unit	Honeywell
FG220A198	Tank Unit	Honeywell
FG220A199	Tank Unit	Honeywell
FG220A200	Tank Unit	Honeywell
FG220A201	Tank Unit	Honeywell
FG220A202	Tank Unit	Honeywell
FG220A203	Tank Unit	Honeywell
FG220A204	Tank Unit	Honeywell
FG220A205	Tank Unit	Honeywell
FG220A206	Tank Unit	Honeywell
FG220A207	Tank Unit	Honeywell
FG220A208	Tank Unit	Honeywell
FG220A209	Tank Unit	Honeywell
FG220A210	Tank Unit	Honeywell
FG220A211	Tank Unit	Honeywell
FG220A212	Tank Unit	Honeywell

FG220A213	Tank Unit	Honeywell
FG220A214	Tank Unit	Honeywell
FG220A215	Tank Unit	Honeywell
FG220A216	Tank Unit	Honeywell
FG220A237	Tank Unit	Honeywell
FG220A238	Tank Unit	Honeywell
FG220A239	Tank Unit	Honeywell
FG220A240	Tank Unit	Honeywell
FG220A241	Tank Unit	Honeywell
FG220A242	Tank Unit	Honeywell
FG220A243	Tank Unit	Honeywell
FG220A244	Tank Unit	Honeywell
FG220A245	Tank Unit	Honeywell
FG220A246	Tank Unit	Honeywell
FG220A247	Tank Unit	Honeywell
FG220A248	Tank Unit	Honeywell
FG220A249	Tank Unit	Honeywell
FG220A250	Tank Unit	Honeywell
FG220A251	Tank Unit	Honeywell
FG220A252	Tank Unit	Honeywell

Primary Part Number	Nomenclature	Manufacture
FG220A253	Tank Unit	Honeywell
FG220A254	Tank Unit	Honeywell
FG220A255	Tank Unit	Honeywell
FG220A256	Tank Unit	Honeywell
FG220A257	Tank Unit	Honeywell
FG220A60	Fuel Quantity Tank Unit	Honeywell
FG220A61	Tank Unit	Honeywell
FG220A62	Tank Unit	Honeywell
FG220A63	Tank Unit	Honeywell
FG220A64	Tank Unit	Honeywell
FG220A65	Tank Unit	Honeywell
FG220A66	Tank Unit	Honeywell
FG220A67	Tank Unit	Honeywell
FG220A68	Tank Unit	Honeywell
FG220A75	Tank Unit	Honeywell
FG220A76	Tank Unit	Honeywell
FG220A83	Tank Unit	Honeywell
FG220A95	Tank Unit	Honeywell
FG220A96	Tank Unit	Honeywell
FG220A97	Tank Unit	Honeywell
FG220A98	Tank Unit	Honeywell
FG220A99	Tank Unit	Honeywell
FG250A42	Fuel Quantity Indicator	Honeywell
FG250A43	Fuel Quantity Indicator	Honeywell
FG250A44	Fuel Quantity Indicator	Honeywell
FG250A51	Fuel Quantity Indicator	Honeywell
FG250A53	Fuel Quantity Indicator	Honeywell
FG250A6	Fuel Quantity Indicator	Honeywell

FG250A7	Fuel Quantity Indicator	Honeywell
FG250A8	Fuel Quantity Indicator	Honeywell
FG430A237	Fuel Quantity Indicator	Honeywell
FG430A238	Fuel Quantity Indicator	Honeywell
FG430A239	Fuel Quantity Indicator	Honeywell
FG430A240	Tank Unit	Honeywell
FG430A241	Tank Unit	Honeywell
FG430A242	Tank Unit	Honeywell
FG430A243	Tank Unit	Honeywell
FG430A244	Tank Unit	Honeywell
FG430A245	Tank Unit	Honeywell
FG430A246	Tank Unit	Honeywell
FG430A247	Tank Unit	Honeywell
FG430A248	Tank Unit	Honeywell
FG430A249	Tank Unit	Honeywell
FG430A250	Tank Unit	Honeywell

Primary Part Number	Nomenclature	Manufacture
FG430A251	Tank Unit	Honeywell
FG430A252	Tank Unit	Honeywell
FG430A253	Tank Unit	Honeywell
FG430A254	Tank Unit	Honeywell
FG430A255	Tank Unit	Honeywell
FG430A256	Tank Unit	Honeywell
FG430A257	Tank Unit	Honeywell
FG430A260	Fuel Quantity	Honeywell
FG430A261	Fuel Quantity	Honeywell
FG450A51	Fuel Quantity Indicator	Honeywell
FG450A53	Fuel Quantity Indicator	Honeywell
FG8B	Tank Unit	Honeywell
FG9A	Tank Unit	Honeywell
FG9B	Tank Unit	Honeywell
FGG8A	Tank Unit	Honeywell
FJ250A43	Fuel Quantity Indicator	Honeywell
G1098B	Fuel Quantity Tank Unit	Honeywell
G1098C	Fuel Quantity Tank Unit	Honeywell
G1098C-10	Fuel Quantity Tank Unit	Honeywell
G1098C-14	Fuel Quantity Tank Unit	Honeywell
G1098C-9	Fuel Quantity Tank Unit	Honeywell
G1098D	Fuel Quantity Tank Unit	Honeywell
G1099B	Fuel Quantity Calibration Unit	Honeywell
G1099C	Fuel Quantity Calibration Unit	Honeywell
G413A	Fuel Quantity Amplifier	Honeywell
G700A	Fuel Quantity Indicator	Honeywell
G700B	Fuel Quantity Indicator	Honeywell
G700C	Fuel Quantity Indicator	Honeywell
GMU-28/A	Liquid Qxygen Qty Indicator	Penn Airborne
GMU-28A/A	Liquid Qxygen Qty Indicator	Penn Airborne
GMU-34/A	Liquid Qxygen Qty Indicator	Penn Airborne
GMU-34A/A	Liquid Qxygen Qty Indicator	Penn Airborne

GMU-37/A	Liquid Qxygen Qty Indicator	Penn Airborne
GMU-37/A(NATO)	Liquid Qxygen Qty Indicator	Penn Airborne
GMU-5/A	Liquid Qxygen Qty Indicator	Penn Airborne
GMU-59/A	Liquid Qxygen Qty Indicator	Penn Airborne
HT-108	Fuel Quantity Indicator	Honeywell
JG130A15	Fuel Quantity Indicator	Honeywell
JG130A68	Fuel Quantity Indicator	Honeywell
JG130C1	Oil Quantity Indicator	Honeywell
JG130C2	Oil Quantity Indicator	Honeywell
JG130C5	Oil Quantity Indicator	Honeywell
JG130C9	Oil Quantity Indicator	Honeywell
JG131A1	Fuel Quantity Indicator	Honeywell

Primary Part Number	Nomenclature	Manufacture
JG131A10	Fuel Quantity Indicator	Honeywell
JG131A2	Fuel Quantity Indicator	Honeywell
JG131A28	Fuel Quantity Indicator	Honeywell
JG131A29	Fuel Quantity Indicator	Honeywell
JG131A3	Fuel Quantity Indicator	Honeywell
JG131A30	Fuel Quantity Indicator	Honeywell
JG131A31	Fuel Quantity Indicator	Honeywell
JG131A33	Fuel Quantity Indicator	Honeywell
JG131A35	Fuel Quantity Indicator	Honeywell
JG131A36	Fuel Quantity Indicator	Honeywell
JG131A37	Fuel Quantity Indicator	Honeywell
JG131A38	Fuel Quantity Indicator	Honeywell
JG131A4	Fuel Quantity Indicator	Honeywell
JG131A40	Fuel Quantity Indicator	Honeywell
JG131A41	Fuel Quantity Indicator	Honeywell
JG131A42	Fuel Quantity Indicator	Honeywell
JG131A43	Fuel Quantity Indicator	Honeywell
JG131A45	Fuel Quantity Indicator	Honeywell
JG131A5	Fuel Quantity Indicator	Honeywell
JG131A51	Fuel Quantity Indicator	Honeywell
JG131A53	Fuel Quantity Indicator	Honeywell
JG131A54	Fuel Quantity Indicator	Honeywell
JG131A55	Fuel Quantity Indicator	Honeywell
JG131A56	Fuel Quantity Indicator	Honeywell
JG131A57	Fuel Quantity Indicator	Honeywell
JG131A58	Fuel Quantity Indicator	Honeywell
JG131A59	Fuel Quantity Indicator	Honeywell
JG131A6	Fuel Quantity Indicator	Honeywell
JG131A60	Fuel Quantity Indicator	Honeywell
JG131A61	Fuel Quantity Indicator	Honeywell
JG131A67	Fuel Quantity Indicator	Honeywell
JG131A68	Fuel Quantity Indicator	Honeywell
JG131A69	Fuel Quantity Indicator	Honeywell
JG131A70	Fuel Quantity Indicator	Honeywell
JG131A71	Fuel Quantity Indicator	Honeywell
JG131A73	Fuel Quantity Indicator	Honeywell

JG131A74	Fuel Quantity Indicator	Honeywell
JG131A75	Fuel Quantity Indicator	Honeywell
JG131A76	Fuel Quantity Indicator	Honeywell
JG131A77	Fuel Quantity Indicator	Honeywell
JG131A79	Fuel Quantity Indicator	Honeywell
JG131A8	Fuel Quantity Indicator	Honeywell
JG131A80	Fuel Quantity Indicator	Honeywell
JG131A83	Fuel Quantity Indicator	Honeywell

Primary Part Number	Nomenclature	Manufacture
JG131A9	Fuel Quantity Indicator	Honeywell
JG141A2	Fuel Quantity Indicator	Honeywell
JG180A5	Liquid Qxygen Qty Indicator	Honeywell
JG3B10	Fuel Quantity Indicator	Honeywell
JG3B11	Fuel Quantity Indicator	Honeywell
JG3B12	Fuel Quantity Indicator	Honeywell
JG3B9	Fuel Quantity Indicator	Honeywell
JG4011	Fuel Quantity Indicator	Honeywell
JG402A	Fuel Quantity Indicator	Honeywell
JG402A2	Fuel Quantity Indicator	Honeywell
JG402A21	Fuel Quantity Indicator	Honeywell
JG402A22	Fuel Quantity Indicator	Honeywell
JG402A23	Fuel Quantity Indicator	Honeywell
JG402A24	Fuel Quantity Indicator	Honeywell
JG402A25	Fuel Quantity Indicator	Honeywell
JG402A3	Fuel Quantity Indicator	Honeywell
JG402A32	Fuel Quantity Indicator	Honeywell
JG402A4	Fuel Quantity Indicator	Honeywell
JG402A52	Fuel Quantity Indicator	Honeywell
JG402A53	Fuel Quantity Indicator	Honeywell
JG402A54	Fuel Quantity Indicator	Honeywell
JG402A55	Fuel Quantity Indicator	Honeywell
JG410A2	Fuel Quantity Indicator	Honeywell
JG410B1	Fuel Quantity Indicator	Honeywell
JG411A1	Fuel Quantity Indicator	Honeywell
JG412A	Fuel Quantity Indicator	Honeywell
JG412A1	Fuel Quantity Indicator	Honeywell
JG412A10	Fuel Quantity Indicator	Honeywell
JG412A11	Fuel Quantity Indicator	Honeywell
JG412A2	Fuel Quantity Indicator	Honeywell
JG412A3	Fuel Quantity Indicator	Honeywell
JG412A4	Fuel Quantity Indicator	Honeywell
JG412A52	Fuel Quantity Indicator	Honeywell
JG412A53	Fuel Quantity Indicator	Honeywell
JG412A54	Fuel Quantity Indicator	Honeywell
JG412A55	Fuel Quantity Indicator	Honeywell
JG412A56	Fuel Quantity Indicator	Honeywell
JG4A16	Fuel Quantity Indicator	Honeywell
JG4B1	Fuel Quantity Indicator	Honeywell
JG4B-1	Fuel Quantity Indicator	Honeywell

Primary Part Number	Nomenclature	Manufacturer
JG4B9	Fuel Quantity Indicator	Honeywell
JG603C2	Fuel Quantity Indicator	Honeywell
JG603C3	Fuel Quantity Indicator	Honeywell
JG603C4	Fuel Quantity Indicator	Honeywell
JG603C42	Fuel Quantity Indicator	Honeywell
JG603C43	Fuel Quantity Indicator	Honeywell
JG603C44	Fuel Quantity Indicator	Honeywell
JG603C51	Fuel Quantity Indicator	Honeywell
JG603C52	Fuel Quantity Indicator	Honeywell
JG603C67	Fuel Quantity Indicator	Honeywell
JG603C70	Fuel Quantity Indicator	Honeywell
JG603C73	Fuel Quantity Indicator	Honeywell
JG603C78	Fuel Quantity Indicator	Honeywell
JG603C80	Fuel Quantity Indicator	Honeywell
JG603C81	Fuel Quantity Indicator	Honeywell
JG7013A	Fuel Quantity Tank Unit	Honeywell
JG7013A-20	Fuel Quantity Tank Unit	Honeywell
JG7013A-37	Fuel Quantity Tank Unit	Honeywell
JG7013A-39	Fuel Quantity Tank Unit	Honeywell
JG7013A-40	Fuel Quantity Tank Unit	Honeywell
JG7013A-41	Fuel Quantity Tank Unit	Honeywell
JG7013A-42	Fuel Quantity Tank Unit	Honeywell
JG7013A-43	Fuel Quantity Tank Unit	Honeywell
JG7013A-50	Fuel Quantity Tank Unit	Honeywell
JG7013A-51	Fuel Quantity Tank Unit	Honeywell
JG7013B-13	Fuel Quantity Indicator	Honeywell
JG7016A	Fuel Quantity Tank Unit	Honeywell
JG7016A-2	Fuel Quantity Tank Unit	Honeywell
JG7016A-5	Fuel Quantity Tank Unit	Honeywell
JG7016A-8	Fuel Quantity Tank Unit	Honeywell
JG7017A	Fuel Quantity Tank Unit	Honeywell
JG7017A-10	Fuel Quantity Indicator	Honeywell
JG7017A-22	Fuel Quantity Tank Unit	Honeywell
JG7017A-24	Fuel Quantity Tank Unit	Honeywell
JG7017A-9	Fuel Quantity Indicator	Honeywell
JG7019A	Fuel Quantity Indicator	Honeywell
JG7019A-16	Fuel Quantity Indicator	Honeywell
JG7019A-17	Fuel Quantity Indicator	Honeywell
JG7019A-24	Fuel Quantity Indicator	Honeywell
JG7019A-25	Fuel Quantity Indicator	Honeywell
JG7019A-26	Fuel Quantity Indicator	Honeywell
JG7019A-27	Fuel Quantity Indicator	Honeywell
JG7020A	Fuel Quantity Indicator	Honeywell
JG7020A-10	Fuel Quantity Indicator	Honeywell
JG7020A-11	Fuel Quantity Indicator	Honeywell
JG7020A-12	Fuel Quantity Indicator	Honeywell
JG7020A-25	Fuel Quantity Indicator	Honeywell
JG7020A-26	Fuel Quantity Indicator	Honeywell

Primary Part Number	Nomenclature	Manufacture
JG7020A-27	Fuel Quantity Indicator	Honeywell
JG7020A-28	Fuel Quantity Indicator	Honeywell
JG7020A-29	Fuel Quantity Indicator	Honeywell
JG7020A-30	Fuel Quantity Indicator	Honeywell
JG7020A-31	Fuel Quantity Indicator	Honeywell
JG7020A-32	Fuel Quantity Indicator	Honeywell
JG7020A-7	Fuel Quantity Indicator	Honeywell
JG7020C	Fuel Quantity Indicator	Honeywell
JG7021A	Fuel Quantity Indicator	Honeywell
JG7021A16	Fuel Quantity Indicator	Honeywell
JG7021A17	Fuel Quantity Indicator	Honeywell
JG7021A18	Fuel Quantity Indicator	Honeywell
JG7021A-19	Fuel Quantity Indicator	Honeywell
JG7021A2	Fuel Quantity Indicator	Honeywell
JG7021A20	Fuel Quantity Indicator	Honeywell
JG7021A21	Fuel Quantity Indicator	Honeywell
JG7021A22	Fuel Quantity Indicator	Honeywell
JG7021A23	Fuel Quantity Indicator	Honeywell
JG7021A24	Fuel Quantity Indicator	Honeywell
JG7021A25	Fuel Quantity Indicator	Honeywell
JG7021A26	Fuel Quantity Indicator	Honeywell
JG7021A27	Fuel Quantity Indicator	Honeywell
JG7021A28	Fuel Quantity Indicator	Honeywell
JG7021A29	Fuel Quantity Indicator	Honeywell
JG7021A3	Fuel Quantity Indicator	Honeywell
JG7021A31	Fuel Quantity Indicator	Honeywell
JG7021A32	Fuel Quantity Indicator	Honeywell
JG7021A33	Fuel Quantity Indicator	Honeywell
JG7021A34	Fuel Quantity Indicator	Honeywell
JG7021A35	Fuel Quantity Indicator	Honeywell
JG7021A36	Fuel Quantity Indicator	Honeywell
JG7021A37	Fuel Quantity Indicator	Honeywell
JG7021A38	Fuel Quantity Indicator	Honeywell
JG7021A39	Fuel Quantity Indicator	Honeywell
JG7021A40	Fuel Quantity Indicator	Honeywell
JG7021A46	Fuel Quantity Indicator	Honeywell
JG7021A47	Fuel Quantity Indicator	Honeywell
JG7021A48	Fuel Quantity Indicator	Honeywell
JG7021A50	Fuel Quantity Indicator	Honeywell
JG7021A52	Fuel Quantity Indicator	Honeywell
JG7021A53	Fuel Quantity Indicator	Honeywell
JG7021A54	Fuel Quantity Indicator	Honeywell
JG7021A55	Fuel Quantity Indicator	Honeywell
JG7021A56	Fuel Quantity Indicator	Honeywell

Primary Part Number	Nomenclature	Manufacture
JG7021A57	Fuel Quantity Indicator	Honeywell
JG7021A58	Fuel Quantity Indicator	Honeywell

JG7021A59	Fuel Quantity Indicator	Honeywell
JG7021A6	Fuel Quantity Indicator	Honeywell
JG7021A60	Fuel Quantity Indicator	Honeywell
JG7021A61	Fuel Quantity Indicator	Honeywell
JG7021A62	Fuel Quantity Indicator	Honeywell
JG7021A63	Fuel Quantity Indicator	Honeywell
JG7021A64	Fuel Quantity Indicator	Honeywell
JG7021A65	Fuel Quantity Indicator	Honeywell
JG7021A66	Fuel Quantity Indicator	Honeywell
JG7021A67	Fuel Quantity Indicator	Honeywell
JG7021A68	Fuel Quantity Indicator	Honeywell
JG7021A69	Fuel Quantity Indicator	Honeywell
JG7021A7	Fuel Quantity Indicator	Honeywell
JG7021A70	Fuel Quantity Indicator	Honeywell
JG7021A71	Fuel Quantity Indicator	Honeywell
JG7021A72	Fuel Quantity Indicator	Honeywell
JG7021A73	Fuel Quantity Indicator	Honeywell
JG7021A74	Fuel Quantity Indicator	Honeywell
JG7021A75	Fuel Quantity Indicator	Honeywell
JG7021A76	Fuel Quantity Indicator	Honeywell
JG7021A77	Fuel Quantity Indicator	Honeywell
JG7021A78	Fuel Quantity Indicator	Honeywell
JG7021A79	Fuel Quantity Indicator	Honeywell
JG7021A8	Fuel Quantity Indicator	Honeywell
JG7021A80	Fuel Quantity Indicator	Honeywell
JG7021A81	Fuel Quantity Indicator	Honeywell
JG7021A82	Fuel Quantity Indicator	Honeywell
JG7021A83	Fuel Quantity Indicator	Honeywell
JG7021A84	Fuel Quantity Indicator	Honeywell
JG7021A85	Fuel Quantity Indicator	Honeywell
JG7021A86	Fuel Quantity Indicator	Honeywell
JG7021A87	Fuel Quantity Indicator	Honeywell
JG7021A88	Fuel Quantity Indicator	Honeywell
JG7021A89	Fuel Quantity Indicator	Honeywell
JG7021A90	Fuel Quantity Indicator	Honeywell
JG7021A91	Fuel Quantity Indicator	Honeywell
JG7021A94	Fuel Quantity Indicator	Honeywell
JG7021A96	Fuel Quantity Indicator	Honeywell
JG7021B-1	Fuel/Oil Quantity Indicator	Honeywell
JG7021B-10	Fuel/Oil Quantity Indicator	Honeywell
JG7021B-11	Fuel/Oil Quantity Indicator	Honeywell
JG7021B-12	Fuel/Oil Quantity Indicator	Honeywell

Primary Part Number	Nomenclature	Manufacture
JG7021B-13	Fuel/Oil Quantity Indicator	Honeywell
JG7021B-14	Fuel/Oil Quantity Indicator	Honeywell
JG7021B-2	Fuel/Oil Quantity Indicator	Honeywell
JG7021B-3	Fuel/Oil Quantity Indicator	Honeywell
JG7021B-6	Fuel Quantity Indicator	Honeywell
JG7021B-7	Fuel/Oil Quantity Indicator	Honeywell

JG7021B-9	Fuel/Oil Quantity Indicator	Honeywell
JG7021C	Fuel Quantity Indicator	Honeywell
JG7023A	Fuel Quantity Tank Unit	Honeywell
JG7031A	Compensator	Honeywell
JG7039A	Fuel Quantity Tank Unit	Honeywell
JG7039B	Fuel Quantity Tank Unit	Honeywell
JG7039C	Fuel Quantity Tank Unit	Honeywell
JG7039D	Fuel Quantity Tank Unit	Honeywell
JG7039E	Fuel Quantity Tank Unit	Honeywell
JG7040A	Fuel Quantity Tank Unit	Honeywell
JG7040B	Fuel Quantity Tank Unit	Honeywell
JG7040C	Fuel Quantity Tank Unit	Honeywell
JG7040D	Fuel Quantity Tank Unit	Honeywell
JG7040E	Fuel Quantity Tank Unit	Honeywell
JG7040F-3	Fuel Quantity Tank Unit	Honeywell
JG7040F-4	Fuel Quantity Tank Unit	Honeywell
JG7040G-2	Fuel Quantity Tank Unit	Honeywell
JG7040G-3	Fuel Quantity Tank Unit	Honeywell
JG7040G-4	Fuel Quantity Tank Unit	Honeywell
JG7041A	Fuel Quantity Indicator	Honeywell
JG7041A-10	Fuel Quantity Indicator	Honeywell
JG7046A	Fuel Quantity Tank Unit	Honeywell
JG7047A	Fuel Quantity Tank Unit	Honeywell
JG7A-1	Fuel Quantity Indicator	Honeywell
JG7A-2	Fuel Quantity Indicator	Honeywell
JG7A-3	Fuel Quantity Indicator	Honeywell
JG7A-4	Fuel Quantity Indicator	Honeywell
JG7A-5	Fuel Quantity Indicator	Honeywell
JG7A-6	Fuel Quantity Indicator	Honeywell
JG7A-8	Fuel Quantity Indicator	Honeywell
KN 63	Distance Measuring System	Honeywell
PAA700-11	FUEL QTY. TANK UNIT	Consolidated Airborn
PAA700-13	FUEL QTY. TANK UNIT	Consolidated Airborn
PAA700-14	FUEL QTY. TANK UNIT	Consolidated Airborn
PAB575-1	Fuel Quantity Tank Unit	Consolidated Airborn
PBB488-2	Oil Quantity Tank Unit	Ragen
PBB488-3	Oil Quantity Tank Unit	Ragen
PF06-N1	Fuel Quantity Indicator	Hokushin

Primary Part Number	Nomenclature	Manufacture
PF06-N3	Fuel Quantity Indicator	Hokushin
PF228-N1	Fuel Quantity Indicator	Hokushin
PF228-N2	Fuel Quantity Indicator	Hokushin
PF229-N1	Fuel Quantity Indicator	Hokushin
PF229-N2	Fuel Quantity Indicator	Hokushin
PF25-C1	Fuel Quantity Indicator	Hokushin
PF25-N32	Liquid Quantity Indicator	Hokushin
PF25-N33	Fuel Quantity Indicator	Hokushin
PF25-N34	Liquid Quantity Indicator	Hokushin
PF25-N35	Liquid Quantity Indicator	Hokushin

PF25-N36	Fuel Quantity Indicator	Hokushin
PF25-N37	Liquid Quantity Indicator	Hokushin
PF25-N38	Liquid Quantity Indicator	Hokushin
PF25-N39	Liquid Quantity Indicator	Hokushin
PF25-N40	Fuel Quantity Indicator	Hokushin
PF25-N41	Liquid Quantity Indicator	Hokushin
PF28-N1	Liquid Quantity Indicator	Hokushin
PF28-N11	Fuel Quantity Indicator	Hokushin
PF28-N3	Liquid Quantity Indicator	Hokushin
PF28-N4	Liquid Quantity Indicator	Hokushin
PF28-N5	Liquid Quantity Indicator	Hokushin
PF28-N6	Liquid Quantity Indicator	Hokushin
PF28-N7	Liquid Quantity Indicator	Hokushin
PF28-N8	Fuel Quantity Indicator	Hokushin
PF28-N9	Fuel Quantity Indicator	Hokushin
PF36-N2	Liquid Quantity Indicator	Hokushin
PF36-N3	Liquid Quantity Indicator	Hokushin
PF36-N4	Liquid Quantity Indicator	Hokushin
PF36-N6	Fuel Quantity Indicator	Hokushin
PF36-N7	Liquid Quantity Indicator	Hokushin
PF36-N8	Fuel Quantity Indicator	Hokushin
PF36-N9	Liquid Quantity Indicator	Hokushin
PF412-N3	Fuel Quantity Indicator	Hokushin
PF412-N4	Fuel Quantity Indicator	Hokushin
PF413-N1	Liquid Quantity Transmitter	Hokushin
PF413-N2	Fuel Quantity Indicator	Hokushin
PF416-N1	Fuel Quantity Indicator	Hokushin
PF530-N3	Fuel Quantity Indicator	Hokushin
PF530-N4	Fuel Quantity Indicator	Hokushin
PF59-N33	Fuel Quantity Indicator	Hokushin
PF59-N34	Liquid Quantity Transmitter	Hokushin
PF59-N36	Fuel Quantity Indicator	Hokushin
PF59-N37	Fuel Quantity Indicator	Hokushin
PF59-N38	Liquid Quantity Transmitter	Hokushin

Primary Part Number	Nomenclature	Manufacture
PF59-N39	Liquid Quantity Transmitter	Hokushin
RG14D3	Totalizer	Honeywell
RG14D7	Totalizer	Honeywell
RG14E1	Totalizer	Avien
RG14E3	Totalizer	Avien
RG473C	Fuel Quantity Tank Unit	Honeywell
SC14 Series	Fuel Management System	Senior Aerospace Ket
SCF1548	Fuel Qty Signal Conditioner	Consolidated Airborn
SCF1548-2	Fuel Qty Signal Conditioner	Consolidated Airborn
SP-2521-1-CES	Fuel Quantity Indicator	Standard Precision
SP-2521-2-CES	Fuel Quantity Indicator	Standard Precision
SRL-C12F	Fluid Quantity Indicator	Ametek
SRL-C12K	Fluid Quantity Indicator	Ametek
TJ-13	Fuel Quantity Tank Unit	Ametek/GE

TJ-17	Fuel Quantity Tank Unit	Ametek/GE
TPA-DSFG1579	Fuel Quantity Indicator	Consolidated Airborn
VSDL-OC403D-1	Fuel Quantity Indicator	Ametek/GE
WL/0201KID/1	Fuel Quantity Indicator	Smith Industries
WL/0201KID/2	Fuel Quantity Indicator	Smith Industries
WL/0201KID/3	Fuel Quantity Indicator	Smith Industries
WL/0201KID/4	Fuel Quantity Indicator	Smith Industries
WL/0801KID/2	Fuel Quantity Indicator	Smith Industries
WL/0803KID/2	Fuel Quantity Indicator	Smith Industries
WL/0803KID/3	Fuel Quantity Indicator	Smith Industries
YG551D24	Fuel Quantity Indicator	Honeywell
YG551D25	Fuel Quantity Indicator	Honeywell
YG554A5	Fuel Quantity Indicator	Honeywell
100-384040-3	Flap Motor Assembly	Electo Mechanical
10166N01N00	Rudder Trim Indicator	Ametek
10-33-00	Photo Electric Scanner	Hass Instrument
10-62035-2	Rudder Trim Indicator	Ametek
107742-01	Cutoff Assy/S. Axis	Lear Siegler
11-3320	Ignition Analyzer	Scintilla
11-3350	Ignition Analyzer	Scintilla
11-3351	Ignition Analyzer	Scintilla
11-3352	Ignition Analyzer	Scintilla
11-3353	Ignition Analyzer	Scintilla
11431-401	Equiptment Rack	Autonetics
11431-401-21	Equipment Racks	Autonetics
119152-01	Cutoff Assy/S. Axis	Lear Siegler
124G610-35	Adaptor	Ryan
133940-01	Mounting Base	Lear Siegler
134278-01	Coupler	Lear Siegler
13651-2-A	Magnetometer	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
138287-01	Mounting Base	Lear Siegler
1426C-06	Periscopic Sextant	Kollsman
162BL402	Resistance Thermometer	Lewis Engineering
162BL402A	Resistance Thermometer	Lewis Engineering
162BL403	Resistance Thermometer	Lewis Engineering
162BL403A	Resistance Thermometer	Lewis Engineering
162BL403B	Resistance Thermometer	Lewis Engineering
162BL403C	Resistance Thermometer	Lewis Engineering
162BL708	Resistance Thermometer	Horizon Aerospace
162BL709	Resistance Thermometer	Horizon Aerospace
162BL709A	Resistance Thermometer	Horizon Aerospace
162BL709B	Resistance Thermometer	Horizon Aerospace
162BL709C	Resistance Thermometer	Horizon Aerospace
162BL710	Resistance Thermometer	Horizon Aerospace
162BL711	Resistance Thermometer	Horizon Aerospace
16906-1G	Control Panel	Bendix
17575A	Skid Landing Gear Shock Absorb	E.R.A.M.
1813-01	Mounting Base	Avien

1824-37LW	Loadmeter Indicator	Weston
1824-39LW	Loadmeter Indicator	Weston
1857-1	Attitude Alert Warning	Avtech
20041-000-03	Engine Oil Transmitter	Goodrich
2100756-3-1	Data Computer	AiResearch
2594816	Mounting Base	Sperry
27-6	Flap Motor Assembly	Electro Mechanical
3000, GAS CHECK	Gas Check	INO Science
37307	Mounting Base	Simmonds
37308	Mounting Base	Simmonds
37309	Mounting Base	Simmonds
37310	Mounting Base	Simmonds
37311	Mounting Base	Simmonds
3S2060DM174A1	Elect. Wire Harness	Ametek/GE
40-621	MOTIONAL TRANSDUCER	CRANE / HYDRO-AIRE
40-621-1	MOTIONAL TRANSDUCER	CRANE / HYDRO-AIRE
4100	Slip Skid Sensor	Bendix King
42E13-2A	Transistorized Deicer Timer	Lucas Aerospace
42E13-3A	Transistorized Deicer Timer	Lucas Aerospace
477579-1	Cover Glass	Simmonds
520311-1	Mounting Base	Kearfott
522-0240-003	Mounting Base	Collins
522270	Loadmeter Indicator	Weston
522275	Loadmeter Indictator	Weston
53200	Cross Wind Cabin Assembly	RE White and Associa
548384-1	Anticipation Sensor	Garrett

Primary Part Number	Nomenclature	Manufacture
548386-1	Anticipation Sensor	Garrett
653130	Air Conditioner Blower Unit	Sperry
659829	Mounting Base	Sperry
661102-B	Phase Adapter	Sperry
672675	Pedestal Controller	Sperry
68S48	Stabilizer	Mitchell
69-37352-38	Door warning annunciator	BAE Systems
69-37352-41	Door warning annunciator	BAE Systems
7-011	L-1011 Logic Assembly	EDC
71502-1111	Turn and Slip	Aerosonic
730833	Avionics Cooling Refrig. Unit	Sundstrand
730833A	Avionics Cooling Refrig. Unit	Sundstrand
730833B	Avionics Cooling Refrig. Unit	Sundstrand
730833C	Avionics Cooling Refrig. Unit	Sundstrand
736539	Cursor Indicator	TGH Aviation
890700	Control Unit	Kidde
891234	Control Unit	Kidde
891234-300	Control Unit	Kidde
893229	Fire Detection System	Kidde
893877	Engine Control Card	Kidde
893877-01	Engine Control Card	Kidde
893877-02	Engine Control Card	Kidde

893877-03	Engine Control Card	Kidde
8DW84	Meter	Ametek/GE
927318-3	Air Condition Flow Transmitter	Honeywell
927318-4	Air Condition Flow Transmitter	Honeywell
AN/AJB-3	Loft Bomb Release Computer Set	Lear Siegler
B362400001	Scale Error Corrector	Kollsman
B4195000202	Control Chassis Assembly	Kollsman
B4195000203	Control Chassis Assembly	Kollsman
B-5A	Intervalometer	Abrams
B-9	Intervalometer	Abrams
C 26040 00 001	Scale Error Corrector	Kollsman
C26040 00 001 MOD AA	Scale Error Corrector	Kollsman
C26040 00 001 MOD BB	Scale Error Corrector	Kollsman
CO9421	Observation System	Hyundai
CR-1	Heat/Fire Detector	Kidde
D3851	Airstream Direction Detectors	Airstream
DPL 1660 MK 1	Pilot Lever Angle Unit	Natec Electronic
ED-11	Mounting Base	Eclipse Pioneer
G6560-03	Audio Control Panel	Gables Engineering In
KMA 24H - 70/71	Audio Selector Panel	Bendix/King
MT-1318/ASN-6	Computer Mount	Ford
QG42A1	Mounting Base	Honeywell

Primary Part Number	Nomenclature	Manufacture
QG53A-1	Mounting Base	Honeywell
R661850	Mounting Base	Sperry
S.149-1-169	Ratiometer Indicator	Weston
SLZ2226A	Airstream Direction Detectors	Airstream
SLZ2481	Airstream Direction Detectors	Airstream
SLZ2482	Airstream Direction Detectors	Airstream
SLZ2501	Airstream Direction Detectors	Airstream
SRDL-OC12D	Flap Position Indicator	Ametek
SUE40028-3	Circuit Card Assemby	Emerson Electric Co
SUE40029-5	Circuit Card Assemby	Emerson Electric Co
SUE40032-5	Circuit Card Assemby	Emerson Electric Co
SUM3863-3	Transformer Assembly	Emerson Electric Co
SUM4160-2	Keypanel Assembly	Emerson Electric Co
T321328	Adaptor	Sperry
TE-5560	Phase Shifter	Kollsman
VA-1A	Backlight	Electronics Intl.
101-389005-1	Synchro Transmitter	Ametek/GE
101-389005-3	Synchro Transmitter	Ametek/GE
1354-10M-A	Autosyn Indicator	Eclipse Pioneer
1355-10N-A	Autosyn Indicator	Eclipse Pioneer
1356-2C-A	Autosyn Indicator	Eclipse Pioneer
13695-1-A	Autosyn Trnasmitter	Eclipse Pioneer
13A1150-A	Autosyn Indicator	Bendix
16017-2-A	Synchro Transmitter	Eclipse Pioneer
16017-2-B	Synchro Transmitter	Eclipse Pioneer
16089-1-A	Synchro Transmitter	Eclipse Pioneer

16089-1-B	Synchro Transmitter	Eclipse Pioneer
16089-1-C	Synchro Transmitter	Eclipse Pioneer
18042-0001	Synchro Transmitter	Bendix King
18049-0002	Synchro Transmitter	Bendix King
1930710-1	Transolver	Bendix King
1U63938	Synchro Indicator	Bendix King
20003-53H-19-A2	Magnesyn Indicator	Eclipse Pioneer
20300-68C-16-A1	Magnesyn Indicator	Eclipse Pioneer
2034758-0701	Synchro Transmitter	Bendix King
22000( )	Magnesyn Transmitter	Eclipse Pioneer
22001( )	Magnesyn Transmitter	Eclipse Pioneer
22002( )	Magnesyn Transmitter	Eclipse Pioneer
22005( )	Magnesyn Transmitter	Eclipse Pioneer
22008( )	Magnesyn Transmitter	Eclipse Pioneer
22009( )	Magnesyn Transmitter	Eclipse Pioneer
22101( )	Magnesyn Transmitter	Eclipse Pioneer
22102( )	Magnesyn Transmitter	Eclipse Pioneer
22105( )	Magnesyn Transmitter	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
22-607	Autosyn Indicator	Sigma Tek
229-0036-00	Synchro Transmitter	Collins
229-0072-00	Synchro Transmitter	Collins
229-0091-010	Resolver Indicator	Collins
229-0092-00	Resolver	Collins
229-0110-00	Resolver	Collins
229-0113-00	Synchro Transmitter	Collins
229-0134-00	Synchro Transmitter	Collins
229-0143-000	Resolver	Collins
229-0151-00	Synchro Transmitter	Collins
229-0171-00	Synchro Transmitter	Collins
229-0175-00	Synchro Transmitter	Collins
229-0176-00	Synchro Receiver	Collins
229-0178-000	Resolver	Collins
229-0194-00	Synchro Transmitter	Collins
229-0202-00	Synchro Transmitter	Collins
229-0215-00	Resolver Indicator	Collins
229-0216-00	Synchro Receiver	Collins
229-0224-00	Synchro Receiver	Collins
229-0244-00	Synchro Receiver	Collins
229-0246-00	Synchro Receiver	Collins
229-0246-010	Synchro Receiver	Collins
229-0249-00	Synchro Receiver	Collins
229-0255-00	Synchro Receiver	Collins
229-0256-00	Synchro Receiver	Collins
229-0259-00	Resolver Indicator	Collins
229-0260-00	Synchro Transmitter	Collins
229-0313-010	Synchro Receiver	Collins
229-3000-00	Synchro Transmitter	Collins
229-3006-00	Synchro Transmitter	Collins

229-3009-00	Synchro Transmitter	Collins
229-3024-00	Synchro Transmitter	Collins
229-3040-00	Synchro Transmitter	Collins
229-3043-10	Synchro Transmitter	Collins
229-3045-00	Synchro Transmitter	Collins
229-4003-00	Synchro Transmitter	Collins
229-4019-010	Synchro Transmitter	Collins
229-4019-020	Synchro Transmitter	Collins
229-5005-00	Synchro Transmitter	Collins
229-5009-00	Synchro Transmitter	Collins
229-5022-010	Synchro Transmitter	Collins
229-6000-00	Resolver	Collins
229-6009-00	Resolver Indicator	Collins
229-6015-000	Synchro Transmitter	Collins

Primary Part Number	Nomenclature	Manufacturer
229-6026-010	Transolver	Collins
229-6026-030	Transolver	Collins
229-6029-010	Synchro Indicator	Collins
229-6032-010	Synchro Transmitter	Collins
229-7012-000	Resolver	Collins
229-7030-010	Resolver	Collins
229-7031-010	Resolver Indicator	Collins
229-7032-010	Resolver	Collins
229-7034-010	Resolver Indicator	Collins
230-0545-010	Synchro Motor	Collins
24100-45G-21-A1	Magnesyn Indicator	Eclipse Pioneer
24500-68A-2-B2	Magnesyn Indicator	Eclipse Pioneer
25100-A17A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A17B-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A17C-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A27A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A27B-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A27C-1-A2	Autosyn Indicator	Eclipse Pioneer
25100-A2A-1-A4	Autosyn Indicator	Eclipse Pioneer
25100-A2A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A2B-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A2C-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A30A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A30B-1-A1	Autosyn Indicator	Eclipse Pioneer
25100-A30B-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A30C-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A30D-1-B2	Autosyn Indicator	Eclipse Pioneer
25100-A30E-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A37A-1-A3	Autosyn Indicator	Eclipse Pioneer
25100-A37A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A37B-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A43A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A46A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-A6A-1-B1	Autosyn Indicator	Eclipse Pioneer

25100-A6C-1-B4	Autosyn Indicator	Eclipse Pioneer
25100-A9A-1-A5	Autosyn Indicator	Eclipse Pioneer
25100-A9A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-B16A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-B7A-1-A6	Autosyn Indicator	Eclipse Pioneer
25100-B7A-1-B1	Autosyn Indicator	Eclipse Pioneer
25100-C8A-1-B3	Autosyn Indicator	Eclipse Pioneer
25101	Autosyn Indicator	Bendix King
25200-A15A-1-1-A1	Autosyn Indicator	Eclipse Pioneer
25200-A15B-1-1-A1	Autosyn Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
25603-A17A-21-A1	Autosyn Indicator	Eclipse Pioneer
2562A-3	Synchro Transmitter	Giannini
42E13-11A	Transistorized Deicer Timer	Lucas Aerospace
42E13-13A	Transistorized Deicer Timer	Lucas Aerospace
42E13-15A	Transistorized Deicer Timer	Lucas Aerospace
42E13-17B	Transistorized Deicer Timer	Lucas Aerospace
42E13-3B	Transistorized Deicer Timer	Lucas Aerospace
42E13-6A	Transistorized Deicer Timer	Lucas Aerospace
42E13-8A	Transistorized Deicer Timer	Lucas Aerospace
42E13-9A	Transistorized Deicer Timer	Lucas Aerospace
551C	Synchro Indicator	Bendix King
6200-B10A-1-A3	Autosyn Indicator	Eclipse Pioneer
6200-B12A-1-A5	Autosyn Indicator	Eclipse Pioneer
6200-B12A-9-A5	Autosyn Indicator	Eclipse Pioneer
6200-B12C-9-A3	Autosyn Indicator	Eclipse Pioneer
6200-B7A-1-A1	Autosyn Indicator	Eclipse Pioneer
6200-B7A-1-A2	Autosyn Indicator	Eclipse Pioneer
6200-B7E-1-A1	Autosyn Indicator	Eclipse Pioneer
6201-C1A-5-A1	Autosyn Indicator	Eclipse Pioneer
6201-C1B-4-A1	Autosyn Indicator	Eclipse Pioneer
6300-A11A-1-A4	Autosyn Indicator	Eclipse Pioneer
6300-A15A-1-A2	Autosyn Indicator	Eclipse Pioneer
6300-A15C-3-A1	Autosyn Indicator	Eclipse Pioneer
6300-A2A-1-A4	Autosyn Indicator	Eclipse Pioneer
6300-A2A-2-A4	Autosyn Indicator	Eclipse Pioneer
6300-A2D-1-A1	Autosyn Indicator	Eclipse Pioneer
6300-A2E-2-A1	Autosyn Indicator	Eclipse Pioneer
6300-A2F-1-A4	Autosyn Indicator	Eclipse Pioneer
6300-A34A-14-A1	Autosyn Indicator	Eclipse Pioneer
6300-A34A-15-A1	Autosyn Indicator	Eclipse Pioneer
6300-A4B-1-A1	Autosyn Indicator	Eclipse Pioneer
6300-A4C-2-A1	Autosyn Indicator	Eclipse Pioneer
6300-A4D-1-A1	Autosyn Indicator	Eclipse Pioneer
6300-A4E-2-A1	Autosyn Indicator	Eclipse Pioneer
6300-A9A-1-A3	Autosyn Indicator	Eclipse Pioneer
6300-A9A-1-A4	Autosyn Indicator	Eclipse Pioneer
6300-A9B-2-A1	Autosyn Indicator	Eclipse Pioneer
6300-A9B-2-A3	Autosyn Indicator	Eclipse Pioneer

6300-A9C-3-A1	Autosyn Indicator	Eclipse Pioneer
6300-A9C-3-A3	Autosyn Indicator	Eclipse Pioneer
6300-A9D-1-A1	Autosyn Indicator	Eclipse Pioneer
6300-A9D-2-A1	Autosyn Indicator	Eclipse Pioneer
6300-A9G-1-A1	Autosyn Indicator	Eclipse Pioneer
6300-A9G-2-A1	Autosyn Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
6300-B4B-14-A1	Autosyn Indicator	Eclipse Pioneer
6300-B4C-15-A1	Autosyn Indicator	Eclipse Pioneer
6300-B4D-1-A1	Autosyn Indicator	Eclipse Pioneer
6300-B4E-2-A1	Autosyn Indicator	Eclipse Pioneer
6300-B5A-14-A1	Autosyn Indicator	Eclipse Pioneer
6300-B5B-15-A1	Autosyn Indicator	Eclipse Pioneer
6300-B7B-1-A1	Autosyn Indicator	Eclipse Pioneer
6300-C7A-29-A4	Autosyn Indicator	Eclipse Pioneer
6400-A15A-1-A2	Autosyn Indicator	Eclipse Pioneer
6400-A15B-1-A2	Autosyn Indicator	Eclipse Pioneer
6400-A23A-1-A4	Autosyn Indicator	Eclipse Pioneer
6400-A2B-1-A2	Autosyn Indicator	Eclipse Pioneer
6400-A30A-1-A2	Autosyn Indicator	Eclipse Pioneer
6400-A30B-1-A2	Autosyn Indicator	Eclipse Pioneer
6400-A34B-1-A4	Autosyn Indicator	Eclipse Pioneer
6400-A6A-1-A1	Autosyn Indicator	Eclipse Pioneer
6400-A6A-1-A4	Autosyn Indicator	Eclipse Pioneer
6400-A9B-1-A2	Autosyn Indicator	Eclipse Pioneer
6400-B4B-1-A6	Autosyn Indicator	Eclipse Pioneer
6400-B5B-1-A6	Autosyn Indicator	Eclipse Pioneer
6400-B7B-1-A2	Autosyn Indicator	Eclipse Pioneer
6400-C2A-1-A5	Autosyn Indicator	Eclipse Pioneer
6400-C2B-1-A5	Autosyn Indicator	Eclipse Pioneer
6400-C3A-1-A5	Autosyn Indicator	Eclipse Pioneer
6400-C3B-1-A5	Autosyn Indicator	Eclipse Pioneer
6400-C4A-1-A5	Autosyn Indicator	Eclipse Pioneer
6400-C4B-1-A5	Autosyn Indicator	Eclipse Pioneer
6800-C1A-1-A1	Autosyn Indicator	Eclipse Pioneer
6800-C1A-41-A2	Autosyn Indicator	Eclipse Pioneer
6800-C1C-44-A2	Autosyn Indicator	Eclipse Pioneer
6800-C2A-41-A2	Autosyn Indicator	Eclipse Pioneer
6800-C2B-44-A2	Autosyn Indicator	Eclipse Pioneer
6800-C3A-41-A2	Autosyn Indicator	Eclipse Pioneer
6800-C3B-44-A2	Autosyn Indicator	Eclipse Pioneer
6800-C4A-1-A2	Autosyn Indicator	Eclipse Pioneer
6800-C4A-41-A2	Autosyn Indicator	Eclipse Pioneer
6800-C4B-44-A2	Autosyn Indicator	Eclipse Pioneer
6800-C5A-41-A2	Autosyn Indicator	Eclipse Pioneer
6800-C5B-44-A2	Autosyn Indicator	Eclipse Pioneer
6800-C6A-41-A2	Autosyn Indicator	Eclipse Pioneer
6800-C6B-44-A2	Autosyn Indicator	Eclipse Pioneer
6801-A38A-13-A1	Autosyn Indicator	Eclipse Pioneer

6801-B7A-13-A2	Autosyn Indicator	Eclipse Pioneer
6801-B7B-13-A2	Autosyn Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
6901-B1A-1-1A1	Autosyn Indicator	Eclipse Pioneer
91-380015-1	Synchro Indicator	Ametek/GE
AB-885-A	Synchro Transmitter	US Gauge
AY100	Autosyn Indicator	Eclipse Pioneer
AY101D	Autosyn Indicator	Eclipse Pioneer
AY101DS	Autosyn Indicator	Eclipse Pioneer
AY102D	Autosyn Indicator	Eclipse Pioneer
AY102DS	Autosyn Indicator	Eclipse Pioneer
AY103D	Autosyn Indicator	Eclipse Pioneer
AY110D	Autosyn Indicator	Eclipse Pioneer
AY110DS	Autosyn Indicator	Eclipse Pioneer
AY111DL	Autosyn Indicator	Eclipse Pioneer
AY111DLS	Autosyn Indicator	Eclipse Pioneer
AY112DL	Autosyn Indicator	Eclipse Pioneer
AY113DL	Autosyn Indicator	Eclipse Pioneer
AY120D	Autosyn Indicator	Eclipse Pioneer
AY120DS	Autosyn Indicator	Eclipse Pioneer
AY123D	Autosyn Indicator	Eclipse Pioneer
AY123DS	Autosyn Indicator	Eclipse Pioneer
AY130D	Autosyn Indicator	Eclipse Pioneer
AY130DS	Autosyn Indicator	Eclipse Pioneer
AY131D	Autosyn Indicator	Eclipse Pioneer
AY131DS	Autosyn Indicator	Eclipse Pioneer
AY200	Autosyn Indicator	Eclipse Pioneer
AY200-10-B	Autosyn Indicator	Eclipse Pioneer
AY200-2-B	Autosyn Indicator	Eclipse Pioneer
AY200-3-B	Autosyn Indicator	Eclipse Pioneer
AY201-11-B	Autosyn Indicator	Eclipse Pioneer
AY201-1-B	Autosyn Indicator	Eclipse Pioneer
AY201-3-B	Autosyn Indicator	Eclipse Pioneer
AY201-4-B	Autosyn Indicator	Eclipse Pioneer
AY201-6-B	Autosyn Indicator	Eclipse Pioneer
AY201-8-B	Autosyn Indicator	Eclipse Pioneer
AY202-15-B	Autosyn Indicator	Eclipse Pioneer
AY202-1-B	Autosyn Indicator	Eclipse Pioneer
AY202-3-B	Autosyn Indicator	Eclipse Pioneer
AY203-10-B	Autosyn Indicator	Eclipse Pioneer
AY203-2-B	Autosyn Indicator	Eclipse Pioneer
AY204-12-B	Autosyn Indicator	Eclipse Pioneer
AY204-14-B	Autosyn Indicator	Eclipse Pioneer
AY204-9-B	Autosyn Indicator	Eclipse Pioneer
AY205-10-B	Autosyn Indicator	Eclipse Pioneer
AY205-2-B	Autosyn Indicator	Eclipse Pioneer
AY221-3-B	Autosyn Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture

AY222-3-B	Autosyn Indicator	Eclipse Pioneer
AY231-3-B	Autosyn Indicator	Eclipse Pioneer
AY231-4-B	Autosyn Indicator	Eclipse Pioneer
AY232-3-B	Autosyn Indicator	Eclipse Pioneer
AY232-4-B	Autosyn Indicator	Eclipse Pioneer
AY-976-A1	Autosyn Indicator	Eclipse Pioneer
JG288A3	Synchro Indicator	US Gauge
JG288A4	Synchro Indicator	US Gauge
SR-015D	Synchro Indicator	US Gauge
SR-015E	Synchro Indicator	US Gauge
SR-015F	Synchro Indicator	US Gauge
SR-09D	Synchro Indicator	Ametek/GE
SR-153C	Synchro Indicator	Ametek/GE
SR-154C	Synchro Indicator	Ametek/GE
SR-2AC	Synchro Indicator	Ametek/GE
SR-2AD	Synchro Indicator	Ametek/GE
SR-2AE	Synchro Indicator	Ametek/GE
SR-2AF	Synchro Indicator	Ametek/GE
SR-2AG	Synchro Indicator	Ametek/GE
SR-2AH	Synchro Indicator	Ametek/GE
SR-2AJ	Synchro Indicator	Ametek/GE
SR-2AK	Synchro Indicator	Ametek/GE
SR-2AM	Synchro Indicator	Ametek/GE
SR-2AP	Synchro Indicator	Ametek/GE
SR-2AR	Synchro Indicator	Ametek/GE
SR-2AT	Synchro Indicator	Ametek/GE
SR-2AW	Synchro Indicator	Ametek/GE
SR-2Y	Synchro Indicator	Ametek/GE
SR-2Z	Synchro Indicator	Ametek/GE
SR-94J	Synchro Indicator	Ametek/GE
SR-94K	Synchro Indicator	Ametek/GE
SR-94L	Synchro Indicator	Ametek/GE
SR-C2AQ	Synchro Indicator	Ametek/GE
SR-C2AS	Synchro Indicator	Ametek/GE
SRDL-7A	Synchro Indicator	Ametek/GE
SRS-2A	Synchro Indicator	US Gauge
SRS-8A	Synchro Indicator	US Gauge
SRSW-94A	Synchro Indicator	Ametek/GE
SRSW-94B	Synchro Indicator	Ametek/GE
SRSW-94C	Synchro Indicator	Ametek/GE
114ES235-4	Switch Assembly	Simmonds Precision
384332-016	Switch Assembly	Simmonds Precision
0070G1	Flap Position Transmitter	Rosemont
0108-003	Flap Position Indicator	Aeritalia

Primary Part Number	Nomenclature	Manufacture
10-61926-1	Flap Position Indicator	Smith Industries
10-61926-2	Flap Position Indicator	Smith Industries
10-61926-3	Flap Position Indicator	Smith Industries
10-61926-4	Flap Position Indicator	Smith Industries

114.060	Discharge Valve Position	Kratos
114.065	Spoiler Position Indicator	Kratos
1159SCF216	Flap Horizontal Stabilizer Pos	Gulfstream
1201-406-2011	Rotary Wing Blade Indicator	Trodyne
1201-416-2011	Rotary Wing Blade Indicator	Trodyne
124.593	Flap Position Indicator	Rogerson
124.614	Flap Position Indicator	Kratos
138740-25	Indicator	Astronautics
138740-9	Indicator	Astronautics
15100	Trim Indicator	Eclipse Pioneer
15101	Trim Indicator	Eclipse Pioneer
15101-1E-A1	Trim Indicator	Eclipse Pioneer
15101-1E-A3	Trim Indicator	Eclipse Pioneer
16541-2-A	Surface Controller	Eclipse Pioneer
16541-2-B	Surface Controller	Eclipse Pioneer
1726E35	Flap Asymetrical Switch	Western Gear Corp
1726E39	Flap Asymetrical Switch	Western Gear Corp
1801299-3-2	Flap Position Indicator	Bendix
18-1299	Flap Position Indicator	Bendix
18-1299-2	Flap Position Indicator	Bendix
18-1299-3	Flap Position Indicator	Bendix
18-1299-3-2	Flap Position Indicator	Bendix
18-1299-4	Flap Position Indicator	Bendix
18-1299-4-2	Flap Position Indicator	Bendix
18-1299-5	Flap Position Indicator	Bendix
18-1299-5-2	Flap Position Indicator	Bendix
18-1299-6	Flap Position Indicator	Bendix
18-1299-6-2	Flap Position Indicator	Bendix
18-1299-7-2	Flap Position Indicator	Bendix
1813-3LW	Rudder Trim Indicator	Western Design
18-1738-10	Flap Position Semsor	Honeywell
18-1738-6	Flap Position Transmitter	Honeywell
18-1738-7	Flap Position Transmitter	Honeywell
18-1738-8	Flap Position Transmitter	Honeywell
18-1738-9	Flap Position Transmitter	Honeywell
18-1937	Nozzle Position Indicator	Bendix
18-1969-15	Positional Transmitter	Bendix
18-1969-16	Position Transmitter	Bendix
18-1969-17	Transmitter	Honeywell
20000	Position Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
20003	Position Indicator	Eclipse Pioneer
2061-11-01	Flap Position Indicator	Smith Industries
2061-12-01	Flap Position Indicator	Smith Industries
2061-13-1	Flap Position Indicator	Smith Industries
2061-14-1	Flap Position Indicator	Smith Industries
21000-16C-4-A1	Position Indicator	Bendix
21000-16C-8-A1	Position Indicator	Bendix
21000-16D-4A1	Magnesyn Position Ind	Eclipse Pioneer

21000-16D-4-A1	Magnesyn Position Ind	Eclipse Pioneer
21000-16F-4-A1	Magnesyn Position Ind	Eclipse Pioneer
21000-16G-13-A1	Position Indicator	Bendix
21000-16H-20-A1	Position Indicator	Bendix
22-104-()	Flap Position Indicator	Sigma Tek
23000	Magnesyn Position Transmitter	Eclipse Pioneer
23004	Magnesyn Position Transmitter	Eclipse Pioneer
23100	Magnesyn Position Transmitter	Eclipse Pioneer
23104	Magnesyn Position Transmitter	Eclipse Pioneer
23203-2-A1	Magnesyn Position Transmitter	Eclipse Pioneer
24100	Position Indicator	Eclipse Pioneer
2514-1	Flap Position Indicator	Eclipse Pioneer
2514-1D	Flap Position Indicator	Eclipse Pioneer
260909	Position Sync And Quantity Ind	Weston
265-023-001	Rudder trim Indicator	Gull
265-023-002	Rudder trim Indicator	Gull
27-82186-033	Trim Indicator	Fairchild
27-82186-057	Trim Indicator	Fairchild
27-BXU7035- ( )	Flap Position Transmitter	TGH Aviation
33600-C1C-1-B1	Nozzle Position Indicator	Bendix
33600-C1C-1-D1	Nozzle Position Indicator	Bendix
33600-C2G-1-C1	Flap Position Indicator	Bendix
3567324-0002	Nozzle Position Indicator	Bendix
3567324-0003	Nozzle Position Indicator	Bendix
38109	Elevator Control Avail. Ind.	Eclipse Pioneer
38109-1-A	Elevator Control Avail. Ind.	Eclipse Pioneer
38109-2-A	Elevator Control Avail. Ind.	Eclipse Pioneer
38111	Elevator Control Avail. Ind.	Eclipse Pioneer
38111-1-A	Elevator Control Avail. Ind.	Eclipse Pioneer
38111-1-B	Elevator Control Avail. Ind.	Eclipse Pioneer
4027170-901	Indicator	Honeywell
4027170-902	Indicator	Honeywell
4027170-904	Indicator	Honeywell
4029529-901	Indicator	Honeywell
4030567-191	Indicator	Sperry
4044541	Motonial Pickup Transducer	Honeywell

Primary Part Number	Nomenclature	Manufacture
4550-2-A2	Flap Position Transmitter	Eclipse Pioneer
4559-7-A6-2	Position Transmitter	Eclipse Pioneer
4562-5-A7-1	Indicator	Eclipse-Pioneer
521318	Rudder Trim Indicator	Western Design
522231	Position Sync And Quantity Ind	Weston
522942	Flap Position Indicator	Weston
532766	Rudder Trim Indicator	Western Design
562-112A	Position Indicator	Hickok
5656-180	Position Indicator	Hickok
5911-12B-1-A	Flap Position Indicator	Eclipse Pioneer
5911-12B-1-B	Flap Position Indicator	Eclipse Pioneer
5911-12C-1-B	Flap Position Indicator	Eclipse Pioneer

6019-30A-3-A	Flap Position Indicator	Eclipse Pioneer
6019-30B-3-A	Flap Position Indicator	Eclipse Pioneer
6019-30B-3-B	Flap Position Indicator	Eclipse Pioneer
6019-30C-3-A	Flap Position Indicator	Eclipse Pioneer
6019-30C-3-B	Flap Position Transmitter	Eclipse Pioneer
6019-30D-42-B	Flap Position Indicator	Eclipse Pioneer
601R93030-1	Flap Position Transmitter	Bombardier Inc
622-4298-001	Horizontal Situation Indicator	Rockwell Collins
62702	Position Indicator Switch	Haydon
62716	Position Indicator Switch	Haydon
62721	Position Indicator Switch	Haydon
64836-001-3	Dual Pressure Indicator	Sextant
64836-201-1	Dual Pressure Indicator	Jaeger
64836-209-1	Dual Pressure Indicator	Jaeger
6610-526-8173	Flap Position Indicator	United Instruments
69D529	Pitch Trim Sensor	Mitchell
720	Trim Indicator	Hickok
720-192	Trim Indicator	Hickok
777-1825-001	Indicator	Rockwell Collins
818154	Trim Indicator	Sperry
88-I-1890	Position Ind And Transmitters	Weston
88-I-2650	Position Ind And Transmitters	Weston
8DJ11PAH	Position Indicator	Ametek/GE
8DJ11PAS	Position Indicator	Ametek/GE
8DJ11PAW	Position Indicator	Ametek/GE
8DJ11PAZ	Position Indicator	Ametek/GE
8DJ11PAZ11	Position Indicator	Ametek/GE
8DJ11PBC	Position Indicator	Ametek/GE
8DJ11PBC11	Position Indicator	Ametek/GE
8DJ11PBD	Position Indicator	Ametek/GE
8DJ11PBD11	Position Indicator	Ametek/GE
8DJ11PBE	Position Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ11PBE11	Position Indicator	Ametek/GE
8DJ11PBS	Position Indicator	Ametek/GE
8DJ11PBS11	Position Indicator	Ametek/GE
8DJ11PBT	Position Indicator	Ametek/GE
8DJ11PBT11	Position Indicator	Ametek/GE
8DJ11PCN	Position Indicator	Ametek/GE
8DJ11PCN11	Position Indicator	Ametek/GE
8DJ11PEA	Position Indicator	Ametek/GE
8DJ11PEK	Position Indicator	Ametek/GE
8DJ11PEK11	Position Indicator	Ametek/GE
8DJ11PEV	Position Indicator	Ametek/GE
8DJ11PEV-Y78	Position Indicator	Ametek/GE
8DJ11PEZ	Position Indicator	Ametek/GE
8DJ11PFK	Position Indicator	Ametek/GE
8DJ11PFK17	Position Indicator	Ametek/GE
8DJ11PFL	Position Indicator	Ametek/GE

8DJ11PFL-Y87	Position Indicator	Ametek/GE
8DJ11PFV	Position Indicator	Ametek/GE
8DJ11PFV17	Position Indicator	Ametek/GE
8DJ11PHV17	Position Indicator	Ametek/GE
8DJ11PKA	Position Indicator	Ametek/GE
8DJ12GAV50	Position Indicator	Ametek/GE
8DJ12PAD	Position Indicator	Ametek/GE
8DJ12PAD11	Position Indicator	Ametek/GE
8DJ12PAD12	Position Indicator	Ametek/GE
8DJ12PAL	Position Indicator	Ametek/GE
8DJ12PAL12	Position Indicator	Ametek/GE
8DJ12PAW	Position Indicator	Ametek/GE
8DJ12PAW12	Position Indicator	Ametek/GE
8DJ12PBB	Position Indicator	Ametek/GE
8DJ12PBB12	Position Indicator	Ametek/GE
8DJ12PBC	Position Indicator	Ametek/GE
8DJ12PBC12	Position Indicator	Ametek/GE
8DJ12PBD	Position Indicator	Ametek/GE
8DJ12PBD12	Position Indicator	Ametek/GE
8DJ12PBF	Position Indicator	Ametek/GE
8DJ12PBF12	Position Indicator	Ametek/GE
8DJ12PBR	Position Indicator	Ametek/GE
8DJ12PBR12	Position Indicator	Ametek/GE
8DJ12PCL	Position Indicator	Ametek/GE
8DJ12PCX	Position Indicator	Ametek/GE
8DJ12PDV13	Position Indicator	Ametek/GE
8DJ12PXA	Position Indicator	Ametek/GE
8DJ12PXB	Position Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ17AAA	Position Indicator	Ametek/GE
8DJ17AAB	Position Indicator	Ametek/GE
8DJ17AAD	Position Indicator	Ametek/GE
8DJ17AAK	Position Indicator	Ametek/GE
8DJ17AAL	Position Indicator	Ametek/GE
8DJ17AAM	Position Indicator	Ametek/GE
8DJ17AAN	Position Indicator	Ametek/GE
8DJ17AAT	Position Indicator	Ametek/GE
8DJ17AAV	Position Indicator	Ametek/GE
8DJ17AAW	Position Indicator	Ametek/GE
8DJ17AAY	Position Indicator	Ametek/GE
8DJ17ABE	Position Indicator	Ametek/GE
8DJ17ABF	Position Indicator	Ametek/GE
8DJ17ABT-Y9	Position Indicator	Ametek/GE
8DJ225	Flap Position Indicator	Ametek/GE
8DJ225WAA1	Flap Position Indicator	Ametek/GE
8DJ225WAB1	Flap Position Indicator	Ametek/GE
8DJ225WAD2	Flap Position Indicator	Ametek/GE
8DJ225WAE2	Flap Position Indicator	Ametek/GE
8DJ225WAJ2	Flap Position Indicator	Ametek/GE

8DJ26AAA1	Flap Position Indicator	Ametek/GE
8DJ26AAA2	Flap Position Indicator	Ametek/GE
8DJ26AAA50	Position Indicator	Ametek/GE
8DJ26AAA51	Position Indicator	Ametek/GE
8DJ26AAB2	Position Indicator	Ametek/GE
8DJ26AAH51	Position Indicator	Ametek/GE
8DJ26AAN51	Position Indicator	Ametek/GE
8DJ28AAB	Position Indicator	Ametek/GE
8DJ28AAC	Position Indicator	Ametek/GE
8DJ28AAD	Position Indicator	Ametek/GE
8DJ28AAE	Position Indicator	Ametek/GE
8DJ28AAF1	Position Indicator	Ametek/GE
8DJ28AAH1	Position Indicator	Ametek/GE
8DJ28AAM1	Position Indicator	Ametek/GE
8DJ28AAM2	Position Indicator	Ametek/GE
8DJ28AAN1	Position Indicator	Ametek/GE
8DJ28AAN2	Position Indicator	Ametek/GE
8DJ28AAW	Position Indicator	Ametek/GE
8DJ28AAX2	Position Indicator	Ametek/GE
8DJ28AAX-Y6	Position Indicator	Ametek/GE
8DJ28AAZ	Position Indicator	Ametek/GE
8DJ28ABA	Position Indicator	Ametek/GE
8DJ28ABB2	Position Indicator	Ametek/GE
8DJ28ABK1	Position Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ28ABK2	Position Indicator	Ametek/GE
8DJ29AAA	Position Indicator	Ametek/GE
8DJ29AAB	Position Indicator	Ametek/GE
8DJ29AAN	Position Indicator	Ametek/GE
8DJ29AAR	Position Indicator	Ametek/GE
8DJ29AAS	Position Indicator	Ametek/GE
8DJ29AAW	Position Indicator	Ametek/GE
8DJ29ABL2	Position Indicator	Ametek/GE
8DJ29WAB	Position Indicator	Ametek/GE
8DJ29WAC	Position Indicator	Ametek/GE
8DJ29WAC50	Position Indicator	Ametek/GE
8DJ2PBC	Position Indicator	Ametek/GE
8DJ2PBE	Position Indicator	Ametek/GE
8DJ2PBT	Position Indicator	Ametek/GE
8DJ2PCT	Position Indicator	Ametek/GE
8DJ2PCV	Position Indicator	Ametek/GE
8DJ3ECC	Position Indicator	Ametek/GE
8DJ3HAB	Position Indicator	Ametek/GE
8DJ48AAD	Position Indicator	Ametek/GE
8DJ48CAB1	Position Indicator	Ametek/GE
8DJ48CAC1	Position Indicator	Ametek/GE
8DJ48CAC2	Position Indicator	Ametek/GE
8DJ48CAD	Position Indicator	Ametek/GE
8DJ48CAD2	Position Indicator	Ametek/GE

8DJ48FAH	Position Indicator	Ametek/GE
8DJ48-FAL	Flap Position Indicator	Ametek/GE
8DJ48FAL1	Position Indicator	Ametek/GE
8DJ48FAL2	Position Indicator	Ametek/GE
8DJ48FAR2	Position Indicator	Ametek/GE
8DJ48GAD1	Position Indicator	Ametek/GE
8DJ48GAD2	Position Indicator	Ametek/GE
8DJ48GAF1	Position Indicator	Ametek/GE
8DJ48GAF2	Position Indicator	Ametek/GE
8DJ48KAB2	Position Indicator	Ametek/GE
8DJ48LAA2	Position Indicator	Ametek/GE
8DJ48LWB2	Nozzle Position Indicator	Ametek/GE
8DJ49GAC1	Position Indicator	Ametek/GE
8DJ49GAD1	Position Indicator	Ametek/GE
8DJ49GAD2	Position Indicator	Ametek/GE
8DJ49GAW1	Position Indicator	Ametek/GE
8DJ49GAW2	Position Indicator	Ametek/GE
8DJ49GAX1	Position Indicator	Ametek/GE
8DJ49GAX2	Position Indicator	Ametek/GE
8DJ49GAY1	Position Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ49GAY2	Position Indicator	Ametek/GE
8DJ49GBV2	Position Indicator	Ametek/GE
8DJ49LAE2	Position Indicator	Ametek/GE
8DJ49LAL2	Position Indicator	Ametek/GE
8DJ49LAM2	Position Indicator	Ametek/GE
8DJ49LAN2	Position Indicator	Ametek/GE
8DJ49LAV2	Position Indicator	Ametek/GE
8DJ49LWF2	Position Indicator	Ametek/GE
8DJ49LWG2	Position Indicator	Ametek/GE
8DJ49LWH2	Position Indicator	Ametek/GE
8DJ4PAA	Position Indicator	Ametek/GE
8DJ4PAC	Position Indicator	Ametek/GE
8DJ4PAL	Position Indicator	Ametek/GE
8DJ4PBD	Position Indicator	Ametek/GE
8DJ4PBL	Position Indicator	Ametek/GE
8DJ4PBM	Position Indicator	Ametek/GE
8DJ4PBV	Position Indicator	Ametek/GE
8DJ4PBX	Position Indicator	Ametek/GE
8DJ4PBZ	Position Indicator	Ametek/GE
8DJ4PCM	Position Indicator	Ametek/GE
8DJ4PCW	Position Indicator	Ametek/GE
8DJ4PDB	Position Indicator	Ametek/GE
8DJ4PDH	Position Indicator	Ametek/GE
8DJ4PDZ	Position Indicator	Ametek/GE
8DJ4PEB	Position Indicator	Ametek/GE
8DJ4PED	Position Indicator	Ametek/GE
8DJ4PEE	Position Indicator	Ametek/GE
8DJ4PEF	Position Indicator	Ametek/GE

8DJ4PFM	Position Indicator	Ametek/GE
8DJ4PGA	Position Indicator	Ametek/GE
8DJ4PWD	Position Indicator	Ametek/GE
8DJ4PWE	Position Indicator	Ametek/GE
8DJ4PXAA	Position Indicator	Ametek/GE
8DJ4PXAB	Position Indicator	Ametek/GE
8DJ4PXAD	Position Indicator	Ametek/GE
8DJ4PXAE	Position Indicator	Ametek/GE
8DJ4PXC	Position Indicator	Ametek/GE
8DJ4PXN	Position Indicator	Ametek/GE
8DJ4PXR	Position Indicator	Ametek/GE
8DJ4PXS	Position Indicator	Ametek/GE
8DJ4PXZ	Position Indicator	Ametek/GE
8DJ4Y13	Position Indicator	Ametek/GE
8DJ4Y6	Position Indicator	Ametek/GE
8DJ4Y9	Position Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ50AAF2	Position Indicator	Ametek/GE
8DJ50GAB1	Nozzle Position Indicator	Ametek/GE
8DJ50LAD2	Stabilization Trim Pos. Ind.	Ametek/GE
8DJ51GAB1	Position Indicator	Ametek/GE
8DJ51GAB2	Position Indicator	Ametek/GE
8DJ51GAB3	Position Indicator	Ametek/GE
8DJ51GAC2	Position Indicator	Ametek/GE
8DJ51GAC3	Position Indicator	Ametek/GE
8DJ51GAD2	Position Indicator	Ametek/GE
8DJ54AAC2	Trim Tab Indicator	Ametek/GE
8DJ54AAD2	Trim Tab Indicator	Ametek/GE
8DJ66GAL1	Position Indicator	Ametek/GE
8DJ66GAL2	Position Indicator	Ametek/GE
8DJ9PEL	Position Transmitter	Ametek/GE
8DJ9PFF	Position Transmitter	Ametek/GE
8TJ18LBF9	Position Transmitter	Ametek/GE
8TJ19AAA	Position Transmitter	Ametek/GE
8TJ19AAB	Position Transmitter	Ametek/GE
8TJ19AAE	Position Transmitter	Ametek/GE
8TJ19AAF	Position Transmitter	Ametek/GE
8TJ19AAH	Position Transmitter	Ametek/GE
8TJ19AAK	Position Transmitter	Ametek/GE
8TJ19Y8	Position Transmitter	Ametek/GE
8TJ39AAA2	Position Transmitter	Ametek/GE
8TJ39AAN2	Position Transmitter	Ametek/GE
8TJ39BAL1	Position Transmitter	Ametek/GE
8TJ39BAL2	Position Transmitter	Ametek/GE
8TJ9A1	Position Transmitter	Ametek/GE
8TJ9PAB	Position Transmitter	Ametek/GE
8TJ9PAN	Position Transmitter	Ametek/GE
8TJ9PAT	Position Transmitter	Ametek/GE
8TJ9PAV	Position Transmitter	Ametek/GE

8TJ9PAY	Position Transmitter	Ametek/GE
8TJ9PBB	Position Transmitter	Ametek/GE
8TJ9PDD	Position Transmitter	Ametek/GE
8TJ9PDL	Position Transmitter	Ametek/GE
8TJ9PEW	Position Transmitter	Ametek/GE
8TJ9PWB	Position Transmitter	Ametek/GE
8TJ9PWE	Position Transmitter	Ametek/GE
8TJ9PWH	Position Transmitter	Ametek/GE
8TJ9PXAL	Position Transmitter	Ametek/GE
8TJ9PXAN	Position Transmitter	Ametek/GE
8TJ9PXAS	Position Transmitter	Ametek/GE
8TJ9PXB	Position Transmitter	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8TJ9PXBC	Position Transmitter	Ametek/GE
8TJ9PXE	Position Transmitter	Ametek/GE
8TJ9PXK	Position Transmitter	Ametek/GE
8TJ9PXV	Position Transmitter	Ametek/GE
8TJ9PY10	Position Transmitter	Ametek/GE
8TJ9PY11	Position Transmitter	Ametek/GE
8TJ9Y8	Position Transmitter	Ametek/GE
9601-02-04	Flap Handle Position Trans.	Litton
9601-02-06	Flap Position Transmitter	Litton
9601-02-08	Flap Position Transmitter	Litton
9601-02-10	Flap Handle Position Trans.	Litton
9601-02-12	Flap Position Transmitter	Litton
9601-02-13	Flap Position Transmitter	Litton
9601-02-14	Flap Position Transmitter	Litton
970-2-3-3-1	Landing Indicator	ECE
9801-09-03	Flap Position Indicator	Sunbeam
9806-03	Engine Exhaust Nozzle Position	Sunbeam
9806-13	Engine Exhaust Nozzle Position	Sunbeam
9813-16	Indicator	Thomas Edison
9819-29	Control Surface Pos. Ind.	Sunbeam
9819-29-01	Control Surface Pos. Ind.	Sunbeam
A-7	Flap Position Indicator	Liquidometer
ALU-13/A	Rudder trim Indicator	Gull
ALU-19/A	Rudder trim Indicator	Gull
AN 5839-1	Landing Gear Position Ind	Keystone
AN-5780-1	Position Ind And Transmitters	Weston
AN5780-2	Position Ind And Transmitters	Weston
AN5785-1	Position Ind and Transmitters	Weston
C-07409	Flap Position Transmitter	Safe Flight
C-26406-2	Lift Computer	Safe Flight
C-26607-2	Lift Transducer	Safe Flight
C-26707-2	Lift Transducer	Safe Flight
C-26707-3	Lift Transducer	Safe Flight
CD532766AS	Rudder trim Indicator	Weston
CG27D-1	Control Stick Force Trans	Honeywell
CG27D-2	Control Stick Force Trans	Honeywell

CG27D-5	Control Stick Force Trans	Honeywell
CM2918-1	Flap Position Indicator	AID
CM2918-2	Flap Position Indicator	AID
CM2918-3	Flap Position Indicator	AID
EA173E-2	Position Transmitter	Simmonds
EA307AN-1	Position Indicator	Liquidometer
EA308-11	Position Indicator	Liquidometer
EA308-2	Position Indicator	Liquidometer

Primary Part Number	Nomenclature	Manufacture
EA308-3	Position Indicator	Liquidometer
EA321-16	Flap Position Indicator	Liquidometer
EA321-22	Position Indicator	Liquidometer
EA323-1	Flap Position Indicator	Liquidometer
EA326-15	Position Indicator	Liquidometer
EA326-15A	Position Indicator	Liquidometer
EA326-2	Position Indicator	Liquidometer
EA326-8	Position Indicator	Liquidometer
EA327-3	Position Indicator	Liquidometer
F71-1A	Flap Position Indicator	United Instruments
H341BRM1	Gyroscopic Horizon	Thales
H351BWM	Indicator	Thales
HSI-45	Horizontal Situation Indicator	Rockwell Collins
JG422A4	Center-of-Gravity Indicator	Honeywell
LG16	Position Transmitter	Honeywell
LG16B	Position Transmitter	Honeywell
LG16B1	Position Transmitter	Honeywell
LG16C	Position Transmitter	Honeywell
LG16C1	Position Transmitter	Honeywell
LG16C2	Position Transmitter	Honeywell
LG16D	Position Transmitter	Honeywell
LG16D1	Position Transmitter	Honeywell
LIBB-E32	Position Indicator	Wacline
ME-2	Position Transmitter	Eclipse Pioneer
MS28023-1	Flap Position Indicator	Keystone
P22-1	Flap Position Indicator	Sundstrand
P35-1	Flap Position Indicator	Sundstrand
SA103-18	Position Indicator	Penn Keystone
SR-18B	Condensor Door Pos. Ind.	US Gauge
SR-18C	Condensor Door Pos. Ind.	US Gauge
SR-4J	Oil Cooler Flap Pos. Ind	US Gauge
SR-4U	Flap Position Indicator	US Gauge
SR-4W	Flap Position Indicator	Ametek/GE
YG554A6	Center-of-Gravity System	Honeywell
006-15619-0000	Voltage Converter	Honeywell/Bendix-Ki
01-0266751-00C	Power Supply	Whelen
1-001-0102-0083	Static Inverter	Avionic Instruments
1-001-0102-0084	Static Inverter	Avionic Instruments
1-001-0102-0085	Static Inverter	Avionics Instruments
1-001-0102-0095	Static Inverter	Avionic Instruments

1-001-0102-0129	Static Inverter	Avionic Instruments
1-001-0102-0296	Static Inverter	Avionic Instruments
1-002-0102-0434	Static Inverter	Avionic Instruments
1-002-0102-0597	Static Inverter	Avionic Instruments

Primary Part Number	Nomenclature	Manufacture
1-002-0102-0901	Static Inverter	Avionic Instruments
1-002-0102-0912	Static Inverter	Avionic Instruments
1-002-0102-1001	Static Inverter	Avionic Instruments
1-002-0102-1657	Static Inverter	Avionic Instruments
100-476848-001	Electrical Indicator	Canadian Marconi
1-01-0102-0086	Static Inverter	Avionic Instruments
101-384107-3	Voltage Frequency Indicator	Hickok
102491	Ammeter	Weston
10-60757-145	Ammeter	Kratos
114.054	Ammeter	Kratos
114.056	Voltmeter	Kratos
114.062	Battery Condition	Kratos
115.033	Voltmeter DC Indicator	Kratos
115.034	Voltmeter AC Indicator	Kratos
115.077	Load Indicator	Kratos
115.250	Voltmeter AC Indicator	Kratos
115-074	Voltmeter	Kratos
115-075	DC Voltmeter	Kratos
115-076	Frequency Meter	Kratos
115-078	DC Load Indicator	Kratos
116215-01	Power Adaptor	Lear Siegler
11DB05-TY902	Voltameter Indicator	Farem
11DB05-TYP1009	Voltameter Indicator	Farem
12126-2-B	Inverter	Eclipse Pioneer
124.039-3	Dual Ampere Indicator	Kratos
124.040-1	Indicator	Kratos
124.501	DC Voltage Indicator	Kratos
124.832	Voltmeter	Voltron
124.833	DC Voltmeter	Voltron
124.835	Frequency Meter	Kratos
124.837	Ammeter	Kratos
124.934A	Dual AC And DC Indicator	Kratos
124-164	Ammeter	Kratos
124-833	DC Voltmeter	Kratos
124-834	DC Ammeter Indicator	Kratos
128308	Ammeter	Weston
12B2009-1	Prop Amps Indicator	R C Allen
12B2009-3	Prop Amps Indicator	R C Allen
13-193	Flasher Power Unit	PML
13-2500	Inverter	Royal Electric
134255	Ammeter	Weston
134400-01	Power Fail Detector	Lear Siegler
134694	Frequency Meter	Weston
138	Voltmeter	Weston

Primary Part Number	Nomenclature	Manufacture
153LCA8	Ammeter	Lewis
153LV30	Voltmeter	Lewis
169A-908	Voltmeter	Sigma Tek
169A-908L	Voltmeter	Sigma Tek
169A-909	Ammeter	Sigma Tek
169A-909-4	Load Meter	Sigma Tek
169A-909-4L	Load Meter	Sigma Tek
169A-909-L	Ammeter	Sigma Tek
169AE-909-7L	Load Meter	Sigma Tek
169AM-909	Ammeter	Sigma Tek
169AR-909-2	Ammeter	Sigma Tek
169B-909-1	Load Meter	Sigma Tek
169B-909-1L	Load Meter	Sigma Tek
169C-909-2	Ammeter	Sigma Tek
169C-909-2L	Ammeter	Sigma Tek
169D-909-2	Ammeter	Sigma Tek
169D-909-2L	Ammeter	Sigma Tek
169E-909-2	Ammeter	Sigma Tek
169E-909-3	Ammeter	Sigma Tek
169P-909-1L	Load Meter	Sigma Tek
169Q-909-2	Ammeter	Sigma Tek
169T-909-5	Ammeter	Sigma Tek
169V-908-1	Voltmeter	Sigma Tek
169V-908-2	Voltmeter	Sigma Tek
169V-909-6	Ammeter	Sigma Tek
1825-10LW	Voltameter Indicator	Weston
185-076	Ammeter	Kratos
1A125-1A	Static Inverter	Avionic Instruments
1A125-1B-1	Static Inverter	Avionic Instruments
1A125-1C-1	Static Inverter	Avionic Instruments
1A250()	Static Inverter	Avionics Instruments
1A50-1A	Static Inverter	Avionic Instruments
1A50-1B-1	Static Inverter	Avionic Instruments
1A50-1C-1	Static Inverter	Avionic Instruments
1B250-1A	Static Inverter	Avionic Instruments
1B250-1B-1	Static Inverter	Avionic Instruments
1B250-1C	Static Inverter	Avionic Instruments
1B250-1D-1	Static Inverter	Avionic Instruments
1B250-1E-1	Static Inverter	Avionic Instruments
1B250-1F-1	Static Inverter	Avionic Instruments
1B350-1A	Static Inverter	Avionic Instruments
1B350-1B-1	Static Inverter	Avionic Instruments
1B350-1B-2	Static Inverter	Avionic Instruments
1B350-1C-1	Static Inverter	Avionic Instruments

Primary Part Number	Nomenclature	Manufacture
1B350-1D	Static Inverter	Avionic Instruments
21706	Ammeter	Roller-Smith

21752	Voltmeter	Roller-Smith
23046 Series 1	DC Starter Generator	TRW
23046 Series 2	DC Starter Generator	TRW
23048-001A	DC Starter-Generator	TRW Aeronautical Sys
23048-004	DC Starter-Generator	TRW Aeronautical Sys
23048-004M	DC Starter-Generator	TRW Aeronautical Sys
23048-004T	DC Starter-Generator	TRW Aeronautical Sys
23048-004TM	DC Starter-Generator	TRW Aeronautical Sys
23048-006	DC Starter-Generator	TRW Aeronautical Sys
23048-008	DC Starter-Generator	TRW Aeronautical Sys
23048-012	DC Starter-Generator	TRW Aeronautical Sys
23048-014	DC Starter-Generator	TRW Aeronautical Sys
23048-015	DC Starter-Generator	TRW Aeronautical Sys
23048-016	DC Starter-Generator	TRW Aeronautical Sys
23048-017	DC Starter-Generator	TRW Aeronautical Sys
23048-018	DC Starter-Generator	TRW Aeronautical Sys
23048-020	DC Starter-Generator	TRW Aeronautical Sys
23048-021	DC Starter-Generator	TRW Aeronautical Sys
23048-022	DC Starter-Generator	TRW Aeronautical Sys
23048-023	DC Starter-Generator	TRW Aeronautical Sys
23048-027	DC Starter-Generator	TRW Aeronautical Sys
23048-028	DC Starter-Generator	TRW Aeronautical Sys
23048-16	DC Starter-Generator	TRW Aeronautical Sys
23080-001	DC Starter-Generator	Lucas Aerospace
23080-001-1	DC Starter-Generator	Lucas Aerospace
23080-002	DC Starter-Generator	Lucas Aerospace
23080-003	DC Starter-Generator	Lucas Aerospace
23080-004	DC Starter-Generator	Lucas Aerospace
23080-005	DC Starter-Generator	Lucas Aerospace
23080-006	DC Starter-Generator	Lucas Aerospace
23080-011	DC Starter-Generator	Lucas Aerospace
23080-012	DC Starter-Generator	Lucas Aerospace
23080-013	DC Starter-Generator	Lucas Aerospace
23080-014	DC Starter-Generator	Lucas Aerospace
23080-014A	DC Starter-Generator	Lucas Aerospace
23080-015	DC Starter-Generator	Lucas Aerospace
23080-018	DC Starter-Generator	Lucas Aerospace
23080-019	DC Starter-Generator	Lucas Aerospace
23080-020	DC Starter-Generator	Lucas Aerospace
23080-023	DC Starter-Generator	Lucas Aerospace
23080-025	DC Starter-Generator	Lucas Aerospace
23085-001	DC Starter- Generator	BF Goodrich

Primary Part Number	Nomenclature	Manufacture
23A697	D.C. Generator	Globe
25257	Inverter	Holtzer-Cabot
25258	Inverter	Holtzer-Cabot
25281	Inverter	Holtzer-Cabot
260456	DC Indicator	Weston
27-1000 SWITCH	Switch Lighting	TGH Aviation

27-19024-1	Voltmeter	AID
27-19025-1	Ammeter	AID
27-19025-3	Ammeter	AID
27-19116-3	DC Ammeter Indicator	Hickok
27-19116-5	DC Ammeter Indicator	Hickok
27-19117-1	DC Voltmeter	Hickok
27-19118-11	Tri Unit Indicator Assembly	Hickok
27-19118-5	Tri Unit Indicator Assembly	Hickok
27-19118-7	Tri Unit Indicator Assembly	Hickok
27-19118-9	Tri Unit Indicator Assembly	Hickok
27-2000	Lighting Power Transformer	TGH Aviation
27-2000 SWITCH	Switch Lighting	TGH Aviation
27-3000	Switch Lighting	TGH Aviation
2928-2	Stater Generator	PML
2928-3	Starter Generator	PML
2A125-1A	Static Inverter	Avionic Instruments
2A125-1B-1	Static Inverter	Avionic Instruments
2A125-1C	Static Inverter	Avionic Instruments
2A250-1A	Static Inverter	Avionic Instruments
2A250-1B-1	Static Inverter	Avionic Instruments
2A250-1C-1	Static Inverter	Avionic Instruments
2A350-1A	Static Inverter	Avionic Instruments
2A350-1B-1	Static Inverter	Avionic Instruments
2A50-1A	Static Inverter	Avionic Instruments
2A50-1B-1	Static Inverter	Avionic Instruments
300066-001	Dual Range Ammeter	Simmonds
300066-002	Dual Range Ammeter	Simmonds
30-5938-1	Inverter	General Design
30-5938-2	Inverter	General Design
30-5938-3	Inverter	General Design
30-5938-4	Inverter	General Design
30-5938-5	Inverter	General Design
30-5938-6	Inverter	General Design
30-5938-7	Inverter	General Design
30B37-37-A	DCGenerator	Bendix
31-304	Inverter	Weston
356 H 28 02	Power Supply	JPC Aviation
36200-1C-A1	Power Fail Ind.	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
371GC01Y02	DCGenerator	ECE
372GC01Y	DCGenerator	ECE
3A125-1B-1	Static Inverter	Avionic Instruments
3A125-1C	Static Inverter	Avionic Instruments
3A250-1B-1	Static Inverter	Avionic Instruments
3A350-1B-1	Static Inverter	Avionic Instruments
3A50-1B-1	Static Inverter	Avionic Instruments
423470-1	Volt/Frequency	Kearfott
423470-2	Volt/Frequency	Kearfott
4371	Magneto	Unison Industries

501-1075-01	Emergency Power Supply	JET
501-1075-02	Emergency Power Supply	JET
501-1075-03	Emergency Power Supply	JET
501-1075-04	Emergency Power Supply	JET
501-1075-05	Emergency Power Supply	JET
501-1075-06	Emergency Power Supply	JET
501-1075-07	Emergency Power Supply	JET
501-1075-08	Emergency Power Supply	JET
501-1075-09	Emergency Power Supply	JET
501-1075-10	Emergency Power Supply	JET
501-1075-11	Emergency Power Supply	JET
501-1075-12	Emergency Power Supply	JET
501-1075-13	Emergency Power Supply	JET
501-1075-14	Emergency Power Supply	JET
501-1075-15	Emergency Power Supply	JET
501-1075-16	Emergency Power Supply	JET
501-1128-( )	Emergency Power Supply	JET
501-1228	Emergency Power Supply	JET
506	Voltameter Indicator	Weston
51-2001	Voltmeter	R C Allen
51B1421/1	Voltmeter	R C Allen
51B2421	Voltmeter	R C Allen
51B2421/2	Voltmeter	R C Allen
520315	DC Indicator	Weston
520609	DC Indicator	Weston
520610	DC Indicator	Weston
522410	DC Indicator	Weston
522541	Voltameter Indicator	Weston
562-936	Indicator Ammeter	Hickok
563-193	Prop Amps Indicator	Hickok
563-267	Prop Amps Indicator	Hickok
563-305	Prop Amps Indicator	Hickok
570-529	Voltmeter	Hickok
58-380089	Prop Amps Indicator	R C Allen

Primary Part Number	Nomenclature	Manufacture
58-380089-1	Prop Amps Indicator	R C Allen
5-90495	Ammeter	Rochester
60-1750	Flashtube Power Sypply	Honeywell/Grimes
60-1750-3	Flashtube Power Sypply	Honeywell/Grimes
60-1750-7	Flashtube Power Sypply	Honeywell/Grimes
60-2000 SERIES	Power Supply	SDI
60-2024	Power Supply	SDI
60-2028	Power Supply	SDI
60-2034	Power Supply	SDI
60-2038	Power Supply	SDI
60-2058	Power Supply	SDI
60-2667-1	Power Supply	Grimes
60-2667-3	Power Supply	Grimes
60-2667-5	Power Supply	Grimes

60-2667-7	Power Supply	Grimes
60-3782-5	Power Supply	Grimes
606	Voltameter Indicator	Weston
61-2004	Power Supply	SDI
61-2008	Power Supply	SDI
62-2024	Power Supply	SDI
62-2028	Power Supply	SDI
62-2034	Power Supply	SDI
62-2038	Power Supply	SDI
62-2058	Power Supply	SDI
640281-115	Ammeter	Rochester
652832	Power Control Unit	Sperry
654946	Induction Generator	Sangame
661205	Power Supply	Sperry
671434	Power Control Unit	Sperry
701020-5	Power Supply	Hoskins
836525	Power Controler	Teledyne
836525-3	Power Controller	Teledyne
836525-5	Power Controler	Teledyne
836525-7	Power Controller	Teledyne
8AW41VBT12	Voltmeter	Ametek/GE
8AW43AAA205	Ammeter	Ametek/GE
8AW43VAB1	Voltmeter	Ametek/GE
8AW59AA1	Frequency Meter	Ametek/GE
8AW59FAA1	Frequency Meter	Ametek/GE
8AW59FAC1	Frequency Meter	Ametek/GE
8AW59HAA1	Voltmeter	Ametek/GE
8AW60F1AA1	Frequency Meter	Ametek/GE
8AW60F2AA1	Frequency Meter	Ametek/GE
8AW60FLE1	Frequency Meter	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8AW60LFA1	Frequency Meter	Ametek/GE
8AW60LFA200	Frequency Meter	Ametek/GE
8AW60LFD2	Frequency Meter	Ametek/GE
8AW61A1AA1	Voltmeter	Ametek/GE
8AW61A1AD1	Voltmeter	Ametek/GE
8AW61A2AA1	Voltmeter	Ametek/GE
8AW61LAA1	Voltmeter	Ametek/GE
8AW61LAA210	Voltmeter	Ametek/GE
8AW61LAA211	Voltmeter	Ametek/GE
8AW61LAB1	Voltmeter	Ametek/GE
8AW61LAC2	Voltmeter	Ametek/GE
8AW61LAC200	Ammeter	Ametek/GE
8AW61LAD2	Voltmeter	Ametek/GE
8AW61LAH1	Voltmeter	Ametek/GE
8AW61LAH214	Voltmeter	Ametek/GE
8AW61LAH216	Voltmeter	Ametek/GE
8AW61LAL3	Voltmeter	Ametek/GE
8AW61LAS1	Voltmeter	Ametek/GE

8AW61LAT1	Voltmeter	Ametek/GE
8AW61LAT213	Voltmeter	Ametek/GE
8AW61LAZ1	Voltmeter	Ametek/GE
8AW61LBA1	Voltmeter	Ametek/GE
8AW61LVA1	Voltmeter	Ametek/GE
8AW61LVA218	Voltmeter	Ametek/GE
8AW61LVD211	Voltmeter	Ametek/GE
8AW61LVF1	Voltmeter	Ametek/GE
8AW61LVZ1	Voltmeter	Ametek/GE
8AW61V1AA1	Voltmeter	Ametek/GE
8DN4ACA	Ammeter	Ametek/GE
8DW53BAC208	Voltameter Indicator	Ametek/GE
8DW53BAC216	Voltameter Indicator	Ametek/GE
8DW53BAC221	Voltameter Indicator	Ametek/GE
8DW53BAD213	Voltameter Indicator	Ametek/GE
8DW53BAD224	Voltmeter	Ametek/GE
8DW53BAD225	Voltameter Indicator	Ametek/GE
8DW53BAD226	Voltameter Indicator	Ametek/GE
8DW53BCB220	Voltameter Indicator	Ametek/GE
8TJ88GAH1	Power Supply	G.E./Ametek
9021	Voltameter Indicator	Insco
90702	Ammeter	Roller-Smith
91000-7	Static Inverter	Flite-Tronics
91300-4	Static Inverter	Flite-Tronics
91300-5	Static Inverter	Flite-Tronics
91300-8	Static Inverter	Flite-Tronics

Primary Part Number	Nomenclature	Manufacture
96-384053-1	Load Meter	Beechcraft
A-1155-1	Load Indicator	Hickok
A-1155-3	Load Indicator	Hickok
AN3203V150	Voltmeter	Hickok
AN3203V30	Voltmeter	Hickok
ASH584-1	Static Inverter	Ametek/GE
ASH584-2	Static Inverter	Ametek/GE
ASH584-4	Static Inverter	Ametek/GE
ASH732-1P	Inverter	General Electric
B-1	Voltmeter	Hickok
BG49A	Power Supply	Honeywell
BG49A-1	Power Supply	Honeywell
BYLM 66800625-0307	Generator	Barber-Colman
BYLM 6680-618-6187	Generator	Barber-Colman
BYLM 74020-18	Generator	Barber-Colman
BYLM 74020-19	Generator	Barber-Colman
BYLM 7G318	Generator	Barber-Colman
BYLM 7G319	Generator	Barber-Colman
C594502-0101	Flasher Power Unit	Aeroflash
C611002-0105	Series Regulator	Cessna
CR2795-B105A1	Voltage Regulator	Air Force
CSV1105-2	DC Voltage Regulator	AMF

CSV1105-20	Voltage Regulator	AMF
DR-10	Power Junction Box	Eclipse Pioneer
DR-12	Power Junction Box	Eclipse Pioneer
DR-13	Power Junction Box	Eclipse Pioneer
DR-13X	Power Junction Box	Eclipse Pioneer
DR-21-A1	Power Junction Box	Eclipse Pioneer
DR-21-A2	Power Junction Box	Eclipse Pioneer
DR-23-A1	Power Junction Box	Eclipse Pioneer
DR-23-A2	Power Junction Box	Eclipse Pioneer
DR-50-A1	Power Junction Box	Bendix
DR-8	Power Junction Box	Eclipse Pioneer
EA-40B-2	Voltage Compensator	Liquidometer
GC-5-A2	Power Supply	Eclipse Pioneer
GC-5-B2	Power Supply	Eclipse Pioneer
KA 39	Voltage Converter	Honeywell/Bendix-Kir
KA39	Voltage Converter	Bendix
L-1037	Magneto	Slick
L-1363C	Magneto	Unison Industries
MF-1	Power Supply	Eclipse Pioneer
MIL-G-6162	Voltage Regulator	Military Specification
P-20	Inverter	JET
P-21	Inverter	JET

Primary Part Number	Nomenclature	Manufacture
PC14	Static Inverter	Flite-Tronics
PC-14	Static Inverter	Flite-Tronics
PC14A	Static Inverter	Flite-Tronics
PC-14A	Static Inverter	Flite-Tronics
PC-14C	Static Inverter	Flite-Tronics
PC-14D	Static Inverter	Flite-Tronics
PC-15B	Static Inverter	Flite-Tronics
PC-15BC	Static Inverter	Flite-Tronics
PC-15BCD	Static Inverter	Flite-Tronics
PC-15BCE	Static Inverter	Flite-Tronics
PC-15BCH	Static Inverter	Flite-Tronics
PC-17	Static Inverter	Flite-Tronics
PC-17A	Static Inverter	Flite-Tronics
PC-250	Static Inverter	Flite-Tronics
PE24-1RM	Emergency Power Supply	AIM
PS-823( )	Emergency Power Supply	JET
PS-835 ( )	Emergency Power Supply	JET
PWC-150	Power Converter	Collins
QG246A	Power Supply	Honeywell
QG274A	Power Supply	Honeywell
QG275A	Power Supply	Honeywell
RG7038A	Power Supply	Honeywell
RG7038B	Power Supply	Honeywell
S6190-61084	Power Fail Detector	Sikorsky
SG6A-1	Power Supply	Honeywell
SG6A-2	Power Supply	Honeywell

SG6A-3	Power Supply	Honeywell
SG6A-4	Power Supply	Honeywell
SG6B-1	Power Supply	Honeywell
SG6B-2	Power Supply	Honeywell
SG6D-1	Power Supply	Honeywell
SG6D-2	Power Supply	Honeywell
SG6D-3	Power Supply	Honeywell
SG6D-4	Power Supply	Honeywell
SG6E-1	Power Supply	Honeywell
SG6E-2	Power Supply	Honeywell
SUE40031-1	High Volt Power Sup Assem	Emerson Electric Co
XP-650	Power Supply	Elenco
XP-750	Power Supply	Elenco
100-384049-3	Indicator	US Gauge
10058-A	Landing Gear Press. Ind.	Electric Auto-Lite Co
10059-A	Oil Pressure Indictaor	Electric Auto-Lite Co
101-384133-1	Suction Gauge	AID
102076-1-5	Cabin Pressure	Airesearch

Primary Part Number	Nomenclature	Manufacture
102076-1-6	Cabin Outflow Valve	Airesearch
102076-3	Cabin Out Flow Valve	Airesearch
102076-3-11	Cabin Pressure	Airesearch
102076-3-12	Cabin Out Flow Valve	Airesearch
102076-350-1	Cabin Out Flow Valve	Airesearch
102076-5	Cabin Pressure	Airesearch
102076-500-3	Cabin Pressure	Airesearch
102076-745-3	Cabin Pressure	Airesearch
102076-8	Cabin Air Pressure Control	Garrett
102094-655	Valve	Airesearch
1021PG/CP	Desynn Pressure Indicator	Smith Industries
10226-A	Oil Pressure Indicator	Electric Auto-Lite Co
10228-A	Oil Pressure Indictaor	Electric Auto-Lite Co
1022PG/SB	Desynn Pressure Indicator	Smith Industries
10230-A	Landing Gear Press. Ind.	Electric Auto-Lite Co
10231-A	Automatic Pilot Pressure	Electric Auto-Lite Co
10232-A	Fuel Pressure Indicator	Electric Auto-Lite Co
102538-2-1	Cabin Pressure	Allied Signal
102538-3-1	Cabin Out Flow Valve	Garrett
102538-5-1	Cabin Out Flow Valve	Allied Signal
103006-1-6	Safety Valve	Airesearch
103006-1-9	Safety Valve	Airesearch
103006-2-6	Valve	Airesearch
103006-714	Safety Valve	Airesearch
103006-810-1	Safety Valve	Airesearch
1030PG/SB	Desynn Pressure Indicator	Smith Industries
103104-2-4	Valve	Airesearch
103104-2-5	Valve	Airesearch
103104-3	Valve	Airesearch
103104-6-1	Valve	Airesearch

103104-942	Safety Valve	Airesearch
103104-942-2	Valve	Airesearch
103648-5	Outflow Valve	Garrett
104250001	Pressure Indicator/Switch	Smith Industries
104-384012-3	Torque Indicator	US Gauge
104598	Valve	Airesearch
104598-1	Valve	Airesearch
104598-2	Valve	Airesearch
10490-A	Oil Pressure Indictaor	Electric Auto-Lite Co
105036	Regulator	Airesearch
105180-200	Regulator	Airesearch
1051PG/CP	Desynn Pressure Indicator	Smith Industries
106076-20	Regulator	Airesearch
106076-25	Regulator	Airesearch

Primary Part Number	Nomenclature	Manufacture
10632-A	Landing Gear Press. Ind.	Electric Auto-Lite Co
108090-120	Regulator	Airesearch
108092-40-1	Regulator	Airesearch
108092-45-1	Regulator	Airesearch
10818-A	Oil Pressure Indictaor	Electric Auto-Lite Co
10845A	Oil Pressure Indicator	Electric Auto-Lite Co
1109PG/CP	Desynn Pressure Indicator	Smith Industries
114.099-3	Hydraulic Pressure Indicator	Kratos
115.026	Hydraulic Pressure Indicator	Kratos
115.201-3	Hydraulic Pressure Indicator	Kratos
1159SCH240-1	Hydraulic Pressure Transmitter	Gulfstream
116049-01	Pressure Control	Lear Siegler
1169U-041041	Oil/Fuel Pressure Ind.	Kollsman
1169U-041042	Oil/Fuel Pressure Ind.	Kollsman
1169U-041043	Oil/Fuel Pressure Ind.	Kollsman
1169U-041044	Oil/Fuel Pressure Ind.	Kollsman
1169U-041046	Oil/Fuel Pressure Ind.	Kollsman
1169U-041056	Oil/Fuel Pressure Ind.	Kollsman
11800-0001	Thrust Indicator	Astronautics
11964A	Fluid Injector Pressure Ind.	Electric Auto-Lite Co
1198PG/CP	Desynn Pressure Indicator	Smith Industries
1227U-041040	Teletorque Pressure Ind.	Kollsman
1227U-041041	Teletorque Pressure Ind.	Kollsman
1227U-041042	Teletorque Pressure Ind.	Kollsman
122PN01	Indicator	E.C.E.
123PN01	Indicator	E.C.E.
124.102	Torque Indicator	Kratos
124.102-2	Torque Indicator	Kratos
124.102-3	Torque Indicator	Kratos
124.102-4	Torque Indicator	Kratos
124.334	Oil Pressure Indictaor	Kratos
124.335	Oil Pressure Indicator	Kratos
124.511-1	Torque Indicator	Kratos
124.511-2	Torque Indicator	Kratos

124.643	Torque Indicator	Kratos
124.643-2	Torque Indicator	Kratos
124.643-3	Torque Indicator	Kratos
1253B-4-02	Manifold Pressure Indicator	Kollsman
1253CU-4-02	Air Pressure Indicator	Kollsman
1268-000	Fuel Diff. Pressure Switch	Le Bozec
126PN01Y07	Indicator	E.C.E.
1271U-8-03	Fuel Pressure Indicator	Kollsman
12882-A	Landing Gear Press. Ind.	Electric Auto-Lite Co
12936-A	Oil Pressure Indictaor	Electric Auto-Lite Co

Primary Part Number	Nomenclature	Manufacture
13006-714	Valve	Airesearch
13010-26	Cabin Pressure Regulator	Airesearch
13010-30	Cabin Pressure Regulator	Airesearch
1301-1001	Altimeter	Aerosonic
13014-18	Cabin Pressure Regulator	Airesearch
13014-28	Cabin Pressure Regulator	Airesearch
13014-8	Cabin Pressure Regulator	Airesearch
13016	Auxiliary Regulator	Airesearch
13016-1	Auxiliary Regulator	Airesearch
13022-12-100	Cabin Pressure Regulator	Airesearch
13022-6	Cabin Pressure Regulator	Airesearch
13022-6-150	Cabin Pressure Regulator	Airesearch
13022-6S	Cabin Pressure Regulator	Airesearch
13023-12	Cabin Pressure Regulator	Airesearch
13023-6	Cabin Pressure Regulator	Airesearch
13036-10	Cabin Pressure Regulator	Airesearch
130400-1-1	Cabin Pressure	Airesearch
130400-2-1	Autflow Valve Controls	Airesearch
13041-8-275	Cabin Pressure Regulator	Airesearch
13046-4	Auxiliary Regulator	Airesearch
13050-10	Cabin Pressure Selector	Airesearch
13050-2	Cabin Pressure Selector	Airesearch
13051-4P	Cabin Pressure Regulator	Airesearch
13052-6	Cabin Pressure Regulator	Airesearch
13052-6S	Cabin Pressure Regulator	Airesearch
13055-22	Cabin Pressure Regulator	Airesearch
13060-2-60	Rate of Change Selector	Airesearch
13060-60	Rate of Change Selector	Airesearch
13062-6	Cabin Pressure Regulator	Airesearch
13063-10-275	Cabin Pressure Regulator	Airesearch
13063-10-275M	Cabin Pressure Regulator	Airesearch
13080-20-500-1	Cabin Pressure Regulator	Airesearch
13080-5-275	Cabin Pressure Regulator	Airesearch
13084	Auxiliary Regulator	Airesearch
13120-2	Differential Changer Assy.	Airesearch
13130	Differential Timer Assy.	Airesearch
13160	Differential Timer Assy.	Airesearch
13160-2	Differential Timer Assy.	Airesearch

1326-041045	Manifold Pressure Transmitter	Kollsman
13298-4A	Cabin Control system	IDC
13299-3	Cabin Control system	IDC
13375-1	Cabin Control System	IDC
1358-041040	Fuel Pressure Transmitter	Kollsman
135PN01	Indicator	E.C.E.

Primary Part Number	Nomenclature	Manufacture
13617-A	Hydraulic Pressure Indicator	Electric Auto-Lite Co
13650	Differential Changer Assy.	Airesearch
13653-A	Oil Pressure Indictaor	Electric Auto-Lite Co
13710	Differential Timer Assy.	Airesearch
1389U-8-03	Cabin Airflow Press. Ind.	Kollsman
1391-041046	Oil/Fuel Pressure Ind.	Kollsman
140506A	Cabin Pressure Control System	Garrett
140506B	Cabin Air Pressure Control Sys	Garrett
1423-1036-101	Pressure Switch	Airweld, Inc.
1425-0414	Differential Circutrol	Kollsman
14267-A	Pressure Indicator	Electric Auto-Lite Co
14320-2	Isobaric Changer Assy.	Airesearch
14320-8	Isobaric Changer Assy.	Airesearch
14546-A	Bleed Manifold Pressure Gage	Electric Auto-Lite Co
1456PG/CP	Desynn Pressure Indicator	Smith Industries
1457PG/CP	Desynn Pressure Indicator	Smith Industries
14590-10-275	Cabin Pressure Regulator	Airesearch
14590-15-500	Cabin Pressure Regulator	Airesearch
150708	Pressure Indicator	Aero Mechanism
1558-041041	Fuel Pressure Indicator	Kollsman
1558-041044	Hydraulic Pressure Indicator	Kollsman
1558B-041041	Fuel Pressure Indicator	Kollsman
1558C-041040	Oil Pressure Indictaor	Kollsman
1558C-041042	Fuel Pressure Indicator	Kollsman
1569-041040	Manifold Pressure Transmitter	Kollsman
1570-041040	Pressure Indicator	Kollsman
1570B-041040	Pressure Indicator	Kollsman
1570C-041041	Pressure Indicator	Kollsman
16184	Torque Indicator	Aerosonic
16298-1	Cabin Control System	IDC
16299-1	Cabin Control System	IDC
169A-910-3L	Oil Pressure Indictaor	Sigma Tek
169A-910-4	Fuel Pressure Indicator	Sigma Tek
169A-910-4L	Fuel Pressure Indicator	Sigma Tek
169AB-914	Oil Pressure Indicator	Sigma Tek
169AB-914-1	Oil Pressure Transmitter	Sigma Tek
169AC-914-1L	Oil Pressure Indictaor	Sigma Tek
169AC-914-1L-1	Oil Pressure Indictaor	Sigma Tek
169AE-914-11L	Oil Pressure Indictaor	Sigma Tek
169AF-914-12L	Oil Pressure Indictaor	Sigma Tek
169AJ-910-3	Oil Pressure Indictaor	Sigma Tek
169AJ-914-1	Fuel Pressure Indicator	Sigma Tek

169AJ-914-2	Fuel Pressure Indicator	Sigma Tek
169AM-914	Oil Pressure Indictaor	Sigma Tek

Primary Part Number	Nomenclature	Manufacture
169AN-914-1	Oil Pressure Indictaor	Sigma Tek
169AN-914-2	Oil Pressure Indictaor	Sigma Tek
169AN-914-3	Fuel Pressure Indicator	Sigma Tek
169AN-914-4	Fuel Pressure Indicator	Sigma Tek
169AR-914-1	Oil Pressure Indictaor	Sigma Tek
169B-914	Oil Pressure Indictaor	Sigma Tek
169B-914L	Oil Pressure Indictaor	Sigma Tek
169C-914-1	Oil Pressure Indictaor	Sigma Tek
169C-914-1L	Oil Pressure Indictaor	Sigma Tek
169D-914-1	Oil Pressure Indictaor	Sigma Tek
169D-914-1L	Oil Pressure Indictaor	Sigma Tek
169E-914-1	Oil Pressure Indictaor	Sigma Tek
169P-914-5L	Oil Pressure Indictaor	Sigma Tek
169P-914-5L-1	Oil Pressure Indictaor	Sigma Tek
169P-914-6L	Fuel Pressure Indicator	Sigma Tek
169Q-914-1	Oil Pressure Indictaor	Sigma Tek
169S-910-3	Oil Pressure Indictaor	Sigma Tek
169U-914-8	Fuel Pressure Indicator	Sigma Tek
18-1105	Hydraulic Pressure Indicator	Courter
18-1108	Oil Pressure Indictaor	Courter
18-1153	Hydraulic Pressure Indicator	Courter
18-1169	Pressure Indicator	Courter
18-1199-01	Pressure Indicator	Courter
18-1699	Pressure Transmitter	Allied Signal
18-1724-2	Pressure Transmitter	Courter
18-1724-3	Pressure Transmitter	Courter
18-1796	Transmitter	Allied-Signal
18-1969-18	Transmitter	Honeywell
18-2021	Pressure Indicator	Courter
18-3114-2	Transmitter	Allies-Signal
1880574-1	Torque Adaptor	Bendix
19-2000	Fuel Pressure Indicator	AID
19697-2	Manifold Pressure Indicator	R C Allen
19697-3	Manifold Pressure Indicator	R C Allen
19697-4	Manifold Pressure Indicator	R C Allen
19697-5	Manifold Pressure Indicator	R C Allen
19697-6	Manifold Pressure Indicator	R C Allen
19697-7	Manifold Pressure Indicator	R C Allen
1G9-37	Suction Gauge	Airborne
1U028-001-1	Manifold Pressure Indicator	Sigma Tek
1U028-001-11	Manifold Pressure Indicator	Sigma Tek
1U028-001-12	Manifold Pressure Indicator	Sigma Tek
1U028-003-34	Fuel Pressure Indicator	Sigma Tek
1U028-003-38	Fuel Pressure Indicator	Sigma Tek

Primary Part Number	Nomenclature	Manufacture

1U028-004-20	Fuel Pressure Indicator	Sigma Tek
1U028-004-22	Fuel Pressure Indicator	Sigma Tek
1U028-004-24	Fuel Pressure Indicator	Sigma Tek
1U028-004-25	Fuel Pressure Indicator	Sigma Tek
1U028-004-26	Fuel Pressure Indicator	Sigma Tek
1U028-004-31	Fuel Pressure Indicator	Sigma Tek
1U028-004-4	Fuel Pressure Indicator	Sigma Tek
1U028-004-40	Fuel Pressure Indicator	Sigma Tek
1U028-104-20	Fuel Pressure Indicator	Sigma Tek
1U028-104-22	Fuel Pressure Indicator	Sigma Tek
1U028-104-23	Fuel Pressure Indicator	Sigma Tek
1U028-104-44	Fuel Pressure Indicator	Sigma Tek
1U028-201-27	Manifold Pressure Indicator	Sigma Tek
1U028-201-32	Manifold Pressure Indicator	Sigma Tek
1U028-202-13	Manifold Pressure Indicator	Sigma Tek
1U028-202-29	Manifold Pressure Indicator	Sigma Tek
1U028-202-33	Manifold Pressure Indicator	Sigma Tek
1U028-202-4	Manifold Pressure Indicator	Sigma Tek
1U028-202-8	Manifold Pressure Indicator	Sigma Tek
1U028-203-41	Torque Indicator	Sigma Tek
1U028-204-7	Pressure Indicator	Sigma Tek
1U028-960	Manifold Pressure Indicator	Sigma Tek
1U028-961	Manifold Pressure Indicator	Sigma Tek
200	Suction Gauge	Collins
20000-37A-4-A3	Torque Indicator	Eclipse Pioneer
20000-3B-4-A1	Pressure Indicator	Eclipse Pioneer
20002-37A-4-A1	Torque Indicator	Eclipse Pioneer
20002-37B-4-A1	Torque Indicator	Eclipse Pioneer
20002-37C-17-A1	Torque Indicator	Eclipse Pioneer
20003-53G-15-A2	Torque Indicator	Eclipse Pioneer
20003-53P-15-A2	Torque Indicator	Eclipse Pioneer
200-071-003	Fuel Pressure Indicator	Gull
200A	Suction Gauge	Collins
200B	Suction Gauge	Collins
201-004-001	Torque Indicator	Gull
20300-38A-4-A1	Pressure Indicator	Eclipse Pioneer
203-023-003	Hydraulic Pressure Indicator	Gull
21000 Series	Pressure Indicator	Eclipse Pioneer
21000-24A-4-A1	Fuel/Oil Pressure Indicator	Eclipse Pioneer
21000-4D-4-A1	Oil Pressure Indictaor	Eclipse Pioneer
21000-4F-4-A1	Oil Pressure Indictaor	Eclipse Pioneer
21000-4R-4-A1	Oil Pressure Indictaor	Eclipse Pioneer
21000-4T-20-A1	Pressure Indicator	Eclipse Pioneer
21000-5AD-20-A1	Pressure Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
21000-5V-4-A1	Fuel Pressure Indicator	Eclipse Pioneer
21000-5W-4-A1	Water Pressure Indicator	Eclipse Pioneer
21002-37A-16-A1	Torque Indicator	Eclipse Pioneer
21004-37C-16-A2	Torque Indicator	Eclipse Pioneer

21004-37D-18-A4	Torque Indicator	Eclipse Pioneer
21005-24B-19-A2	Fuel/Oil Pressure Indicator	Eclipse Pioneer
21005-24C-19-A3	Fuel/Oil Pressure Indicator	Eclipse Pioneer
21005-4L-19-A1	Oil Pressure Indicator	Eclipse Pioneer
21005-4S-19-A2	Oil Pressure Indictaor	Eclipse Pioneer
21005-85B-19-A2	Fuel/Oil Pressure Indicator	Eclipse Pioneer
21100-3C-100-A1	Pressure Indicator	Eclipse Pioneer
21100-3C-99-A1	Pressure Indicator	Eclipse Pioneer
212-070-160-07	Dual Torque Indicator	BELL
212-070-160-1	Torque Indicator	McGraw-Edison
212-070-2383	Altimeter	Aerosonic
217-00141	Oil Pressure Indicator	Edison
217-00151	Oil Pressure Indicator	Edison
217-00251	Oil Pressure Indicator	Edison
217-06251	Oil Pressure Indictaor	Edison
217-100A	Oil Pressure Indictaor	Edison
217-12261	Torque Indicator	Edison
217-13241	Torque Indicator	Edison
217-13261	Torque Indicator	Edison
217-15261	Torque Indicator	Edison
217-16261	Torque Indicator	Edison
217-21242	Oil Pressure Indicator	Edison
217-50A	Oil Pressure Indictaor	Edison
217A-100A	Oil Pressure Indictaor	Edison
217A-50A	Oil Pressure Indictaor	Edison
217A-60A	Oil Pressure Indictaor	Edison
218-100	Oil Pressure Indictaor	Edison
218-100A	Oil Pressure Indictaor	Edison
218-50A	Oil Pressure Indictaor	Edison
21B304	Manifold/Fuel Pressure Ind.	Beechcraft
21C361	Manifold/Fuel Pressure Ind.	AID
22000-1-A1	Fuel Pressure Transmitter	Eclipse Pioneer
22001-2-A1	Oil Pressure Transmitter	Eclipse Pioneer
22001-2-C1-2	Oil Pressure Transmitter	Eclipse Pioneer
22002-15-A1	Water Pressure Transmitter	Eclipse Pioneer
22002-4-A1	Water Pressure Transmitter	Eclipse Pioneer
22003-2-A1	Oil Press Transmitter	Eclipse Pioneer
22003-2-B1	Oil Pressure Transmitter	Eclipse Pioneer
22005-15-A1-2	Water Pressure Transmitter	Eclipse Pioneer
22005-1-A1-2	Fuel Pressure Transmitter	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
22005-4-A1-1	Fuel Pressure Transmitter	Eclipse Pioneer
22005-4-A1-2	Water Pressure Transmitter	Eclipse Pioneer
22007-30-A1-2	Oil Pressure Transmitter	Eclipse Pioneer
22101-19-A5	Torque Pressure Transmitter	Eclipse Pioneer
22102-19-A5	Torque Pressure Transmitter	Eclipse Pioneer
22105-19-A5-1	Torque Pressure Transmitter	Eclipse Pioneer
22105-19-A5-2	Torque Pressure Transmitter	Eclipse Pioneer
22105-19-A5-3	Torque Pressure Transmitter	Eclipse Pioneer

22105-25-A5-1	Torque Pressure Transmitter	Eclipse Pioneer
22105-53-A5-1	Torque Pressure Transmitter	Eclipse Pioneer
22200-8-A5	Pressure Transmitter	Eclipse Pioneer
22201-14-A5	Pressure Transmitter	Eclipse Pioneer
22201-14-B5-1	Pressure Transmitter	Eclipse Pioneer
22-260-014	Manifold Pressure Indicator	Electric Auto-Lite Co
22-260-020	Dual Manifold Pressure	Garwin
22300-23-B5	Pressure Transmitter	Eclipse Pioneer
22-868	Fuel Pressure Indicator	Electric Auto-Lite Co
22-869	Fuel Pressure Indicator	Electric Auto-Lite Co
229-8009-020	Torque Indicator	Collins
229-8009-040	Torque Indicator	Collins
229-8010-030	Torque Indicator	Collins
24024	EPR Transmitter	Airesearch
24024-1	EPR Transmitter	Airesearch
24024-2	EPR Transmitter	Airesearch
24100-37B-20-A6	Torque Indicator	Eclipse Pioneer
24100-40A-4-A1	Water Pressure Indicator	Eclipse Pioneer
24100-40B-19-A7	Water Pressure Indicator	Eclipse Pioneer
24100-40C-19-A8	Water Pressure Indicator	Eclipse Pioneer
24100-45H-21-A1	Pressure Indicator	Eclipse Pioneer
24100-45J-21-A1	Pressure Indicator	Eclipse Pioneer
24100-4K-21-A1	Oil Pressure Indictaor	Bendix
24100-5F-4-A1	Water Pressure Indicator	Eclipse Pioneer
24128	EPR Indicator	Airesearch
2418-43A-A1	Fuel Pressure Indicator	Eclipse Pioneer
2418-43A-C1	Fuel Pressure Indicator	Eclipse Pioneer
24200-14B-43-A1	Hydraulic Pressure Indicator	Eclipse Pioneer
24200-78A-43-A1	Pressure Indicator	Eclipse Pioneer
24200-78A-44-A1	Pressure Indicator	Eclipse Pioneer
24414	EPR Transmitter	Airesearch
24500-37A-1-A1	Torque Indicator	Eclipse Pioneer
24500-37A-1-B1	Torque Indicator	Eclipse Pioneer
25000-A46A-1-3B1	Pressure Indicator	Eclipse Pioneer
25000-A46A-1-3B2	Pressure Indicator	Eclipse Pioneer
25000-A6A-1-1A1	Pressure Indicator	Eclipse Pioneer
Primary Part Number	**Nomenclature**	**Manufacture**
25000-A6A-1-1B1	Pressure Indicator	Eclipse Pioneer
25000-B14A-1-2B1	Pressure Indicator	Eclipse Pioneer
25001-A46A-1-3A1	Pressure Indicator	Eclipse Pioneer
25001-A6A-1-1A1	Pressure Indicator	Eclipse Pioneer
25001-A6B-1-1A2	Pressure Indicator	Eclipse Pioneer
25001-A6C-1-1A1	Pressure Indicator	Eclipse Pioneer
25001-B14A-1-2A1	Pressure Indicator	Eclipse Pioneer
25100-A15A-1-B1	Pressure Indicator	Eclipse Pioneer
253683	Oil Pressure Indicator	Weston
254BK-4-087	Cabin Pressure	Kollsman
254BK-8-046	Suercharger Airflow Indicator	Kollsman
2550	Vacuum Regulator	Schwien

25500-A1A-1-A1	Pressure Indicator	Eclipse Pioneer
25500-A56A-1-A1	Pressure Indicator	Eclipse Pioneer
25601-A17A-20-A1	Hydraulic Pressure Indicator	Bendix
25601-A37C-7-A1	Hydraulic Pressure Indicator	Bendix
256118-1	Cabin Pressure Calibrator	Airesearch
2650	Vacuum Regulator	Schwien
2650A	Vacuum Regulator	Schwien
26801A3083A1	Oil Pressure Indicator	Bendix
26801-A30B-3-A1	Oil Pressure Indicator	Bendix
27-1004	Manifold Pressure Indicator	R C Allen
27-19121-3	Hydraulic Pressure Indicator	Hickok
27-19123-5	Oxygen Pressure Indicator	Hickok
27-19123-7	Oxygen Pressure Indicator	Hickok
27-19124-3	Deice Pressure Ind.	Hickok
27-19161-1	Fuel Pressure Indicator	Hickok
27-19177-1	Fuel Pressure Indicator	Hickok
27-2000-1	Manifold Pressure Indicator	R C Allen
27-2000-2	Manifold Pressure Indicator	R C Allen
27-2000-3	Manifold Pressure Indicator	R C Allen
27-2000-4	Manifold Pressure Indicator	R C Allen
27-2000-5	Manifold Pressure Indicator	R C Allen
27-2000-6	Manifold Pressure Indicator	R C Allen
27-2000-7	Manifold Pressure Indicator	R C Allen
27-3100	Oil Pressure Indictaor	AID
2750	Vacuum Regulator	Schwien
2750A	Vacuum Regulator	Schwien
27-7003	Hydraulic Pressure Indicator	R C Allen
27B411	Suction Gauge	AID
30100-1-3.00	Relief Valve	Pacific Airmotive
30100-2-3.00	Relief Valve	Pacific Airmotive
30100-3.5	Relief Valve	Pacific Airmotive
30100-3.50	Relief Valve	Pacific Airmotive

Primary Part Number	Nomenclature	Manufacture
30150-3.50	Relief Valve	Pacific Airmotive
30150-5.35	Relief Valve	Pacific Airmotive
303-006-003	Torque Indicator	Gull
3057-3-131	Torque Indicator	Labem
3057-3-136-1	Torque Indicator	Labem
3057-3-136-3	Torque Indicator	Labem
3057-3-136-4	Torque Indicator	Labem
3057-3-136-5	Torque Indicator	Labem
3060-0018	Pressure Transmitter	Rochester
3-102-43	Torque Indicator	UMA
3120-2-A	Fuel/Water Pressure Ind.	Eclipse Pioneer
3123-2-A	Fuel/Water Pressure Ind.	Eclipse Pioneer
3124-1-A-18	Vacuum Warning Switch	Eclipse Pioneer
3129-1-A	Fuel/Water Pressure Ind.	Eclipse Pioneer
3131-1-A-200	Oil Pressure Warn Switch	Eclipse Pioneer
3131-1-B-250	Oil Pressure Warn Switch	Eclipse Pioneer

3131-1-B-750	Oil Pressure Warn Switch	Eclipse Pioneer
3135-11-C-180	Pressure Warning Unit	Bendix
3135-12-C-120	Pressure Warning Unit	Bendix
3135-13-C-35	Pressure Warning Unit	Bendix
3135-15-C-170	Pressure Warning Unit	Bendix
3135-1-A	Pressure Warning Unit	Bendix
3135-6-C-20	Pressure Warning Unit	Bendix
3135-7-C-180	Pressure Warning Unit	Bendix
3140-1-A	Oil Pressure Warn Switch	Bendix
3140-1-B	Oil Pressure Warn Switch	Bendix
3140-1-C	Oil Pressure Warn Switch	Bendix
3140-2-A	Oil Pressure Warn Switch	Bendix
3140-2-B	Oil Pressure Warn Switch	Bendix
3140-3-A	Oil Pressure Warn Switch	Bendix
3140-3-B	Oil Pressure Warn Switch	Bendix
3140-5-A	Oil Pressure Warn Switch	Bendix
3140-5-B	Oil Pressure Warn Switch	Bendix
3149-1-A	Pressure Warning Unit	Bendix
318-100	Oil Pressure Indictaor	Edison
31817	Manifold Pressure Indicator	Ranco
31853	Manifold Pressure Indicator	Ranco
318-60	Oil Pressure Indictaor	Edison
31888	Manifold Pressure Indicator	Ranco
31888A	Manifold Pressure Indicator	Ranco
31980	Pressure Indicator	Ranco
32734	Fuel Pressure Indicator	United Instruments
33092-1	Pressure Transmitter	Aerosonic
33494	Torque Indicator	Badin

Primary Part Number	Nomenclature	Manufacture
3360	Pressure Transducer	Aerosonic
34300-C1A-1-A1	EPR Indicator	Bendix
34401-30-A22-1	Oil Pressure Transmitter	Bendix
34800C1A1A2	Pressure Ratio Indicator	Bendix
34800-C1A-1-A2	Pressure Ratio Indicator	Bendix
3567617-2302	Autosyn Pressure Transmitter	Bendix
3567707	Pressure Transmitter	Allied Signal
3567707-0202	Pressure Transmitter	Allied Signal
3567707-0203	Pressure Transmitter	Allied Signal
3567707-0701	Pressure Transmitter	Allied Signal
3567707-3001	Pressure Transmitter	Allied Signal
3567707-3002	Pressure Transmitter	Allied Signal
3567707-3004	Pressure Transmitter	Allied Signal
3567707-3005	Pressure Transmitter	Allied Signal
3567707-9801	Pressure Transmitter	Allied Signal
3567707-9901	Pressure Transmitter	Allied Signal
3567742-1001	Transmitter	Allied
3567762-3001	Oil Pressure Transmitter	Honeywell
3571212-0010	Torque Indicator	Bendix
3571212-0011	Torque Indicator	Bendix

3571214-6004	Torque Indicator	Bendix
3571214-6005	Torque Indicator	Bendix
3571214-6009	Torque Indicator	Bendix
3571220-6003	Fuel Pressure Indicator	Bendix
3571220-6012	Fuel Pressure Indicator	Bendix
3571220-6013	Oil Pressure Indictaor	Bendix
3571220-6015	Oil Pressure Indictaor	Bendix
3571251-9202	Torque Indicator	Bendix
3571251-9207	Torque Indicator	Bendix
3571251-9209	Torque Indicator	Bendix
3571251-9210	Fuel Pressure Indicator	Bendix
3571251-9212	Torque Indicator	Bendix
3571251-9212M	Torque Indicator	Bendix
3571251-9215	Torque Indicator	Bendix
3571251-9216	Torque Indicator	Bendix
3571810-0007	Pressure Indicator	Bendix
3581320-1001	Oil Pressure Indictaor	Bendix
3809312-6	Torque Indicator	Bendix
3809313-5	Torque Indicator	Bendix
3809431-1	Torque Indicator	Bendix
389-00340	Pressure Transmitter	McGraw-Edison
394312-10-1	Fuel Pressure Regulator	Allied Signal
394312-1-1	Fuel Pressure Regulator	Allied Signal
394312-5-1	Fuel Pressure Regulator	Allied Signal

Primary Part Number	Nomenclature	Manufacture
394316-2-1	Fuel Pressure Valve	Garrett
3950220-9001	Torque Indicator	Bendix
402291	Hydraulic Press Warning Switch	Bendix
4025116-904	Data Computer	Sperry
4025116-905	Data Computer	Honeywell
4025116-907	Data Computer	Honeywell
4025116-908	Data Computer	Honeywell
404456	Hydraulic Press Warning Switch	Bendix
404720	Hydraulic Press Warning Switch	Bendix
404720-2-0	Hydraulic Press Warning Switch	Bendix
4050-3-A3	Fuel Pressure Transmitter	Eclipse Pioneer
4050-4-A4	Fuel Pressure Transmitter	Eclipse Pioneer
4050-4-B4	Fuel Pressure Transmitter	Eclipse Pioneer
4052-2-A2	Fuel Pressure Transmitter	Eclipse Pioneer
4052-4-A4	Fuel Pressure Transmitter	Eclipse Pioneer
4052-6-A6	Fuel Pressure Transmitter	Eclipse Pioneer
4053-2-A2	Fuel Pressure Transmitter	Eclipse Pioneer
4053-4-A4	Fuel Pressure Transmitter	Eclipse Pioneer
4053-6-A6	Fuel Pressure Transmitter	Eclipse Pioneer
4053-6-B6	Fuel Pressure Transmitter	Eclipse Pioneer
4058254-901	Thrust Rating Panel	Honeywell
4058254-902	Thrust Rating Panel	Honeywell
4059-8-A8	Oil Pressure Transmitter	Eclipse Pioneer
40-619-2	Hydraulic Pressure Indicator	Natec Electronic

40-619-3	Indicator	Ragen
4062-11-A11	Pressure Transmitter	Eclipse Pioneer
410-10L-13	Pressure Activated Switch	Meletron
410-10L-2	Pressure Activated Switch	Meletron
4101-21BL-1	Pressure Activated Switch	Meletron
4101-22B-25	Pressure Activated Switch	Meletron
4101-22B-27-1	Pressure Activated Switch	Meletron
4101-22B-27-2	Pressure Activated Switch	Meletron
4101-22B-28	Pressure Activated Switch	Meletron
4101-22B-44A	Pressure Activated Switch	Meletron
410-15-142	Pressure Activated Switch	Meletron
410-15-142A	Pressure Activated Switch	Meletron
410-15-94	Pressure Activated Switch	Meletron
410-15B-53	Pressure Activated Switch	Meletron
410-15B-95	Pressure Activated Switch	Meletron
410-15BL-201	Pressure Activated Switch	Meletron
410-15BL-80	Pressure Activated Switch	Meletron
410-15BL-93	Pressure Activated Switch	Meletron
410-15L-98A	Pressure Activated Switch	Meletron
4101E-21B-22	Pressure Activated Switch	Meletron

Primary Part Number	Nomenclature	Manufacture
410-22L-160	Pressure Activated Switch	Meletron
410-23-118	Pressure Activated Switch	Meletron
410-5L-12A	Pressure Activated Switch	Meletron
410-A21DL-116	Pressure Activated Switch	Meletron
410-A21DL-153	Pressure Activated Switch	Meletron
410-A21DL-154	Pressure Activated Switch	Meletron
410B-30-302	Pressure Activated Switch	Meletron
410E-10DBL-263	Pressure Activated Switch	Meletron
410E-10DBL-263A	Pressure Activated Switch	Meletron
410E-10DBL-264	Pressure Activated Switch	Meletron
410E-10DBL-264A	Pressure Activated Switch	Meletron
410E-15DBL-210	Pressure Activated Switch	Meletron
410E-16L-189	Pressure Activated Switch	Meletron
410E-21B-23	Pressure Activated Switch	Meletron
410E-21L-89	Pressure Activated Switch	Meletron
410E-24BL-253	Pressure Activated Switch	Meletron
410E-39DBL-256	Pressure Activated Switch	Meletron
410E-39DBL-256A	Pressure Activated Switch	Meletron
410E-A20DL-106	Pressure Activated Switch	Meletron
410E-A21DL-107	Pressure Activated Switch	Meletron
410EB-10DL-320	Pressure Activated Switch	Meletron
410EB-11L-305	Pressure Activated Switch	Meletron
411-11D-11	Vacuum Actuated Switch	Meletron
411-31-12	Vacuum Actuated Switch	Meletron
411-31-18	Vacuum Actuated Switch	Meletron
412-20BL-27A	Pressure Activated Switch	Meletron
412-32B-14	Pressure Activated Switch	Meletron
412-32B-38	Pressure Activated Switch	Meletron

412-6BL-34	Pressure Activated Switch	Meletron
412-8BL-37	Pressure Activated Switch	Meletron
412-C1LM-22	Pressure Activated Switch	Meletron
41400-C5A-1-A3	Torque Indicator	Bendix
414-10DBL-32	Pressure Activated Switch	Meletron
414-10DBL-32A	Pressure Activated Switch	Meletron
414-10DBL-33	Pressure Activated Switch	Meletron
414-10DBL-33A	Pressure Activated Switch	Meletron
414-12DBL-12	Pressure Activated Switch	Meletron
414-12DBL-35	Pressure Activated Switch	Meletron
414-15D-2	Pressure Activated Switch	Meletron
414-21DBL-25	Pressure Activated Switch	Meletron
414-22DBL-17	Pressure Activated Switch	Meletron
414-24DBL-38	Pressure Activated Switch	Meletron
4143-1	Manifold/Fuel Pressure Ind.	B & D Instruments, In
414-37DBL-5	Pressure Activated Switch	Meletron

Primary Part Number	Nomenclature	Manufacture
4150-11-A11	Torque Pressure Transmitter	Eclipse Pioneer
4150-12B-1	Aneroid Switch	Meletron
4150-16B-2	Aneroid Switch	Meletron
4150-21-B21	Oil Pressure Transmitter	Eclipse Pioneer
4150-3-A3	Oil Pressure Transmitter	Eclipse Pioneer
4150-3-B3	Oil Pressure Transmitter	Eclipse Pioneer
4151-12B-39	Aneroid Switch	Meletron
4152-1-A1	Oil Pressure Transmitter	Eclipse Pioneer
4152-22B-2	Aneroid Switch	Meletron
4152-3-A3	Oil Pressure Transmitter	Eclipse Pioneer
4152-8-A8	Oil Pressure Transmitter	Eclipse Pioneer
4153-9-A9	Oil Pressure Transmitter	Eclipse Pioneer
4154-10-A10	Oil Pressure Transmitter	Eclipse Pioneer
4154-11-A11	Torque Pressure Transmitter	Eclipse Pioneer
4154-12-A12	Torque Pressure Transmitter	Eclipse Pioneer
4154-18-A18	Fuel Pressure Transmitter	Eclipse Pioneer
4154-19-B5	Fuel Pressure Transmitter	Eclipse Pioneer
4154-9-A9	Oil Pressure Transmitter	Eclipse Pioneer
4155-3-A3	Oil Pressure Transmitter	Eclipse Pioneer
4155-8-A8	Oil Pressure Transmitter	Eclipse Pioneer
4155-8-B8	Oil Pressure Transmitter	Eclipse Pioneer
4156-32B-1	Aneroid Switch	Meletron
4158-22-A22	Torque Pressure Transmitter	Eclipse Pioneer
4159-9-A9	Torque Pressure Transmitter	Eclipse Pioneer
415EF-31-33	Aneroid Switch	Meletron
415PG	Desynn Pressure Indicator	Smith Industries
415PG/SB	Desynn Pressure Indicator	Smith Industries
4163-21-A8	Pressure Transmitter	Eclipse Pioneer
4163-27-A8	Pressure Transmitter	Eclipse Pioneer
4163-8-A8	Pressure Transmitter	Eclipse Pioneer
4164-14-A8	Pressure Transmitter	Eclipse Pioneer
4164-18-A8	Pressure Transmitter	Eclipse Pioneer

4164-6-A8	Pressure Transmitter	Eclipse Pioneer
4165-21-A25	Oil Pressure Transmitter	Eclipse Pioneer
4166-28-A25	Fuel Pressure Transmitter	Eclipse Pioneer
4166-28-A25-1	Fuel Pressure Transmitter	Eclipse Pioneer
4170-14DBL-12	Pressure Activated Switch	Meletron
417-15BL-4	Pressure Activated Switch	Meletron
4171E-20B-19	Pressure Activated Switch	Meletron
4171E-24B-14	Pressure Activated Switch	Meletron
4171E-24B-18	Pressure Activated Switch	Meletron
417-6-47	Pressure Activated Switch	Meletron
417-A7DBL-94	Pressure Activated Switch	Meletron
417E-15BL-44	Pressure Activated Switch	Meletron

Primary Part Number	Nomenclature	Manufacture
417E-5BL-32	Pressure Activated Switch	Meletron
417E-5BL-65	Pressure Activated Switch	Meletron
418-000	Oil Pressure Transmitter	Edison
418-00044	Oil Pressure Transmitter	Edison
418-15-8	Pressure Activated Switch	Meletron
418-15L-18	Pressure Activated Switch	Meletron
418-26044	Oil Pressure Transmitter	Edison
418-27044	Oil Pressure Transmitter	Edison
4250-1-A1	Manifold Pressure Transmitter	Pioneer
4250-1-B1	Manifold Pressure Transmitter	Eclipse Pioneer
4250-2-A2	Manifold Pressure Transmitter	Eclipse Pioneer
4250-2-B2	Manifold Pressure Transmitter	Eclipse Pioneer
42641	Torque Indicator	Aerosonic
4308-3018	Torque Indicator	Insco
431-15-6	Pressure Activated Switch	Meletron
436-30SSL-2	Pressure Activated Switch	Meletron
436-46L-14-1	Pressure Activated Switch	Meletron
436-46L-15	Pressure Activated Switch	Meletron
436-46L-26	Pressure Activated Switch	Meletron
438-10L-2	Pressure Activated Switch	Meletron
438-12L-1	Pressure Activated Switch	Meletron
45173F-2	Pressure Transmitter	Giannini
45716	EPR Indicator	Airesearch
45944-1	EPR Indicator	Airesearch
46603	Manifold Pressure Indicator	R C Allen
466320	Hydraulic Press Warning Switch	Bendix
472021	Oil Pressure Indictaor	Simmonds
49-0209	Fuel Pressure Indicator	R C Allen
5002-003	Torque Indicator	B & D Instruments, In
5012A	Torque Pressure Switch	Airite
50233	Pressure Indicator	Kratos
50233-3	Indicator	Kratos
50234	Pressure Transmitter	Kratos
50243	Pressure Indicator	Kratos
50-380105	Pressure Indicator	AID
50-380105-1	Pressure Indicator	AID

50-380105-3	Pressure Indicator	AID
50579	Hydraulic Pressure Transmitter	Kratos
50629	Pressure Transmitter	Kratos
510784-1	EPR Indicator	Garrett
5111-5	Oil Pressure Transmitter	Labem
5111-5C	Oil Pressure Transmitter	Labem
5-1215	Oil Pressure Indictaor	Rochester
522783	Cabin Pressurization Indicator	Weston

Primary Part Number	Nomenclature	Manufacture
522796	Hydraulic Pressure Indicator	Weston
523PG	Desynn Pressure Indicator	Smith Industries
523PG/CP	Desynn Pressure Indicator	Smith Industries
523PG/SB	Desynn Pressure Indicator	Smith Industries
5301-6	Torque Pressure Transmitter	Labem
5425	Regulator	Scott
5425-1	Regulator	Scott
5425-3	Regulator	Scott
5425-5	Regulator	Scott
5907-1B-1-A	Manifold Pressure Indicator	Eclipse Pioneer
5907-5B-1-A	Oil Pressure Indictaor	Eclipse Pioneer
5907-81A-1-A	Manifold Pressure Indicator	Eclipse Pioneer
5950-31C-1-A	Fuel Pressure Indicator	Eclipse Pioneer
5950-31E-11-A	Fuel Pressure Indicator	Eclipse Pioneer
5950-31F-11-A	Fuel Pressure Indicator	Eclipse Pioneer
5950-31G-12-A	Fuel Pressure Indicator	Eclipse Pioneer
5950-53B-1-A	Oil Pressure Indictaor	Eclipse Pioneer
5950-5C-1-A	Oil Pressure Indictaor	Bendix
5950-5F-12-A	Oil Pressure Indictaor	Eclipse Pioneer
5958-92B-15-A	Fuel Pressure Indicator	Eclipse Pioneer
5958-96B-15-A	Oil Pressure Indictaor	Eclipse Pioneer
6000T	Manifold Pressure Indicator	United Instruments
6002-D22	Manifold Pressure Indicator	United Instruments
6007-14C-6-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-14D-27-B	Fuel Pressure Indicator	Eclipse Pioneer
6007-14D-28-B	Fuel Pressure Indicator	Eclipse Pioneer
6007-14D-7-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-14D-7-B	Fuel Pressure Indicator	Eclipse Pioneer
6007-14E-14-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-14E-14-B	Fuel Pressure Indicator	Eclipse Pioneer
6007-14E-27-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-14E-27-B	Fuel Pressure Indicator	Eclipse Pioneer
6007-14E-28-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-14E-28-B	Fuel Pressure Indicator	Eclipse Pioneer
6007-14E-7-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-14F-1-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-14F-1-B	Fuel Pressure Indicator	Eclipse Pioneer
6007-14F-2-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-14F-4-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-1B-1-A	Manifold Pressure Indicator	Eclipse Pioneer

6007-1C-6-A	Manifold Pressure Indicator	Eclipse Pioneer
6007-1D-7-A	Manifold Pressure Indicator	Eclipse Pioneer
6007-1D-7-B	Manifold Pressure Indicator	Eclipse Pioneer
6007-1E-7-A	Manifold Pressure Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
6007-1F-7-A	Manifold Pressure Indicator	Eclipse Pioneer
6007-37A-7-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-41A-20-A	Torque Indicator	Eclipse Pioneer
6007-41A-21-A	Torque Indicator	Eclipse Pioneer
6007-41B-13-A	Torque Indicator	Eclipse Pioneer
6007-41B-18-A	Torque Indicator	Eclipse Pioneer
6007-41B-20-A	Torque Indicator	Eclipse Pioneer
6007-41B-21-A	Torque Indicator	Eclipse Pioneer
6007-41B-2-A	Torque Indicator	Eclipse Pioneer
6007-41B-7-A	Torque Indicator	Eclipse Pioneer
6007-41C-20-B1	Torque Indicator	Eclipse Pioneer
6007-41C-21-B1	Torque Indicator	Eclipse Pioneer
6007-42B-15-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-42C-43-B	Torque Indicator	Eclipse Pioneer
6007-42C-44-B	Torque Indicator	Eclipse Pioneer
6007-42C-45-B	Torque Indicator	Eclipse Pioneer
6007-4B-5-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4C-1-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4C-7-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4D-6-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4D-6-B	Oil Pressure Indictaor	Eclipse Pioneer
6007-4E-1-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4E-1-B	Oil Pressure Indictaor	Eclipse Pioneer
6007-4E-2-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4E-2-B	Oil Pressure Indictaor	Eclipse Pioneer
6007-4E-7-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4F-7-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4F-7-B	Oil Pressure Indictaor	Eclipse Pioneer
6007-4H-14-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4H-14-B	Oil Pressure Indictaor	Eclipse Pioneer
6007-4H-27-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4H-27-B	Oil Pressure Indictaor	Eclipse Pioneer
6007-4H-28-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-4H-28-B	Oil Pressure Indictaor	Eclipse Pioneer
6007-4H-7-A	Oil Pressure Indictaor	Eclipse Pioneer
6007-50A-14-A	Manifold Pressure Indicator	Eclipse Pioneer
6007-50A-14-B	Manifold Pressure Indicator	Eclipse Pioneer
6007-50A-7-A	Manifold Pressure Indicator	Eclipse Pioneer
6007-54B-7-B	Pressure Indicator	Eclipse Pioneer
6007-54C-36-B	Pressure Indicator	Eclipse Pioneer
6007-64A-30-B	Manifold Pressure Indicator	Eclipse Pioneer
6007-64A-31-B	Manifold Pressure Indicator	Eclipse Pioneer
6007-64A-32-B	Manifold Pressure Indicator	Eclipse Pioneer
6007-64A-36-B	Manifold Pressure Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
6007-72B-92-B	Fuel/Oil Pressure Indicator	Eclipse Pioneer
6007-85A-92-B	Fuel/Oil Pressure Indicator	Eclipse Pioneer
6007-9B-7-A	Fuel Pressure Indicator	Eclipse Pioneer
6007-9C-7-A	Fuel Pressure Indicator	Eclipse Pioneer
6008-25A-4-A	Oil Pressure Indictaor	Eclipse Pioneer
6009-19A-2-A	Fuel Pressure Indicator	Eclipse Pioneer
6009-19A-5-A	Fuel Pressure Indicator	Eclipse Pioneer
6009-1A-2-A	Manifold Pressure Indicator	Eclipse Pioneer
6009-1A-5-A	Manifold Pressure Indicator	Eclipse Pioneer
6009-21A-3-A	Pressure Indicator	Eclipse Pioneer
6009-22A-3-A	Pressure Indicator	Eclipse Pioneer
6009-23A-3-A	Pressure Indicator	Eclipse Pioneer
6009-4B-2-A	Oil Pressure Indictaor	Eclipse Pioneer
6009-4B-5-A	Oil Pressure Indictaor	Eclipse Pioneer
6020-60101	Manifold Pressure Indicator	United Instruments
6020-60104	Manifold Pressure Indicator	United Instruments
6020-E40	Manifold Pressure Indicator	United Instruments
6020T	Manifold Pressure Indicator	United Instruments
6020T-E35	Manifold Pressure Indicator	United Instruments
6040T	Fuel Pressure Indicator	United Instruments
6054-2B-31-A	Pressure Indicator	Eclipse Pioneer
6054-89A-31-A	Pressure Indicator	Eclipse Pioneer
6054-90A-31-A	Pressure Indicator	Eclipse Pioneer
6054-91A-31-A	Pressure Indicator	Eclipse Pioneer
6054-92A-31-A	Pressure Indicator	Eclipse Pioneer
6054-9A-31-A	Pressure Indicator	Eclipse Pioneer
6058-24A-9-A	Fuel/Oil Pressure Indicator	Eclipse Pioneer
6058-24B-10-A	Fuel/Oil Pressure Indicator	Eclipse Pioneer
6060	Fuel Pressure Indicator	United Instruments
6060T	Fuel Pressure Indicator	United Instruments
6062	Fuel Pressure Indicator	United Instruments
6080	Manifold/Fuel Pressure Ind.	United Instruments
6080-C0207	Manifold Pressure Indicator	United Instruments
6080-H35	Manifold Pressure Indicator	United Instruments
6080-H38	Manifold Pressure Indicator	United Instruments
6080-H42	Manifold/Fuel Pressure Ind.	United Instruments
6100	Manifold Pressure Indicator	United Instruments
61015-001-4	Torque Indicator	Thomson
61015-007-1	Torque Indicator	Thomson
61015-008-1	Torque Indicator	Thomson
6111	Manifold Pressure Indicator	United Instruments
6111-D9	Manifold Pressure Indicator	United Instruments
6112	Manifold Pressure Indicator	United Instruments
61121-04	Torque Indicator	Lewis

Primary Part Number	Nomenclature	Manufacture
61121-05	Torque Indicator	Lewis
6121	Manifold Pressure Indicator	United Instruments

6121-E34	Manifold Pressure Indicator	United Instruments
6121-E43	Manifold Pressure Indicator	United Instruments
6121-E76	Manifold Pressure Indicator	United Instruments
6121-E78	Manifold Pressure Indicator	United Instruments
6121-E80	Manifold Pressure Indicator	United Instruments
6121-E98	Manifold Pressure Indicator	United Instruments
6122	Manifold Pressure Indicator	United Instruments
6122-E2	Manifold Pressure Indicator	United Instruments
6200	Fuel Pressure Indicator	United Instruments
6211	Fuel Pressure Indicator	United Instruments
6212	Fuel Pressure Indicator	United Instruments
6213	Fuel Pressure Indicator	United Instruments
6221	Fuel Pressure Indicator	United Instruments
6221-G85	Manifold Pressure Indicator	United Instruments
6222	Fuel Pressure Indicator	United Instruments
6223	Fuel Pressure Indicator	United Instruments
6224	Fuel Pressure Indicator	United Instruments
6225	Fuel Pressure Indicator	United Instruments
6225-G82	Manifold Pressure Indicator	United Instruments
6300	Manifold/Fuel Pressure Ind.	United Instruments
6300-A15A-1-A1	Pressure Warning Unit	Eclipse Pioneer
6300-A15B-2-A1	Pressure Warning Unit	Eclipse Pioneer
6300-A15B-2-A2	Pressure Warning Unit	Eclipse Pioneer
6300-A15C-3-A2	Pressure Warning Unit	Eclipse Pioneer
6300-A49A-14-A4	Pressure Indicator	Eclipse Pioneer
6300-A49A-15-A4	Pressure Indicator	Eclipse Pioneer
6313	Manifold Pressure Indicator	United Instruments
6314-H101	Manifold Pressure Indicator	United Instruments
6331-H40	Manifold Pressure Indicator	United Instruments
6331-H42	Manifold Pressure Indicator	United Instruments
6331-H63	Manifold Pressure Indicator	United Instruments
6331-H67	Manifold Pressure Indicator	United Instruments
6333-H38	Manifold Pressure Indicator	United Instruments
6333-H82	Manifold/Fuel Pressure Ind.	United Instruments
6411A-D42	Manifold Pressure Indicator	United Instruments
6411-D74	Manifold Pressure Indicator	United Instruments
6411-D84	Manifold Pressure Indicator	United Instruments
6414A-D43	Manifold Pressure Indicator	United Instruments
6414-D46	Manifold Pressure Indicator	United Instruments
64191-204-1	Pressure Indicator	Sextant
64191-214-1	Pressure Indicator	Sextant
64191-215-1	Pressure Indicator	Sextant

Primary Part Number	Nomenclature	Manufacture
64191-217-1	Pressure Indicator	Sextant
64836-200-1	Dual Pressure Indicator	Jaeger
660063-501	Manifold/Fuel Pressure Ind.	AID
660PG	Desynn Pressure Indicator	Smith Industries
660PG/CP	Desynn Pressure Indicator	Smith Industries
660PG/SB	Desynn Pressure Indicator	Smith Industries

66745-0111	Oil Pressure Indictaor	Aerosonic
6703-83	Suction Gauge	Manning, Maxwell, &
6704-152	Suction Gauge	Manning, Maxwell, &
6704-185	Suction Gauge	Manning, Maxwell, &
6740-88	Manifold Pressure Indicator	Manning, Maxwell, &
6743-108	Manifold Pressure Indicator	Manning, Maxwell, &
6748-157	Manifold Pressure Indicator	Manning, Maxwell, &
6754-110	Fuel Pressure Indicator	Manning, Maxwell, &
6755-306	Pressure Indicator	Manning, Maxwell, &
6755T-306	Pressure Indicator	Manning, Maxwell, &
6770-161	Manifold Pressure Indicator	Manning, Maxwell, &
6800	Fuel Pressure Warning Ind.	Manning, Maxwell, &
6800-C2A-1-A1	Pressure Indicator	Eclipse Pioneer
6800-C3A-1-A1	Pressure Indicator	Eclipse Pioneer
6800-C4A-1-A1	Pressure Indicator	Eclipse Pioneer
6800-C5A-1-A1	Pressure Indicator	Eclipse Pioneer
6803A	Suction Reg. Valve	Manning, Maxwell, &
681118-0104	Torque Indicator	Aerosonic
68229274	Torque Indicator	MHD
6829274	Torque Indicator	Texas Instruments
6840003	Torque Indicator	Texas Instruments
6914-385	Cabin Air Pressure Ind.	Manning, Maxwell, &
69-42A	Fuel Pressure Indicator	Electric Auto-Lite Co
6960-268	Torque Indicator	Manning, Maxwell, &
698611-1	Torque Indicator	Texas Instruments
7-100-1	Manifold Pressure Indicator	UMA
7-100-XX	Manifold Pressure Indicator	UMA
7121-38B-2	Pressure Activated Switch	Meletron
71558-31-3	Aneroid Switch	Meletron
71558-31-4	Aneroid Switch	Meletron
71558-31-5	Aneroid Switch	Meletron
71558-31-6	Aneroid Switch	Meletron
719-03-1710	Manifold/Fuel Pressure Ind.	Mac Leod Instrument
721-03-1310	Manifold/Fuel Pressure Ind.	Mac Leod Instrument
728FU-10-04	Manifold Pressure Indicator	Kollsman
728FU-10-045	Manifold Pressure Indicator	Kollsman
728FU-10-05	Manifold Pressure Indicator	Kollsman
730-03-1210	Manifold/Fuel Pressure Ind.	Mac Leod Instrument

Primary Part Number	Nomenclature	Manufacture
735-21-1310	Manifold/Fuel Pressure Ind.	Mac Leod Instrument
7500-15-A5-1	Pressure Warning Unit	Eclipse Pioneer
7500-15-A8-2	Pressure Transmitter	Eclipse Pioneer
7501-9-A7-2	Manifold Pressure Transmitter	Eclipse Pioneer
7501-9-A7-2A	Manifold Pressure Transmitter	Eclipse Pioneer
7502-15-A8-1	Pressure Transmitter	Eclipse Pioneer
751PG/CP	Desynn Pressure Indicator	Smith Industries
7600-17-A8-1	Pressure Transmitter	Eclipse Pioneer
7600-27-A8-1	Pressure Transmitter	Eclipse Pioneer
7600-29-A8-1	Pressure Transmitter	Eclipse Pioneer

7600-2-A8-1	Pressure Transmitter	Eclipse Pioneer
7600-30-A8-1	Pressure Transmitter	Eclipse Pioneer
7600-49-A5-1	Pressure Transmitter	Eclipse Pioneer
7601-2-A5-1	Pressure Transmitter	Eclipse Pioneer
7609-17-C5-1	Transmitter	Bendix
7609-37-A5-1	Pressure Transmitter	Bendix
7609-37-B5-2	Transmitter	Bendix
7609-37-D5-2	Pressure Transmitter	Bendix
7613-6-A11-1	Pressure Transmitter	Eclipse Pioneer
7617-23A8-1	Autosyn Pressure Transmitter	Bendix
7700-15-A5-1	Pressure Transmitter	Bendix
7700-15-A5-1A	Pressure Transmitter	Bendix
7700-15-A5-2	Pressure Transmitter	Bendix
7703-30-A5-1A	Pressure Transmitter	Bendix
7703-30-A5-2	Pressure Transmitter	Bendix
7706-15-A5-1	Pressure Transmitter	Bendix
7707-111-A25-1	Pressure Transmitter	Allied Signal
7707-2-A5-1	Pressure Transmitter	Eclipse Pioneer
7707-2-A8-1	Pressure Transmitter	Eclipse Pioneer
7707-2-C5-1	Pressure Transmitter	Eclipse Pioneer
7707-2-D5-1	Pressure Transmitter	Allied Signal
7707-30-A23-1	Pressure Transmitter	Allied Signal
7707-30-A5-1	Pressure Transmitter	Eclipse Pioneer
7707-30-B8-2	Pressure Transmitter	Allied Signal
7707-30-D5-1	Pressure Transmitter	Allied Signal
7707-30-D5-2	Pressure Transmitter	Allied Signal
7707-7-A5-1	Pressure Transmitter	Allied Signal
7707-99-A5-1	Pressure Transmitter	Allied Signal
7708-44-A12-1	Pressure Transmitter	Bendix
7709-15-A5-1	Pressure Transmitter	Bendix
7709-15-B5-1	Pressure Transmitter	Bendix
7710-9-A7-1	Pressure Transmitter	Eclipse Pioneer
7714-61-A5-2	Pressure Transmitter	Eclipse Pioneer
7714-61-B5-2	Pressure Transmitter	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
776/1PG/SB	Desynn Pressure Indicator	Smith Industries
776PG/SB	Desynn Pressure Indicator	Smith Industries
7860A	Thrust Indicator	Space Corp.
788EU-4-026	Manifold Pressure Indicator	Kollsman
7G418	Pressure Switch	Custom Component
8007	Pressure Indicator	Aero Mechanism
838K4-011	Pressure Indicator	Kollsman
86425-1	Hydraulic Pressure Indicator	General Aero
865616-2	Pressure Switch	Garrett
865616-3	Pressure Switch	Garrett
868	Suction Gauge	Pioneer
8979-A	Landing Gear Press. Ind.	Electric Auto-Lite Co
8DJ174	EPR Indicator	Ametek/GE
8DJ174LKP1	EPR Indicator	Ametek/GE

8DJ174LWA1	EPR Indicator	Ametek/GE
8DJ174LWE1	EPR Indicator	Ametek/GE
8DJ174LWG1	EPR Indicator	Ametek/GE
8DJ174LWK1	EPR Indicator	Ametek/GE
8DJ174LWM1	EPR Indicator	Ametek/GE
8DJ181LWC2	Torque Indicator	Ametek/GE
8DJ181LWD2	Torque Indicator	Ametek/GE
8DJ184LWA1	EPR Indicator	Ametek/GE
8DJ184LWN2	EPR Indicator	Ametek/GE
8DJ184LWT2	EPR Indicator	Ametek/GE
8DJ276WAB1	EPR Indicator	Ametek/GE
8KE91AAB1	Engine Torque Electronic Unit	Ametek/GE
8KE91AAB2	Torque Indicator	Ametek/GE
9016-3002	Fuel Pressure Indicator	Insco
9016-3003	Fuel Pressure Indicator	Insco
906D-13-018	Pressure Indicator	Kollsman
91-380012-3	Torque Indicator	Beechcraft
91850-714-1	Safety Valve	Airesearch
92850-714-1	Valve	Airesearch
94650-0-4	Valve	Airesearch
94650-375	Safety Valve	Airesearch
94670-812	Valve	Airesearch
948402-1-03	Cabin Air Pressure Amplifier	Honeywell
948402-1-1	Cabin Air Pressure Amplifier	Honeywell
948402-1-2	Cabin Air Pressure Amplifier	Honeywell
948402-1-3	Cabin Air Pressure Amplifier	Honeywell
949C 0411	Teletorque Unit	Kollsman
968B-01	Cabin Pressure Limits Control	Kollsman
968C-01	Cabin Pressure Limits Control	Kollsman
97-01	Suction Gauge	Kollsman

Primary Part Number	Nomenclature	Manufacture
9752-A	Landing Gear Press. Ind.	Electric Auto-Lite Co
9753-A	Automatic Pilot Pressure	Electric Auto-Lite Co
9756-A	Oil Pressure Indictaor	Electric Auto-Lite Co
9813-25-05	Torque Indicator	Litton
9813-25-07	Torque Indicator	Litton
9813-25-12	Torque Indicator	Litton
9813-25-13	Torque Indicator	Litton
9813-25-15	Torque Indicator	Litton
9813-25-16	Torque Indicator	Litton
9813-25-17	Torque Indicator	Litton
9813-25-18	Torque Indicator	Litton
9813-25-19	Torque Indicator	Litton
9813-25-21	Torque Indicator	Litton
990-01	Manifold Pressure Indicator	Kollsman
9A1100	Torque Indicator	Penn Airborne
9A2100	Torque Indicator	Penn Airborne
9U001-01	Pressure Transducer	Electric Auto-Lite Co
9U001-02	Pressure Transducer	Electric Auto-Lite Co

9U001-03	Pressure Transducer	Electric Auto-Lite Co
9U001-04	Pressure Transducer	Electric Auto-Lite Co
9U001-05	Pressure Transducer	Electric Auto-Lite Co
9U001-06	Pressure Transducer	Electric Auto-Lite Co
9U001-07	Pressure Transducer	Electric Auto-Lite Co
A2920710021	Cabin Pressure Controller	Kollsman
A2920710024	Cabin Pressure Controller	Kollsman
A-301-3W	Pressure Switch	Aerotec
A-301-B	Pressure Switch	Aerotec
A-301-BX	Pressure Switch	Aerotec
A-301-E	Pressure Switch	Aerotec
A-301-K	Pressure Switch	Aerotec
A-301-W1	Pressure Switch	Aerotec
A-301-W2	Pressure Switch	Aerotec
A31537 10 001	EPR Indicator	Kollsman
A31577 10 001	EPR Indicator	Kollsman
A3258304001	Percentage Thrust Indicator	Kollsman
AC-1009	Cabin Air Pressure Ind.	Lackner
AC-103	Cabin Airflow Press. Ind.	Lackner
AC-106	Cabin Airflow Press. Ind.	Lackner
AC-106-1P	Cabin Airflow Press. Ind.	Lackner
AE343-1-A	Pressure Transmitter	US Gauge
AEU-13/A	Torque Indicator	Natec Electronic
AGU-17/A	Hydraulic Pressure Indicator	Natec Electronic
AGU-21/A	Indicator	Ragen
AGU-3/A	Hydraulic Pressure Indicator	Courter

Primary Part Number	Nomenclature	Manufacture
AN5769-1	Hydraulic Pressure Indicator	US Gauge
AN5769-1A	Hydraulic Pressure Indicator	US Gauge
AN5770-1	Manifold Pressure Indicator	Manning, Maxwell, &
AN5770-2	Manifold Pressure Indicator	Ranco
AN5770-2-12	Manifold Pressure Indicator	Ranco
AN5770-2-34	Manifold Pressure Indicator	Ranco
AN5770-2A-12	Manifold Pressure Indicator	Ranco
AN5770-2A-34	Manifold Pressure Indicator	Ranco
AN5770-3	Manifold Pressure Indicator	Ranco
AN5770-4-12	Manifold Pressure Indicator	Ranco
AN5770-4-34	Manifold Pressure Indicator	Ranco
AN5772-1-12	Fuel Pressure Indicator	Ranco
AN5772-1-34	Fuel Pressure Indicator	Ranco
AN5772-1A-12	Fuel Pressure Indicator	Ranco
AN5772-1A-34	Fuel Pressure Indicator	Ranco
AVI6B2070B-1	Fuel Shut Off Valve	ITT
AW-1 7/8-14	Pressure Indicator	US Gauge
AW-1 7/8-14-DU	Oil Pressure Indictaor	US Gauge
AW-1 7/8-15-AN	Fuel Pressure Indicator	US Gauge
AW-1 7/8-15-BP	Fuel Pressure Indicator	US Gauge
AW-1 7/8-15-CFF4	Pressure Indicator	US Gauge
AW-1 7/8-15-CIF4	Pressure Indicator	US Gauge

AW-1 7/8-15-CJ	Fuel Pressure Indicator	US Gauge
AW-1 7/8-15-F	Pressure Indicator	US Gauge
AW-1 7/8-15-K	Fuel Pressure Indicator	US Gauge
AW-1 7/8-17-CZ6	Hydraulic Pressure Indicator	US Gauge
AW-1 7/8-18	Pressure Indicator	US Gauge
AW-1 7/8-21AK	Suction Gauge	US Gauge
AW-1 7/8-21AK2	Suction Gauge	US Gauge
AW-1-7/8-14	Oil Pressure Indictaor	US Gauge
AW-1-7/8-14-CK	Automatic Pilot Pressure	US Gauge
AW-1-7/8-14-CL	Oil Pressure Indictaor	US Gauge
AW-1-7/8-14-CZ	Oil Pressure Indictaor	US Gauge
AW-1-7/8-14-CZ2	Oil Pressure Indictaor	US Gauge
AW-1-7/8-14-DI	Oil Pressure Indictaor	US Gauge
AW-1-7/8-14-DR	Oil & Hydraulic Pressure Gauge	US Gauge
AW-1-7/8-14-DU	Oil Pressure Indictaor	US Gauge
AW-1-7/8-14R	Oil Pressure Indictaor	US Gauge
AW-1-7/8-15	Fuel Pressure Indicator	US Gauge
AW-1-7/8-15-AN	Fuel Pressure Indicator	US Gauge
AW-1-7/8-15-BP	Fuel Pressure Indicator	US Gauge
AW-1-7/8-15-CFF4	Fuel Pressure Indicator	US Gauge
AW-1-7/8-15-CIF4	Fuel Pressure Indicator	US Gauge
AW-1-7/8-15-CJ	Fuel Pressure Indicator	US Gauge

Primary Part Number	Nomenclature	Manufacture
AW-1-7/8-15-F	Fuel Pressure Indicator	US Gauge
AW-1-7/8-15-K	Fuel Pressure Indicator	US Gauge
AW-1-7/8-17-AK	Landing Gear Press. Ind.	US Gauge
AW-1-7/8-17-AL	Oil & Hydraulic Pressure Gauge	US Gauge
AW-1-7/8-17-BP	Oil & Hydraulic Pressure Gauge	US Gauge
AW-1-7/8-17-CD	Landing Gear Press. Ind.	US Gauge
AW-1-7/8-17-CN	Landing Gear Press. Ind.	US Gauge
AW-1-7/8-17-CN13	Oil & Hydraulic Pressure Gauge	US Gauge
AW-1-7/8-17-CN8	Oil & Hydraulic Pressure Gauge	US Gauge
AW-1-7/8-17-CZ4	Oil & Hydraulic Pressure Gauge	US Gauge
AW-1-7/8-17-CZA	Hydraulic Pressure Indicator	US Gauge
AW-1-7/8-17DI	Pressure Indicator	US Gauge
AW-1-7/8-18	Oil Pressure Indictaor	US Gauge
AW-1-7/8-21	Suction Gauge	US Gauge
AW-1-7/8-21AH	Suction Gauge	US Gauge
AW-1-7/8-21AK	Suction Gauge	US Gauge
AW-1-7/8-21AK2	Suction Gauge	US Gauge
AW-1-7/8-21Q	Suction Gauge	US Gauge
AW-1-7/8-27-C	Oxygen Pressure Indicator	US Gauge
AW-1-7/8-27HF-4	Nitrogen Cylinder Press Gauge	US Gauge
AW-1-7/8-30-D6	Hydraulic Pressure Indicator	US Gauge
AW-1-7/8-30F	Hydraulic Pressure Indicator	US Gauge
AW-1-7/8-30G	Oil & Hydraulic Pressure Gauge	US Gauge
AW-1-7/8-32-AF4	Manifold Pressure Indicator	US Gauge
AW-1-7/8-5	Pressure Indicator	US Gauge
AW1817AC02	Hydraulic Pressure Indicator	US Gauge

AW-2 3/4-25-H	Manifold Pressure Indicator	US Gauge
AW-2 3/4-25-H3	Manifold Pressure Indicator	US Gauge
AW-2 3/4-25-L	Manifold Pressure Indicator	US Gauge
AW-2 3/4-40-B	Fuel Pressure Indicator	US Gauge
AW-2 3/4-40-B2	Fuel Pressure Indicator	US Gauge
AW-2-14-B	Oil Pressure Indictaor	US Gauge
AW2-16	Landing Gear Press. Ind.	US Gauge
AW2-16A	Landing Gear Press. Ind.	US Gauge
AW2-16C	Landing Gear Press. Ind.	US Gauge
AW2-16E	Landing Gear Press. Ind.	US Gauge
AW-2-20	Suction Gauge	US Gauge
AW2-21	Fuel Pressure Indicator	US Gauge
AW2-21A	Fuel Pressure Indicator	US Gauge
AW2-21B	Fuel Pressure Indicator	US Gauge
AW2-29	Oil Pressure Indictaor	US Gauge
AW-2-3/4-34-GF2	Hydraulic Pressure Indicator	US Gauge
AW-2-3/4-34-GF4	Hydraulic Pressure Indicator	US Gauge
AW-2-3/4-34-JF5	Hydraulic Pressure Indicator	US Gauge

Primary Part Number	Nomenclature	Manufacture
AW-2-3/4-40-B	Fuel Pressure Indicator	US Gauge
AW-2-3/4-40-B2	Fuel Pressure Indicator	US Gauge
AW-2-31-B	Manifold Pressure Indicator	US Gauge
AW-2-31-B2	Manifold Pressure Indicator	US Gauge
AW-2-31-D	Pressure Indicator	US Gauge
AW-2-31-H2	Radar Pressure Gauge	US Gauge
AW-2-33A1	Cabin Air Pressure Gage	US Gauge
AW2-34	Landing Gear Press. Ind.	US Gauge
AW2-34A	Landing Gear Press. Ind.	US Gauge
AW-2-35	Suction Gauge	US Gauge
AW-2-35-D	Suction Gauge	US Gauge
AW2-36	Fuel Pressure Indicator	US Gauge
AW2-36A	Pressure Indicator	US Gauge
AW2-36B	Fuel Pressure Indicator	US Gauge
AW2-36C	Fuel Pressure Indicator	US Gauge
AW2-37	Oil Pressure Indictaor	US Gauge
AW2835AH01	Pressure Indicator	Ametek
AW-3-1/2-43-C	Landing Gear Press. Ind.	US Gauge
B0838501022	Pressure Indicator	Kollsman
B0838504011	Pressure Indicator	Kollsman
B0838504022	Pressure Indicator	Kollsman
B0838504033	Pressure Indicator	Kollsman
B0838510011	Pressure Indicator	Kollsman
B0838510013	Pressure Indicator	Kollsman
B0838528023	Pressure Indicator	Kollsman
B-410	Pressure Indicator	AID
B44202-10-003	Altimeter	Kollsman
B44202-10-004	Altimeter	Kollsman
B44502-10-002	Altimeter	Kollsman
B-5	Pressure Indicator	US Gauge

B571-9	Torque Indicator	Simmonds
B572-17	Torque Indicator	Simmonds
B-8A	Pressure Indicator	US Gauge
C-10	Pressure Indicator	US Gauge
C-13	Pressure Indicator	US Gauge
C16158AA	Indicator	Thales
C16158CA	Indicator	Thales
C44202-10-002	Altimeter	Kollsman
C-5	Torque Indicator	Skyway
C668519-0105	Suction Gauge	Superior Labs
C668540-0101	Suction Gauge	Superior Labs
D-23	Manifold Pressure Indicator	US Gauge
E-1	Fuel Pressure Indicator	US Gauge
E-868	Suction Gauge	Pioneer

Primary Part Number	Nomenclature	Manufacture
EA711ANH-2	Fuel Pressure Indicator	Liquidometer
EA721-G-1A	Fuel Pressure Indicator	Liquidometer
FA-149201	Aneroid Switch	Wallace Tiernan
FL-3	Cabin Press Airflow Ind	Lackner
G-1561	Pressure Indicator	Glassco
IU037	Pressure Indicator	Electric Auto-Lite Co
JG151A1	EPR Indicator	Honeywell
JG288A2	EPR Indicator	Honeywell
JG298B1	EPR Indicator	Honeywell
LG14C12	Transmitter	Honeywell
LG14C20	Transmitter	Honeywell
LG80A11	EPR Transmitter	Honeywell
LG80A12	EPR Transmitter	Honeywell
LG80A18	EPR Transmitter	Honeywell
LG80A3	EPR Transmitter	Honeywell
LG80A6	EPR Transmitter	Honeywell
LG80A7	EPR Transmitter	Honeywell
LG80A9	EPR Transmitter	Honeywell
M0-127-1	Suction Gauge	AID
M-1009	PRESSURE SWITCH	AEROTEC
M-818	Differential Pressure Switch	Aerotec
M-826	Oil Pressure Switch	Aerotec
M-860	Differential Pressure Switch	Aerotec
M-877	Differential Pressure Switch	Aerotec
M-890	Differential Pressure Switch	Aerotec
MS25470-7	Pressure Indicator	Courter
MS28005-1	Pressure Transmitter	US Gauge
MS28010-1	Pressure Indicator	US Gauge
MS28010-2	Oil Pressure Indictaor	US Gauge
MS28010-3	Oil Pressure Indictaor	US Gauge
MS28010-4	Fuel Pressure Indicator	US Gauge
MS28010-5	Hydraulic Pressure Indicator	US Gauge
MS28010-6	Manifold Pressure Indicator	US Gauge
MS28010-7	Fuel Pressure Indicator	US Gauge

MS28130-16	Autosyn Pressure Transmitter	Bendix
MS28131-12T	Transmitter	Allied
MS33638	Manifold Pressure Indicator	R C Allen
N-943-CC	Landing Gear Press. Ind.	Manning, Maxwell, &
N-943-F	Landing Gear Press. Ind.	Manning, Maxwell, &
N-955	Pressure Indicator	Manning, Maxwell, &
N-962	Automatic Pilot Pressure	Manning, Maxwell, &
P-801-DC	Pressure Switch	Aerotec
P-80-A	Cabin Pressure	Aerosonic
P-904-1	Differential Pressure Switches	Aerotec

Primary Part Number	Nomenclature	Manufacture
P-904-2	Differential Pressure Switches	Aerotec
P-904-3	Differential Pressure Switches	Aerotec
P-904-G	Differential Pressure Switches	Aerotec
P-904-GA	Differential Pressure Switches	Aerotec
P-904-JA	Differential Pressure Switches	Aerotec
P-904-L	Differential Pressure Switches	Aerotec
P-904-R	Differential Pressure Switches	Aerotec
P-904-RA	Differential Pressure Switches	Aerotec
P-904-T	Differential Pressure Switches	Aerotec
PA-904-1	Differential Pressure Switches	Aerotec
PG15A	Pressure Transmitter	Honeywell
PG15A1	Pressure Transmitter	Honeywell
PG208AS	Pressure Switch	Honeywell
PG208B	Pressure Switch	Honeywell
PG208C	Pressure Switch	Honeywell
PR12-1-2	EPR Indicator	Airesearch
PS50031-8-2	Fuel Pressure Indicator	United Instruments
PW-631-PG	Pressure Indicator	Smith Industries
RCA70-01	Torque Indicator	R C Allen
RCA70-05	Torque Indicator	R C Allen
S6115-20520-3	BIM Indicator	Sikorsky
SA-142	DC Torquer Actuator	J.E.T.
SAS261-016	Pressure Regulating Valve	Aeronautical Systems
SAS261-017	Pressure Regulating Valve	Aeronautical Systems
SAS261-019	Pressure Regulating Valve	Aeronautical Systems
SEL-OC4AE	Oil Pressure Indicator	Ametek/GE
SEL-OC4AF	Oil Pressure Indicator	Ametek/GE
SE-OC2B	Torque Indicator	Ametek/GE
SE-OC2B-1	Torque Indicator	Ametek/GE
SE-OC2F	Torque Indicator	Ametek/GE
SL1001-001-1	Suction Gauge	Superior Labs
SL1001-005-7	Suction Gauge	Superior Labs
SL1003	Vacuum Indicator	Superior Labs
SL5050-2001-H04	Suction Gauge	Superior Labs
SL5050-2001-N00	Suction Gauge	Superior Labs
SR-03R	Fuel Pressure Indicator	US Gauge
SR-04E	Oil Pressure Indicator	US Gauge
SR-151-A	Pressure Indicator	US Gauge

SR-152-A	Pressure Indicator	US Gauge
SR-2AB	Torque Indicator	Ametek/GE
SR-2H	Pressure Indicator	US Gauge
SR-2W	Torque Indicator	Ametek/GE
SR-3A	Pressure Indicator	US Gauge
SR-3C	Pressure Indicator	US Gauge

Primary Part Number	Nomenclature	Manufacture
SR-3J	Fuel Crossfeed Pressure Ind.	US Gauge
SR-4A	Pressure Indicator	US Gauge
SR-4B	Pressure Indicator	US Gauge
SR-4K	Oil Pressure Indicator	US Gauge
SR-4M	Oil Pressure Indictaor	US Gauge
SR-5A	Pressure Indicator	US Gauge
SR-5B	Pressure Indicator	US Gauge
SR-5E	Manifold Pressure Indicator	US Gauge
SR-5F	Condensor Pressure Ind.	US Gauge
SR-5G	Pressure Indicator	US Gauge
SR-6A	Pressure Indicator	US Gauge
SR-7A	Pressure Indicator	US Gauge
SR-8B	Pressure Indicator	US Gauge
SR-97A	Hydraulic Pressure Indicator	US Gauge
SR-9A	Pressure Indicator	US Gauge
SRA-14A	Torque Indicator	US Gauge
SRA-14E	Torque Indicator	US Gauge
SRD-302D	Torque Indicator	US Gauge
SRD-302E	Torque Indicator	US Gauge
SRD-302ZK	Torque Indicator	US Gauge
SRD-303D	Fuel Pressure Indicator	US Gauge
SRD-304A	Oil Pressure Indicator	US Gauge
SRD-304B	Oil Pressure Indicator	US Gauge
SRD-4A	Pressure Indicator	US Gauge
SRD-4G	Pressure Indicator	US Gauge
SRD-7A	Pressure Indicator	US Gauge
SRD-7C	Pressure Indicator	US Gauge
SRD-7E	Starter Air Pressure Ind.	US Gauge
SRD-7J	Hydraulic Brake Pressure Ind	US Gauge
SRD-7K	Hydraulic Pressure Indicator	US Gauge
SRD9B	Cabin Air Com Pressure Ind	Ametek
SRD-9B	Compressor Inlet-Discharge Ind	US Gauge
SRDL-6D	Pressure Indicator	Ametek/GE
SRDL-7G	Hydraulic Brake Pressure Ind	US Gauge
SRDL-7H	Hydraulic Pressure Indicator	US Gauge
SRDS-15A	Thrust Indicator	US Gauge
SRL-015C	EPR Indicator	Ametek/US Gauge
SRL-4C	OIL Pressure indicator	US Gauge
SRL-94B	Oil Pressure Indicator	US Gauge
ST-104A	Oil Pressure Transmitter	US Gauge
ST-104-B	Oil Pressure Transmitter	US Gauge
ST-104D	Pressure Transmitter	US Gauge

ST-104E	Oil Pressure Transmitter	US Gauge
ST-104M	Oil Pressure Transmitter	US Gauge

Primary Part Number	Nomenclature	Manufacture
ST-104Z	Oil Pressure Transmitter	US Gauge
ST-107H	Hydraulic Pressure Transmitter	US Gauge
ST-107J	Hydraulic Pressure Transmitter	US Gauge
ST107Q	Transmitter	Ametek
ST-109C	Cabin Air Pressure Transmitter	Ametek/GE
ST-13B	Pressure Transmitter	US Gauge
ST-207A	Hydraulic Pressure Transmitter	US Gauge
ST-2A	Torque Pressure Transmitter	US Gauge
ST-2G	Torque Pressure Transmitter	US Gauge
ST-2J	Torque Pressure Transmitter	US Gauge
ST-2K	Torque Pressure Transmitter	US Gauge
ST-3A	Fuel Pressure Transmitter	US Gauge
ST-3B	Fuel Pressure Transmitter	US Gauge
ST-3D	Oil Pressure Transmitter	US Gauge
ST-3E	Torque Pressure Transmitter	US Gauge
ST-4B	Oil Pressure Transmitter	US Gauge
ST-4C	Oil Pressure Transmitter	US Gauge
ST-4D	Oil Pressure Transmitter	US Gauge
ST-4E	Oil Pressure Transmitter	US Gauge
ST-4H	Oil Pressure Transmitter	US Gauge
ST-4J	Oil Pressure Transmitter	US Gauge
ST-4K	Fuel Pressure Transmitter	US Gauge
ST-4N	Transmitter	US Gauge
ST-502J-1	Indicator	US Gauge
ST-504A	Oil Press Transmitter	US Gauge
ST-506A	Pressure Transmitter	Ametek/GE
ST-53A	Pressure Transmitter	US Gauge
ST-57A	Pressure Transmitter	US Gauge
ST-5E	Manifold Pressure Transmitter	US Gauge
ST-60A	Remote Pressure Transmitter	US Gauge
ST-61A	Remote Pressure Transmitter	US Gauge
ST-62A	Remote Pressure Transmitter	US Gauge
ST-6B	Pressure Transmitter	US Gauge
ST-6C	Pressure Transmitter	US Gauge
ST-70	Hydraulic Pressure Transmitter	US Gauge
ST-7A	Hydraulic Pressure Transmitter	US Gauge
ST-7B	Hydraulic Pressure Transmitter	US Gauge
ST-7C	Hydraulic Pressure Transmitter	US Gauge
ST-7D	Hydraulic Pressure Transmitter	US Gauge
ST-7E	Hydraulic Pressure Transmitter	US Gauge
ST-7R	Hydraulic Pressure Transmitter	US Gauge
ST-7T	Hydraulic Pressure Transmitter	US Gauge
ST-9A	Pressure Transmitter	US Gauge
TRU-60/A	Transmitter	Honeywell

Primary Part Number	Nomenclature	Manufacture

TRU-80/A	Oil Pressure Transmitter	General Aero
UD-100	Differential Pressure Switch	Aerotec
UD-101A	Differential Pressure Switch	Aerotec
UD-107	Differential Pressure Switch	Aerotec
UD-703	Differential Pressure Switch	Aerotec
UG-130	Pressure Indicator/Switch	Aerotec
UI-6100	Manifold Pressure Indicator	United Instruments
UI6411-D42	Manifold Pressure Indicator	United Instruments
VSDL-OC204C	Oil Pressure Indictaor	Ametek/GE
006-01069-00010	Indicator	Honeywell/Bendix-Kir
006-01069-00011	Indicator	Honeywell/Bendix-Kir
006-01069-00012	Indicator	Honeywell/Bendix-Kir
006-01069-00013	Indicator	Honeywell/Bendix-Kir
006-01069-00014	Indicator	Honeywell/Bendix-Kir
006-01069-0005	Indicator	Honeywell/Bendix-Kir
006-15542-002	NAV/COMM Tranceiver	Honeywell/Bendix-Kir
006-15669-0012	Communication Control Unit	Honeywell/Bendix-Kir
011-00280-10	GPS	Garmin
017-1282-72	Communication Control Unit	Honeywell/Bendix-Kir
066-01069-00	Indicator, Bearing	Honeywell/Bendix-Kir
066-01069-0001	Indicator	Honeywell/Bendix-Kir
066-01069-0002	Indicator	Honeywell/Bendix-Kir
066-01069-0003	Indicator	Honeywell/Bendix-Kir
066-01069-0007	Indicator	Honeywell/Bendix-Kir
066-01069-0008	Indicator	Honeywell/Bendix-Kir
066-01069-0009	Indicator	Honeywell/Bendix-Kir
066-01072-000	ADF receiver	Honeywell
066-03056-0011	Navigation Indicator	Bendix-King
066-3056-11	Navigation Indicator	Bendix-King
066-3063-00	ADF Indicator	Bendix King
066-3063-01	ADF Indicator	Bendix King
069-01029-0703	GPS	Bendix King
069-01032-0101	NAV/COMM Tranceiver	Honeywell/Bendix-Kir
069-01032-0201	NAV/COMM Tranceiver	Honeywell/Bendix-Kir
069-01034-0102	GPS	Honeywell
071-01618-0204	Transponder	Honeywell/Bendix-Kir
071-1273-12	Nav Control Unit	Honeywell/Bendix-Kir
071-1282-24	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-25	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-26	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-27	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-29	Communication Control Unit	Honewell/Bendix-King
071-1282-30	Communication Control Unit	Honeywell
071-1282-31	Communication Control Unit	Honeywell/Bendix-Kir

Primary Part Number	Nomenclature	Manufacture
071-1282-32	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-33	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-34	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-35	Communication Control Unit	Honeywell/Bendix-Kir

071-1282-36	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-39	Communication Control Unit	Honewywell/Bendix-K
071-1282-40	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-64	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-65	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-66	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-67	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-69	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-70	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-71	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-74	Communication Control Unit	Honeywell\Bendix-Kir
071-1282-75	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-76	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-77	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-80	Communication Control Unit	Honeywell/Bendix-Kir
071-1282-99	Communication Control Unit	Honeywell/Bendix-Kir
071-1283-13	Nav Control Unit	Honeywell/Bendix-Kir
071-1283-15	Nav Control Unit	Honeywell/Bendix-Kir
071-1283-16	Nav Control Unit	Kollsman
071-1283-17	Nav Control Unit	Honeywell/Bendix-Kir
071-1283-18	Nav Control Unit	Honeywell/Bendix-Kir
071-1283-20	Nav Control Unit	Honeywell/Bendix-Kir
071-1283-21	Nav Control Unit	Honeywell/Bendix-Kir
071-1283-22	Nav Control Unit	Honeywell/Bendix-Kir
071-1283-23	Nav Control Unit	Honeywell
071-1283-26	Nav Control Unit	Honeywell/Bendix-Kir
071-1283-27	Nav Control Unit	Honeywell/Bendix-Kir
071-1283-99	Nav Control Unit	Honeywell/Bendix-Kir
071-128-81	Communication Control Unit	Honeywell/Bendix-Kir
1U041	Audio Amplifier	Bendix King
2067631-5151	Altimeter	Honeywell
328A-5	Amplifier	Collins
332C-10B	Radio Magnetic Indicator	Collins
346B-3	Audio Control Center	Collins
400W Series	GPS	Garmin
500W Series	GPS	Garmin
522-2703-00	ATC Transponder	Collins
522-3763-001	Audio Control Center	Collins
522-7382-103	Receiver	Collins
523-0774370	DME Transceiver	Collins

Primary Part Number	Nomenclature	Manufacture
614L-12	ADF Control Unit	Collins
621A-3	ATC Transponder	Collins
622-1195-301	Radio Altimeter	Collins
622-1234-012	Indicator	Collins
622-2855-001	Altimeter	Rockwell Collins
622-2885-001	Radio Altimeter	Rockwell Collins
622-7381-103	Receiver	Collins
622-7382-001	Receiver	Collins

622-7382-102	Receiver	Collins
622-7382-103	Receiver	Collins
622-7382-104	Receiver	Collins
622-7382-105	Receiver	Collins
622-7382-106	Receiver	Collins
622-7382-107	Receiver	Collins
622-7382-108	Receiver	Collins
622-7382-109	Receiver	Collins
622-7382-110	Receiver	Collins
622-7382-111	Receiver	Collins
622-8126-003	Receiver Transmitter	Collins
ADF-462	Receiver	Collins
ADF-60 ()	ADF	Collins
ALT 55	Radio Altimeter	Collins
ALT 55B	Radio Altimeter	Collins
ALT-50	Radar Transeiver	Collins
ALT-50A	Radar Transciever	Collins
ALT-55A	Altimeter	Rockwell Collins
AMR-350	Audio Panel	Collins
AMR-350H	Audio Panel	Collins
AN/AIC-14	Intercommunication Set	Aeronautical Systems
AT 150	Transponder	Narco
AT 50	Transponder	Narco
AT 50A	Transponder	Narco
AUD-250	Audio Panel	Collins
AUD-250H	Audio Panel	Collins
AUD-251H	Audio Panel	Collins
DME-442	DME Transceiver	Collins
GNC420	GPS	Garmin
GNC420A	GPS	Garmin
GNC420AW	GPS	Garmin
GNC420W	GPS	Garmin
GNC430	GPS	Garmin
GNS 530AW TAWS	GPS	Garmin
GNS430AW	GPS	Garmin
GNS430W	GPS	Garmin

Primary Part Number	Nomenclature	Manufacture
GNS530AW	GPS	Garmin
GNS530W	GPS	Garmin
GNS530W, TAWS	GPS	Garmin
GPS400	GPS	Garmin
GPS400W	GPS	Garmin
GPS500	GPS	Garmin
GPS500 TAWS	GPS	Garmin
GPS500, TAWS	GPS	Garmin
GPS500W	GPS	Garmin
GPS500W TAWS	GPS	Garmin
GPS500W, TAWS	GPS	Garmin
HF-9000	Receiver-Transmitter	Collins

KA 285	Annunciator	Bendix King
KA133	Converter	Bendix King
KA22	Marker Beacon Receiver	Bendix King
KA93A	VHF Portable	Bendix King
KA94A	VHF Mobile	Bendix King
KAA-445	Audio Control Center	Bendix King
KDF800	ADF System	Bendix King
KDF805	ADF System	Bendix King
KDI 573	Indicator	Honeywell/Bendix-Kir
KDI 574	Indicator	Honeywell/Bendix-Kir
KFS 564A	Nav Control Unit	Honeywell/Bendix-Kir
KFS562	Frequency Selector	Bendix King
KFS590A	COM Control	Bendix King
KGM690	Glide Slope/Marker Receiver	Bendix King
KGS670	Glide Slope/Marker Receiver	Bendix King
KGS680	Glide Slope/Marker Receiver	Bendix King
KGS681	Glide Slope/Marker Receiver	Bendix King
KI 203	VOR/LOC/GS Indicator	Bendix King
KI 204	VOR/LOC/GS Indicator	Bendix King
KI 207	VOR/LOC/GS Indicator	Bendix King
KI 208	VOR/LOC-OBS Indicator	Bendix King
KI 208A	Navigation Indicators	Bendix-King
KI 209	Vor/Loc-Obs Indicator	Bendix King
KI 209A	Navigation Indicator	Bendix-King
KI 227	ADF Indicator	Bendix King
KI201C	VOR/LOC-OBS Indicator	Bendix King
KI205	VOR/LOC Indicator	Bendix King
KI209	VOR/LOC/GS Indicator	Bendix King
KI210	Converter	Bendix King
KI213	VOR/LOC-OBS Indicator	Bendix King
KI214	VOR/LOC-OBS Indicator	Bendix King
KI228	ADF Indicator	Bendix King

Primary Part Number	Nomenclature	Manufacture
KLN 35A	GPS Receiver	Honeywell
KLN 94	GPS	Honeywell
KLN89/89B	GPS	Bendix King
KLN90B	GPS	Bendix King
KLX 135	GPS	Bendix King
KLX 135/135A	GPS Receiver	Bendix-King
KLX 135/A	GPS	Bendix King
KLX 135A	GPS	Bendix King
KMA 24	Audio Panel	Honeywell/Bendix-Kir
KMA 24H-70/71	Audio Selector	Bendix King
KMA24	Audio Panel	Bendix King
KMA24H	Audio Control Center	Bendix King
KMA24H-50/54	Audio Selector Panel	Bendix King
KMA24H-70/71	Audio Panel	Bendix King
KMR675	Marker Beacon Receiver	Bendix King
KN40	NAV Converter	Bendix King

KN53	NAV Receiver	Bendix King
KN72	VOR/LOC Converter	Bendix King
KN75	Glide Slope Receiver	Bendix King
KNR 634/634A	NAV Receiver	Bendix King
KNR600A	VOR/LOC Receiver	Bendix King
KNR601	VOR/LOC Receiver	Bendix King
KNR660A	VOR/LOC Receiver	Bendix King
KNR661	VOR/LOC-RMI Receiver	Bendix King
KR 87	ADF Reciever	Honeywell
KR21	Marker Beacon Receiver	Bendix King
KR22	Marker Beacon Receiver	Bendix King
KR80	ADF System	Bendix King
KR85	ADF System	Bendix King
KR86	ADF System	Bendix King
KR87	ADF System	Bendix King
KT 79	Transponder	Bendix/King
KX 155	VHF NAV/COM Transceivers	Bendix King
KX 155A	NAV/COMM Tranceiver	Honeywell/Bendix-Kir
KX 165A	Tranceiver	Bendix-King
KX110	NAV/COM	Bendix King
KX125	NAV/COM	Bendix King
KX130	COM/VOR/ILS Unit	Bendix King
KX145	NAV/COM	Bendix King
KX150B	COM/NAV/VOR Unit	Bendix King
KX160	NAV/COM	Bendix King
KX165	VHF NAV/COM Transceivers	Bendix King
KX170	NAV/COM	Bendix King
KX170A	NAV/COM	Bendix King

Primary Part Number	Nomenclature	Manufacture
KX170B	NAV/COM	Bendix King
KX175	NAV/COM	Bendix King
KX175B	NAV/COM	Bendix King
KX195	NAV/COM	Bendix King
KX195B	NAV/COM	Bendix King
KX99	VHF COM/NAV System	Bendix King
KY 196/197	Indicator	Bendix/King
KY195	COM Transceiver	Bendix King
KY196	VHF COM Transceiver	Bendix King
KY196A	VHF COM Transceiver	Bendix King
KY196E	VHF COM Transceiver	Bendix King
KY197	VHF COM Transceiver	Bendix King
KY197A	VHF COM Transceiver	Bendix King
KY197E	VHF COM Transceiver	Bendix King
KY90A	Radio	Bendix King
KY92	VHF COM Transceiver	Bendix King
KY97A	VHF COM Transceiver	Bendix King
MST 67A	Transponder	Honeywell/Bendix-Kir
TDR94	Transponder	Collins
0105-( )	Roll Servo	S-TEC

0106-( )	Roll Servo	S-TEC
121535	Motorized Shut Off Valve	Whittaker Controls
121535-1	Motorized Shut Off Valve	Whittaker Controls
129027-01	Trim Coupler	Lear Siegler
150201	Motorized Shut Off Valve	Whittaker Controls
15425-1-A	Servo Amplifier	Pioneer Central
15482-1A1	Servo Amplifier	Bendix
18043-0001	Motor Gear Head	Bendix King
1U027	Servo Amplifier indicator	Bendix King
2037592-0001	Servo Motor Tachometer	Bendix King
2239-01	Servo Amplifier	Kollsman
2578015	Motor Assembly	Sperry
4000166-8501	Capstan	Bendix King
4000240-5101	Servo Amplifier indicator	Bendix King
4000523-8501	Primary Servo	Bendix King
4000524-8506	Trim Servo	Bendix King
4000524-8507	Trim Servo	Bendix King
4000524-8508	Trim Servo	Bendix King
4000524-8509	Trim Servo	Bendix King
4009506-8501	Primary Servo	Bendix King
4009506-8502	Primary Servo	Bendix King
423060-2	Servo Amplifier	Kearfott
423060-3	Servo Amplifier	Kearfott
423412-1	Integrator Servo	Kearfott

Primary Part Number	Nomenclature	Manufacture
423419-1	Roll/Pitch Servo	Kearfott
423419-2	Roll/Pitch Servo	Kearfott
423468-1	Ground Speed Servo	Kearfott
501-1115-01	Servo Amplifier	JET
520285-1	Azimuth Servo	Kearfott
520285-2	Azimuth Servo	Kearfott
5-42270-1	Azimuth Servo	Boeing
5-42270-2	Azimuth Servo	Boeing
5-42270-4	Azimuth Servo	Boeing
551B	Servo Amplifier indicator	Bendix King
551E	Servo Amplifier indicator	Bendix King
551RL	Servo Amplifier indicator	Bendix King
618379	Servo Amplifier	Sperry
654872-11	Trim Tab Motor/Drive Assembly	Sperry
65720	Motor Driven Switch	Hamilton Standard
658679-161	Medium Servo Drive Assembly	Sperry
658679-261	Medium Servo Drive Assemembly	Sperry
658679-361	Medium Servo Drive Assemembly	Sperry
658680-161	Servo Drive	Sperry
658680-261	Servo Drive	Sperry
658680-361	Servo Drive	Sperry
658680-461	Servo Drive	Sperry
658920-261	Medium Servo Drive Assembly	Sperry
658920-361	Medium Servo Drive Assembly	Sperry

661501	Brackett & Drum Assembly	Sperry
664575	Brackett & Drum Assembly	Sperry
6680-556-1999	Servo Motor	Diehl
669352	Trim Tab Servo	Sperry
669388-01	Trim Tab Servo	Sperry
669778-161	Servo Engaging Switch	Sperry
669805	Trim Tab Servo	Sperry
670040	Servo Engaging Switch	Sperry
670040B	Servo Engaging Switch	Sperry
678919-161	Servo	Sperry
678919-461	Servo	Sperry
678920-161	Servo	Sperry
678920-361	Servo	Sperry
679567	Servo Engaging Switch	Sperry
679802-161	Servo	Sperry
679802-261	Servo	Sperry
679802-361	Servo	Sperry
679803-161	Servo	Sperry
679803-461	Servo Drive	Sperry
681874	Servo Engaging Switch	Sperry

Primary Part Number	Nomenclature	Manufacture
69009	Motor Driven Switch	Hamilton Standard
818920	Brackett & Drum Assembly	Sperry
8214K73P001	Servo Motor	Ametek/GE
8214K73P002	Servo Motor	Ametek/GE
99289-04	Capstan	Lear Siegler
AM-101	Servo Amplifier	JET
ASK-8A	Servo Amplifier	Bendix
KC 275	Servo	Bendix King
KC 276	Servo	Bendix King
KC 277	Servo	Bendix King
KM 275	Servo Mount	Bendix King
KM275	Servo Mount	Bendix King
KM276	Servo Mount	Bendix King
KM277	Servo Mount	Bendix King
KRB434	Rudder Boost System	Bendix King
KS 270	Servo	Bendix King
KS 271	Servo	Bendix King
KS 273	Servo	Bendix King
KS177	Pitch Servo	Bendix King
KS178	Primary Servo	Bendix King
KS179	Pitch Servo	Bendix King
KS270	Pitch Servo	Bendix King
KS270A	Pitch Servo	Bendix King
KS271	Roll Servo	Bendix King
KS271A	Roll Servo	Bendix King
KS272	Trim Servo	Bendix King
KS272A	Trim Servo	Bendix King
KS273	Servo	Bendix King

L221429-1	Servo Motor Tachometer	Bendix
RG7064A1	Servo Amplifier	Honeywell
RG7064B1	Servo Amplifier	Honeywell
SG3A	Trim Interrupter	Honeywell
SG3A-4	Trim Interrupter	Honeywell
T-100844	Servo Analyzer	Sperry
TE5709	Servo Indicator	Kollsman
TE5710	Servo Amplifier	Kollsman
008-0004	Proximity Switch	EDC
03722-0600	Control Panel	Narco
115032-01	Mode Control	Lear Siegler
15265-1-A1	Monitor Control	Eclipse Pioneer
15265-1-B1	Monitor Control	Eclipse Pioneer
15276-1-A1	Monitor Control	Eclipse Pioneer
15276-1-B1	Monitor Control	Eclipse Pioneer
15276-1-C1	Monitor Control	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
15750-1-A	Control Panel	Eclipse Pioneer
17001-2-A	Function Selector	Eclipse Pioneer
1-899-101-1	Proximity Sensor	EDC
1-899-15	Proximity Sensor	EDC
19623-707845-3	Lamo Dimmer	Aerospace Corporatic
1C771	Mode Control	Century Flight System
217877	Switch	Ideal Aerosmith
27-1000	Switch	TGH Aviation
285T0855	FDAS Controller	BAE Systems
2-899-10	Switch	EDC
2-899-111	Switch	EDC
3101396-1	Shut-Off Valve	Garrett
384178-091	Selector Switch	Simmonds
384-178-103	Precision Select Switch	Simmonds
4018368-901	MS-500 Mode Selector	Honeywell
410CC01-40	Single Pole Contactor	ECE
423050-2	Control Panel	Singer Kearfott
423050-3A	Control Panel	Singer Kearfott
52E61-3	Enviromental Prsov Valve Assem	Navair
55 103G	Shut-Off Valve	Le Bozec
55 103GA	Shut-Off Valve	Le Bozec
652886	Selector Switch	Sperry
658421	Selector Switch	Sperry
667835-21	Selector Switch	Sperry
670658	Selector Switch	Sperry
673338-21	Selector Switch	Sperry
675995-21	Selector Switch	Sperry
679565	Selector Switch	Sperry
681900	Pilot Engage Control	Sperry
683310-1	Rudder Limit Switch	Sperry
683947-2	Relay Unit	Sperry
70011676-901	Mode Control	Sperry

7001676-902	Mode Control	Sperry
761 B18.2	Plug Valve	Le Bozec
7-899-21	Integrated Switch	EDC
8-001-01	Switch	EDC
8-018-02	Proximity Sensor	EDC
8-018-03	Proximity Sensor	EDC
8-018-04	Proximity Sensor	EDC
8-018-05	Proximity Sensor	EDC
8-018-06	Proximity Sensor	EDC
8-018-07	Proximity Sensor	EDC
8-019-01	Proximity Sensor	EDC
8-025	DC-10 Switch System	EDC

Primary Part Number	Nomenclature	Manufacture
8-053-02	Proximity Switch	EDC
8-060-02	Switch	EDC
8-072-01	Switch	EDC
8-073	Switch	EDC
8-078-02	Proximity Switch	EDC
8-081	Vehicle Detector System	EDC
8-082	Vehicle Detector System	EDC
8-083	Vehicle Detector System	EDC
8-090-01	Miniature Switch	EDC
86881-01	Auto Approach Engage Switch	Lear Siegler
899	Proximity Switch	EDC
A-201	Pressure Switch	Scott ATO
AC66444	Control Handle	Dunlop
AV16B1294D	Shut-Off Valve	ITT
AV16B1296D	Shut-Off Valve	ITT
AV16B1464C	Gate Valve	General Controls/ITT
AV16B1467D	Fuel Gate Valve	General Controls
AV16B1700B	Shut-Off Valve	ITT
B-3	Control Panel	Lear Siegler
BFS 150A	Valve Filter Block	Samm
C709009000	Control Panel	Singer Kearfott
C709009002	Control Panel	Singer Kearfott
CG29B	Function Selector	Honeywell
CG29B-1	Function Selector	Honeywell
CG29B4	Function Selector	Honeywell
CQ-10	Control Selector Switch	Eclipse Pioneer
CQ-10-A1	Control Selector Switch	Eclipse Pioneer
CQ-16-A1	Clutch Switch	Eclipse Pioneer
CQ-16-A2	Clutch Switch	Eclipse Pioneer
CQ-16-A3	Clutch Switch	Eclipse Pioneer
CQ-21-A1	Clutch Switch	Eclipse Pioneer
CQ-22-A1	Clutch Switch	Eclipse Pioneer
CQ-9	Clutch Switch	Eclipse Pioneer
EA-29-141	Selector Switch	Liquidometer
EB-10-A2	Relay Unit	Eclipse Pioneer
EB24-B1	Relay Unit	Eclipse Pioneer

EB34-A1	Relay Unit	Eclipse Pioneer
EB34-B1	Relay Unit	Eclipse Pioneer
F-7351	Fluid Indicator Switch	Revere
GC34-2	Control Panel	Lear Siegler
H6-1009	Hermetic Switch	Controls Co.
KC 290	Mode Control	Bendix King
KC 292	Mode Control	Bendix King
M-1009-10	Pressure Switch	Scott ATO

Primary Part Number	Nomenclature	Manufacture
MA-2	Function Selector	Eclipse Pioneer
ME-1009	Pressure Switch	Scott ATO
RG15A-1	Relay Unit	Honeywell
SG7A-1	Switch	Honeywell
SG7B-1	Switch	Honeywell
SG7D-1	Switch	Honeywell
SG7E-1	Switch	Honeywell
UG658A1	RELAYB TESTER	Honeywell
V5000-121	Shut-Off Valve	Valcor
0402-005	Tachometer Indicator	B & D Instruments, In
0403-004	Tachometer Indicator	B & D Instruments, In
0513-002	Tachometer Indicator	B & D Instruments, In
0513-003	Tachometer Indicator	B & D Instruments, In
0520-006	Tachometer Indicator	B & D Instruments, In
0728 KTD/1	Tachometer Indicator	Smith Industries
0728-KTD/1	Percent RPM Indicator	Smith Industries
1001G-01	Tach Generator	Kollsman
101106	Thrust Indicator	Astronautics
10-162650-1	Tachometer Indicator	Bendix
10-162650-3	Tachometer Indicator	Bendix
10-162650-4	Tachometer Indicator	Bendix
10-162650-5	Tachometer Indicator	Bendix
10-162810-2	Tachometer Indicator	Bendix
10-162950( )	Tachometer Indicator	Bendix
10261G01W00	Torque Indicator	AMETEK
10-274097-2	Tachometer Indicator	BF Goodrich
1035G-02	Tach Generator	Kollsman
10-374091-1	Tachometer Indicator	Bendix
10-374095-1	Tachometer Indicator	Bendix
10-374097-1	Tachometer Indicator	Bendix
10-374097-1-2	Tachometer Indicator	Bendix
10-374097-2	Tachometer Indicator	Bendix
10-382300-1	Tachometer Indicator	Bendix
10-382300-3	Tachometer Indicator	Bendix
1041-15-04	Tachometer Indicator	Kollsman
10446N01W00	Torque Indicator	AMETEK
10446N02W00	Torque Indicator	AMETEK
1053-13-01	Tachometer Indicator	Kollsman
10571N01W00	Torque Indicator	AMETEK
1070BU-4-03	Tachometer Indicator	Kollsman

Primary Part Number	Nomenclature	Manufacturer
1070U-4-03	Tachometer Indicator	Kollsman
108305	Tachometer Indicator	Weston
1118GB-0120304	Tach Generator	Kollsman
1118GC-0120304	Tach Generator	Kollsman
1118GD-0120304	Tach Generator	Kollsman
1159CU-8-03	Tachometer Indicator	Kollsman
1159CU-8-04	Tachometer Indicator	Kollsman
1159U-8-03	Tachometer Indicator	Kollsman
1159U-8-04	Tachometer Indicator	Kollsman
117800	Indicator	Astronautics
125587	Tach Generator	Weston
1277-4-03	Tachometer Indicator	Kollsman
1277-4-034	Tachometer Indicator	Kollsman
128374-01-04	Speed Decreaser	Lear Siegler
1284U-4-03	Tachometer Indicator	Kollsman
131348-1	Turbine Speed Indicator	Airesearch
131348-3	Turbine Speed Indicator	Garrett
131348-4	Turbine Speed Indicator	GARRETT - AIRSEARCH
131-9001	Tach Generator	Jack & Heintz
1354-0111302	Tach Generator	Kollsman
1354-0112302	Tach Generator	Kollsman
1354C-0120302	Tach Generator	Tachometer
140510-01-01	Tachometer Indicator	Lear Siegler
140510-01-02	Tachometer Indicator	Lear Siegler
1415U-4-03	Tachometer Indicator	Kollsman
1422-15A-A1	Tachometer Indicator	Pioneer
1461BU-8-03	Tachometer Indicator	Kollsman
1461CU-8-03	Tachometer Indicator	Kollsman
1461D-8-03	Tachometer Indicator	Kollsman
1461DU-8-03	Tachometer Indicator	Kollsman
1461FU-10-01	Tachometer Indicator	Kollsman
1461FX-10-01	Tachometer Indicator	Kollsman
1461FX-8-03	Tachometer Indicator	Kollsman
1461U-8-03	Tachometer Indicator	Kollsman
1467-4-03	Tachometer Indicator	Kollsman
1492-0120304	Tach Generator	Kollsman
1492B-0120304	Tach Generator	Kollsman
1559-4-03	Tachometer Indicator	Kollsman
1559-4-06	Tachometer Indicator	Kollsman
1559C-4-06	Tachometer Indicator	Kollsman
1560U-4-03	Tachometer Indicator	Kollsman
162CF609	Percent RPM Indicator	Lewis
162CF613A	RPM Indicator	Lewis
162CF613B	RPM Indicator	Lewis
162CF613C	RPM Indicator	Lewis
162CF614	RPM Indicator	Lewis
162CF615	RPM Indicator	Lewis
162CF615A	RPM Indicator	Lewis

Primary Part Number	Nomenclature	Manufacture
162CF621	RPM Indicator	Lewis
1880666-1	Tachometer Indicator	Bendix
1880666-2	Tachometer Indicator	Bendix
1880676-1	Tachometer Indicator	Bendix
1880676-2	Tachometer Indicator	Bendix
1U320	Tachometer Indicator	Sigma Tek
200-069-002	Indicator	Gull
204-905-002	N1 Percent RPM Indicator	Gull
206-075-739-101	Torque Indicator	BELL
206-075-739-103	Torque Indicator	BELL
206-075-739-105	Torque Indicator	BELL
206-075-739-107	Torque Indicator	BELL
206-075-739-109	Torque Indicator	BELL
206-075-739-111	Torque Indicator	BELL
206-075-739-113	Torque Indicator	BELL
206-075-739-115	Torque Indicator	BELL
206-375-013-101	Torque Indicator	BELL
209-075-655-101	Tachometer Indicator	Bendix
2100794-3	Fan Speed Indicator	Airesearch
212-070-108-3	Tachometer Indicator	Bendix
212-070-108-5	Tachometer Indicator	Bell
213100	Actuator	Woodward
2185-04-03	Tachometer Indicator	Kollsman
218-901-002	Percent RPM Indicator	Gull
218-909-001	Percent RPM Indicator	Gull
22-279 SERIES	Percent RPM Indicator	Electric Auto-Lite Co
22-280	Tachometer Indicator	Electric Auto-Lite Co
22-280-026-1	Synchroscope	Electric Auto-Lite Co
22-280-026-2	Synchroscope	Electric Auto-Lite Co
22-280-032	Tachometer Indicator	Electric Auto-Lite Co
22-280-033-1	Tachometer Indicator	Electric Auto-Lite Co
22-280-902	Synchroscope	Electric Auto-Lite Co
22-280-904	Tachometer Indicator	Electric Auto-Lite Co
22-281	Tachometer Indicator	Electric Auto-Lite Co
22-284	Tachometer Indicator	Electric Auto-Lite Co
22-285	Tachometer Indicator	Electric Auto-Lite Co
22-285-01	Tachometer Indicator	Electric Auto-Lite Co
22-285-02	Tachometer Indicator	Electric Auto-Lite Co
224-902-002	N1 Indicator	Gull
224-907-001	Fan Speed Indicator	Gull
224-917-001	Prop RPM Indicator	Gull
229-2029-00	Motor Rate Tachometer	Collins
229-2045-030	Motor Rate Tachometer	Collins
229-2054-030	Tachometer Indicator	Collins

Primary Part Number	Nomenclature	Manufacture
22A524	Tach Generator	Globe
22A554	Tach Generator	Globe

22A571	Tach Generator	Globe
22A592	Tach Generator	Globe
22A649	Tach Generator	Globe
22A667	Tach Generator	Globe
22A685	Tach Generator	Globe
2300	Chronometric Tachometer	Jaeger
23-2004	Tach Generator	AID
23A571	Tach Generator	Globe
23A6000	Tach Generator	Globe
23A667	Tach Generator	Globe
23A731	Tach Generator	Globe
23A738	Tach Generator	Globe
2504-200	Tachometer Indicator	B & D Instruments, In
2504-200A	Tachometer Indicator	B & D Instruments, In
2504-500	Tachometer Indicator	B & D Instruments, In
2504-500A	Tachometer Indicator	B & D Instruments, In
25140-22A703	Tach Generator	Globe
267-942-002	RPM Indicator	Gull
267-960-001	Percent RPM Indicator	Gull
269-4251	Tachometer Indicator	Consolidated Airborn
269A-4251	Tachometer Indicator	Consolidated Airborn
269A4251-5	Tachometer Indicator	Consolidated Airborn
29-19157-3	Tachometer Indicator	Lewis
2ASY20A1B	Tach Generator	Ametek/GE
2CM11BAA4	Tach Generator	Ametek/GE
2CM5ABW	Tach Generator	Ametek/GE
2CM5ACE	Tach Generator	Ametek/GE
2CM5ACZ	Tach Generator	Ametek/GE
2CM5ADR	Tach Generator	Ametek/GE
2CM5AEN	Tach Generator	Ametek/GE
2CM5AFE46	Tach Generator	Ametek/GE
2CM5BAL	Tach Generator	Ametek/GE
2CM5BAM	Tach Generator	Ametek/GE
2CM7AAA	Tach Generator	Ametek/GE
2CM9AA6	Tach Generator	Ametek/GE
2CM9AAA1	Tach Generator	Ametek/GE
2CM9AAA2	Tach Generator	Ametek/GE
2CM9AAA6	Tach Generator	Ametek/GE
2CM9AAB	Tach Generator	Ametek/GE
2CM9AAC1	Tach Generator	Ametek/GE
2CM9AAC2	Tach Generator	Ametek/GE
2CM9AAC6	Tach Generator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
2CM9AAF2	Tach Generator	Ametek/GE
2CM9AAH4	Tach Generator	Ametek/GE
2CM9AAV6	Tach Generator	Ametek/GE
2CM9AAZ6	Tach Generator	Ametek/GE
2CM9AB27	Tach Generator	Ametek/GE
2CM9ABE6	Tach Generator	Ametek/GE

2CM9ABH7	Tach Generator	Ametek/GE
2CM9ABK7	Tach Generator	Ametek/GE
2CM9ABY7	Tach Generator	Ametek/GE
2CM9ABZ7	Tach Generator	Ametek/GE
2CM9ACE7	Tach Generator	Ametek/GE
2CM9ACF8	Tach Generator	Ametek/GE
2CM9ACH7	Tach Generator	Ametek/GE
2CM9ACY7	Tach Generator	Ametek/GE
2CM9ADB9	Tach Generator	Ametek/GE
2CM9ADE8	Tach Generator	Ametek/GE
2CM9ADT6	Tach Generator	Ametek/GE
32005-002	Tach Generator	Lear Siegler
32005-007	Tach Generator	Avitron
32005-023	Tach Generator	AAE
3201 KGA/CP/1	Tach Generator	Smith Industries
3202 KGA/MS/1	Tach Generator	Smith Industries
32050-000	Tach Generator	LSI
32164-000	Tach Generator	LSI
32164-005	Tach Generator	LSI
32164-007	Tach Generator	LSI
32631	Tachometer Indicator	Aerosonic
3300	Tachometer Indicator	BF Goodrich
34101C2C7-2E1	Tachometer Indicator	Bendix
34102C2B3-2D1	Tachometer Indicator	Bendix
34107C1AG13-1A3	Tachometer Indicator	Bendix
34108C1AF13-1A3	Tachometer Indicator	Bendix
3571260-4001	Tachometer Indicator	Bendix
3571261-3002	Tachometer Indicator	Bendix
3571261-3101	Tachometer Indicator	Bendix
3571261-3102	Tachometer Indicator	Bendix
3571261-3104	Tachometer Indicator	Bendix
3571262-2301	Tachometer Indicator	Bendix
3571262-2302	Tachometer Indicator	Bendix
3571262-2303	Tachometer Indicator	Bendix
3571262-2306	Tachometer Indicator	Bendix
3571262-2307	Tachometer Indicator	Bendix
3571262-2308	Tachometer Indicator	Bendix
3571280-4001	Tachometer Indicator	Bendix

Primary Part Number	Nomenclature	Manufacture
3571281-8102	Tach Indicator	Bendix
3571371-6001	Tachometer Indicator	Bendix
3571371-6002	Tachometer Indicator	Bendix
3572160	Tachometer Indicator	Bendix
36-380007	Tachometer Indicator	R C Allen
36-380007-1	Tachometer Indicator	R C Allen
36-380007-27	Tachometer Indicator	Beechcraft
36-380007-3	Tachometer Indicator	R C Allen
36-380007-5	Tachometer Indicator	R C Allen
3800	Chronometric Tachometer	Jaeger

3809311-3	Gas Producer Tachometer Ind	Bendix
3809314-4	Tachometer Indicator	Bendix
3809314-5	Tachometer Indicator	Bendix
3940231-9001	Tachometer Indicator	Bendix
3940231-9002	Tachometer Indicator	Bendix
3940231-9003	Tachometer Indicator	Bendix
3940231-9004	Tachometer Indicator	Bendix
3941231-9002	Prop RPM Indicator	Bendix
3941231-9003	Prop RPM Indicator	Bendix
3941231-9004	Prop RPM Indicator	Bendix
3941231-9005	Prop RPM Indicator	Bendix
3941231-9006	Prop RPM Indicator	Bendix
4012	Tachometer Indicator	United Instruments
4012-D-M.45	Tachometer Indicator	United Instruments
4013	Tachometer Indicator	United Instruments
4013 Series	Pulse Sensitive Indicator	United Instruments
4022A	Tachometer Indicator	United Instruments
40-625	Wheel Speed/Spoiler Transducer	Crane
40-625-2	Wheel Speed/Spoiler Transducer	Crane
40-625-4	Wheel Speed/Spoiler Transducer	Crane
40-625-4A	Wheel Speed/Spoiler Transducer	Crane
40-625-5	Wheel Speed/Spoiler Transducer	Crane
41105-C5A-4-B3	Tachometer Indicator	Bendix
41105-C5A-4-E3	Tachometer Indicator	Bendix
415540	Tachometer Indicator	Norden Ketay
41934	Tachometer Indicator	Aerosonic
425430-2A	Tach Generator	Kearfott
4350-2A-A2	Tachometer Transmitter	Eclipse Pioneer
4350-2A-B2	Tachometer Transmitter	Eclipse Pioneer
4700	Chronometric Tachometer	Jaeger
472018	Turbine Speed Indicator	Simmonds
472019	Fan Speed Indicator	Simmonds
4770	Chronometric Tachometer	Jaeger
4A1227	Tach Generator	Globe

Primary Part Number	Nomenclature	Manufacture
50-380010-19	Tachometer Indicator	Beechcraft
50-380034-3	RPM Indicator	Beechcraft
50-380035-5	Tachometer Indicator	R C Allen
50-389091	Synchroscope	Electric Auto-Lite Co
512-	Tachometer Indicator	Instruments Inc.
512-0101	Tachometer Indicator	Cessna
512-0102	Tachometer Indicator	Cessna
512-0103	Tachometer Indicator	Cessna
512-0104	Tachometer Indicator	Cessna
512-0105	Tachometer Indicator	Cessna
512-0106	Tachometer Indicator	Cessna
512-0107	Tachometer Indicator	Cessna
512-0108	Tachometer Indicator	Cessna
512-0109	Tachometer Indicator	Cessna

512-0110	Tachometer Indicator	Cessna
51471-110-2	Tachometer Indicator	Jaeger
522041	Tachometer Indicator	Weston
522544	APU/RPM Indicator	Weston
545	Tachometer Indicator	Weston
5485-010	Actuator	Woodward
5485-016	Prop Synchronizer	Woodward
5485-020	Prop Synchronizer	Woodward
5485-022	Actuator	Woodward
5485-040	Prop Synchronizer	Woodward
5485-054	Actuator	Woodward
5485-058	Actuator	Woodward
5485-062	Actuator	Woodward
5485-066	Actuator	Woodward
5485-068	Actuator	Woodward
549	Synchroscope	Kollsman
549B-01	Synchroscope	Kollsman
549B-09	Synchroscope	Kollsman
5550-7070-1	Turn and Slip Indicator	General Design
563-030	Prop Indicator	Hickok
57-4AW	Tachometer Indicator	Consolidated Airborn
57-6AW	Tachometer Indicator	Consolidated Airborn
57-P14-1	Tachometer Indicator	Consolidated Airborn
58-380089-3	Prop Amp Indicator	R C Allen
585-37800-002	Tachometer Indicator	IDC
585-37801-002	Tachometer Indicator	IDC
590BK-3-01	Tachometer Indicator	Kollsman
600	Chronometric Tachometer	Jaeger
6007-28A-1-A	Tachometer Indicator	Eclipse Pioneer
6007-28B-6-A	Tachometer Indicator	Eclipse Pioneer

Primary Part Number	Nomenclature	Manufacture
6007-28C-14-A	Tachometer Indicator	Eclipse Pioneer
6007-28C-14-B	Tachometer Indicator	Eclipse Pioneer
6007-28C-7-A	Tachometer Indicator	Eclipse Pioneer
6007-28E-7-A	Tachometer Indicator	Eclipse Pioneer
61111-14	Percent RPM Indicator	Lewis
612-45S-501	Tachometer Indicator	B & D Instruments, In
612-45S-503	Tachometer Indicator	B & D Instruments, In
612-45S-505	Tachometer Indicator	B & D Instruments, In
61471-109-2	Tachometer Indicator	Jaeger
61471-109-3	Tachometer Indicator	Jaeger
61471-110-3	Tachometer Indicator	Jaeger
63-11	Tachometer Indicator	Consolidated Airborn
63-5	Tachometer Indicator	Consolidated Airborn
64550-005-1	Tach Generator	Jaeger
64550-023-1	Tach Generator	Jaeger
6501	Tachometer Indicator	Instrument Spec.
6501-( )	Tachometer Indicator	Insco
6501-1006	Tachometer Indicator	Insco

6501-1010	Tachometer Indicator	Insco
6501-1014	Tachometer Indicator	Insco
6501-1016	Tachometer Indicator	Insco
6501-1040	Tachometer Indicator	Insco
6501-1044	Tachometer Indicator	Insco
6501-1047	Tachometer Indicator	Insco
6501-1051	Tachometer Indicator	Insco
6501-1055	Tachometer Indicator	Insco
6501-1056	Tachometer Indicator	Insco
6501-1058	Tachometer Indicator	Insco
6501-1068	Tachometer Indicator	Insco
6501-3007	Tachometer Indicator	Insco
6501-3008	Tachometer Indicator	Insco
6501-3034	Tachometer Indicator	Insco
6501-3037	Tachometer Indicator	Insco
6501-3061	Tachometer Indicator	Insco
6501-3062	Tachometer Indicator	Insco
6502-1001	Tachometer Indicator	Insco
6502-1002	Tachometer Indicator	Insco
6502-1006	Tachometer Indicator	Insco
6502-1007	Tachometer Indicator	Insco
6502-1008	Tachometer Indicator	Insco
6502-1009	Tachometer Indicator	Insco
6502-1011	Tachometer Indicator	Insco
6502-1013	Tachometer Indicator	Insco
6502-1014	Tachometer Indicator	Insco

Primary Part Number	Nomenclature	Manufacture
6502-1019	Tachometer Indicator	Insco
6502-1024	Tachometer Indicator	Insco
6502-1032	Tachometer Indicator	Insco
6502-1033	Tachometer Indicator	Insco
6502-1034	Tachometer Indicator	Insco
6502-1038	Tachometer Indicator	Insco
6502-1041	Tachometer Indicator	Insco
6502-2004	Tachometer Indicator	Insco
6502-3003	Tachometer Indicator	Insco
6502-3010	Tachometer Indicator	Insco
6502-3031	Tachometer Indicator	Insco
6502-3045	Tachometer Indicator	Insco
6503A	Tachometer Indicator	Insco
6505A	Triple Tachometer	Instrument Specialtie
6511 Series	Pulse Sensitive Indicator	United Instruments
6547	Tachometer Indicator	Consolidated Airborn
654-A-1	Tachometer Indicator	Consolidated Airborn
665-52-86	Tach Generator	General Motors
6862450	Tach Generator	General Motors
7040-2	Engine Speed Indicator	Officine Galileo
7040-3	Engine Speed Indicator	Officine Galileo
724	Tachometer Indicator	Weston

724B	Tachometer Indicator	Weston
724C	Tachometer Indicator	Weston
740CK-4-020	Tachometer Indicator	Kollsman
740CK-4-021	Tachometer Indicator	Kollsman
740CK-4-022	Tachometer Indicator	Kollsman
740CK-4-026	Tachometer Indicator	Kollsman
740CK-4-027	Tachometer Indicator	Kollsman
751BK-02	Tachometer Indicator	Kollsman
751CK-02	Tachometer Indicator	Kollsman
751CK-10-027	Tachometer Indicator	Kollsman
751CK-10-032	Tachometer Indicator	Kollsman
751CK-8-021-2	Tachometer Indicator	Kollsman
751CU-4-02	Tachometer Indicator	Kollsman
751K-02	Tachometer Indicator	Kollsman
772BK-4-02	Synchroscope	Kollsman
772BU-4-03	Synchroscope	Kollsman
772CU-4-02	Synchroscope	Kollsman
772DU-4-02	Synchroscope	Kollsman
772K-02	Synchroscope	Kollsman
772U-02	Synchroscope	Kollsman
78035-01100	Tachometer Indicator	Aerosonic
78035-01112	Tachometer Indicator	Aerosonic

Primary Part Number	Nomenclature	Manufacture
78035-01113	Tachometer Indicator	Aerosonic
78035-0113	Tachometer Indicator	Aerosonic
78035-01173	Tachometer Indicator	Aerosonic
78035-0130	Tachometer Indicator	Aerosonic
78035-0161	Tachometer Indicator	Aerosonic
78035-0169	Tachometer Indicator	Aerosonic
78035-0175	Tachomter Indicator	Aerosonic
78035-0179	Tachometer Indicator	Aerosonic
78035-0180	Tachometer Indicator	Aerosonic
78035-0181	Tachometer Indicator	Aerosonic
78035-0182	Tachometer Indicator	Aerosonic
78035-0189	Tachometer Indicator	Aerosonic
78035-0190	Tachometer Indicator	Aerosonic
78035-0194	Tachometer Indicator	Aerosonic
78035-11105	Tachometer Indicator	Aerosonic
78035-11109	Tachometer Indicator	Aerosonic
78035-181	Tachometer Indicator	Aerosonic
78305	Tachometer Indicator	Aerosonic
785084-1-001	Digital Propeller Synchrophase	Hamilton Sundstrand
785084-1-002	Digital Propeller Synchrophase	Hamilton Sundstrand
785084-1-003	Digital Propeller Synchrophase	Hamilton Sundstrand
785084-1-004	Digital Propeller Synchrophase	Hamilton Sundstrand
785084-1-005	Digital Propeller Synchrophase	Hamilton Sundstrand
785085-1-001	Digital Propeller Synchrophase	Hamilton Sundstrand
785085-1-002	Digital Propeller Synchrophase	Hamilton Sundstrand
785085-1-003	Digital Propeller Synchrophase	Hamilton Sundstrand

785085-1-004	Digital Propeller Synchrophase	Hamilton Sundstrand
785085-1-005	Digital Propeller Synchrophase	Hamilton Sundstrand
785085-1-006	Digital Propeller Synchrophase	Hamilton Sundstrand
785086-1-001	Digital Propeller Synchrophase	Hamilton Sundstrand
785086-1-002	Digital Propeller Synchrophase	Hamilton Sundstrand
785086-1-003	Digital Propeller Synchrophase	Hamilton Sundstrand
785086-1-004	Digital Propeller Synchrophase	Hamilton Sundstrand
785086-1-005	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-1-001	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-1-002	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-1-003	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-1-004	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-1-005	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-1-006	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-1-007	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-2-008	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-2-009	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-3-010	Digital Propeller Synchrophase	Hamilton Sundstrand

Primary Part Number	Nomenclature	Manufacture
785087-4-011	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-4-014	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-5-012	Digital Propeller Synchrophase	Hamilton Sundstrand
785087-6-013	Digital Propeller Synchrophase	Hamilton Sundstrand
785088-1-001	Digital Propeller Synchrophase	Hamilton Sundstrand
785088-1-002	Digital Propeller Synchrophase	Hamilton Sundstrand
785088-1-003	Digital Propeller Synchrophase	Hamilton Sundstrand
785088-1-004	Digital Propeller Synchrophase	Hamilton Sundstrand
785088-1-005	Digital Propeller Synchrophase	Hamilton Sundstrand
798570-1-001	Digital Propeller Synchrophase	Hamilton Sundstrand
798570-1-002	Digital Propeller Synchrophase	Hamilton Sundstrand
798570-2-003	Digital Propeller Synchrophase	Hamilton Sundstrand
8000	Indicator	United
800021	Synchroscope	Lear Siegler
800134	Synchroscope	Lear Siegler
800196	Synchroscope	Lear Siegler
819253-1-001	Digital Propeller Synchrophase	Hamilton Sundstrand
850192-501	Tachometer Indicator	Aero Commander
850192-503	Tachometer Indicator	Aero Commander
850192-505	Tachometer Indicator	Aero Commander
880003-501	Signal Cable-Electronic Tach	Mooney
880039-501	Tachometer Indicator	Mooney
880039-503	Tachometer Indicator	Mooney
880039-507	Tachometer Indicator	B & D Instruments, In
88527800001	Tach Generator	Kollsman
8DJ119SHD	Tachometer Indicator	Ametek/GE
8DJ131AAB1	Tachometer Indicator	Ametek/GE
8DJ131AAE1	Tachometer Indicator	Ametek/GE
8DJ131AAJ1	Tachometer Indicator	Ametek/GE
8DJ131AAT2	Tachometer Indicator	Ametek/GE

8DJ131LAC1	Tachometer Indicator	Ametek/GE
8DJ131LAE1	Tachometer Indicator	Ametek/GE
8DJ131LAN1	Tachometer Indicator	Ametek/GE
8DJ131LAV1	Tachometer Indicator	Ametek/GE
8DJ131LAW1	Tachometer Indicator	Ametek/GE
8DJ131LAZ1	Tachometer Indicator	Ametek/GE
8DJ131LBA1	Tachometer Indicator	Ametek/GE
8DJ13AAA	Tachometer Indicator	Ametek/GE
8DJ13AAS33	Tachometer Indicator	Ametek/GE
8DJ13AAT	Tachometer Indicator	Ametek/GE
8DJ13ABK	Tachometer Indicator	Ametek/GE
8DJ13ABN	Tachometer Indicator	Ametek/GE
8DJ13ACX	Tachometer Indicator	Ametek/GE
8DJ13ADL	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacturer
8DJ13ADX	Tachometer Indicator	Ametek/GE
8DJ13AEL	Tachometer Indicator	Ametek/GE
8DJ13AFN	Tachometer Indicator	Ametek/GE
8DJ13AFX	Tachometer Indicator	Ametek/GE
8DJ13AGT	Tachometer Indicator	Ametek/GE
8DJ13AKD	Tachometer Indicator	Ametek/GE
8DJ148CAB1	Tachometer Indicator	Ametek/GE
8DJ148CAC	Tachometer Indicator	Ametek/GE
8DJ148WAC2	Tachometer Indicator	Ametek/GE
8DJ148WAC3	Tachometer Indicator	Ametek/GE
8DJ148WAD2	Tachometer Indicator	Ametek/GE
8DJ148WAD3	Tachometer Indicator	Ametek/GE
8DJ150FAC1	Tachometer Indicator	Ametek/GE
8DJ150FAD1	Tachometer Indicator	Ametek/GE
8DJ150FAE1	Tachometer Indicator	Ametek/GE
8DJ150FAF1	Tachometer Indicator	Ametek/GE
8DJ150FAH1	Tachometer Indicator	Ametek/GE
8DJ150FAK1	Tachometer Indicator	Ametek/GE
8DJ150LAC1	Tachometer Indicator	Ametek/GE
8DJ150LAD1	Tachometer Indicator	Ametek/GE
8DJ150LAE1	Tachometer Indicator	Ametek/GE
8DJ150WAA1	Tachometer Indicator	Ametek/GE
8DJ150WAC1	Tachometer Indicator	Ametek/GE
8DJ150WAD1	Tachometer Indicator	Ametek/GE
8DJ150WAE1	Tachometer Indicator	Ametek/GE
8DJ150WAF1	Tachometer Indicator	Ametek/GE
8DJ150WAG1	Tachometer Indicator	Ametek/GE
8DJ150WAH1	Tachometer Indicator	Ametek/GE
8DJ15AAC	Tachometer Indicator	Ametek/GE
8DJ162	Tachometer Indicator	Ametek/GE
8DJ162LWL2	Tachometer Indicator	Ametek/GE
8DJ162LWM2	Tachometer Indicator	Ametek/GE
8DJ162LWY2	Tachometer Indicator	Ametek/GE
8DJ162LXE2	Tachometer Indicator	Ametek/GE

8DJ162LXG2	Tachometer Indicator	Ametek/GE
8DJ162LXH2	Tachometer Indicator	Ametek/GE
8DJ162LXK2	Tachometer Indicator	Ametek/GE
8DJ162LXL2	Tachometer Indicator	Ametek/GE
8DJ162LXM2	Tachometer Indicator	Ametek/GE
8DJ162LXN2	Tachometer Indicator	Ametek/GE
8DJ162LXP2	Tachometer Indicator	Ametek/GE
8DJ162LXR2	Tachometer Indicator	Ametek/GE
8DJ162LXT2	Tachometer Indicator	Ametek/GE
8DJ162LYE2	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ162LYL2	Tachometer Indicator	Ametek/GE
8DJ162LYS2	Tachometer Indicator	Ametek/GE
8DJ162LZE2	Tachometer Indicator	Ametek/GE
8DJ162LZT2	Tachometer Indicator	Ametek/GE
8DJ162LZV2	Tachometer Indicator	Ametek/GE
8DJ162LZW2	Tachometer Indicator	Ametek/GE
8DJ162LZX2	Tachometer Indicator	Ametek/GE
8DJ162WAA2	Tachometer Indicator	Ametek/GE
8DJ162WAD2	Tachometer Indicator	Ametek/GE
8DJ176LWG2	Engine Core Speed Indicator	Ametek/GE
8DJ176LWV2	Engine Core Speed Indicator	Ametek/GE
8DJ176LWX1	Engine Speed Indicator	Ametek/GE
8DJ176LWY1	Engine Speed Indicator	Ametek/GE
8DJ176LXA1	Engine Speed Indicator	Ametek/GE
8DJ176LXG1	Engine Speed Indicator	Ametek/GE
8DJ176LXH1	Engine Speed Indicator	Ametek/GE
8DJ176LXK1	Engine Speed Indicator	Ametek/GE
8DJ176LXL1	Engine Speed Indicator	Ametek/GE
8DJ176LXN1	Engine Speed Indicator	Ametek/GE
8DJ176LXS1	Engine Speed Indicator	Ametek/GE
8DJ176LXT1	Engine Speed Indicator	Ametek/GE
8DJ176LXV1	Engine Speed Indicator	Ametek/GE
8DJ176LZB1	Engine Speed Indicator	Ametek/GE
8DJ176LZC1	Engine Speed Indicator	Ametek/GE
8DJ176LZE2	Engine Core Speed indicator	Ametek/GE
8DJ176LZF2	Engine Core Speed Indicator	Ametek/GE
8DJ176LZP1	Engine Speed Indicator	Ametek/GE
8DJ176LZR1	Engine Speed Indicator	Ametek/GE
8DJ176LZS2	Engine Core Speed indicator	Ametek/GE
8DJ176LZY1	Engine Speed Indicator	Ametek/GE
8DJ176WAE1	Engine Speed Indicator	Ametek/GE
8DJ176WAR2	Engine Core Speed Indicator	Ametek/GE
8DJ176XEY1	Engine Speed Indicator	Ametek/GE
8DJ176XLE1	Engine Speed Indicator	Ametek/GE
8DJ19AAB3	Tachometer Indicator	Ametek/GE
8DJ19AAH	Tachometer Indicator	Ametek/GE
8DJ19AAR	Tachometer Indicator	Ametek/GE
8DJ19AAS	Tachometer Indicator	Ametek/GE

8DJ19AAW	Tachometer Indicator	Ametek/GE
8DJ19AAW2	Tachometer Indicator	Ametek/GE
8DJ19AAW3	Tachometer Indicator	Ametek/GE
8DJ19AAX	Tachometer Indicator	Ametek/GE
8DJ19AAY	Tachometer Indicator	Ametek/GE
8DJ19ABE	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ19ABF	Tachometer Indicator	Ametek/GE
8DJ19ABF3	Tachometer Indicator	Ametek/GE
8DJ19ABR	Tachometer Indicator	Ametek/GE
8DJ19ABS3	Tachometer Indicator	Ametek/GE
8DJ19ABS5	Tachometer Indicator	Ametek/GE
8DJ19ABT3	Tachometer Indicator	Ametek/GE
8DJ19ABT5	Tachometer Indicator	Ametek/GE
8DJ19ACA	Tachometer Indicator	Ametek/GE
8DJ19ACB	Tachometer Indicator	Ametek/GE
8DJ19ACV	Tachometer Indicator	Ametek/GE
8DJ19ADH	Tachometer Indicator	Ametek/GE
8DJ19ADH6	Tachometer Indicator	Ametek/GE
8DJ19ADK	Tachometer Indicator	Ametek/GE
8DJ19ADK6	Tachometer Indicator	Ametek/GE
8DJ19ADL5	Tachometer Indicator	Ametek/GE
8DJ19ADT5	Tachometer Indicator	Ametek/GE
8DJ19ADT-Y29	Tachometer Indicator	Ametek/GE
8DJ19ADV	Tachometer Indicator	Ametek/GE
8DJ19ADV6	Tachometer Indicator	Ametek/GE
8DJ19GAC6	Tachometer Indicator	Ametek/GE
8DJ19GAE5	Tachometer Indicator	Ametek/GE
8DJ19GAF	Tachometer Indicator	Ametek/GE
8DJ19GAF6	Tachometer Indicator	Ametek/GE
8DJ19GAN6	Tachometer Indicator	Ametek/GE
8DJ215WAD1	Engine Fan Speed Indicator	Ametek/GE
8DJ215WAT1	Engine Rotor Speed Indicator	Ametek/GE
8DJ215WBA1	Indicator	GE
8DJ278WAC1	Engine Fan Speed Indicator	Ametek/GE
8DJ278WAD1	N1 Percent RPM Indicator	Ametek/GE
8DJ43AAD	Tachometer Indicator	Ametek/GE
8DJ43AAE	Tachometer Indicator	Ametek/GE
8DJ43AAF14	Tachometer Indicator	Ametek/GE
8DJ43AAF6	Tachometer Indicator	Ametek/GE
8DJ43AAH	Tachometer Indicator	Ametek/GE
8DJ43AAK1	Tachometer Indicator	Ametek/GE
8DJ43AAK3	Tachometer Indicator	Ametek/GE
8DJ43AAK5	Tachometer Indicator	Ametek/GE
8DJ43AAL13	Tachometer Indicator	Ametek/GE
8DJ43AAL14	Tachometer Indicator	Ametek/GE
8DJ43AAM	Tachometer Indicator	Ametek/GE
8DJ43AAM14	Tachometer Indicator	Ametek/GE
8DJ43BAD	Tachometer Indicator	Ametek/GE

8DJ43BAE	Tachometer Indicator	Ametek/GE
8DJ43BAE14	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ43BAH14	Tachometer Indicator	Ametek/GE
8DJ57FAA1	Tachometer Indicator	Ametek/GE
8DJ57FAA4	Tachometer Indicator	Ametek/GE
8DJ57FAA5	Tachometer Indicator	Ametek/GE
8DJ57HAA2	Tachometer Indicator	Ametek/GE
8DJ57HAA3	Tachometer Indicator	Ametek/GE
8DJ57HAA4	Tachometer Indicator	Ametek/GE
8DJ57HAA5	Tachometer Indicator	Ametek/GE
8DJ57HAV5	Tachometer Indicator	Ametek/GE
8DJ67AAC!	Tachometer Indicator	Ametek/GE
8DJ67AAL1	Tachometer Indicator	Ametek/GE
8DJ67FAB1	Tachometer Indicator	Ametek/GE
8DJ67FAC1	Tachometer Indicator	Ametek/GE
8DJ67FAE1	Tachometer Indicator	Ametek/GE
8DJ67FAK1	Tachometer Indicator	Ametek/GE
8DJ67FAW1	Tachometer Indicator	Ametek/GE
8DJ67FBC1	Tachometer Indicator	Ametek/GE
8DJ67FBE1	Tachometer Indicator	Ametek/GE
8DJ67FBN1	Tachometer Indicator	Ametek/GE
8DJ67FBS1	Tachometer Indicator	Ametek/GE
8DJ67FCC1	Tachometer Indicator	Ametek/GE
8DJ81AAA1	Tachometer Indicator	Ametek/GE
8DJ81AAB1	Tachometer Indicator	Ametek/GE
8DJ81BAA1	Tachometer Indicator	Ametek/GE
8DJ81BAC1	Tachometer Indicator	Ametek/GE
8DJ81BLB4	Tachometer Indicator	Ametek/GE
8DJ81BLC4	Tachometer Indicator	Ametek/GE
8DJ81CAA1	Tachometer Indicator	Ametek/GE
8DJ81CAA2	Tachometer Indicator	Ametek/GE
8DJ81CAA4	Tachometer Indicator	Ametek/GE
8DJ81CAB2	Tachometer Indicator	Ametek/GE
8DJ81CAC1	Tachometer Indicator	Ametek/GE
8DJ81CAC2	Tachometer Indicator	Ametek/GE
8DJ81CAE1	Tachometer Indicator	Ametek/GE
8DJ81CAE2	Tachometer Indicator	Ametek/GE
8DJ81CAE3	Tachometer Indicator	Ametek/GE
8DJ81CAF1	Tachometer Indicator	Ametek/GE
8DJ81CAF2	Tachometer Indicator	Ametek/GE
8DJ81CAH1	Tachometer Indicator	Ametek/GE
8DJ81CAH2	Tachometer Indicator	Ametek/GE
8DJ81CAK1	Tachometer Indicator	Ametek/GE
8DJ81CAL1	Tachometer Indicator	Ametek/GE
8DJ81CAM1	Tachometer Indicator	Ametek/GE
8DJ81CAN1	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture

8DJ81CAN2	Tachometer Indicator	Ametek/GE
8DJ81CAN4	Tachometer Indicator	Ametek/GE
8DJ81CAS2	Tachometer Indicator	Ametek/GE
8DJ81CAX2	Tachometer Indicator	Ametek/GE
8DJ81CAY2	Tachometer Indicator	Ametek/GE
8DJ81CAZ2	Tachometer Indicator	Ametek/GE
8DJ81CBA2	Tachometer Indicator	Ametek/GE
8DJ81CBB2	Tachometer Indicator	Ametek/GE
8DJ81CBD1	Tachometer Indicator	Ametek/GE
8DJ81CBD4	Tachometer Indicator	Ametek/GE
8DJ81CBK2	Tachometer Indicator	Ametek/GE
8DJ81CBX2	Tachometer Indicator	Ametek/GE
8DJ81CCK2	Tachometer Indicator	Ametek/GE
8DJ81CCL2	Tachometer Indicator	Ametek/GE
8DJ81CCM2	Tachometer Indicator	Ametek/GE
8DJ81CDC2	Tachometer Indicator	Ametek/GE
8DJ81CDE2	Tachometer Indicator	Ametek/GE
8DJ81CDH2	Tachometer Indicator	Ametek/GE
8DJ81CDR4	Tachometer Indicator	Ametek/GE
8DJ81CDS4	Tachometer Indicator	Ametek/GE
8DJ81CDW4	Tachometer Indicator	Ametek/GE
8DJ81CDX4	Tachometer Indicator	Ametek/GE
8DJ81CDY2	Tachometer Indicator	Ametek/GE
8DJ81CDZ4	Tachometer Indicator	Ametek/GE
8DJ81FAA1	Tachometer Indicator	Ametek/GE
8DJ81FAA2	Tachometer Indicator	Ametek/GE
8DJ81LAA1	Tachometer Indicator	Ametek/GE
8DJ81LAA2	Tachometer Indicator	Ametek/GE
8DJ81LAA4	Tachometer Indicator	Ametek/GE
8DJ81LAB2	Tachometer Indicator	Ametek/GE
8DJ81LAC1	Tachometer Indicator	Ametek/GE
8DJ81LAC2	Tachometer Indicator	Ametek/GE
8DJ81LAD1	Tachometer Indicator	Ametek/GE
8DJ81LAD2	Tachometer Indicator	Ametek/GE
8DJ81LAE1	Tachometer Indicator	Ametek/GE
8DJ81LAE2	Tachometer Indicator	Ametek/GE
8DJ81LAK1	Tachometer Indicator	Ametek/GE
8DJ81LAK2	Tachometer Indicator	Ametek/GE
8DJ81LAN2	Tachometer Indicator	Ametek/GE
8DJ81LAT1	Tachometer Indicator	Ametek/GE
8DJ81LAT2	Tachometer Indicator	Ametek/GE
8DJ81LAV2	Tachometer Indicator	Ametek/GE
8DJ81LAW1	Tachometer Indicator	Ametek/GE
8DJ81LAW2	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ81LAX2	Tachometer Indicator	Ametek/GE
8DJ81LAY2	Tachometer Indicator	Ametek/GE
8DJ81LAZ2	Tachometer Indicator	Ametek/GE
8DJ81LBC2	Tachometer Indicator	Ametek/GE

8DJ81LBD2	Tachometer Indicator	Ametek/GE
8DJ81LBE2	Tachometer Indicator	Ametek/GE
8DJ81LBF2	Tachometer Indicator	Ametek/GE
8DJ81LBH2	Tachometer Indicator	Ametek/GE
8DJ81LBK2	Tachometer Indicator	Ametek/GE
8DJ81LBL2	Tachometer Indicator	Ametek/GE
8DJ81LBS2	Tachometer Indicator	Ametek/GE
8DJ81LBT2	Tachometer Indicator	Ametek/GE
8DJ81LBX2	Tachometer Indicator	Ametek/GE
8DJ81LCA2	Tachometer Indicator	Ametek/GE
8DJ81LCA4	Tachometer Indicator	Ametek/GE
8DJ81LCB2	Tachometer Indicator	Ametek/GE
8DJ81LCD2	Tachometer Indicator	Ametek/GE
8DJ81LCF2	Tachometer Indicator	Ametek/GE
8DJ81LCK2	Tachometer Indicator	Ametek/GE
8DJ81LCP4	Tachometer Indicator	Ametek/GE
8DJ81LCR4	Tachometer Indicator	Ametek/GE
8DJ81LCT4	Tachometer Indicator	Ametek/GE
8DJ81LSC4	Tachometer Indicator	Ametek/GE
8DJ81LSC4-U	Tachometer Indicator	Ametek/GE
8DJ81LVA4	Tachometer Indicator	Ametek/GE
8DJ81LVB4	Tachometer Indicator	Ametek/GE
8DJ81LVB4-U	Tachometer Indicator	Ametek/GE
8DJ81LVF4	Tachometer Indicator	Ametek/GE
8DJ81LVG4	Tachometer Indicator	Ametek/GE
8DJ81LVL4	Tachometer Indicator	Ametek/GE
8DJ81LVL4-U	Tachometer Indicator	Ametek/GE
8DJ81LWA1	Tachometer Indicator	Ametek/GE
8DJ81LWA2	Tachometer Indicator	Ametek/GE
8DJ81LWA3	Tachometer Indicator	Ametek/GE
8DJ81LWA4	Tachometer Indicator	Ametek/GE
8DJ81LWB2	Tachometer Indicator	Ametek/GE
8DJ81LWC2	Tachometer Indicator	Ametek/GE
8DJ81LWC4	Tachometer Indicator	Ametek/GE
8DJ81LWH2	Tachometer Indicator	Ametek/GE
8DJ81LWM2	Tachometer Indicator	Ametek/GE
8DJ81LWN2	Tachometer Indicator	Ametek/GE
8DJ81LWR2	Tachometer Indicator	Ametek/GE
8DJ81LWR4	Tachometer Indicator	Ametek/GE
8DJ81LWS2	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ81LWS4	Tachometer Indicator	Ametek/GE
8DJ81LWT2	Tachometer Indicator	Ametek/GE
8DJ81LWT4	Tachometer Indicator	Ametek/GE
8DJ81LWT4-U	Tachometer Indicator	Ametek/GE
8DJ81LWV2	Tachometer Indicator	Ametek/GE
8DJ81LWY2	Tachometer Indicator	Ametek/GE
8DJ81LWY4	Tachometer Indicator	Ametek/GE
8DJ81LWZ2	Tachometer Indicator	Ametek/GE

8DJ81LWZ4	Tachometer Indicator	Ametek/GE
8DJ81LXC2	Tachometer Indicator	Ametek/GE
8DJ81LXD2	Tachometer Indicator	Ametek/GE
8DJ81LXE2	Tachometer Indicator	Ametek/GE
8DJ81LXF2	Tachometer Indicator	Ametek/GE
8DJ81LXF4	Tachometer Indicator	Ametek/GE
8DJ81LXF4-U	Tachometer Indicator	Ametek/GE
8DJ81LXG2	Tachometer Indicator	Ametek/GE
8DJ81LXG4	Tachometer Indicator	Ametek/GE
8DJ81LXG4-U	Tachometer Indicator	Ametek/GE
8DJ81LXH2	Tachometer Indicator	Ametek/GE
8DJ81LXH4	Tachometer Indicator	Ametek/GE
8DJ81LXH4-U	Tachometer Indicator	Ametek/GE
8DJ81LXK2	Tachometer Indicator	Ametek/GE
8DJ81LXK4	Tachometer Indicator	Ametek/GE
8DJ81LXL2	Tachometer Indicator	Ametek/GE
8DJ81LXM2	Tachometer Indicator	Ametek/GE
8DJ81LXN2	Tachometer Indicator	Ametek/GE
8DJ81LXP2	Tachometer Indicator	Ametek/GE
8DJ81LXT2	Tachometer Indicator	Ametek/GE
8DJ81LXT4	Tachometer Indicator	Ametek/GE
8DJ81LXV2	Tachometer Indicator	Ametek/GE
8DJ81LXW2	Tachometer Indicator	Ametek/GE
8DJ81LXY2	Tachometer Indicator	Ametek/GE
8DJ81LXZ2	Tachometer Indicator	Ametek/GE
8DJ81LYA2	Tachometer Indicator	Ametek/GE
8DJ81LYB2	Tachometer Indicator	Ametek/GE
8DJ81LYC2	Tachometer Indicator	Ametek/GE
8DJ81LYP2	Tachometer Indicator	Ametek/GE
8DJ81LYP4	Tachometer Indicator	Ametek/GE
8DJ81LYT2	Tachometer Indicator	Ametek/GE
8DJ81LYT4	Tachometer Indicator	Ametek/GE
8DJ81LYT4-U	Tachometer Indicator	Ametek/GE
8DJ81LYV2	Tachometer Indicator	Ametek/GE
8DJ81LYV4	Tachometer Indicator	Ametek/GE
8DJ81LYV4-U	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ81LYW2	Tachometer Indicator	Ametek/GE
8DJ81LYX2	Tachometer Indicator	Ametek/GE
8DJ81LYX4	Tachometer Indicator	Ametek/GE
8DJ81LYZ2	Tachometer Indicator	Ametek/GE
8DJ81LZA2	Tachometer Indicator	Ametek/GE
8DJ81LZA4	Tachometer Indicator	Ametek/GE
8DJ81LZB2	Tachometer Indicator	Ametek/GE
8DJ81LZC2	Tachometer Indicator	Ametek/GE
8DJ81LZC4	Tachometer Indicator	Ametek/GE
8DJ81LZE2	Tachometer Indicator	Ametek/GE
8DJ81LZE4	Tachometer Indicator	Ametek/GE
8DJ81LZF2	Tachometer Indicator	Ametek/GE

8DJ81LZF4	Tachometer Indicator	Ametek/GE
8DJ81WAG2	Tachometer Indicator	Ametek/GE
8DJ81WAG4	Tachometer Indicator	Ametek/GE
8DJ81WAG4-U	Tachometer Indicator	Ametek/GE
8DJ81WAL4	Tachometer Indicator	Ametek/GE
8DJ81WAP4	Tachometer Indicator	Ametek/GE
8DJ81WAY4	Tachometer Indicator	Ametek/GE
8DJ81WBA4	Tachometer Indicator	Ametek/GE
8DJ81WBB4	Tachometer Indicator	Ametek/GE
8DJ81WBC4	Tachometer Indicator	Ametek/GE
8DJ81WBD4	Tachometer Indicator	Ametek/GE
8DJ81WBF4-U	Tachometer Indicator	Ametek/GE
8DJ81WBG4	Tachometer Indicator	Ametek/GE
8DJ81WBG4-U	Tachometer Indicator	Ametek/GE
8DJ81WBL4	Tachometer Indicator	Ametek/GE
8DJ81WBM4	Tachometer Indicator	Ametek/GE
8DJ81WBS4	Tachometer Indicator	Ametek/GE
8DJ81WBT4	Tachometer Indicator	Ametek/GE
8DJ81WCF4	Tachometer Indicator	Ametek/GE
8DJ81WCF4-U	Tachometer Indicator	Ametek/GE
8DJ81WCG4	Tachometer Indicator	Ametek/GE
8DJ81WCG4-U	Tachometer Indicator	Ametek/GE
8DJ81WCR4	Tachometer Indicator	Ametek/GE
8DJ81WCS4	Tachometer Indicator	Ametek/GE
8DJ81WCT4	Tachometer Indicator	Ametek/GE
8DJ81WCT4-U	Tachometer Indicator	Ametek/GE
8DJ81WCW4	Tachometer Indicator	Ametek/GE
8DJ81WCW4-U	Tachometer Indicator	Ametek/GE
8DJ81WCX4	Tachometer Indicator	Ametek/GE
8DJ81WDA4-U	Tachometer Indicator	Ametek/GE
8DJ81WDK4	Tachometer Indicator	Ametek/GE
8DJ81WDL4	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ82CAA1	Tachometer Indicator	Ametek/GE
8DJ82CAB1	Tachometer Indicator	Ametek/GE
8DJ82CAS1	Tachometer Indicator	Ametek/GE
8DJ82FAD1	Tachometer Indicator	Ametek/GE
8DJ82FAM	Tachometer Indicator	Ametek/GE
8DJ8LAA4	Tachometer Indicator	Ametek/GE
94798	Tachometer Indicator	Weston
96-384059-1	Tachometer Indicator	Beechcraft
981B-3-06	Tachometer Indicator	Kollsman
981B-4-012	Tachometer Indicator	Kollsman
981B-4-016	Tachometer Indicator	Kollsman
981B-4-018	Tachometer Indicator	Kollsman
981B-4-022	Tachometer Indicator	Kollsman
981B-5-019	Tachometer Indicator	Kollsman
981B-5-020	Tachometer Indicator	Kollsman
981B-8-023	Tachometer Indicator	Kollsman

981BX-8-023	Tachometer Indicator	Kollsman
985G-02	Tach Generator	Kollsman
985G-021	Tach Generator	Kollsman
A-70BP-1	Tachometer Indicator	Kollsman
AG34	Tach Generator	Donallco
AG35	Tach Generator	Task
AL/0718-KTD/CP/1	Percent RPM Indicator	Smith Industries
AN05-5B-2	Tachometer Indicator	Weston
AN5544-3	Tach Generator	Jack & Heintz
AW1842BA01	Torque Indicator	AMETEK
AW1842BA02	Torque Indicator	AMETEK
AW1842BA03	Torque Indicator	AMETEK
AW1842BA04	Torque Indicator	AMETEK
AW1842BA05	Torque Indicator	AMETEK
AW1842BA06	Torque Indicator	AMETEK
B0704-10004	Overspeed Limit Sensor	Lear Siegler
B0704-10006	Overspeed Limit Sensor	Lear Siegler
B0704-10010	Overspeed Limit Sensor	Lear Siegler
B0704-10011	Overspeed Limit Sensor	Lear Siegler
B0704-10012	Overspeed Limit Sensor	Lear Siegler
B0704-10016	Overspeed Limit Sensor	Lear Siegler
B0704-10042	Overspeed Limit Sensor	Lear Siegler
B0709-10001	Over Speed Limit Sensor	Lear Siegler
B0709-10002	Over Speed Limit Sensor	Lear Siegler
B365	Tachometer Indicator	AID
B4271000001	Speed Command Module	Kollsman
BH185L-37	Fan Speed Indicator	Howell
BH185L-37C	Tachometer Indicator	Howell

Primary Part Number	Nomenclature	Manufacture
C2-24	Tachometer Indicator	Ametek/GE
C-26105-3	Speed Control Indicator	Safe Flight
C-26105-4	Speed Control Indicator	Safe Flight
C668017-	Tachometer Indicator	Instruments Inc.
C-9	Chronometric Tachometer	Jaeger
C-9A	Chronometric Tachometer	Jaeger
CM-9	Tach Generator	Ametek/GE
CO751110040	Tachometer Indicator	Kollsman
CO751110041	Tachometer Indicator	Kollsman
DG-OC11OC	Turbine Speed Indicator	Ametek/GE
DG-OC11OF	Turbine Speed Indicator	Ametek/GE
DJ-89	Tachometer Indicator	Ametek/GE
DO-35	Tachometer Indicator	Ametek/GE
E-12	Tachometer Indicator	Weston
EM8000	Tach Generator	Electromech Technol
EM8001	Tach Generator	Electromech Technol
EM8002	Tach Generator	Electromech Technol
ES495-2	Tach Generator	Emerson Electric Co
ES495-2A01	Tach Generator	Emerson Electric Co
ES495-2B01	Tach Generator	Emerson Electric Co

F15597 10 003	Electric Tachometer Indicator	Kollsman
FDE 41-26-1	Tach Generator	Diehl
GEU7A	Tach Generator	Globe
GTG-3-025	Tach Generator	Small Motors, Inc
H300	Fan Speed Indicator	Howell
H330C	Tachometer Indicator	Howell
H331	Fan Speed Indicator	Howell
H331C	Tachometer Indicator	Howell
H60-000	Tach Generator	LSI
H60-050	Tach Generator	LSI
H60-090	Tach Generator	LSI
H60-103	Tach Generator	Jack & Heintz
IU052	Tachometer Indicator	Electric Auto-Lite Co
KTD-0601	Tachometer Indicator	Smith Industries
KTD-0602	Tachometer Indicator	Smith Industries
KTD-0603	Tachometer Indicator	Smith Industries
KTD-0604	Tachometer Indicator	Smith Industries
KTD-0606	Tachometer Indicator	Smith Industries
KTD-0607	Tachometer Indicator	Smith Industries
KTD-0609	Tachometer Indicator	Smith Industries
KTD-0610	Tachometer Indicator	Smith Industries
KTD-0611	Tachometer Indicator	Smith Industries
KTD-0613	Tachometer Indicator	Smith Industries
KTD-0614	Tachometer Indicator	Smith Industries

Primary Part Number	Nomenclature	Manufacture
KTD-0616	Tachometer Indicator	Smith Industries
KTD-0617	Tachometer Indicator	Smith Industries
KTD-0618	Tachometer Indicator	Smith Industries
KTD-0619	Tachometer Indicator	Smith Industries
KTD-0620	Tachometer Indicator	Smith Industries
KTD-0621	Tachometer Indicator	Smith Industries
KTD-0701K	Percent RPM Indicator	Smith Industries
KTD-0701L	Percent RPM Indicator	Smith Industries
KTD-0701V	Percent RPM Indicator	Smith Industries
KTD-0701W	Percent RPM Indicator	Smith Industries
KTD-0704L	Percent RPM Indicator	Smith Industries
KTD-0704W	Percent RPM Indicator	Smith Industries
MG-18	Tach Generator	Erco
MS28000-1	Tachometer Indicator	Norden Ketay
MS28054-2	Tach Generator	Jack & Heintz
NB-80-A2-1101	RPM Indicator	Island
PW/0706-KTD-CP-1	Percent RPM Indicator	Smith Industries
PW/0707-KTD/CP-1	Percent RPM Indicator	Smith Industries
PW/0708-KTD-CP-1	Percent RPM Indicator	Smith Industries
PW/0711-KTD/CP/1	Percent RPM Indicator	Smith Industries
PW/0720-KTD/CP/1	Percent RPM Indicator	Smith Industries
PW/0721-KTD/CP/1	Percent RPM Indicator	Smith Industries
PW/0722-KTD/CP/1	Percent RPM Indicator	Smith Industries
PW/0723-KTD-CP/1	Percent RPM Indicator	Smith Industries

PW/0725-KTD/CP/1	Percent RPM Indicator	Smith Industries
PW/0725-KTD/CP/2	Tachometer Indicator	Smith Industries
PW/0726-KTD/MS/1	Percent RPM Indicator	Smith Industries
PW/0729-KTD/1	Percent RPM Indicator	Smith Industries
RCA40-01	Tachometer Indicator	R C Allen
RCA40-02	Tachometer Indicator	R C Allen
RCA40-03	Tachometer Indicator	R C Allen
RCA40-04	Tachometer Indicator	R C Allen
RCA40-05	Tachometer Indicator	R C Allen
RCA40-06	Tachometer Indicator	R C Allen
RCA40-07	Tachometer Indicator	R C Allen
RCA40-08	Tachometer Indicator	R C Allen
RCA40-09	Tachometer Indicator	R C Allen
RCA40A-10	Tachometer Indicator	R C Allen
RCA40A-11	Tachometer Indicator	R C Allen
RCA40B-01	Tachometer Indicator	R C Allen
RCA40B-02	Tachometer Indicator	R C Allen
RCA40B-03	Tachometer Indicator	R C Allen
RCA40B-04	Tachometer Indicator	R C Allen
RCA40B-05	Tachometer Indicator	R C Allen

Primary Part Number	Nomenclature	Manufacture
RCA40B-06	Tachometer Indicator	R C Allen
RCA40B-07	Tachometer Indicator	R C Allen
RCA40B-08	Tachometer Indicator	R C Allen
RCA40B-09	Tachometer Indicator	R C Allen
RCA40B-10	Tachometer Indicator	R C Allen
RCA40B-11	Tachometer Indicator	R C Allen
RCA40B-12	Tachometer Indicator	R C Allen
RCA41-01	Tachometer Indicator	R C Allen
RCA41-02	Tachometer Indicator	R C Allen
RCA41-03	Tachometer Indicator	R C Allen
RCA41-04	Tachometer Indicator	R C Allen
RCA41-05	Tachometer Indicator	R C Allen
RCA41-06	Tachometer Indicator	R C Allen
RCA41-07	Tachometer Indicator	R C Allen
RCA41-09	Tachometer Indicator	R C Allen
RCA41-09A	Tachometer Indicator	R C Allen
RCA41-10	Tachometer Indicator	R C Allen
RCA41-11	Tachometer Indicator	R C Allen
RCA41-11A	Tachometer Indicator	R C Allen
RCA41-12	Tachometer Indicator	R C Allen
RCA41A-15	Tachometer Indicator	R C Allen
RCA41A-16	Tachometer Indicator	R C ALLEN
RCA41AB-	Tachometer Indicator	R C Allen
RCA41B-01	Tachometer Indicator	R C Allen
RCA41B-02	Tachometer Indicator	R C Allen
RCA41B-03	Tachometer Indicator	R C Allen
RCA41B-04	Tachometer Indicator	R C Allen
RCA41B-05	Tachometer Indicator	R C Allen

RCA42-01	Tachometer Indicator	R C Allen
RCA42-02	Tachometer Indicator	R C Allen
RCA42-03	Tachometer Indicator	R C Allen
RCA42-04	Tachometer Indicator	R C Allen
RCA42-05	Tachometer Indicator	R C Allen
RCA42-06	Tachometer Indicator	R C Allen
RCA42-07	Tachometer Indicator	R C Allen
RCA42-08	Tachometer Indicator	R C Allen
RCM-60-AC-1	Rate of Climb Indicator	Aerosonic
S128-5-139	RPM Indicator	Island
S128-5-150	RPM Indicator	Island
SEDL-OC329A	Tachometer Indicator	Ametek/GE
SEL-OC29DA	Tachometer Indicator	Ametek/GE
SEL-OC29DF	RPM Indicator	Ametek/GE
SEL-OC29F	Gas Producer Tachometer Ind	Ametek/GE
SETL-0C329A	Tachometer Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
SETL-OC329A	Tachometer Indicator	Ametek/GE
SL1010 ( )	Tachometer Indicator	Superior Labs
SP-100B	Synchrophaser	Cessna
SP-105A	Synchrophaser	Cessna
SP-105B	Synchrophaser	Cessna
SP-105B-1	Synchrophaser	Cessna
SP5503-0101-CES	Tachometer Indicator	Cessna
SP5503-0102-CES	Tachometer Indicator	Cessna
SP5503-0103-CES	Tachometer Indicator	Cessna
SP5503-0104-CES	Tachometer Indicator	Cessna
TG255-001	Tach Generator	Aircraft Appliances
TG255-002	Tach Generator	Aircraft Appliances
TG255-003	Tach Generator	Aircraft Appliances
TG255-004	Tach Generator	Aircraft Appliances
TG255-005	Tach Generator	Aircraft Appliances
TG255-006	Tach Generator	Aircraft Appliances
TG255-007	Tach Generator	Aircraft Appliances
TG255-008	Tach Generator	Aircraft Appliances
VSDL-OC410A	Digital Fan Speed Indicator	Ametek/GE
VSDL-OC410A-1	Digital Fan Speed Indicator	Ametek/GE
VSDL-OC410R	Digital Fan Speed Indicator	Ametek/GE
VSDL-OC410S	Digital Fan Speed Indicator	Ametek/GE
VSDL-OC410T	Digital Fan Speed Indicator	Ametek/GE
WL651RAA3	N2 Percent RPM Indicator	Smith Industries
WL651RSA1	N2 Percent RPM Indicator	Smith Industries
WL651RSA4	N2 Percent RPM Indicator	Smith Industries
WL651RSA5	N2 Percent RPM Indicator	Smith Industries
WL651RSA6	N2 Percent RPM Indicator	Smith Industries
WL702RSA1	N1 Percent RPM Indicator	Smith Industries
WL719RSA1	N1 Percent RPM Indicator	Smith Industries
X-70BP	Tachometer Indicator	Chicago Flex Shaft
X-70BP-1	Tachometer Indicator	Chicago Flex Shaft

X-70BP-2	Tachometer Indicator	Chicago Flex Shaft
01-003-1	EGT Indicator	Alcor
01-004-1	EGT Indicator	Alcor
0203-005	EGT-OAT Indicator	B & D Instruments, In
0203-006	EGT-OAT Indicator	B & D Instruments, In
0203-008	EGT Indicator	B & D Instruments, In
0205-003	EGT Indicator	B & D Instruments, In
08DB19	Head Temperature Indicator	Farem
100-384058-1	Oil Temp/Press. Indicator	Beechcraft
100-384058-3	Oil Temp/Press. Indicator	Beechcraft
100-384058-5	Oil Temp/Press. Indicator	Beechcraft
100-384058-7	Oil Temp/Press. Indicator	Beechcraft

Primary Part Number	Nomenclature	Manufacture
100-384058-9	Oil Temp/Press. Indicator	Beechcraft
102-00000	Temp Probe	Norwich
102114	Temperature Indicator	Weston
102116	Temperature Indicator	Weston
102130	Temperature Indicator	Weston
102134	Temperature Indicator	Weston
102138	Temperature Indicator	Weston
102316	Temperature Indicator	Weston
102319	Temperature Indicator	Weston
102330	Temperature Indicator	Weston
102576	Temperature Indicator	Astronautics
10283-A	Temperature Indicator	Electric Auto-Lite Co
103106	Temperature Indicator	Weston
103107	Temperature Indicator	Weston
104-384009	Temperature Indicator	Beechcraft
10498-A	Temperature Indicator	Electric Auto-Lite Co
10499-A	Temperature Indicator	Electric Auto-Lite Co
10-60757-28	Indicator, Temperature	Rogerson Kratos
10-61890-1	EGT Indicator	Ametek
10-61890-4	EGT Indicator	Ametek
10-61890-5	EGT Indicator	Ametek
10-61890-6	EGT Indicator	Ametek
10-61890-9	EGT Indicator	Ametek
106498	Temperature Indicator	Weston
106499	Temperature Indicator	Weston
10738-A	Temperature Indicator	Electric Auto-Lite Co
108261	Temperature Indicator	Weston
110077	Temperature Indicator	Weston
110430	Temperature Indicator	Weston
110507	Temperature Indicator	Weston
110612	Temperature Indicator	Weston
114.005	Oil Temperature Indicator	Kratos
114.022	Oil Temperature Indicator	Kratos
114.058	Fuel Temperature Indicator	Kratos
114.059	Duct Temperature	Kratos
114657	Temperature Indicator	Weston

1147L2	Temperature Indicator	Lewis
115.024	Cabin Temp. Indicator	Kratos
115-384012-3	Temperature Indicator	Voltron
115703	Temperature Indicator	Weston
115704	Temperature Indicator	Weston
11600-0001	Temperature Indicator	Astronautics
117244	Temperature Indicator	Weston
117662	Temperature Indicator	Weston

Primary Part Number	Nomenclature	Manufacture
117663	Temperature Indicator	Weston
117B2	Temperature Indicator	Lewis
120901	Temperature Indicator	Weston
122434	Temperature Indicator	Weston
124.013	Temp and Press Indicator	Kratos
124.041	Temp and Press Indicator	Kratos
124.041-1	Temp and Press Indicator	Kratos
124.041-3	Temp and Press Indicator	Kratos
124.043	Indicator	Kratos
124.045	Temp and Press Indicator	Kratos
124.067-2	Temperature Indicator	Kratos
124.1013	Temp and Press Indicator	Kratos
124.115	Temp and Press Indicator	Kratos
124.115-3	Temp and Press Indicator	Kratos
124.115-5	Temp and Press Indicator	Kratos
124.146	Temperature Indicator	Kratos
124.183	Outside Air Temp Ind	Kratos
124.251	Oil Temperature Indicator	Kratos
124.273	Hydraulic Temp. Ind.	Kratos
124.514-1	EGT Indicator	Kratos
124.514-10	EGT Indicator	Kratos
124.514-12	EGT Indicator	Kratos
124.514-2	EGT Indicator	Kratos
124.514-6	EGT Indicator	Kratos
124.546	Temp and Press Indicator	Kratos
124.550	Temp and Press Indicator	Kratos
124.774	Temp and Press Indicator	Kratos
124.838	Indicator, Temperature	Rogerson Kratos
124.935A	Temp and Press Indicator	Kratos
124.972A	Temp and Press Indicator	Kratos
124-014	Temperature/Pressure Indicator	Kratos
124-014-111	Temperature/Pressure Indicator	Kratos
124-014-121	Temperature/Pressure Indicator	Kratos
124-014-13	Temperature/Pressure Indicator	Kratos
124-014-15	Temperature/Pressure Indicator	Kratos
124-014-17	Temperature/Pressure Indicator	Kratos
124-014-19	Temperature/Pressure Indicator	Kratos
124-014-23	Temperature/Pressure Indicator	Kratos
124-014-25	Temperature/Pressure Indicator	Kratos
12410	Thermoswitch Unit	Fenwal

12411	Thermoswitch Unit	Fenwal
124-115-1	Temp and Press Indicator	Kratos
124-444	Turbine Gas Temp Indicator	Kratos
124-444-100	TOT Indicator	Kratos

Primary Part Number	Nomenclature	Manufacture
124-549	Temp and Press Indicator	Kratos
124B101	Temperature Indicator	Lewis
124B3	Temperature Indicator	Lewis
124B34E	Temperature Indicator	Lewis
124D10	Temperature Indicator	Lewis
124D12	Temperature Indicator	Lewis
125	Temperature Indicator	Alcor
125-380029-11	Cabin Temp. Indicator	Beechcraft
126	Temperature Indicator	Alcor
126237	Temperature Indicator	Weston
128848	Temperature Indicator	Weston
128850	Temperature Indicator	Weston
129991	Temperature Indicator	Weston
130948	Temperature Indicator	Weston
131350-3	Temperature Indicator	Airesearch
132702	Temperature Indicator	Weston
132706	Temperature Indicator	Weston
132875	Temperature Indicator	Weston
132876	Temperature Indicator	Weston
134.014-19	Temp and Press Indicator	Kratos
135	EGT Indicator	Alcor
135640	Temperature Indicator	Weston
135641	Temperature Indicator	Weston
135643	Temperature Indicator	Weston
136	EGT Indicator	Alcor
137652	Temperature Indicator	Weston
137660	Temperature Indicator	Weston
137661	Temperature Indicator	Weston
138325	Temperature Indicator	Weston
143224	Temperature Indicator	Weston
143422	Temperature Indicator	Weston
145	EGT Indicator	Alcor
146	EGT Indicator	Alcor
147B10	Temperature Indicator	Lewis
147B13	Temperature Indicator	Lewis
147B13A	Temperature Indicator	Lewis
147B15A	Temperature Indicator	Lewis
147B30	Temperature Indicator	Lewis
147B30A	Temperature Indicator	Lewis
147B31	Temperature Indicator	Lewis
147B31A	Temperature Indicator	Lewis
147B31A3	Temperature Indicator	Lewis
147B31B	Temperature Indicator	Lewis
147B31C	Temperature Indicator	Lewis

Primary Part Number	Nomenclature	Manufacture
147B32	Temperature Indicator	Lewis
147B32A	Temperature Indicator	Lewis
147B7	Temperature Indicator	Lewis
147B7A	Temperature Indicator	Lewis
147B8	Temperature Indicator	Lewis
147B9	Temperature Indicator	Lewis
147B9A	Temperature Indicator	Lewis
147L2A	Temperature Indicator	Lewis
147L6	Temperature Indicator	Lewis
147LC10	Oil Temperature Indicator	Horizon Aerospace
149270-01-01	Temperature/EPR Indicator	Lear Siegler
149270-02-01	Temperature/EPR Indicator	Lear Siegler
149B30	Temperature Indicator	Lewis
149B5	Temperature Indicator	Lewis
149B6	Temperature Indicator	Lewis
149E27	Temperature Indicator	Lewis
149E28	Temperature Indicator	Lewis
149E30	Temperature Indicator	Lewis
149E31B	EGT Indicator	Lewis
149E5	Temperature Indicator	Lewis
152623	Temperature Indicator	Weston
152B2	Temperature Indicator	Lewis
152B2A	Temperature Indicator	Lewis
152B3	Temperature Indicator	Lewis
152B4	Temperature Indicator	Lewis
152B5	Temperature Indicator	Lewis
152B8	Temperature Indicator	Lewis
152BL2	Temperature Indicator	Weston
152BL702	Temperature Indicator	Lewis
152BL702A	Temperature Indicator	Lewis
152BL702C	Temperature Indicator	Lewis
152BL702D	Temperature Indicator	Lewis
152BL703	Temperature Indicator	Lewis
152BL704	Temperature Indicator	Lewis
152BL706	Temperature Indicator	Lewis
152BL708	Temperature Indicator	Lewis
152BL708A	Temperature Indicator	Lewis
152BL708B	Temperature Indicator	Lewis
152BL708H	Temperature Indicator	Lewis
152BL709	Temperature Indicator	Lewis
152BL719	Temperature Indicator	Lewis
152BL722	Temperature Indicator	Lewis
152BL801	Temperature Indicator	Lewis
152BL801A	Temperature Indicator	Lewis

Primary Part Number	Nomenclature	Manufacture
152BL801B	Temperature Indicator	Lewis
152BL801C	Temperature Indicator	Lewis

152BL801D	Temperature Indicator	Lewis
152BL801E	Temperature Indicator	Lewis
152BL802A	Temperature Indicator	Lewis
152BL802C	Temperature Indicator	Lewis
152BL803	Temperature Indicator	Lewis
152BL803A	Temperature Indicator	Lewis
152BL803B	Temperature Indicator	Lewis
152C4	Thermometer	Lewis
152C40A	Thermometer	Lewis
152C42	Temperature Indicator	Lewis
152C4A	Thermometer	Lewis
152L6	Temperature Indicator	Lewis
152LC208H	Temperature Indicator	Lewis
157405-01-01	Temperature/EPR Indicator	Lear Siegler
157770-01-01	Temperature/EPR Indicator	Lear Siegler
157800	Temperature Indicator	Weston
157801	Temperature Indicator	Weston
159871	EGT Indicator	Weston
162B2	Temperature Indicator	Lewis
162B203F	Indicator	Lewis
162B2D	Temperature Indicator	Lewis
162B3	Temperature Indicator	Lewis
162B3A	Temperature Indicator	Lewis
162B4	Temperature Indicator	Lewis
162BCL10	Temperature Indicator	Lewis
162BCL10F	Temperature Indicator	Lewis
162BCL11	Temperature Indicator	Lewis
162BCL12	Temperature Indicator	Lewis
162BCL15	Temperature Indicator	Lewis
162BCL16	Temperature Indicator	Lewis
162BCL17	Temperature Indicator	Lewis
162BCL17W	Temperature Indicator	Lewis
162BL501	Temperature Indicator	Ultra Electronics
162BL502	Temperature Indicator	Ultra Electronics
162BL503	Temperature Indicator	Ultra Electronics
162BL504	Temperature Indicator	Ultra Electronics
162BL505	Temperature Indicator	Ultra Electronics
162BL507A	OAT/EGT Indicator	Lewis
162BL602	Temperature Indicator	Flightline Systems
162BL701	Temperature Indicator	Flightline Systems
162BL701A	Temperature Indicator	Flightline Systems
162BL702	Temperature Indicator	Flightline Systems
Primary Part Number	**Nomenclature**	**Manufacture**
162BL703	Temperature Indicator	flightline Systems
162BL704	Temperature Indicator	Flightline Systems
162BL704A	Temperature Indicator	Flightline Systems
162BL704C	Temperature Indicator	Flightline Systems
162BL704D	Temperature Indicator	Flightline Systems
162BL704F	Temperature Indicator	Flightline Systems

162BL704H	Temperature Indicator	Flightline Systems
162BL704K	Temperature Indicator	Flightline Systems
162BL704L	Temperature Indicator	Flightline Systems
162BL704N	Temperature Indicator	Flightline Systems
162BL801	Temperature Indicator	Flightline Systems
162BL802	Temperature Indicator	Flightline Systems
162BL802A	Temperature Indicator	Flightline Systems
162BL803	Temperature Indicator	Flightline Systems
162BL803A	Temperature Indicator	Flightline Systems
162BL804A	Temperature Indicator	Ultra Electronics
162BL901	Temperature Indicator	Ultra Electronics
162BL902	Temperature Indicator	Ultra Electronics
162BL903	Temperature Indicator	Ultra Electronics
162BL906	Temperature Indicator	Ultra Electronics
162BL907	Temperature Indicator	Ultra Electronics
162BL908	Indicator	Horizon Aerospace
162BL908A	Indicator	Horizon Aerospace
162C7A	Thermometer	Lewis Engineering
162CPT605	Temp and Press Indicator	Lewis
162LC601A	OAT Indicator	Lewis
162LC607	OAT Indicator	Lewis
162LC612	OAT Indicator	Lewis
163B109	Fuel Temperature Indicator	Lewis
163B137	Temperature Indicator	Lewis
163B-18	Temperature Indicator	Lewis
163B2	Temperature Indicator	Lewis
163B2D	Temperature Indicator	Lewis
163B4	Temperature Indicator	Lewis
163BL501	Temperature Indicator	Lewis
163BL501C	Temperature Indicator	Lewis
163BL506	Temperature Indicator	Lewis
163BL507	Temperature Indicator	Lewis
163BL507B	Temperature Indicator	Lewis
163BL507H	Temperature Indicator	Lewis
163BL508	Temperature Indicator	Lewis
163BL511	Temperature Indicator	Lewis
163BL511A	Temperature Indicator	Lewis
165ES100-4	Temperature Indicator	Lewis

Primary Part Number	Nomenclature	Manufacture
169A-910-2	Oil Temperature Indicator	Sigma Tek
169A-910-2L	Oil Temperature Indicator	Sigma Tek
169AB-910-25	CHT Indicator	Sigma Tek
169AB-910-26	CARB Temp. Indicator	Sigma Tek
169AC-910-11L	Oil Temperature Indicator	Sigma Tek
169AC-910-11L-1	Oil Temperature Indicator	Sigma Tek
169AC-910-1L	CHT Indicator	Sigma Tek
169AC-910-1L-1	CHT Indicator	Sigma Tek
169AE-910-39L	Oil Temperature Indicator	Sigma Tek
169AE-910-41L	CARB Temp. Indicator	Sigma Tek

169AE-910-43L	CHT Indicator	Sigma Tek
169AE-910-44L	CARB Temp. Indicator	Sigma Tek
169AJ-910-1	CHT Indicator	Sigma Tek
169AJ-910-2	Oil Temperature Indicator	Sigma Tek
169AM-910-1	Oil Temperature Indicator	Sigma Tek
169AM-910-2	CHT Indicator	Sigma Tek
169AN-910-3	CHT Indicator	Sigma Tek
169AN-910-4	CHT Indicator	Sigma Tek
169AR-910-11	Oil Temperature Indicator	Sigma Tek
169AR-910-12	CHT Indicator	Sigma Tek
169B-910-5	Oil Temperature Indicator	Sigma Tek
169B-910-5L	Oil Temperature Indicator	Sigma Tek
169B-910-7	CHT Indicator	Sigma Tek
169B-910-7L	CHT Indicator	Sigma Tek
169B-910-8	CARB Temp. Indicator	Sigma Tek
169B-910-8L	CARB Temp. Indicator	Sigma Tek
169C-910-11	Oil Temperature Indicator	Sigma Tek
169C-910-11L	Oil Temperature Indicator	Sigma Tek
169C-910-12	CHT Indicator	Sigma Tek
169C-910-12L	CHT Indicator	Sigma Tek
169D-910-11L	Oil Temperature Indicator	Sigma Tek
169D-910-12	CHT Indicator	Sigma Tek
169D-910-12L	CHT Indicator	Sigma Tek
169E-910-11	Oil Temperature Indicator	Sigma Tek
169E-910-12	CHT Indicator	Sigma Tek
169P-910-5L	Oil Temperature Indicator	Sigma Tek
169P-910-5L-1	Oil Temperature Indicator	Sigma Tek
169Q-910-11	Oil Temperature Indicator	Sigma Tek
169Q-910-12	CHT Indicator	Sigma Tek
169S-910-1	CHT Indicator	Sigma Tek
169S-910-2	Oil Temperature Indicator	Sigma Tek
169V-910-29	Oil Temperature Indicator	Sigma Tek
169V-910-29-1	Oil Temperature Indicator	Sigma Tek
176391	Temperature Indicator	Weston

Primary Part Number	Nomenclature	Manufacture
17AT-1A	Temperature Indicator	Lewis
17AT-2	Temperature Indicator	Lewis
17AT3D	Temperature Indicator	Lewis
17AT4B	Temperature Indicator	Lewis
17AT4D	Temperature Indicator	Lewis
17AT-5	Temperature Indicator	Lewis
17B17	Temperature Indicator	Lewis
17B25	Temperature Indicator	Lewis
17B31	Temperature Indicator	Lewis
17B502A	Temperature Indicator	Lewis
17B506	Temperature Indicator	Lewis
17B531	Temperature Indicator	Lewis
182-013-A100	Temperature Indicator	Avien
182-029-12	Temperature Indicator	Avien

182-029-16	Temperature Indicator	Avien
182-029C	Temperature Indicator	Avien
182-032-2	Indicator	Avien
182-032A	Indicator	Avien
1822-362LW	Battery Temp. Indicator	Ametek/GE
1822-397LW	Battery Temp. Indicator	Ametek/GE
1825	Oil Temp/Press. Indicator	Weston
1825-103LW	CABIN TEMPERATURE INDICATOR	AMETEK
1834-16LW	Generator Oil Temp. Indicator	Ametek/GE
184-012H	Temperature Indicator	Avien
200-1	Temperature Indicator	Edison
200-2	Temperature Indicator	Edison
201-1	Temperature Indicator	Edison
201-1A5A	Temperature Indicator	Edison
201-2	Temperature Indicator	Edison
202-070-241-1	Indicator	Voltron
202-1	Temperature Indicator	Edison
202-1B3B3A	Temperature Indicator	Edison
202-2	Temperature Indicator	Edison
202-3	Temperature Indicator	Edison
202A-1B	EGT Indicator	Alcor
202A-7AY	EGT Indicator	Alcor
202B-7AY	EGT Indicator	Alcor
203-022-005	Engine Oil Temp/Pressure	Gull
203-022-008	Trans. Oil Temp/Pressure	Gull
203-022-014	Transmission Oil Temperature	Gull
203-1	Temperature Indicator	Edison
203-2	Temperature Indicator	Edison
203-3	Temperature Indicator	Edison
204-1	Temperature Indicator	Edison

Primary Part Number	Nomenclature	Manufacture
204-1A	EGT Indicator	Alcor
204-2	Temperature Indicator	Edison
204-2F1A	CHT Indicator	Edison
204-60926-1	Indicator	Horizon Aerospace
204-60929-1	N2 indicator	AMETEK
204-60929-2	N2 Indicator	AMETEK
204-60930-1	EGT Indicator	AMETEK
204-60930-2	EGT Indicator	AMETEK
204-906-002	ITT Indicator	Gull
204A-1	Temperature Indicator	Edison
204A-2	Temperature Indicator	Edison
205-1	Temperature Indicator	Edison
205-1A	EGT Indicator	Alcor
206-075-680-101	TOT Indicator	Bell
206-075-680-103	TOT Indicator	Bell
206-075-680-105	TOT Indicator	Bell
206-075-680-107	TOT Indicator	Bell
206-1A	EGT Indicator	Alcor

206-375-005-101	TOT Indicator	Bell
206-375-006-101	TOT Indicator	Bell
206-375-007-101	TOT Indicator	Bell
206-375-009-101	TOT Indicator	Bell
208-013-002	Turbine Inlet Temperature	Gull
208-013-003	Turbine Inlet Temperature	Gull
208-013-004	Turbine Inlet Temperature	Gull
208-013-005	Turbine Inlet Temperature	Gull
208-905-001	ITT Indicator	Gull
208-906-001	ITT Indicator	Gull
208-906M01	ITT Indicator	Gull
208-906R01	ITT Indicator	Gull
208-906T01	ITT Indicator	Gull
210-1A	EGT Indicator	Alcor
212-070-116-3	Temperature and Pressure Ind	Kollsman
215-1	Temperature Indicator	Edison
215-1S2S2TT2AX	Temperature Indicator	Edison
215-2	Temperature Indicator	Edison
215-3	Temperature Indicator	Edison
216-914-002	Oil Temp/Press. Indicator.	Gull
22-209	CARB Temp. Indicator	AID
22-290	Temperature Indicator	Electric Auto-Lite Co
22-290- ( )	Temperature Indicator	Weston
22-292	Temperature Indicator	Electric Auto-Lite Co
22-292- ( )	Temperature Indicator	Weston
22-293	Temperature Indicator	Electric Auto-Lite Co

Primary Part Number	Nomenclature	Manufacture
22-293- ( )	Temperature Indicator	Weston
22-294	Temperature Indicator	Electric Auto-Lite Co
22-294- ( )	Temperature Indicator	Weston
22-295	Temperature Indicator	Electric Auto-Lite Co
22-295- ( )	Temperature Indicator	Weston
22-296	Temperature Indicator	Electric Auto-Lite Co
22-296- ( )	Temperature Indicator	Weston
22-297	Temperature Indicator	Electric Auto-Lite Co
22-297- ( )	Temperature Indicator	Weston
22-298	Temperature Indicator	Electric Auto-Lite Co
22-298- ( )	Temperature Indicator	Weston
224-901-002	ITT Indicator	Gull
224-908-001	ITT Indicator	Gull
224-911/006	ITT Indicator	Gull
224-911-002B	ITT Indicator	Gull
224-911-006	ITT Indicator	Gull
22-995	Temperature Indicator	Electric Auto-Lite Co
22-995- ( )	Temperature Indicator	Weston
231-30-10	Windshield Temperature Control	Pacific Electro Dynam
253638	Temperature Indicator	Weston
253682	Oil Temperature Indicator	Weston
253686	Temperature Indicator	Weston

25900-A1A-1-1A1	CHT Indicator	Bendix
260637	Temperature Indicator	Weston
260638	Fuel Temperature Indicator	Weston
261-914-002	Oil Temp/Press. Indicator	Gull
27-19145-3	Cabin Air Temp. Indicator	Hickok
27-19145-5	Cabin Air Temp. Indicator	Hickok
27-19160-1	Oil Temp/Press. Indicator	Hickok
27-19178-1	Oil Temp/Press. Indicator	Hickok
27231317	Temperature Controller	Sundstrand
27231317-01	Temperature Controller	Sundstrand
2724A	Temperature/EPR Indicator	Lear Siegler
2724A1	Temperature/EPR Indicator	Lear Siegler
2724B	Temperature/EPR Indicator	Lear Siegler
2724C	Temperature/EPR Indicator	Lear Siegler
27904-C2B-6-B1	Temperature Indicator	Bendix
29-209	CARB Temp. Indicator	R C Allen
29745	Oil Temperature Rise Indicator	Sundstrand
29C-208	CARB Temp. Indicator	R C Allen
29C-208-1	CARB Temp. Indicator	R C Allen
29C-208-2	CARB Temp. Indicator	R C Allen
29C-208-3	CARB Temp. Indicator	R C Allen
29C-208-4	CARB Temp. Indicator	R C Allen

Primary Part Number	Nomenclature	Manufacture
29C-208-5	CARB Temp. Indicator	R C Allen
29C-208-6	CARB Temp. Indicator	R C Allen
2A3-1	Temperature Indicator	Westach
305520-10-1	EGT Control Assy.	Garrett
305520-1-1	EGT Control Assy.	Garrett
305520-11-1	EGT Control Assy.	Garrett
305520-12-1	EGT Control Assy.	Garrett
305520-13-1	EGT Control Assy.	Garrett
305520-14-1	EGT Control Assy.	Garrett
305520-16-1	EGT Control Assy.	Garrett
305520-17-1	EGT Control Assy.	Garrett
305520-18-1	EGT Control Assy.	Garrett
305520-19-1	EGT Control Assy.	Garrett
305520-20-1	EGT Control Assy.	Garrett
305520-2-1	EGT Control Assy.	Garrett
305520-21-1	EGT Control Assy.	Garrett
305520-22-1	EGT Control Assy.	Garrett
305520-23-1	EGT Control Assy.	Garrett
305520-24-1	EGT Control Assy.	Garrett
305520-25-1	EGT Control Assy.	Garrett
305520-26-1	EGT Control Assy.	Garrett
305520-27-1	EGT Control Assy.	Garrett
305520-28-1	EGT Control Assy.	Garrett
305520-29-1	EGT Control Assy.	Garrett
305520-30-1	EGT Control Assy.	Garrett
305520-3-1	EGT Control Assy.	Garrett

305520-31-1	EGT Control Assy.	Garrett
305520-32-1	EGT Control Assy.	Garrett
305520-33-1	EGT Control Assy.	Garrett
305520-34-1	EGT Control Assy.	Garrett
305520-35-1	EGT Control Assy.	Garrett
305520-36-1	EGT Control Assy.	Garrett
305520-37-1	EGT Control Assy.	Garrett
305520-38-1	EGT Control Assy.	Garrett
305520-39-1	EGT Control Assy.	Garrett
305520-40-1	EGT Control Assy.	Garrett
305520-4-1	EGT Control Assy.	Garrett
305520-41-1	EGT Control Assy.	Garrett
305520-42-1	EGT Control Assy.	Garrett
305520-43-1	EGT Control Assy.	Garrett
305520-5-1	EGT Control Assy.	Garrett
305520-6-1	EGT Control Assy.	Garrett
305520-7-1	EGT Control Assy.	Garrett
305520-8-1	EGT Control Assy.	Garrett

Primary Part Number	Nomenclature	Manufacture
305520-9-1	EGT Control Assy.	Garrett
3057-165-2	Temperature Indicator	LABEM
3057-165-3	Temperature Indicator	LABEM
3057-165-4	Temperature Indicator	LABEM
309-901-001	EGT Indicator	Gull
31657-001	Oil Temperature Control Box	Kollsman
322	Temperature Indicator	Edison
33204	Temperature Indicator	Edison
33205	Temperature Indicator	Edison
33349	Temperature Indicator	Edison
33350	Temperature Indicator	Edison
33724	Temperature Indicator	Edison
33980	Temperature Indicator	Edison
34970	Temperature Indicator	Edison
35	EGT Indicator	Alcor
35350	Temperature Indicator	Edison
3571250-8001	Temperature Indicator	Bendix
3581480-1001	ITT Indicator	Allied Signal
36	EGT Indicator	Alcor
3809310-3	Gas Temperature Indicator	Bendix
40-625-6	Wheel Speed/Spoiler Transducer	Crane
41501-C1B-1-A1	Temperature Indicator	Bendix
4452-2B-A2	Temp Transmitter	Eclipse Pioneer
4453-2B-A2	Temp Transmitter	Eclipse Pioneer
4454-2B-A2	Temp Transmitter	Eclipse Pioneer
4456-5C-A5	Temp Transmitter	Eclipse Pioneer
4457-2B-A2	Temp Transmitter	Eclipse Pioneer
461-424	Temperature Indicator	Hickok
46150	EGT Indicator	Alcor
465-45812	EGT Indicator	Alcor

472017	ITT Indicator	Simmonds
472020	Oil Temperature Indicator	Simmonds
472741-3	F2735	Depot
472742-1	Fuel Qty Gaging Control Unit	Depot
47B19	Temperature Indicator	Lewis
47B20	Temperature Indicator	Lewis
47B46	Temperature Indicator	Lewis
47B504B	Temperature Indicator	Lewis
49B14	Temperature Indicator	Lewis
49B3	Temperature Indicator	Lewis
49B503	Temperature Indicator	Lewis
49B522A	Temperature Indicator	Lewis
49B525	Temperature Indicator	Lewis
5006-1016	Temperature Indicator	Insco

Primary Part Number	Nomenclature	Manufacture
5006-1020	Temperature Indicator	Insco
5008/5021	Turbine Outlet Temperature Ind	Insco
5008-3001	Turbine Outlet Temperature Ind	Insco
5021- (Series)	Temperature Indicator	Insco
5029-3003	Turbine Temperature Indicator	Insco
502BL10	Temperature Indicator	Lewis
502BL10A	Temperature Indicator	Lewis
502BL3	Temperature Indicator	Lewis
502BL3B	Temperature Indicator	Lewis
502BL3E	Temperature Indicator	Lewis
502BL3G	Temperature Indicator	Lewis
50-389102-SER.	Temperature Indicator	AID
5-1212	CHT Indicator	Rochester
5-1213	CARB Temp. Indicator	Rochester
520192	Temperature Indicator	Weston
520223	Temperature Indicator	Weston
520749	Temperature Indicator	Weston
520750	Temperature Indicator	Weston
520773	Temperature Indicator	Ametek/GE
520774	Temperature Indicator	Ametek/GE
521163	EGT Indicator	Weston
521299	Battery Temp. Indicator	Weston
521372	Dual Oil Pressure Temperature	Weston
521637	Generator Oil Temp. Indicator	Ametek/GE
521688	Temperature Indicator	Ametek/GE
521689	Temperature Indicator	Ametek/GE
521939	Temperature Indicator	Weston
521940	Temperature Indicator	Weston
521942	Temperature Indicator	Weston
521944	Temperature Indicator	Weston
521945	Temperature Indicator	Weston
522105	Oil Temperature Probe	Weston
522274	Fuel Temperature Indicator	Weston
522320	ITT Indicator	Weston

522325	Temperature Indicator	Weston
522542	CABIN TEMPERATURE INDICATOR	AMETEK
522543	APU/EGT Indicator	Ametek/GE
522545	Battery Temp. Indicator	Ametek/GE
522560	Temperature Indicator	Weston
522561	Temperature Indicator	Weston
523029	EGT Indicator	Weston
523271	Battery Temp. Indicator	Ametek/GE
529192	Temperature Indicator	Weston
543700-1	Amplifier Assem. Temp. Control	Texas Instruments

Primary Part Number	Nomenclature	Manufacture
548376-3	Temperature Controller	Garrett
548388-1	Temperator Sensor	Garrett
548392-1	Temperator Sensor	Garrett
5617-352-91-11	Indicator	Brion Leroux
5617-352-91-12	Indicator	Brion Leroux
5617-353-91-11	Indicator	Brion Leroux
5617-353-99-10	Indicator	Brion Leroux
5617-357-91-10	Indicator	Brion Leroux
5617-358-91-10	Indicator	Brion Leroux
5617-359-80-10	Indicator	Brion Leroux
563-266	Oil Temp/Press. Indicator	Hickok
563-303	CHT/EGT Indicator	Hickok
563-306	Oil Temp/Press. Indicator	Hickok
56B	Resistance Bulb	Lewis
5812	Temperature Indicator	Hickok
58-380104-1	CHT Indicator	Hickok
585-33984-001	Fuel Temperature Indicator	IDC
585-33984-002	Fuel Temperature Indicator	IDC
585-33986-001	Fuel Temperature Control Box	IDC
5-90371	Engine Oil Temperature	Rochester
5-90434	Oil Temperature Indicator	Rochester
5950-100A-12-A	Relative Humidity Indicator	Eclipse Pioneer
5950-100C-12-A	Relative Humidity Indicator	Eclipse Pioneer
598-509	Temperature Indicator	Lewis
60014	Temperature Indicator	Hickok
60015	Temperature Indicator	Hickok
6007-31A-7-A	Temperature Indicator	Eclipse Pioneer
6007-3B-7-A	Temperature Indicator	Eclipse Pioneer
6009-20A-2-A	Temperature Indicator	Eclipse Pioneer
6009-20A-5-A	Temperature Indicator	Eclipse Pioneer
602	CHT Indicator	Weston
607512-1	Temperator Sensor	Garrett
60B00133-162	EGT Indicator	Smith Industries
60B00133-163	EGT Indicator	Smith Industries
60B00133-164	EGT Indicator	Smith Industries
60B00133-211	EGT Indicator	Smith Industries
60B00133-212	EGT Indicator	Smith Industries
60B00133-31	EGT Indicator	Smith Industries

60B00133-32	EGT Indicator	Smith Industries
60B00133-33	EGT Indicator	Smith Industries
60B00133-34	EGT Indicator	Smith Industries
60B00133-35	EGT Indicator	Smith Industries
60B00133-36	EGT Indicator	Smith Industries
60B00133-37	EGT Indicator	Smith Industries

Primary Part Number	Nomenclature	Manufacture
60B00133-38	EGT Indicator	Smith Industries
60B00133-39	EGT Indicator	Smith Industries
60B00142-6	Temperature Indicator	Ametek/GE
60B00142-7	Temperature Indicator	Ametek/GE
60B00142-8	Temperature Indicator	Ametek/GE
60B00142-9	Temperature Indicator	Ametek/GE
60B40121-1	Generator Oil Temp. Indicator	Ametek/GE
61100-01	Temperature Indicator	Lewis
61100-03	Temperature Indicator	Lewis
61104-03	EGT Indicator	Lewis
61474-103-1	Tach Indicator	Sextant
61474-103-2	Tach Indicator	Sextant
61474-103-4	Indicator	Sextant
61474-108-1	Indicator	Sextant
61474-112-1	Indicator	Sextant
61474-112-2	Indicator	Sextant
61474-114-1	Indicator	Sextant
61474-130-1	Indicator	Sextant
61474-130-2	Indicator	Sextant
61474-131-2	Indicator	Sextant
61474-132-1	Indicator	Sextant
61474-133-1	Indicator	Sextant
61474-134-1	Indicator	Sextant
61474-135-1	Indicator	Sextant
6174-108-2	Indicator	Sextant
6246-00054	CHT Indicator	Rochester
6246-00106	CHT Indicator	Rochester
6246-00173	Oil Temperature Indicator	Rochester
627570-1	Temperator Sensor	Garrett
635	CHT Indicator	Weston
640281-111	CHT Indicator	Rochester
640281-149	Oil Temperature Indicator	Rochester
6685-642-0533	Temperature Indicator	John Oster
67000	Thermoswitch Unit	Fenwal
67021	Thermoswitch Unit	Fenwal
67100	Thermoswitch Unit	Fenwal
67121	Thermoswitch Unit	Fenwal
67300	Thermoswitch Unit	Fenwal
67321	Thermoswitch Unit	Fenwal
68000	Thermoswitch Unit	Fenwal
68021	Thermoswitch Unit	Fenwal
6867588	Temperature Limiter Amplifier	Smith Industries

68820-1120	Oil Temp./Pressure Ind.	Aerosonic
68825-1124	ITT and EGT indicator	Aerosonic

Primary Part Number	Nomenclature	Manufacture
6888495	Temperature Limiter Amplifier	Smith Industries
71700-10	Temperature Indicator	Lewis
71700-18	Temperature Indicator	Lewis
727MV/22	Temperature Indicator	Smith Industries
727MV/24	Temperature Indicator	Smith Industries
727MV/25/640	Temperature Indicator	Smith Industries
727MV/26	Temperature Indicator	Smith Industries
727MV/28/580	Temperature Indicator	Smith Industries
727MV/BU/1	Temperature Indicator	Smith Industries
727MV/BU/1/740	Temperature Indicator	Smith Industries
727MV/BU/10	Temperature Indicator	Smith Industries
727MV/BU/11	Temperature Indicator	Smith Industries
727MV/BU/12	Temperature Indicator	Smith Industries
727MV/BU/14	Temperature Indicator	Smith Industries
727MV/BU/15	Temperature Indicator	Smith Industries
727MV/BU/16	Temperature Indicator	Smith Industries
727MV/BU/17/580	Temperature Indicator	Smith Industries
727MV/BU/17/600	Temperature Indicator	Smith Industries
727MV/BU/17/640	Temperature Indicator	Smith Industries
727MV/BU/18/580	Temperature Indicator	Smith Industries
727MV/BU/18/610	Temperature Indicator	Smith Industries
727MV/BU/18/620	Temperature Indicator	Smith Industries
727MV/BU/18/640	Temperature Indicator	Smith Industries
727MV/BU/19	Temperature Indicator	Smith Industries
727MV/BU/2	Temperature Indicator	Smith Industries
727MV/BU/20/500	Temperature Indicator	Smith Industries
727MV/BU/20/560	Temperature Indicator	Smith Industries
727MV/BU/21/500	Temperature Indicator	Smith Industries
727MV/BU/3	Temperature Indicator	Smith Industries
727MV/BU/32	Temperature Indicator	Smith Industries
727MV/BU/33/580	Temperature Indicator	Smith Industries
727MV/BU/34/700	Temperature Indicator	Smith Industries
727MV/BU/37	Temperature Indicator	Smith Industries
727MV/BU/38	Temperature Indicator	Smith Industries
727MV/BU/39/700	Temperature Indicator	Smith Industries
727MV/BU/4	Temperature Indicator	Smith Industries
727MV/BU/40/700	Temperature Indicator	Smith Industries
727MV/BU/42/690	Temperature Indicator	Smith Industries
727MV/BU/435500	Temperature Indicator	Smith Industries
727MV/BU/44/700	Temperature Indicator	Smith Industries
727MV/BU/46/650	Temperature Indicator	Smith Industries
727MV/BU/47/580	Temperature Indicator	Smith Industries
727MV/BU/48	Temperature Indicator	Smith Industries
727MV/BU/5	Temperature Indicator	Smith Industries

Primary Part Number	Nomenclature	Manufacture

727MV/BU/50	Temperature Indicator	Smith Industries
727MV/BU/51/700	Temperature Indicator	Smith Industries
727MV/BU/52/640	Temperature Indicator	Smith Industries
727MV/BU/53/650	Temperature Indicator	Smith Industries
727MV/BU/53/750	Temperature Indicator	Smith Industries
727MV/BU/54/690	Temperature Indicator	Smith Industries
727MV/BU/56/730	Temperature Indicator	Smith Industries
727MV/BU/57/740	Temperature Indicator	Smith Industries
727MV/BU/59/720	Temperature Indicator	Smith Industries
727MV/BU/6	Temperature Indicator	Smith Industries
727MV/BU/60/720	Temperature Indicator	Smith Industries
727MV/BU/61/750	Temperature Indicator	Smith Industries
727MV/BU/62/700	Temperature Indicator	Smith Industries
727MV/BU/63	Temperature Indicator	Smith Industries
727MV/BU/64/660	Temperature Indicator	Smith Industries
727MV/BU/65/720	Temperature Indicator	Smith Industries
727MV/BU/66/660	Temperature Indicator	Smith Industries
727MV/BU/68/640	Temperature Indicator	Smith Industries
727MV/BU/69/750	Temperature Indicator	Smith Industries
727MV/BU/7	Temperature Indicator	Smith Industries
727MV/BU/8	Temperature Indicator	Smith Industries
752490-4	Cabin Temp. Controller	Hamilton Standard
75448-2	Temperature Indicator	Lewis
762MV/BU/10/700	Temperature Indicator	Smith Industries
762MV/BU/11	Temperature Indicator	Smith Industries
762MV/BU/12	Temperature Indicator	Smith Industries
762MV/BU/15/725	Temperature Indicator	Smith Industries
762MV/BU/16/580	Temperature Indicator	Smith Industries
762MV/BU/18/740	Temperature Indicator	Smith Industries
762MV/BU/18/750	Temperature Indicator	Smith Industries
762MV/BU/19/700	Temperature Indicator	Smith Industries
762MV/BU/2/580	Temperature Indicator	Smith Industries
762MV/BU/20/860	Temperature Indicator	Smith Industries
762MV/BU/21/860	Temperature Indicator	Smith Industries
762MV/BU/22/680	Temperature Indicator	Smith Industries
762MV/BU/23/860	Temperature Indicator	Smith Industries
762MV/BU/24/790	Temperature Indicator	Smith Industries
762MV/BU/25/720	Temperature Indicator	Smith Industries
762MV/BU/26/700	Temperature Indicator	Smith Industries
762MV/BU/27/860	Temperature Indicator	Smith Industries
762MV/BU/28/800	Temperature Indicator	Smith Industries
762MV/BU/3/560	Temperature Indicator	Smith Industries
762MV/BU/30/770	Temperature Indicator	Smith Industries
762MV/BU/31/810	Temperature Indicator	Smith Industries

Primary Part Number	Nomenclature	Manufacture
762MV/BU/33/700	Temperature Indicator	Smith Industries
762MV/BU/34/700	Temperature Indicator	Smith Industries
762MV/BU/36/860	Temperature Indicator	Smith Industries
762MV/BU/37/800	Temperature Indicator	Smith Industries

762MV/BU/38/790	Temperature Indicator	Smith Industries
762MV/BU/40/860	Temperature Indicator	Smith Industries
762MV/BU/41/805	Temperature Indicator	Smith Industries
762MV/BU/42/900	Temperature Indicator	Smith Industries
762MV/BU/43/900	Temperature Indicator	Smith Industries
762MV/BU/44/791	Temperature Indicator	Smith Industries
762MV/BU/5/590	Temperature Indicator	Smith Industries
762MV/BU/5/600	Temperature Indicator	Smith Industries
762MV/BU/6/580	Temperature Indicator	Smith Industries
762MV/BU/7	Temperature Indicator	Smith Industries
762MV/BU/8/550	Temperature Indicator	Smith Industries
762MV/BU/9/550	Temperature Indicator	Smith Industries
76AT3	Temperature Indicator	Lewis
76AT3B	Temperature Indicator	Lewis
76AT3C	Temperature Indicator	Lewis
76B15	Temperature Indicator	Lewis
76B502A	Temperature Indicator	Lewis
76B503	Temperature Indicator	Lewis
76B526	Temperature Indicator	Lewis
76B6	Temperature Indicator	Lewis
76B711	Temperature Indicator	Lewis
76B9	Temperature Indicator	Lewis
77B12	Temperature Indicator	Lewis
77B203	Temperature Indicator	Lewis
77B203A	Temperature Indicator	Lewis
77B204	Temperature Indicator	Lewis
77B205	Temperature Indicator	Lewis
77B46	Temperature Indicator	Lewis
77C7B	Temperature Indicator	Lewis
77C8B	Temperature Indicator	Alcor
77C9B	Temperature Indicator	Alcor
800496	Battery Temp. Indicator	Lear Siegler
800496-()	Battery Temp Indicator	Lear Seigler
800496-16	Battery Temp Indicator	Lear Seigler
800496H-OTL	Battery Temp. Indicator	Lear Siegler
852B3M3	Temperature Indicator	Lewis
880005-501	Thermocouple Probe	Mooney
880023-503	OAT Indicator	Mooney
8DJ100	Temperature Indicator	Ametek/GE
8DJ100AAA1	Temperature Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ100AAF1	Temperature Indicator	Ametek/GE
8DJ100AAK1	Temperature Indicator	Ametek/GE
8DJ100AAS4	Temperature Indicator	Ametek/GE
8DJ100LAB1	Temperature Indicator	Ametek/GE
8DJ100LAC1	Temperature Indicator	Ametek/GE
8DJ100LAE1	Temperature Indicator	Ametek/GE
8DJ100LAF1	Temperature Indicator	Ametek/GE
8DJ100LAK1	Temperature Indicator	Ametek/GE

8DJ100LAR1	Temperature Indicator	Ametek/GE
8DJ100LAT1	Temperature Indicator	Ametek/GE
8DJ100LAV1	Temperature Indicator	Ametek/GE
8DJ100LAW1	Temperature Indicator	Ametek/GE
8DJ100LAY1	Temperature Indicator	Ametek/GE
8DJ100LBA1	Temperature Indicator	Ametek/GE
8DJ100WAA1	Temperature Indicator	Ametek/GE
8DJ100WAA2	Temperature Indicator	Ametek/GE
8DJ100WAD2	Temperature Indicator	Ametek/GE
8DJ100WAD3	Temperature Indicator	Ametek/GE
8DJ100WAD5	Temperature Indicator	Ametek/GE
8DJ100WAE4	Temperature Indicator	Ametek/GE
8DJ100WAG2	Temperature Indicator	Ametek/GE
8DJ100WAH4	Temperature Indicator	Ametek/GE
8DJ100WAM4	Temperature Indicator	Ametek/GE
8DJ100WAS2	Temperature Indicator	Ametek/GE
8DJ100WBA5	Temperature Indicator	Ametek/GE
8DJ100WBD2	Indicator	GE
8DJ163LWT2	Gas Temperature Indicator	Ametek/GE
8DJ163LWV2	Gas Temperature Indicator	Ametek/GE
8DJ163LWY3	Gas Temperature Indicator	Ametek/GE
8DJ163LWZ2	Gas Temperature Indicator	Ametek/GE
8DJ163LXB2	Gas Temperature Indicator	Ametek/GE
8DJ163LXB3	Gas Temperature Indicator	Ametek/GE
8DJ163LXB4	Gas Temperature Indicator	Ametek/GE
8DJ163LXD2	Gas Temperature Indicator	Ametek/GE
8DJ163LXD3	Gas Temperature Indicator	Ametek/GE
8DJ163LXD4	Gas Temperature Indicator	Ametek/GE
8DJ163LXE2	Gas Temperature Indicator	Ametek/GE
8DJ163LXE3	Gas Temperature Indicator	Ametek/GE
8DJ163LXE4	Gas Temperature Indicator	Ametek/GE
8DJ163LXF2	Gas Temperature Indicator	Ametek/GE
8DJ163LXF3	Gas Temperature Indicator	Ametek/GE
8DJ163LXF4	Gas Temperature Indicator	Ametek/GE
8DJ163LXG2	Gas Temperature Indicator	Ametek/GE
8DJ163LXG3	Gas Temperature Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ163LXG4	Gas Temperature Indicator	Ametek/GE
8DJ163LXH4	Gas Temperature Indicator	Ametek/GE
8DJ163LXP4	Gas Temperature Indicator	Ametek/GE
8DJ163LXR4	Gas Temperature Indicator	Ametek/GE
8DJ163LXZ4	Gas Temperature Indicator	Ametek/GE
8DJ163LYC4	Gas Temperature Indicator	Ametek/GE
8DJ163LYD4	Gas Temperature Indicator	Ametek/GE
8DJ163LYH4	Gas Temperature Indicator	Ametek/GE
8DJ163LYN4	Gas Temperature Indicator	Ametek/GE
8DJ163LYP4	Gas Temperature Indicator	Ametek/GE
8DJ163LYR4	Gas Temperature Indicator	Ametek/GE
8DJ163LYS4	Gas Temperature Indicator	Ametek/GE

8DJ163LYT4	Gas Temperature Indicator	Ametek/GE
8DJ163LYV4	Gas Temperature Indicator	Ametek/GE
8DJ163LYW4	Gas Temperature Indicator	Ametek/GE
8DJ163LYX4	Gas Temperature Indicator	Ametek/GE
8DJ163LYY4	Gas Temperature Indicator	Ametek/GE
8DJ163LYZ4	Gas Temperature Indicator	Ametek/GE
8DJ174LWS2	EGT Indicator	Ametek/GE
8DJ175	Turbine Gas Temp Indicator	Ametek/GE
8DJ175LWK2	EGT Indicator	Ametek/GE
8DJ175LWK2-T	EGT Indicator	Ametek/GE
8DJ175LWL1	Turbine Gas Temp Indicator	Ametek/GE
8DJ175LWM2	EGT Indicator	Ametek/GE
8DJ175LWP2	EGT Indicator	Ametek/GE
8DJ175LWR1	Turbine Gas Temp Indicator	Ametek/GE
8DJ175LWT2	EGT Indicator	Ametek/GE
8DJ175LWX1	Turbine Gas Temp Indicator	Ametek/GE
8DJ175LXA1	Turbine Gas Temp Indicator	Ametek/GE
8DJ175LXB2	EGT Indicator	Ametek/GE
8DJ175LXC2	EGT Indicator	Ametek/GE
8DJ175LXF2	EGT Indicator	Ametek/GE
8DJ175LXH1	Turbine Gas Temp Indicator	Ametek/GE
8DJ175LXK1	Turbine Gas Temp Indicator	Ametek/GE
8DJ175LXR2	EGT Indicator	Ametek/GE
8DJ175LXT1	Turbine Gas Temp Indicator	Ametek/GE
8DJ175LXV1	Turbine Gas Temp Indicator	Ametek/GE
8DJ177 (SERIES)	Temperature Indicator	Ametek/GE
8DJ179BA2	Temperature Indicator	Ametek/GE
8DJ179DBD3	Turbine Inlet Temperature	Ametek/GE
8DJ179DBE1	Turbine Inlet Temperature	Ametek/GE
8DJ179DDP3	Turbine Inlet Temperature	Ametek/GE
8DJ179KAA2	Temperature Indicator	Ametek/GE
8DJ179KDA1	Temperature Indicator	Ametek/GE

Primary Part Number	Nomenclature	Manufacture
8DJ179LAD4	Temperature Indicator	Ametek/GE
8DJ179WAD1	Temperature Indicator	Ametek/GE
8DJ179WAD4	Temperature Indicator	Ametek/GE
8DJ179WBA1	Temperature Indicator	Ametek/GE
8DJ179WBH1	Temperature Indicator	Ametek/GE
8DJ179WBK1	Temperature Indicator	Ametek/GE
8DJ98AAA1	Temperature Indicator	Ametek/GE
8DJ98AAC1	Temperature Indicator	Ametek/GE
8DK163LWY2	Gas Temperature Indicator	Ametek/GE
8DW53TAB	Temperature Indicator	Ametek/GE
8DW53TBB	Temperature Indicator	Ametek/GE
8KE55AAA1	Temperature Indicator	Ametek/GE
8KE55AAB1	Temperature Synchro Signal Amp	Ametek/GE
9009-3003	Oil Temp/Press. Indicator	Insco
9009-3004	Oil Temp/Press. Indicator	Insco
9009-3009	Oil Temp/Press. Indicator	Insco

9009-3010	Oil Temp/Press. Indicator	Insco
9009-3013	Oil Temp/Press. Indicator	Insco
90-384026-()	Temperature Indicator	Beechcraft
91943	Temperature Indicator	Weston
91945	Temperature Indicator	Weston
93787	Temperature Indicator	Weston
93925	Temperature Indicator	Weston
9616-03	Temperature Indicator	John Oster
96200	Free Air Temperature	Weston
9A-375	Temperature Indicator	Penn Airborne
9A-400	Temperature Indicator	Penn Airborne
9A-550	Temperature Indicator	Penn Airborne
A-23	Temperature Indicator	Edison
A-24	Temperature Indicator	Edison
A-25	Temperature Indicator	Edison
A-261	Free Air Temperature	Weston
A-261B	Free Air Temperature	Weston
A29257 10 001	Static Air Temp Indicator	Kollsman
A29257 10 021	Static Air Temp Indicator	Kollsman
A301A	Battery Temp. Indicator	KS Avionics Inc.
AM-10465-3	Temperature Indicator	Voltron
AM10465-3	Oil Temperature Indicator	Voltron
AN5536-2	Temperature Indicator	Weston
AN5790	Temperature Indicator	Electric Auto-Lite Co
AN5790T6A	Temperature Indicator	Electric Auto-Lite Co
AN5795- ( )	Temperature Indicator	Weston
AN5795-6	Temperature Indicator	Electric Auto-Lite Co
AN5795T6A	Temperature Indicator	Electric Auto-Lite Co

Primary Part Number	Nomenclature	Manufacture
B1508-1B	Total Temperature Indicator	Simmonds
B1508-1C	Total Temperature Indicator	Simmonds
B1508-2	Total Temperature Indicator	Simmonds
B1508-5	Total Temperature Indicator	Simmonds
B1508-6	Total Temperature Indicator	Simmonds
B1508-7	Total Temperature Indicator	Simmonds
B-1564-10	Total Temperature Indicator	Simmonds
B36197 01 001	Static Air Temp Indicator	Kollsman
B36197 10 021	Static Air Temp Indicator	Kollsman
B588-10-1	EGT Indicator	Simmonds
B588-10-2	EGT Indicator	Simmonds
B588-12B	Temperature Indicator	Simmonds
B588-15	Temperature Indicator	Simmonds
B588-15R	Temperature Indicator	Simmonds
B588-15R1	Temperature Indicator	Simmonds
B588-15W	Temperature Indicator	Simmonds
B588-15W1	Temperature Indicator	Simmonds
B588-35	Temperature Indicator	Simmonds
BH1185-154	Autotemp Indicator	Howell
BH1187M-4	Turbine Inlet Temperature	Howell

BH154R-29	Autotemp Indicator	Howell
BH183M	Autotemp Indicator	Howell
BH183M-21	Autotemp Indicator	Howell
BH183R-58	Turbine Inlet Temperature	Howell
BH183R-6	EGT Indicator	Howell
BH185R-134	Temperature Indicator	Howell
BH185R-232	Temperature Indicator	Howell
BH185R-280A	Autotemp Indicator	Howell
BH187R-111	Autotemp Indicator	Howell
BH187R-13	Temperature Indicator	Howell
BH187R-14B	Autotemp Indicator	Howell
BH187R-164	Temperature Indicator	Howell
BH187R-34	Temperature Indicator	Howell
BH187R-6	Autotemp Indicator	Howell
BH187R-8	Temperature Indicator	Howell
BM183M	Temperature Indicator	Howell
BM183M-21	Temperature Indicator	Howell
BTI600-2A	Battery Temp. Indicator	Foxtronics
C 25725 10 001	Static Air Temp Indicator	Kollsman
C166065-010	Windshield Temperature Control	Cessna
C166065-0101	Windshield Temperature Control	Ice Corp
C25725-10-001	Static Air Temp Indicator	Kollsman
C-6	Free Air Temperature	Weston
C668501-0211	EGT Indicator	Alcor

Primary Part Number	Nomenclature	Manufacture
C-7	Temperature Indicator	Lewis
CM2628-( )	Temperature Indicator	Cessna
DDL-OC119C	Fuel Temperature Indicator	Ametek/GE
DJ-100	Temperature Indicator	Ametek/GE
DST 1017-5	ITT Indicator	Consolidated Airborn
DST-16	Temperature Indicator	Consolidated Airborn
DST-17	Temperature Indicator	Consolidated Airborn
DST-17-1	Temperature Indicator	Consolidated Airborn
DST1800-1	EGT Indicator	Bendix
DST18001-1	Dual Temperature Indicator	Bendix
DST-29-1	Temperature Indicator	Consolidated Airborn
DST-29-2	Temperature Indicator	Consolidated Airborn
DST-29-3	Temperature Indicator	Consolidated Airborn
DST-29-6	Temperature Indicator	Consolidated Airborn
DST-49	Temperature Indicator	Consolidated Airborn
DST497-1	Temperature Indicator	Consolidated Airborn
DST497-2	Temperature Indicator	Consolidated Airborn
E-100	EGT Indicator	Hanna-Aero
EGT	EGT Indicator	KS Avionics Inc.
EHU-1/A	Temperature Indicator	Ametek/GE
EHU-11/A	Indicator	Avien
EHU-15/A	Temperature Indicator	Consolidated Airborn
EHU-9/A	Temperature Indicator	Consolidated Airborn
F-10	Temperature Indicator	Edison

F-11	Temperature Indicator	Edison
F-12	Temperature Indicator	Edison
F-8	Temperature Indicator	Edison
G-5	Temperature Indicator	Lewis
G-6	Temperature Indicator	Lewis
H4170	Pyrometer Potentiometer	Howell
H900K-203	Autotemp Indicator	Howell
H900K-238	Autotemp Indicator	Howell
H900K-288	Autotemp Indicator	Howell
HYLZ-50426	Windshield Temperature Control	Barber-Colman
IFR-11A	Temperature Indicator	IFR
JG165A2	Temperature Indicator	Honeywell
LKCC-8031	Oil Temperature Indicator	Wacline
LKCC-8032	Oil Temperature Indicator	Wacline
MCI-105C	EGT Indicator	Alcor
MCI-105C-1	EGT Indicator	Alcor
MCI-110B	EGT Indicator	Alcor
MCI-110B-1	EGT Indicator	Alcor
MD11-( )	CARB Temp. Indicator	Mid Continent
MD-63-3	Oil Temp/Press. Indicator	Mid Continent

Primary Part Number	Nomenclature	Manufacture
MIL-I-27209C	Temperature Indicator	Military Specification
MJ1	Temperature Indicator	Lewis
MJ-1	Temperature Indicator	Lewis
MJ2	Temperature Indicator	Lewis
MJ-2	Temperature Indicator	Lewis
MML-OC19AR	ITT Indicator	Ametek/GE
MM-OC19E	ITT Indicator	Ametek/GE
MS24569-1	Temperature Indicator	Bendix
MS28009-1	Temperature Indicator	Military Specification
MS28034-1	Temp Probe	Norwich
NO PN	Oil Temp/Press. Indicator	Aerosonic
OR22-295-09	Outside Air Temperature	Electric Auto-Lite Co
PW/727MV/BU/1	Temperature Indicator	Smith Industries
PW/727MV/BU/10	Temperature Indicator	Smith Industries
PW/727MV/BU/11	Temperature Indicator	Smith Industries
PW/727MV/BU/12	Temperature Indicator	Smith Industries
PW/727MV/BU/14	Temperature Indicator	Smith Industries
PW/727MV/BU/15	Temperature Indicator	Smith Industries
PW/727MV/BU/16	Temperature Indicator	Smith Industries
PW/727MV/BU/17/580	Temperature Indicator	Smith Industries
PW/727MV/BU/17/600	Temperature Indicator	Smith Industries
PW/727MV/BU/17/640	Temperature Indicator	Smith Industries
PW/727MV/BU/18/580	Temperature Indicator	Smith Industries
PW/727MV/BU/18/610	Temperature Indicator	Smith Industries
PW/727MV/BU/18/620	Temperature Indicator	Smith Industries
PW/727MV/BU/18/640	Temperature Indicator	Smith Industries
PW/727MV/BU/19	Temperature Indicator	Smith Industries
PW/727MV/BU/2	Temperature Indicator	Smith Industries

PW/727MV/BU/20/500	Temperature Indicator	Smith Industries
PW/727MV/BU/20/560	Temperature Indicator	Smith Industries
PW/727MV/BU/21/500	Temperature Indicator	Smith Industries
PW/727MV/BU/22	Temperature Indicator	Smith Industries
PW/727MV/BU/24	Temperature Indicator	Smith Industries
PW/727MV/BU/25/640	Temperature Indicator	Smith Industries
PW/727MV/BU/26	Temperature Indicator	Smith Industries
PW/727MV/BU/28/580	Temperature Indicator	Smith Industries
PW/727MV/BU/3	Temperature Indicator	Smith Industries
PW/727MV/BU/30	Temperature Indicator	Smith Industries
PW/727MV/BU/32	Temperature Indicator	Smith Industries
PW/727MV/BU/33/580	Temperature Indicator	Smith Industries
PW/727MV/BU/34/700	Temperature Indicator	Smith Industries
PW/727MV/BU/37	Temperature Indicator	Smith Industries
PW/727MV/BU/38	Temperature Indicator	Smith Industries
PW/727MV/BU/39/700	Temperature Indicator	Smith Industries

Primary Part Number	Nomenclature	Manufacture
PW/727MV/BU/4	Temperature Indicator	Smith Industries
PW/727MV/BU/40/700	Temperature Indicator	Smith Industries
PW/727MV/BU/42/690	Temperature Indicator	Smith Industries
PW/727MV/BU/43/550	Temperature Indicator	Smith Industries
PW/727MV/BU/44/700	Temperature Indicator	Smith Industries
PW/727MV/BU/46/650	Temperature Indicator	Smith Industries
PW/727MV/BU/47/580	Temperature Indicator	Smith Industries
PW/727MV/BU/48	Temperature Indicator	Smith Industries
PW/727MV/BU/5	Temperature Indicator	Smith Industries
PW/727MV/BU/50	Temperature Indicator	Smith Industries
PW/727MV/BU/51/700	Temperature Indicator	Smith Industries
PW/727MV/BU/52/640	Temperature Indicator	Smith Industries
PW/727MV/BU/53/650	Temperature Indicator	Smith Industries
PW/727MV/BU/53/750	Temperature Indicator	Smith Industries
PW/727MV/BU/54/69-	Temperature Indicator	Smith Industries
PW/727MV/BU/56/730	Temperature Indicator	Smith Industries
PW/727MV/BU/57/740	Temperature Indicator	Smith Industries
PW/727MV/BU/59/720	Temperature Indicator	Smith Industries
PW/727MV/BU/6	Temperature Indicator	Smith Industries
PW/727MV/BU/60/720	Temperature Indicator	Smith Industries
PW/727MV/BU/61/750	Temperature Indicator	Smith Industries
PW/727MV/BU/62/700	Temperature Indicator	Smith Industries
PW/727MV/BU/63	Temperature Indicator	Smith Industries
PW/727MV/BU/64/660	Temperature Indicator	Smith Industries
PW/727MV/BU/65/720	Temperature Indicator	Smith Industries
PW/727MV/BU/66/660	Temperature Indicator	Smith Industries
PW/727MV/BU/68/640	Temperature Indicator	Smith Industries
PW/727MV/BU/69/750	Temperature Indicator	Smith Industries
PW/727MV/BU/7	Temperature Indicator	Smith Industries
PW/727MV/BU/8	Temperature Indicator	Smith Industries
PW/762MV/BU/1/740	Temperature Indicator	Smith Industries
PW/762MV/BU/10/700	Temperature Indicator	Smith Industries

PW/762MV/BU/11	Temperature Indicator	Smith Industries
PW/762MV/BU/12	Temperature Indicator	Smith Industries
PW/762MV/BU/15/725	Temperature Indicator	Smith Industries
PW/762MV/BU/16/580	Temperature Indicator	Smith Industries
PW/762MV/BU/18/740	Temperature Indicator	Smith Industries
PW/762MV/BU/18/750	Temperature Indicator	Smith Industries
PW/762MV/BU/19/700	Temperature Indicator	Smith Industries
PW/762MV/BU/2/580	Temperature Indicator	Smith Industries
PW/762MV/BU/20/860	Temperature Indicator	Smith Industries
PW/762MV/BU/21/860	Temperature Indicator	Smith Industries
PW/762MV/BU/22/680	Temperature Indicator	Smith Industries
PW/762MV/BU/23/860	Temperature Indicator	Smith Industries

Primary Part Number	Nomenclature	Manufacture
PW/762MV/BU/24/790	Temperature Indicator	Smith Industries
PW/762MV/BU/25/720	Temperature Indicator	Smith Industries
PW/762MV/BU/26/700	Temperature Indicator	Smith Industries
PW/762MV/BU/27/860	Temperature Indicator	Smith Industries
PW/762MV/BU/28/800	Temperature Indicator	Smith Industries
PW/762MV/BU/3/520	Temperature Indicator	Smith Industries
PW/762MV/BU/3/560	Temperature Indicator	Smith Industries
PW/762MV/BU/30/770	Temperature Indicator	Smith Industries
PW/762MV/BU/31/810	Temperature Indicator	Smith Industries
PW/762MV/BU/33/700	Temperature Indicator	Smith Industries
PW/762MV/BU/34/700	Temperature Indicator	Smith Industries
PW/762MV/BU/36/860	Temperature Indicator	Smith Industries
PW/762MV/BU/37/800	Temperature Indicator	Smith Industries
PW/762MV/BU/38/790	Temperature Indicator	Smith Industries
PW/762MV/BU/40/860	Temperature Indicator	Smith Industries
PW/762MV/BU/41/805	Temperature Indicator	Smith Industries
PW/762MV/BU/42/900	Temperature Indicator	Smith Industries
PW/762MV/BU/43/900	Temperature Indicator	Smith Industries
PW/762MV/BU/44/791	Temperature Indicator	Smith Industries
PW/762MV/BU/5/590	Temperature Indicator	Smith Industries
PW/762MV/BU/5/600	Temperature Indicator	Smith Industries
PW/762MV/BU/6/580	Temperature Indicator	Smith Industries
PW/762MV/BU/7	Temperature Indicator	Smith Industries
PW/762MV/BU/8/550	Temperature Indicator	Smith Industries
PW/762MV/BU/9/550	Temperature Indicator	Smith Industries
S1311-1	CARB Temp. Indicator	R C Allen
S1311-2	CARB Temp. Indicator	R C Allen
S1311-3	CARB Temp. Indicator	R C Allen
S1311-4	CARB Temp. Indicator	R C Allen
S1311-5	CARB Temp. Indicator	R C Allen
S1311-6	CARB Temp. Indicator	R C Allen
S231N212-6	Oil Temperature Indicator	Horizon Aerospace
SEL-019BC	Turbine Temperature Indicator	Ametek/GE
SEL-019BD	Turbine Temperature Indicator	Ametek/GE
SEL-019BU	Turbine Temperature Indicator	Ametek/GE
SEL-019BW	Turbine Temperature Indicator	Ametek/GE

SEL-019DR	Turbine Temperature Indicator	Ametek/GE
SEL-019DS	Turbine Temperature Indicator	Ametek/GE
SEL-019DT	Turbine Temperature Indicator	Ametek/GE
SEL-019ED	Turbine Temperature Indicator	Ametek/GE
SEL-C19L	EGT Indicator	AMETEK
SEL-C19N	EGT Indicator	AMETEK
SEL-C19R	EGT Indicator	Ametek/GE
SEL-C29J	N2 indicator	AMETEK

Primary Part Number	Nomenclature	Manufacture
SEL-C29L	N2 indicator	AMETEK
SEL-OC19AG	EGT Indicator	Ametek/GE
SEL-OC19AM	Turbine Temperature Indicator	US Gauge
SEL-OC19AP	Turbine Temperature Indicator	US Gauge
SEL-OC19BT	ITT Indicator	Ametek/GE
SEL-OC19D	EGT Indicator	Ametek/GE
SEL-OC19DC	ITT Indicator	US Gauge
SEL-OC19DW	ITT Indicator	US Gauge
SEL-OC19E	EGT Indicator	Ametek/GE
SEL-OC19EJ	ITT Indicator	Ametek/GE
SEL-OC19F	EGT Indicator	Ametek/GE
SEL-OC19G	EGT Indicator	Ametek/GE
SYLZ 50683-1	Temperature Controller	Barber Coleman
SYLZ 50684	Temperature Controller	Barber Coleman
SYLZ 50685	Teperature Controller	Barber Coleman
TYP1019	Rear Oil Temperature Indicator	Farem
VSDL-OC219C	Oil Temperature Indicator	Ametek/GE
WL706RSA3	Turbine Gas Temp Indicator	Ametek/GE
WL706RSA4	Turbine Gas Temp Indicator	Ametek/GE
WL706RSA5	Turbine Gas Temp Indicator	Ametek/GE
Z-22.22	Temperature Indicator	Dejur-Amsco
Z-22.24	Temperature Indicator	Dejur-Amsco
Z-22-24	Temperature Indicator	Dejur-Amsco
15461-1-A1	Vertical Speed Indicator	Bendix
1600-A1	Vertical Speed Indicator	Pioneer
1601-B1	Vertical Speed Indicator	Pioneer
1610-A1	Vertical Speed Indicator	Pioneer
1611-A1	Vertical Speed Indicator	Pioneer
1625-1Q-C1	Vertical Speed Indicator	Pioneer
1634-1AG-B1	Vertical Speed Indicator	Pioneer
1634-1AH-A1	Vertical Speed Indicator	Pioneer
1634-1AH-B1	Vertical Speed Indicator	Pioneer
1634-1AH-C1-1	Vertical Speed Indicator	Pioneer
1634-1AH-C1-2	Vertical Speed Indicator	Pioneer
1634-1M-A1	Vertical Speed Indicator	Pioneer
1634-1U-A1	Vertical Speed Indicator	Pioneer
1634-1X-A1	Vertical Speed Indicator	Pioneer
1636-6A-A1	Vertical Speed Indicator	Pioneer
1636-6A-B1	Vertical Speed Indicator	Pioneer
1636-6G-B1	Vertical Speed Indicator	Pioneer

1636-6H-B1	Vertical Speed Indicator	Pioneer
1636-6K-B1	Vertical Speed Indicator	Pioneer
1636-6M-B1	Vertical Speed Indicator	Pioneer
1636-6M-B2	Vertical Speed Indicator	Pioneer

Primary Part Number	Nomenclature	Manufacture
1640-6E-A1	Vertical Speed Indicator	Pioneer
1640-6L-A1	Climb Indicator	Pioneer
1644-6N-A1	Vertical Speed Indicator	Pioneer
1646-6R-A2	Vertical Speed Indicator	Bendix
1646-6S-A2	Vertical Speed Indicator	Bendix
1646-6T-A2-1	Vertical Speed Indicator	Bendix
1648-6U-A6-1	Vertical Speed Indicator	Bendix
1648-6U-B6-1	Vertical Speed Indicator	Bendix
1649-1AS-A-1	Vertical Speed Indicator	Pioneer
1649-1AS-C1-1	Vertical Speed Indicator	Pioneer
1652-6AJ-B6-1	Vertical Speed Indicator	Bendix
1652-6Z-A6-1	Vertical Speed Indicator	Bendix
1653	Vertical Speed Indicator	Bendix
1654	Vertical Speed Indicator	Bendix
1655-6AE-B6-1	Vertical Speed Indicator	Bendix
1655-6AP-B6-1	Vertical Speed Indicator	Bendix
1659	Vertical Speed Indicator	Bendix
1662	Vertical Speed Indicator	Bendix
18001-2A2A1	Vertical Speed Indicator	Bendix
18001-2A5B1	Vertical Speed Indicator	Bendix
18001-2A5C1	Vertical Speed Indicator	Bendix
18001-2A5D1	Vertical Speed Indicator	Bendix
18001-2A5E1	Vertical Speed Indicator	Bendix
18005-5A8B1	Vertical Speed Indicator	Bendix
18007-7A10A1	Vertical Speed Indicator	Bendix
18007-7A10A2	Vertical Speed Indicator	Bendix
212-070-239-1	Indicator	Aerosonic
212-070-714-1	Indicator	Lear Siegler
22-201	Vertical Speed Indicator	Electric Auto-Lite Co
22-220-03	Vertical Speed Indicator	Garwin
22-991	Vertical Speed Indicator	Electric Auto-Lite Co
22-998-03	Vertical Speed Indicator	Garwin
27-19171-1	Angle of Attack Indicator	Hickok
30230-0124	Vertical Speed Indicator	Aerosonic
30230-1176	Vertical Speed Indicator	Aerosonic
30260-1117	IVSI	Aerosonic
320-21-1210	Climb Indicator	Mac Leod Instrument
32-1004	Vertical Speed Indicator	AID
329B-8V	Indicator	Collins
340-36-1210	Climb Indicator	Mac Leod Instrument
350-362	Vertical Speed Indicator	AID
35060-0116	Vertical Speed Indicator	Aerosonic
35060-1122	Indicator	Aerosonic
35160-2182	IVSI	Aerosonic

Primary Part Number	Nomenclature	Manufacture
360-27-1210	Climb Indicator	Mac Leod Instrument
40-416-2	Vertical Speed Indicator	McDonnell Douglas/B
4A16	Vertical Speed Indicator	Thommen
4A58	Vertical Speed Indicator	Thommen
550-18013B-950	Vertical Speed Indicator	IDC
550-18013B-960	Vertical Speed Indicator	IDC
585-31658-001	Vertical Speed Indicator	IDC
613K-025	Vertical Speed Indicator	Kollsman
661KN-02	Climb Indicator	Kollsman
7000	Vertical Speed Indicator	United Instruments
7000B	Vertical Speed Indicator	United Instruments
7030	Vertical Speed Indicator	United Instruments
7040	Vertical Speed Indicator	United Instruments
70450-21988-101	Vertical Speed Indicator	Sikorsky
7060	Vertical Speed Indicator	United Instruments
7060-C.20	Vertical Speed Indicator	United Instruments
7100	Vertical Speed Indicator	United Instruments
7130-C.44	IVSI	United Instruments
716BK-5-046	Vertical Speed Indicator	Kollsman
716BK-8-036	Vertical Speed Indicator	Kollsman
716BU-10-052	Vertical Speed Indicator	Kollsman
716BU-4-052	Vertical Speed Indicator	Kollsman
716BU-8-036	Vertical Speed Indicator	Kollsman
716BU-8-050	Vertical Speed Indicator	Kollsman
716CU-4-052	Vertical Speed Indicator	Kollsman
716CU-4-053	Vertical Speed Indicator	Kollsman
716CX-4-051	Vertical Speed Indicator	Kollsman
716U-03	Vertical Speed Indicator	Kollsman
731KN-02	Climb Indicator	Kollsman
731KN-04	Climb Indicator	Kollsman
731KN-08	Climb Indicator	Kollsman
731KNL-010	Climb Indicator	Kollsman
787-6892-001	Indicator	Collins
8.041.003	Vertical Speed Indicator	Aeritalia
8.041.008.1	Vertical Speed Indicator	Aeritalia
8.041.503	Vertical Speed Indicator	Aeritalia
8.041.508.1	Vertical Speed Indicator	Aeritalia
8.041.603	Vertical Speed Indicator	Aeritalia
8.041.608.1	Vertical Speed Indicator	Aeritalia
8.041.703	Vertical Speed Indicator	Aeritalia
8.041.708.1	Vertical Speed Indicator	Aeritalia
8-041-003	Climb Indicator	Aeritalia
8-041-008-1	Climb Indicator	Aeritalia
8-041-503	Climb Indicator	Aeritalia

Primary Part Number	Nomenclature	Manufacture
8-041-508-1	Climb Indicator	Aeritalia
8-041-603	Climb Indicator	Aeritalia

8-041-608-1	Climb Indicator	Aeritalia
8-041-703	Climb Indicator	Aeritalia
8-041-708-1	Climb Indicator	Aeritalia
8-210-XX	Indicator	UMA
8-310-XX	Indicator	UMA
843-67-1	Vertical Speed Indicator	Kearflex
843-67-1A	Vertical Speed Indicator	Kearflex
843-67-2	Vertical Speed Indicator	Kearflex
843-67-2A	Vertical Speed Indicator	Kearflex
843-67-3	Vertical Speed Indicator	Kearflex
86M029	Vertical Speed Indicator	Electric Auto-Lite Co
88-I-725	Climb Indicator	Bendix
A25363 10 002	Vertical Speed Indicator	Kollsman
A25363-10-003	Vertical Speed Indicator	Kollsman
A25753 04 001	Vertical Speed Indicator	Kollsman
A25753-10-001	Vertical Speed Indicator	Kollsman
A3206910006	Vertical Speed Indicator	Kollsman
A3206910106	Vertical Speed Indicator	Kollsman
A34521 10 006	Vertical Speed Indicator	Kollsman
AAU-18/A	Indicator	Aerosonic
B4018710022	Cabin Rate of Climb	Sun Chemical Corp
B4018710033	Cabin Rate of Climb	Sun Chemical Corp
B4018710133	Cabin Rate of Climb	Kollsman
C-2	Vertical Speed Indicator	Kollsman
C2536310002	Vertical Speed Indicator	Kollsman
C2536310021	Vertical Speed Indicator	Kollsman
C3745110001	Vertical Speed Indicator	Kollsman
CM2633	IVSI	Kollsman
D07161-04-051	Vertical Speed Indicator	Kollsman
D07163 04 052	Vertical Speed Indicator	Kollsman
EA-1400	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-1	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-1-FU	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-1-ROB	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-1Z1	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-1ZL	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-1Z-ROB	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-2	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-2Z	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-6Z-GAF	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-7Z-SAB	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403-8Z-PA	Vertical Speed Indicator	Electric Auto-Lite Co

Primary Part Number	Nomenclature	Manufacture
EA-1403A-1ZL	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403A-1Z-ROB	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403A-2Z	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403A-6Z-GAF	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403A-7Z-SAB	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1403A-8Z-PA	Vertical Speed Indicator	Electric Auto-Lite Co

EA-1409-1	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409-1Z	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409-1ZL	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409-1ZL-BEL	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409-2ZL	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409-3Z	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409-4Z-CES	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409A-1Z	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409A-1ZL	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409A-1ZL-BEL	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409A-2ZL	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409A-3Z	Vertical Speed Indicator	Electric Auto-Lite Co
EA-1409A-4Z-CES	Vertical Speed Indicator	Electric Auto-Lite Co
G933-02-1A	Vertical Speed Indicator	Weston
G991-02-1A	Vertical Speed Indicator	Weston
ID-2277A/A	Vertical Speed Indicator	Astronautics
MS28049-1	Vertical Speed Indicator	Aerosonic
RC30V	Vertical Velocity Indicator	Aerosonic
RC30V10	Vertical Speed Indicator	Aerosonic
RC-30-V-10-1	Vertical Speed Indicator	Aerosonic
RC-30-VIL	Indicator	Aerosonic
RC-30-VIL-4	Vertical Velocity Indicator	Aerosonic
RC-30-V-LE	Vertical Speed Indicator	Aerosonic
RC-60	Vertical Speed Indicator	Aerosonic
RC-60MS	Vertical Speed Indicator	Aerosonic
RC-60MS-10-3	Vertical Speed Indicator	Aerosonic
RC-60MS-AAU-9/A	Vertical Speed Indicator	Aerosonic
RC-60-VIL-1	Vertical Speed Indicator	Aerosonic
RCS-60-IL	Vertical Speed Indicator	Aerosonic
SLZ8126	Vertical Speed Indicator	Teledyne
SLZ8826	Vertical Speed Indicator	Teledyne
SLZ9039	IVSI	Teledyne
SLZ9065	Vertical Speed Indicator	Teledyne
SLZ9066	Vertical Speed Indicator	Teledyne
SLZ9067	Vertical Speed Indicator	Teledyne
SLZ9068	Vertical Speed Indicator	Teledyne
SLZ9084	Vertical Speed Indicator	Teledyne
SLZ9085	Vertical Speed Indicator	Teledyne

Primary Part Number	Nomenclature	Manufacture
SLZ9123	Vertical Speed Indicator	Teledyne
SLZ9125	Vertical Speed Indicator	Teledyne
SLZ9125A	Vertical Speed Indicator	Teledyne
SLZ9127	Vertical Speed Indicator	Teledyne
SLZ9145	Vertical Speed Indicator	Teledyne
SLZ9155	IVSI	Teledyne
SLZ9157	Vertical Speed Indicator	Teledyne
SLZ9158	Vertical Speed Indicator	Teledyne
SLZ9190	Vertical Speed Indicator	Teledyne
SLZ9200	Vertical Speed Indicator	Teledyne

SLZ9211	Vertical Speed Indicator	Teledyne
SLZ9239	Vertical Speed Indicator	Teledyne
SLZ9244	Vertical Speed Indicator	Teledyne
SLZ9247	Vertical Speed Indicator	Teledyne
SLZ9248	Vertical Speed Indicator	Teledyne
SLZ9270	Vertical Speed Indicator	Teledyne
SLZ9392A	Vertical Speed Indicator	Teledyne
SLZ9410	Vertical Speed Indicator	Teledyne
SLZ9415	Vertical Speed Indicator	Teledyne
SLZ9416	Vertical Speed Indicator	Teledyne
SLZ9464A	Vertical Speed Indicator	Teledyne
SLZ9464A-1	Vertical Speed Indicator	Teledyne
SLZ9504A	Vertical Speed Indicator	Teledyne
SLZ9603	Vertical Speed Indicator	Teledyne
SLZ9620	Vertical Speed Indicator	Teledyne
SLZ9635	Vertical Speed Indicator	Teledyne
SLZ9638	Vertical Speed Indicator	Teledyne
SLZ9660	Vertical Speed Indicator	Teledyne
SLZ9669	Vertical Speed Indicator	Teledyne
SLZ9669-2	IVSI	Teledyne
SLZ96888A	Vertical Speed Indicator	Teledyne
SLZ9706	Vertical Speed Indicator	Teledyne
SLZ9832A	Vertical Speed Indicator	Teledyne
SLZ9845A	Vertical Speed Indicator	Teledyne
SLZ9851	Vertical Speed Indicator	Teledyne
SLZ9851-1	Vertical Speed Indicator	Teledyne
SP-1400	Vertical Speed Indicator	Standard Precision
WL-301RC-JA-1	Vertical Speed Indicator	Smith Industries
WL-301RC-MS-3	Vertical Speed Indicator	Smith Industries
WL-301RC-MS-4	Vertical Speed Indicator	Smith Industries
642-101000-11	INS Aural Warning Logic Unit	McDonnell Douglas/B
642-101000-21	INS Aural Warning Logic Unit	McDonnell Douglas/B
642-101000-31	INS Aural Warning Logic Unit	McDonnell Douglas/B
837976-1	Caution Panel	Teledyne

Primary Part Number	Nomenclature	Manufacture
837976-3	Caution Panel	Teledyne
837976-5	Caution Panel	Teledyne
837976-7	Caution Panel	Teledyne
837976-9	Caution Panel	Teledyne
H05A0035-1	Central Aural Warning System	McDonnell Douglas/B
H05A0035-10	Central Aural Warning System	McDonnell Douglas/B
H05A0035-3	Central Aural Warning System	McDonnell Douglas/B
H05A0035-4	Central Aural Warning System	McDonnell Douglas/B
H05A0035-5	Central Aural Warning System	McDonnell Douglas/B
H05A0035-51	Central Aural Warning System	McDonnell Douglas/B
H05A0035-52	Central Aural Warning System	McDonnell Douglas/B
H05A0035-53	Central Aural Warning System	McDonnell Douglas/B
H05A0040-1	Annunciator Control Unit	McDonnell Douglas/B
T321329	Flag Logic/Master Warning	Sperry

CAPABILITIES

Manufacturer

Aerosonic

Aerosonic
Aerosonic
Sundstrand Data Control, Inc.
Burton
Lear Siegler
Kollsman
Courter
Burton
Burton
Burton
Burton
Burton
Burton
Burton
Eclipse Pioneer
Pioneer
Pioneer
Pioneer
Pioneer
Eclipse Pioneer
Kollsman
Natec Electronic -- Natec / ASI
Kollsman
Kollsman
Kollsman
Kollsman
Kollsman
Honeywell
Honeywell
Sundstrand Data Control, Inc.
Giannini
Giannini
Honeywell
Honeywell
Honeywell
Honeywell
Honeywell
Honeywell
Honeywell

Bendix

r

r

r

r

r

r

:orp

:orp

r

r

r

r

r

r

r

r

r

r

r

r

r

: Corp.
: Corp.
: Corp.
: Corp.
: Corp.
: Corp.
: Corp.
: Corp.

: Corp.
: Corp.
: Corp.
: Corp.
: Corp.
: Corp.

: Corp.
: Corp.

r

r

ıs

ıs

ıs

ıs

ıs

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

ıents

ıents

r

r

r

r

on

on

r

r

r

r

r

r

r

r

r

r

r

e

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

e

r

e
e

r

ng

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

ıs

ıs

ıs

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

,

,

,
,
,

r

,

, Inc.
, Inc.
, Inc.
, Inc.
, Inc.
, Inc.

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

ıs

e
e
e
e
e

r

r

r

r

r

r

r

r

r

r

r

ıs

ıs

r

r

r

r

r

r

r

r

e

r

r

r

r

r

r

r

r

vell

r

e

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

e

r

r

r

e
e
e
e
e

e

r

e

e

e

e

e

e

e

e

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

e
e
e
e

r

r

ema
e
e

e

r

DIVISION
DIVISION

tes

r

ıc.

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

r

ng

r

r

r

stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems
stems

r

r

r

r

r

ng

r

r

r

r

r

r

r

r

r

r

r

r

r

r

c.

r

r

c.

r

r

r

r

r

Moore
Moore
Moore
Moore
Moore
Moore
Moore
Moore
Moore
Moore
Moore

Moore

Moore

Moore

Corp.
Corp.

Corp.

r

Corp.

r

r

r

Moore

r

r

r

Moore
Moore
Moore
Moore

r

r

r

r

ng
ng
ng
ng
ng
ng
ng
ng

ng
ng
ng
ng
ng
ng
ng
ng

ng
ng

ng
ng
ng
ng
ng
ng
g

ng
r

ng

ng
ng
ng

ng
King
ng
ng
ng
ng
ng
ng
ng
ng
ng
ng
ng
ng
ng
ng
ng
ng

ng
ng
ng
ng
ng

ng
ng
ng
ng

r

r

ng
ng
ng

r

ng

ng

r

ng

r

r

r

on

ns

r

Aerospace

r

c.
c.
c.
c.
c.

r

H

r

r

c.
c.
c.
c.

e
e
e

r

r

r

e
e
e

r

c.
c.
c.

e
e

r

s Company

e
e

r

r

c.

r

r

r

r

r

r

r

r

r

r

ogies
ogies
ogies

r

r

r

c.

c.

c.

c.

r

r

r

r

r

r

r

r

r

r

ıics

r

r

r

r

r

r

r

r

r

r

r

r

r

e
e
e
e

e
e
e
e
e
e
e

e
e

r

r

r

r

r

: Corp.

: Corp.

r

: Corp.

Boeing

r

r

r

Boeing
Boeing
Boeing

r

Boeing
Boeing
Boeing
Boeing
Boeing
Boeing
Boeing
Boeing
Boeing