



LIME DESCALER

LIME & SCALE REMOVER

Lime Descaler scale remover is a concentrated acidic liquid for use in dish machines to dissolve light to medium scale buildup. It contains surfactant and emulsifiers to penetrate and remove lime and other difficult deposits. It is also recommended for use on food service equipment such as: stainless steel, steam tables, food preparation equipment and coffee urns.

DIRECTIONS

Automatic Dish Machines:

1. Drain and clean out dish machine.
2. Set machine dispenser to the DELIME setting or cycle.
3. Close drain valve and fill tank with hot water.
4. Add Lime Descaler at 4-8 oz. per gallon of water.
5. Allow machine to run until lime deposits can be brushed or flushed away.
6. Rinse away residual lime deposits and drain tank.
7. Set dish machine to the RUN setting or cycle and use dish machine as normal.
8. For excessive lime buildup, pour ½ to 1 gallon of Lime Descaler into the wash tank and allow machine to run on the delime cycle.

Ice Machines: Leave pump operating but turn off refrigerator unit if possible. Drain unit and refill with water. Dilute Lime Descaler 32 oz. to 2/3 gallon of water. Add diluted cleaner to unit. Allow to circulate for about 45 minutes. If cleaner does not cover all surfaces, use clean bowl mop to coat all surfaces with solution. If scale is extra heavy, increase amount of cleaner up to one part Lime Descaler to one part water. After cleaning, drain unit a flush with clean water. Lime Descaler can be used as a hard surface delimer when diluted 2 to 4 oz. per gallon. Simply spray diluted mixture onto lime scale buildup, allow it to penetrate, and wipe off.

PHYSICAL PROPERTIES

Appearance: Clear Pink Liquid
Specific Gravity: 1.15
Odor: Characteristic
Ph (Conc.): 0-1
Flash Point: N/A

PACKAGING

This product is available in gallons,
5 gallon pails & 55 gallon drums

PRECAUTIONARY STATEMENT

Prevention: Wear eye protection/face protection. Wash hands and exposed skin thoroughly after handling. Wear protective gloves. **Response:** IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Immediately call a POISON CENTER/ doctor/ medical professional. IF ON SKIN: Wash with plenty of water for at least 15 minutes. Specific treatment (see section 4 on the Safety Data Sheet). If skin irritation occurs: Get medical advice/attention. Take off contaminated clothing and wash it before reuse.

