



Using PurTabs with the PX200 Electrostatic Sprayer

Please read the complete operation manual for detailed instructions and safety handling.

▶ STEP 1

Rotate the dial of the tank lock towards the unlock position. Pull the tank release ring and carefully remove the tank.

▶ STEP 3

Align tank grooves to sprayer; insert until release ring clicks into place. Secure by rotating tank dial to the "lock" position.

▶ STEP 2

Fill tank with warm water to the fill line. Drop **four (4) 3.3g PurTabs** tablets into the tank to achieve a **4306 ppm solution**. Allow 2-3 minutes to dissolve.

▶ STEP 4

Slide electrostatic component to the "On" position. Maintain a 2-3 ft. distance from the desired surface and spray.



4306 PPM



purtabs™
SANITIZING & DISINFECTION TABLETS BY EVACLEAN

