

GET STARTED

1 Connect the Mouse Mover to a 5V USB power source or the USB port on your PC.

2 Place the mouse on the spinning disc, ensuring the mouse sensor is on the disc.



Optional Settings

Activity (Arrow icon): Press Activity button to increase/ decrease random pauses between each disc spin, hence cursor movements on screen. Choose from 3 levels:

- High (LED turns **Red**): 10-12 seconds.
- Medium (LED turns **Blue**): 30-40 seconds.
- Low (LED turns **Green**): 50-60 seconds.

Note: Last used Activity setting is saved to device memory for next time the device is turned On.

Timer (Hourglass icon): Need to turn the Mouse Mover OFF after a certain time automatically? Press Timer button to cycle between 1 Hour (**Red**), 2 Hours (**Blue**) or Non-Stop (**Green**, default).

FAQs, Troubleshooting, Tips and Tricks at
tech8usa.com/demo

NEED HELP?

Resolution in minutes. Guaranteed.

Email

help@tech8usa.com

... or scan the QR code on the right to chat with us.

Chat



“ Amy with Tech8 USA customer service was amazing. She went above and beyond to address my concerns and resolve the issue quickly! Thank You! ”



TIPS & TRICKS

Watch quick video demo

SCAN ME



FAQs, Troubleshooting, Tips and Tricks at
tech8usa.com/demo

FAQs

1. What does the Mouse Mover do?

The Mouse Mover prevents your computer from going to sleep by randomly moving your optical mouse. It prevents "Away" status on Team Lync, Zoom, Skype, WebEx etc.

2. Does it work with all mouse types?

Yes! Mouse Mover has been tested on most popular PC optical, laser, wired and wireless mouse. Also, it can accommodate most sizes.

3. Is there any software to install?

No, there is no software to install. The Mouse Mover only draws 5V power from the USB port of your PC. Alternatively, it can be plugged into a phone charger.

4. How often will my mouse move?

Depending on the "Activity" level set, the spinning disc (thus your mouse), will pause for different lengths of time. e.g. Red is 10-12 seconds, Blue is 30-40 seconds, and Green is 50-60 seconds pause between each spin.

5. Can this be detected by my IT?

No. Tech8 Mouse Mover is a "mechanical device" and imitates a human physically moving the mouse. There are no software to install. Also, since our device does not have any data pins, you can even plug the device directly into the USB port of your PC, and it won't be visible in your "Device Manager".

6. What about Returns and Replacements?

No problem! Contact us at help@tech8usa.com with your order number.

7. Is Tech8 USA an American company?

Yes, we are an American company created, set up and incorporated in Austin, and take pride in our roots and heritage.

FAQs, Troubleshooting, Tips and Tricks at
tech8usa.com/demo

FEATURED IN



BuzzFeed

SLATE

DailyMail.com

VICE



The Guardian



If your boss is a micro-manager who doesn't realize that presence does **not** equal productivity, this is the device. If you are one of those bosses reading this review... no one likes you.



Invented, Patented, Trademarked,
Designed, Engineered & Packaged in
USA



tech8usa.com

Life
is about
Balance

World's Most Beautiful Mouse Mover
Dual Disc - Twister