

LWAD DEVICE USER GUIDE, model: LAX-G-SAFE (Lone Worker Alert Device)

**1. TAKE THE LWAD DEVICE**

A USB magnetic charging cable is supplied with each LWAD device.



**2. TURN ON LWAD DEVICE press the lower button on the right side for 2 seconds**

The screen will light up and display:

- The battery percentage
- Cellular connection
- Today's date



**3. WEARING THE DEVICE**

Insert the device in the neoprene pouch and attached to belt or clip on your clothes **OR** use the Velcro fastener already installed and attached to your belt or other place on your clothes.



**4. SOS CALL BUTTON**

Press the SOS Button for 3 seconds. You will hear a beep sound, SOS will display on screen and a vibration will occur, **First an alert will be sent with all info and then after 10 seconds the device will dial the SOS call.**



**5. MANDOWN DETECTION**

If the DEVICE detects the criteria of a fall, the device will beep and display MD on screen. An alert will be sent with all info and **then after a few seconds the device will create a call to responder.**



The device does not detect 100% of falls, during a real fall, if no call is done after a few seconds, press the SOS button. If the device is too sensitive notify us and we will modify it.

**6. CHARGING YOUR DEVICE \*IMPORTANT\***

At the end of each shift, put the magnetic cable connection **on the back of the device (magnetic side)** make sure that you check the screen that it indicates charging.

