



# WI-FI ROUTER SETTINGS

For the correct operation of the remote diagnostics application you are advised to perform following TCP/UDP port settings in your WiFi router. Open outgoing TCP/UDP ports:

**443** user interfacing

**10001** user interfacing

**46329** (CAN Bus data -AES encrypted)

**Alternatively if port 46329 fails:** 80 (optional, port 80 is fall-back for port 46329, CAN Bus data - AES encrypted)

The wifi security should be set to **WPA/WPA2**.

The A1 Remote Interface only supports a network band of **2.4GHz**

