

WHAT SETS US APART:

EXTREME DURABILITY

- IMPACT RESISTANCE
(MEDIUM & HIGH AVAILABLE)
- BLEACH CLEANABLE
- UV PROTECTED
- MARKER RESISTANT
- NOT EASILY CHIPPED
- SCRATCH RESISTANT
- STAIN RESISTANT



STAIN RESISTANCE:

Reagent	Score	Effect
Acetone	0	ME
Ammonia	0	N
Hot Coffee	0	N
Hot Tea	0	N
Tomato Catsup	1	N
Yellow Mustard	3	N
Iodine	4	ME
Wax Crayon		N
White Out	4	SE
Marker	3	N
Ball Point Ink	3	N
Cola Beverage	0	N
100-Proof Alcohol	0	N
Vinegar	0	N
Dry Erase Marker	1	N
Nail Polish	0	SL
Lipstick	1	N
Olive Oil	0	N
Distilled Water	0	N
10% Bleach Mix	0	N

Effect:

See NRRI/TR-2005/33 for full description
 N= No Effect
 SL= Slight Effect
 ME= Moderate Effect
 SE= Severe Effect

Cleaning Steps:

See NRRI/TR-2005/33 for full description
 0= Removed with water
 1= 25 cycles spray cleaner or sponge
 2= 25 cycles baking soda plus spray cleaner on brush
 3= Acetone and cotton ball
 4= Bleach plus cotton ball
 5= Not removed



SAFELY CLEANED & DISINFECTED WITH THE FOLLOWING:

- Asepticare TB-II
- Bleach 5:1
- Bleach-Rite® disinfecting spray
- Cavicide® surface disinfectant
- Citrace® germicide
- Clorox® germicidal wipes
- Dispatch® spray hospital cleaner disinfectant with bleach
- Fade-A-Dyne® stain remover
- Lysol® spray disinfectant
- Precise™ hospital cleaner
- PDI® Super Sani-Cloth® germicidal wipes
- PDI Sani-Cloth HB germicidal wipes
- PDI Sani-Cloth Plus germicidal wipes
- SaniZide Plus® germicidal solution
- Virex® II 256 cleaner
- Virox® AHP 5 disinfectant cleaner surface wipes



DURABILITY – FAR SUPERIOR TO HP LAMINATE:

TEST	FILM	HPL
Hoffman (Scratch)	1300 g	1000 g
NEMA Wear (Abrasion)	750 cycles	300 cycles
NEMA Ball (Impact)	3000 mm	1100 mm