

## **PEDIGROOM WALL-MOUNTED DOUBLE MOTOR DRYER OPERATOR INSTRUCTIONS**

### **Before Use**

- Brush coat and towel-dry pet
- Check hose/nozzle are secure
- Ensure air filter is clean

### **Start**

1. Switch **Motor 1 ON**
2. Start on **low airflow**
3. Switch **Motor 2 ON** if needed
4. Use **heat only if fitted & required**

### **During Drying**

- Hold nozzle **20–40 cm** from coat
- Keep airflow moving at all times
- Avoid face, ears, eyes & genitals
- Never leave pet unattended

### **Stop**

1. Turn **heat OFF**
2. Switch motors **OFF**
3. Allow unit to cool

### **Safety**

- Indoor use only
- Do not block air intake
- Stop immediately if pet shows distress