



3-Stage Sequencing Halo LED Tail lights for C5

IMPORTANT!!!

- The hyperflash harness must be installed for correct function. See [this link](#) for installation:
- One light on each side is designated the “Master”. The connector on the master light has a “X” engraved on one side of the connector. When connecting to the factory socket the “X” should be oriented so that it is on the wire side of the socket (see picture)
- The other light needs to be connected to the master. It must be plugged into the master the sequencing function. There is a multi-pin connector that links the master and control lights. Connect these connectors and the factory connector and verify function using both the hazard switch to test the sequencing function and parking lights to check the Halo function.

