

Thermodynamic cycle

42 languages

Article

Talk

Read

Edit

View history

Tools

From Wikipedia, the free encyclopedia

A **thermodynamic cycle** consists of linked sequences of [thermodynamic processes](#) that involve [transfer of heat](#) and [work](#) into and out of the system, while varying pressure, temperature, and other [state variables](#) within the system, and that eventually returns the [system](#) to its initial state.^[1] In the process of passing through a cycle, the working fluid (system) may convert heat from a warm source into useful work, and dispose of the remaining heat to a cold sink, thereby acting as a [heat engine](#). Conversely, the cycle may be reversed and use work to move heat from a cold source and transfer it to a warm sink thereby acting as a [heat pump](#). If at every point in the cycle the system is in [thermodynamic equilibrium](#), the cycle is reversible. Whether carried out reversibly or irreversibly, the net [entropy](#) change of the system is zero, as entropy is a [state function](#).

During a closed cycle, the system returns to its original thermodynamic state of temperature and pressure. [Process quantities](#) (or path quantities), such as [heat](#) and [work](#) are process dependent. For a cycle for which the system returns to its initial state the [first law of thermodynamics](#) applies:

$$\Delta U = E_{in} - E_{out} = 0$$

The above states that there is no change of the internal energy (*U*) of the system over the cycle. *E_{in}* represents the total work and heat input during the cycle and *E_{out}* would be the total work and heat output during the cycle. The repeating nature of the process path allows for continuous operation, making the cycle an important concept in [thermodynamics](#). Thermodynamic cycles are often represented mathematically as [quasistatic processes](#) in the modeling of the workings of an actual device.

Heat and work [edit]

Two primary classes of thermodynamic cycles are **power cycles** and **heat pump cycles**. Power cycles are cycles which convert some heat input into a [mechanical work](#) output, while heat pump cycles transfer heat from low to high temperatures by using mechanical work as the input. Cycles composed entirely of quasistatic processes can operate as power or heat pump cycles by controlling the process direction. On a [pressure–volume \(PV\) diagram](#) or [temperature–entropy diagram](#), the [clockwise and counterclockwise](#) directions indicate power and heat pump cycles, respectively.

Relationship to work [edit]

Because the net variation in state properties during a thermodynamic cycle is zero, it forms a closed loop on a [PV diagram](#). A PV diagram's Y axis shows pressure (*P*) and X axis shows volume (*V*). The area enclosed by the loop is the work (*W*) done by the process:

(1)
$$W = \oint P \, dV$$

This work is equal to the balance of heat (*Q*) transferred into the system:

(2)
$$W = Q = Q_{in} - Q_{out}$$

Equation (2) is consistent with the First Law; even though the internal energy changes during the course of the cyclic process, when the cyclic process finishes the system's internal energy is the same as the energy it had when the process began.


If the cyclic process moves clockwise around the loop, then *W* will be positive, and it represents a [heat engine](#). If it moves counterclockwise, then *W* will be negative, and it represents a [heat pump](#).

A list of thermodynamic processes [edit]

The following processes are often used to describe different stages of a thermodynamic cycle:

- Adiabatic** : No energy transfer as heat (*Q*) during that part of the cycle (**δ*Q* = 0**). Energy transfer is considered as work done by the system only.

Thermodynamics



The classical Carnot heat engine

Branches

show

Laws

show

Systems

show

System properties

show

Material properties

show

Equations

show

Potentials

show

HistoryCulture


show

Scientists


show

Other

show


 Category

VTE



- **Isothermal** : The process is at a constant temperature during that part of the cycle ($T=\text{constant}$, $\delta T = 0$). Energy transfer is considered as heat removed from or work done by the system.
- **Isobaric** : Pressure in that part of the cycle will remain constant. ($P=\text{constant}$, $\delta P = 0$). Energy transfer is considered as heat removed from or work done by the system.
- **Isochoric** : The process is constant volume ($V=\text{constant}$, $\delta V = 0$). Energy transfer is considered as heat removed from the system, as the work done by the system is zero.
- **Isentropic** : The process is one of constant entropy ($S=\text{constant}$, $\delta S = 0$). It is adiabatic (no heat nor mass exchange) and reversible.
- **Isenthalpic** : The process that proceeds without any change in enthalpy or specific enthalpy.
- **Polytropic** : The process that obeys the relation $pV^n = C$.
- **Reversible** : The process where the net entropy production is zero; $dS - \frac{dQ}{T} = 0$.

Example: The Otto cycle [[edit](#)]




The **Otto Cycle** is an example of a reversible thermodynamic cycle.

- 1→2: **Isentropic / adiabatic expansion**: Constant **entropy** (s), Decrease in **pressure** (P), Increase in **volume** (v), Decrease in **temperature** (T)
- 2→3: **Isochoric cooling**: Constant volume (v), Decrease in pressure (P), Decrease in entropy (S), Decrease in temperature (T)
- 3→4: **Isentropic / adiabatic compression**: Constant entropy (s), Increase in pressure (P), Decrease in volume (v), Increase in temperature (T)
- 4→1: **Isochoric heating**: Constant volume (v), Increase in pressure (P), Increase in entropy (S), Increase in temperature (T)

Power cycles [[edit](#)]

Main article: [Heat engine](#)

Thermodynamic power cycles are the basis for the operation of heat engines, which supply most of the world's **electric power** and run the vast majority of **motor vehicles**. Power cycles can be organized into two categories: real cycles and ideal cycles. Cycles encountered in real world devices (real cycles) are difficult to analyze because of the presence of complicating effects (friction), and the absence of sufficient time for the establishment of equilibrium conditions. For the purpose of analysis and design, idealized models (ideal cycles) are created; these ideal models allow engineers to study the effects of major parameters that dominate the cycle without having to spend significant time working out intricate details present in the real cycle model.



Power cycles can also be divided according to the type of heat engine they seek to model. The most common cycles used to model **internal combustion engines** are the **Otto cycle**, which models **gasoline engines**, and the **Diesel cycle**, which models **diesel engines**. Cycles that model **external combustion engines** include the **Brayton cycle**, which models **gas turbines**, the **Rankine cycle**, which models **steam turbines**, the **Stirling cycle**, which models **hot air engines**, and the **Ericsson cycle**, which also models hot air engines.

For example :--the pressure-volume **mechanical work** output from the ideal Stirling cycle (net work out), consisting of 4 thermodynamic processes, is^{[[citation needed](#)][[dubious](#) – [discuss](#)]}:

$$(3) \quad W_{\text{net}} = W_{1 \rightarrow 2} + W_{2 \rightarrow 3} + W_{3 \rightarrow 4} + W_{4 \rightarrow 1}$$


$$W_{1 \rightarrow 2} = \int_{V_1}^{V_2} P dV, \text{ negative, work done on system}$$

$$W_{2 \rightarrow 3} = \int_{V_2}^{V_3} P dV, \text{ zero work since } V_2 = V_3$$

$$W_{3 \rightarrow 4} = \int_{V_3}^{V_4} P dV, \text{ positive, work done by system}$$

$$W_{4 \rightarrow 1} = \int_{V_4}^{V_1} P dV, \text{ zero work since } V_4 = V_1$$

For the ideal Stirling cycle, no volume change happens in process 4-1 and 2-3, thus equation (3) simplifies to:




$$(4) \quad W_{\text{net}} = W_{1 \rightarrow 2} + W_{3 \rightarrow 4}$$

Heat pump cycles [edit]

Main article: [Heat pump and refrigeration cycle](#)


Thermodynamic heat pump cycles are the [models](#) for household [heat pumps](#) and [refrigerators](#). There is no difference between the two except the purpose of the refrigerator is to cool a very small space while the household heat pump is intended to warm or cool a house. Both work by moving heat from a cold space to a warm space. The most common refrigeration cycle is the [vapor compression cycle](#), which models systems using [refrigerants](#) that change phase. The [absorption refrigeration cycle](#) is an alternative that absorbs the refrigerant in a liquid solution rather than evaporating it. Gas refrigeration cycles include the reversed Brayton cycle and the [Hampson–Linde cycle](#). Multiple compression and expansion cycles allow gas refrigeration systems to [liquify gases](#).

Modeling real systems [edit]



Thermodynamic cycles may be used to model real devices and systems, typically by making a series of assumptions.^[2] simplifying assumptions are often necessary to reduce the problem to a more manageable form.^[2] For example, as shown in the figure, devices such a [gas turbine](#) or [jet engine](#) can be modeled as a [Brayton cycle](#). The actual device is made up of a series of stages, each of which is itself modeled as an idealized thermodynamic process. Although each stage which acts on the working fluid is a complex real device, they may be modelled as idealized processes which approximate their real behavior. If energy is added by means other than combustion, then a further assumption is that the exhaust gases would be passed from the exhaust to a heat exchanger that would sink the waste heat to the environment and the working gas would be reused at the inlet stage.

The difference between an idealized cycle and actual performance may be significant.^[2] For example, the following images illustrate the differences in work output predicted by an ideal [Stirling cycle](#) and the actual performance of a Stirling engine:



As the net work output for a cycle is represented by the interior of the cycle, there is a significant difference between the predicted work output of the ideal cycle and the actual work output shown by a real engine. It may also be observed that the real individual processes diverge from their idealized counterparts; e.g., isochoric expansion (process 1-2) occurs with some actual volume change.

Well-known thermodynamic cycles [edit]

In practice, simple idealized thermodynamic cycles are usually made out of four [thermodynamic processes](#). Any thermodynamic processes may be used. However, when idealized cycles are modeled, often processes where one state variable is kept constant, such as:

- [adiabatic](#) (constant heat)
- [isothermal](#) (constant temperature)
- [isobaric](#) (constant pressure)
- [isochoric](#) (constant volume)
- [isentropic](#) (constant entropy)
- [isenthalpic](#) (constant enthalpy)

Some example thermodynamic cycles and their constituent processes are as follows:

Cycle	Compression, 1→2	Heat addition, 2→3	Expansion, 3→4	Heat rejection, 4→1	Notes
Power cycles normally with external combustion - or heat pump cycles:					
Bell Coleman	adiabatic	isobaric	adiabatic	isobaric	A reversed Brayton cycle
Carnot	isentropic	isothermal	isentropic	isothermal	Carnot heat engine
Ericsson	isothermal	isobaric	isothermal	isobaric	The second Ericsson cycle from 1853
Rankine	adiabatic	isobaric	adiabatic	isobaric	Steam engines
Hygroscopic	adiabatic	isobaric	adiabatic	isobaric	
Scuderi	adiabatic	variable pressure and volume	adiabatic	isochoric	
Stirling	isothermal	isochoric	isothermal	isochoric	Stirling engines
Manson	isothermal	isochoric	isothermal	isochoric then adiabatic	Manson and Manson-Guise engines
Stoddard	adiabatic	isobaric	adiabatic	isobaric	
Power cycles normally with internal combustion :					
Atkinson	isentropic	isochoric	isentropic	isochoric	Differs from Otto cycle in that $V_1 < V_4$.
Brayton	adiabatic	isobaric	adiabatic	isobaric	Ramjets , turbojets , -props , and -shafts . Originally developed for use in reciprocating engines. The external combustion version of this cycle is known as the first Ericsson cycle from 1833.
Diesel	adiabatic	isobaric	adiabatic	isochoric	Diesel engine
Humphrey	isentropic	isochoric	isentropic	isobaric	Shcramjets , pulse- and continuous detonation engines
Lenoir		isochoric	adiabatic	isobaric	Pulse jets . Note that 1→2 accomplishes both the heat rejection and the compression. Originally developed for use in reciprocating engines.
Otto	isentropic	isochoric	isentropic	isochoric	Gasoline / petrol engines

Ideal cycle [\[edit \]](#)

An ideal cycle is simple to analyze and consists of:

1. TOP (A) and BOTTOM (C) of the loop: a pair of parallel **isobaric** processes
2. RIGHT (B) and LEFT (D) of the loop: a pair of parallel **isochoric** processes


If the working substance is a [perfect gas](#), U is only a function of T for a closed system since its [internal pressure](#) vanishes. Therefore, the internal energy changes of a perfect gas undergoing various processes connecting initial state a to final state b are always given by the formula

$$\Delta U = \int_a^b C_v dT$$

Assuming that C_v is constant, $\Delta U = C_v \Delta T$ for any process undergone by a perfect gas.

Under this set of assumptions, for processes A and C we have $W = p\Delta v$ and $Q = C_p \Delta T$, whereas for processes B and D we have $W = 0$ and $Q = \Delta U = C_v \Delta T$.

The total work done per cycle is $W_{cycle} = p_A(v_2 - v_1) + p_C(v_4 - v_3) = p_A(v_2 - v_1) + p_C(v_1 - v_2) = (p_A - p_C)(v_2 - v_1)$, which is just the area of the rectangle. If the total heat flow per cycle is required, this is easily obtained. Since $\Delta U_{cycle} = Q_{cycle} - W_{cycle} = 0$, we have $Q_{cycle} = W_{cycle}$.



Thus, the total heat flow per cycle is calculated without knowing the heat capacities and temperature changes for each step (although this information would be needed to assess the [thermodynamic efficiency](#) of the cycle).

Carnot cycle [\[edit \]](#)

Main article: [Carnot cycle](#)

The [Carnot cycle](#) is a cycle composed of the totally [reversible processes](#) of [isentropic](#) compression and expansion and [isothermal](#) heat addition and rejection. The [thermal efficiency](#) of a Carnot cycle depends only on the absolute temperatures of the two reservoirs in which heat transfer takes place, and for a power cycle is:

$$\eta = 1 - \frac{T_L}{T_H}$$

where T_L is the lowest cycle temperature and T_H the highest. For Carnot power cycles the [coefficient of performance](#) for a [heat pump](#) is:

$$COP = 1 + \frac{T_L}{T_H - T_L}$$

and for a [refrigerator](#) the coefficient of performance is:

$$COP = \frac{T_L}{T_H - T_L}$$

The second law of thermodynamics limits the efficiency and COP for all cyclic devices to levels at or below the Carnot efficiency. The [Stirling cycle](#) and [Ericsson cycle](#) are two other reversible cycles that use regeneration to obtain isothermal heat transfer.

Stirling cycle [\[edit \]](#)

Main article: [Stirling cycle](#)

A Stirling cycle is like an Otto cycle, except that the adiabats are replaced by isotherms. It is also the same as an Ericsson cycle with the isobaric processes substituted for constant volume processes.

1. TOP and BOTTOM of the loop: a pair of quasi-parallel **isothermal** processes
2. LEFT and RIGHT sides of the loop: a pair of parallel **isochoric** processes

Heat flows into the loop through the top isotherm and the left isochore, and some of this heat flows back out through the bottom isotherm and the right isochore, but most of the heat flow is through the pair of isotherms. This makes sense since all the work done by the cycle is done by the pair of isothermal processes, which are described by $Q=W$. This suggests that all the net heat comes in through the top isotherm. In fact, all of the heat which comes in through the left isochore comes out through the right isochore: since the top isotherm is all at the same warmer temperature T_H and the bottom isotherm is all at the same cooler temperature T_C , and since change in energy for an isochore is proportional to change in temperature, then all of the heat coming in through the left isochore is cancelled out exactly by the heat going out the right isochore.

State functions and entropy [\[edit \]](#)

If Z is a [state function](#) then the balance of Z remains unchanged during a cyclic process:

$$\oint dZ = 0.$$

Entropy is a state function and is defined in an absolute sense through the [Third Law of Thermodynamics](#) as

$$S = \int_0^T \frac{dQ_{rev}}{T}$$

where a reversible path is chosen from [absolute zero](#) to the final state, so that for an isothermal reversible process

$$\Delta S = \frac{Q_{rev}}{T}.$$

In general, for any cyclic process the state points can be connected by reversible paths, so that

$$\oint dS = \oint \frac{dQ_{rev}}{T} = 0$$

meaning that the net entropy change of the working fluid over a cycle is zero.