

NATIONAL HIGHWAY INSTITUTE SOILS & FOUNDATIONS: STRESS & STRAIN IN SOILS

Main Category:	Civil Engineering
Sub Category:	Geotechnical Engineering
Course #:	GEO-114
Course Content:	104 pgs
PDH/CE Hours:	9

OFFICIAL COURSE/EXAM (SEE INSTRUCTIONS ON NEXT PAGE)

<u>WWW.ENGINEERING-PDH.COM</u> TOLL FREE (US & CA): 1-833-ENGR-PDH (1-833-364-7734) <u>SUPPORT@ENGINEERING-PDH.COM</u>

GEO-114 EXAM PREVIEW

- TAKE EXAM! -

Instructions:

- At your convenience and own pace, review the course material below. When ready, click "Take Exam!" above to complete the live graded exam. (Note it may take a few seconds for the link to pull up the exam.) You will be able to re-take the exam as many times as needed to pass.
- Upon a satisfactory completion of the course exam, which is a score of 70% or better, you will be provided with your course completion certificate. Be sure to download and print your certificates to keep for your records.

Exam Preview:

- 1. The engineering analysis of soils is often more complex than the analysis of other construction materials because soil is not a continuum.
 - a. True
 - b. False
- 2. A great deal of geotechnical information can and should be gathered during the construction phase of a project to validate or revise the geotechnical design parameters. A geotechnical design is considered complete wen construction starts.
 - a. True
 - b. False
- 3. Which activity is the last step of the activity flowchart for a typical Geotechnical design-bid-build project?
 - a. Troubleshoot Construction Problems
 - b. Establish Construction Quality Assurance Criteria & Monitoring Program
 - c. Prepare Project-specific Special Provisions
 - d. Provide Post-Construction Services such as Instrumentation Monitoring
- 4. Which phase of Geotechnical Engineer involvement in a project would be to review final plans & make appropriate adjustments to geotechnical information if necessary.
 - a. 1
 - b. 3
 - c. 4
 - d. 6

- 5. The volumes and weights of the different phases of matter in a soil mass can be represented by a block diagram which also known as a:
 - a. Gannt Diagram
 - b. Phase Diagram
 - c. Flow Diagram
 - d. Stress Diagram
- 6. Which soil property defines relative volume of voids to total volume of soil?
 - a. Porosity
 - b. Void Ratio
 - c. Moisture Content
 - d. Specific Gravity
- 7. Moisture content is used for soil classification & in weight volume relations.
 - a. True
 - b. False
- 8. The solid phase of soil is composed of soil grains. Particles having sizes larger than the No. _____ sieve are termed "coarse-grained".
 - a. 100
 - b. 200
 - **c.** 300
 - d. 400
- Uniformly Loaded Continuous (Strip) and Square Footings A loaded area is considered to be infinitely long when its length, L, to width, B, ratio is greater than or equal to 100, i.e., L/B ≥ 100.
 - a. True
 - b. False
- 10. Effect of Shear Strength of Soils on Lateral Pressures Elastic theory, when suitably modified to reflect observed phenomena in soils, provides a tool to obtain a reasonable first approximation to a solution for many problems in geotechnical engineering. However, elastic theory does not recognize the role of shear strength of soil in the development of lateral pressures.
 - a. True
 - b. False



Publication No. FHWA NHI-06-088 December 2006

NHI Course No. 132012

SOILS AND FOUNDATIONS

Reference Manual – Volume I - Ch.2 STRESS & STRAIN

IN SOILS





National Highway Institute

ENGINEERING-PDH.COM | GEO-114 |

NOTICE

The contents of this report reflect the views of the authors, who are responsible for the facts and the accuracy of the data presented herein. The contents do not necessarily reflect policy of the Department of Transportation. This report does not constitute a standard, specification, or regulation. The United States Government does not endorse products or manufacturers. Trade or manufacturer's names appear herein only because they are considered essential to the objective of this document.

Technical Report Documentation Page

	100	linncar N	eport Document	auon i age		
1. Report No.	2. Government Accession No.	3. Recip	ient's Catalog No.			
FHWA-NHI-06-088						
4. Title and Subtitle		5. Repor	t Date			
	Dece	ember 2006				
SOILS AND FOUNDATIONS	6. Perfor	ming Organization C	ode			
REFERENCE MANUAL – Volum						
7. Author(s)	8. Perfor	ming Organization R	eport No.			
Naresh C. Samtani*, PE, PhD and E	Edward A. Nowatzki*, PE, PhD					
9. Performing Organization Name and According Inc.	ddress	10. Worl	k Unit No. (TRAIS)			
2190 Leyland Alcove Woodbury	MN 55125					
* NCS GeoResources LLC		11. Cont	ract or Grant No.			
640 W Paseo Rio Grande, Tucso	on, AZ 85737	DTI	FH-61-02-T-6301	6		
12. Sponsoring Agency Name and Addre	SS	13. Type	of Report and Period	d Covered		
National Highway Institute						
U.S. Department of Transportation	1	14. Spon	soring Agency Code			
Federal Highway Administration,	Washington, D.C. 20590					
15. Supplementary Notes						
FHWA COTR – Larry Jones						
FHWA Technical Review – Jer	ry A. DiMaggio, PE; Silas Nicho	ols, PE; R	ichard Cheney, P	E;		
Be Contractor Technical Paviau - Pu	njamin Rivers, PE; Justin Henwo	od, PE.) . .			
Ba	rrv R. Christopher, PhD, PE	18, F IID, F	L,			
This manual is an update of the 3^{rd} Ea	lition prepared by Parsons Brincker	hoff Quade	e & Douglas, Inc, in	n 2000.		
Author: Richard Cheney, PE. The authors of the 1^{st} and 2^{nd} editions prepared by the FHWA in 1982 and 1993,						
respectively, were Richard Cheney, PE and Ronald Chassie, PE.						
16. Abstract						
The Reference Manual for Soils and Fo	oundations course is intended for designed	gn and cons	struction profession	als involved		
geared towards practitioners who routi	inely deal with soils and foundations	ice transpo issues but	who may have little	e theoretical		
background in soil mechanics or found	lation engineering. The manual's co	ntent follo	ws a project-oriente	ed approach		
where the geotechnical aspects of a	project are traced from preparation	n of the b	oring request thro	ugh design		
computation of settlement, allowable	e footing pressure, etc., to the cons	truction o	f approach emban	kments and		
Recommendations are presented on 1	how to layout borings efficiently, h	low to mi	nimize approach ei	mbankment		
settlement, how to design the most	cost-effective pier and abutment for	oundations	, and how to trans	smit design		
information properly through plans, sp	pecifications, and/or contact with the	project eng	gineer so that the pro-	oject can be		
consulucieu efficientiy.						
The objective of this manual is to prese	nt recommended methods for the safe	, cost-effe	ctive design and con	struction of		
geotechnical features. Coordination between geotechnical specialists and project team members at all phases of a project is stressed. Readers are appouraged to develop an appreciation of geotechnical activities in all project phases						
that influence or are influenced by their work.						
17. Key Words 18.Distribution Statement						
Subsurface exploration, testing, slope foundations, driven piles, drilled shaft	stability, embankments, cut slopes,	shallow ction	No restrict	ions.		
19. Security Classif. (of this report)	20. Security Classif. (of this page)		21. No. of Pages	22. Price		
			100			
UNCLASSIFIED	UNCLASSIFIED		462			

Form DOT F 1700.7(8-72)

Reproduction of completed page authorized

[THIS PAGE INTENTIONALLY BLANK]

PREFACE

This update to the Reference Manual for the Soils and Foundations course was developed to incorporate the guidance available from the FHWA in various recent manuals and Geotechnical Engineering Circulars (GECs). The update has evolved from its first two versions prepared by Richard Cheney and Ronald Chassie in 1982 and 1993, and the third version prepared by Richard Cheney in 2000.

The updated edition of the FHWA Soils and Foundations manual contains an enormous amount of information ranging from methods for theoretically based analyses to "rules of thumb" solutions for a wide range of geotechnical and foundation design and construction issues. It is likely that this manual will be used nationwide for years to come by civil engineering generalists, geotechnical and foundation specialists, and others involved in transportation facilities. That being the case, the authors wish to caution against indiscriminate use of the manual's guidance and recommendations. The manual should be considered to represent the minimum standard of practice. The user must realize that there is no possible way to cover all the intricate aspects of any given project. Even though the material presented is theoretically correct and represents the current state-of-the-practice, engineering judgment based on local conditions and knowledge must be applied. This is true of most engineering disciplines, but it is especially true in the area of soils and foundation engineering and construction. For example, the theoretical and empirical concepts in the manual relating to the analysis and design of deep foundations apply to piles installed in the glacial tills of the northeast as well as to drilled shafts installed in the cemented soils of the southwest. The most important thing in both applications is that the values for the parameters to be used in the analysis and design be selected by a geotechnical specialist who is intimately familiar with the type of soil in that region and intimately knowledgeable about the regional construction procedures that are required for the proper installation of such foundations in local soils.

General conventions used in the manual

This manual addresses topics ranging from fundamental concepts in soil mechanics to the practical design of various geotechnical features ranging from earthworks (e.g., slopes) to foundations (e.g., spread footings, driven piles, drilled shafts and earth retaining structures). In the literature each of these topics has developed its own identity in terms of the terminology and symbols. Since most of the information presented in this manual appears in other FHWA publications, textbooks and publications, the authors faced a dilemma on the regarding terminology and symbols as well as other issues. Following is a brief discussion on such issues.

• Pressure versus Stress

The terms "pressure" and "stress" both have units of force per unit area (e.g., pounds per square foot). In soil mechanics "pressure" generally refers to an applied load distributed over an area or to the pressure due to the self-weight of the soil mass. "Stress," on the other hand, generally refers to the condition induced at a point within the soil mass by the application of an external load or pressure. For example, "overburden pressure," which is due to the self weight of the soil, induces "geostatic stresses" within the soil mass. Induced stresses cause strains which ultimately result in measurable deformations that may affect the behavior of the structural element that is applying the load or pressure. For example, in the case of a shallow foundation, depending upon the magnitude and direction of the applied loading and the geometry of the footing, the pressure distribution at the base of the footing can be uniform, linearly varying, or non-linearly varying. In order to avoid confusion, the terms "pressure" and "stress" will be used interchangeably in this manual. In cases where the distinction is important, clarification will be provided by use of the terms "applied" or "induced."

• Symbols

Some symbols represent more than one geotechnical parameter. For example, the symbol C_c is commonly used to identify the coefficient of curvature of a grain size distribution curve as well as the compression index derived from consolidation test results. Alternative symbols may be chosen, but then there is a risk of confusion and possible mistakes. To avoid the potential for confusion or mistakes, the Table of Contents contains a list of symbols for each chapter.

• Units

English units are the primary units in this manual. SI units are included in parenthesis in the text, except for equations whose constants have values based on a specific set of units, English or SI. In a few cases, where measurements are conventionally reported in SI units (e.g., aperture sizes in rock mapping), only SI units are reported. English units are used in example problems. Except where the units are related to equipment sizes (e.g., drill rods), all unit conversions are "soft," i.e., approximate. Thus, 10 ft is converted to 3 m rather than 3.05 m. The soft conversion for length in feet is rounded to the nearest 0.5 m. Thus, 15 ft is converted to 4.5 m not 4.57 m.

• Theoretical Details

Since the primary purpose of this manual is to provide a concise treatment of the fundamental concepts in soil mechanics and an introduction to the practical design of various geotechnical features related to highway construction, the details of the theory underlying the methods of analysis have been largely omitted in favor of discussions on the application of those theories to geotechnical problems. Some exceptions to this general approach were made. For example, the concepts of lateral earth pressure and bearing capacity rely too heavily on a basic understanding of the Mohr's circle for stress for a detailed presentation of the Mohr's circle theory to be omitted. However, so as not to encumber the text, the basic theory of the Mohr's circle is presented in Appendix B for the reader's convenience and as an aid for the deeper understanding of the concepts of earth pressure and bearing capacity.

• Standard Penetration Test (SPT) N-values

The SPT is described in Chapter 3 of this manual. The geotechnical engineering literature is replete with correlations based on SPT N-values. Many of the published correlations were developed based on SPT N-values obtained with cathead and drop hammer methods. The SPT N-values used in these correlations do not take in account the effect of equipment features that might influence the actual amount of energy imparted during the SPT. The cathead and drop hammer systems typically deliver energy at an estimated average efficiency of 60%. Today's automatic hammers deliver energy at a significantly higher efficiency (up to 90%). When published correlations based on SPT N-values are presented in this manual, they are noted as N_{60} -values and the measured SPT N-values should be corrected for energy before using the correlations.

Some researchers developed correction factors for use with their SPT N-value correlations to address the effects of overburden pressure. When published correlations presented in this manual are based upon values corrected for overburden they are noted as $N1_{60}$. Guidelines are provided as to when the N_{60} -values should be corrected for overburden.

• Allowable Stress Design (ASD) and Load and Resistance Factor Design (LRFD) Methods

The design methods to be used in the transportation industry are currently (2006) in a state of transition from ASD to LRFD. The FHWA recognizes this transition and has developed separate comprehensive training courses for this purpose. Regardless of whether the ASD or LRFD is used, it is important to realize that the fundamentals of soil mechanics, such as the

determination of the strength and deformation of geomaterials do not change. The only difference between the two methods is the way in which the uncertainties in loads and resistances are accounted for in design. Since this manual is geared towards the fundamental understanding of the behavior of soils and the design of foundations, ASD has been used because at this time most practitioners are familiar with that method of design. However, for those readers who are interested in the nuances of both design methods Appendix C provides a brief discussion on the background and application of the ASD and LRFD methods.

ACKNOWLEDGEMENTS

The authors would like to acknowledge the following events and people that were instrumental in the development of this manual.

- Permission by the FHWA to adapt the August 2000 version of the Soils and Foundations Workshop Manual.
- Provision by the FHWA of the electronic files of the August 2000 manual as well as other FHWA publications.
- The support of Ryan R. Berg of Ryan R. Berg and Associates, Inc. (RRBA) in facilitating the preparation of this manual and coordinating reviews with the key players.
- The support provided by the staff of NCS Consultants, LLC, (NCS) Wolfgang Fritz, Juan Lopez and Randy Post (listed in alphabetical order of last names). They prepared some graphics, some example problems, reviewed selected data for accuracy with respect to original sources of information, compiled the Table of Contents, performed library searches for reference materials, and checked internal consistency in the numbering of chapter headings, figures, equations and tables.
- Discussions with Jim Scott (URS-Denver) on various topics and his willingness to share reference material are truly appreciated. Dov Leshchinsky of ADAMA Engineering provided copies of the ReSSA and FoSSA programs which were used to generate several figures in the manual as well as presentation slides associated with the course presentation. Robert Bachus of Geosyntec Consultants prepared Appendices D and E. Allen Marr of GeoComp Corporation provided photographs of some laboratory testing equipment. Pat Hannigan of GRL Engineers, Inc. reviewed the driven pile portion of Chapter 9. Shawn Steiner of ConeTec, Inc. and Salvatore Caronna of gINT Software prepared the Cone Penetration Test (CPT) and boring logs, respectively, shown in Chapter 3 and Appendix A. Robert (Bob) Meyers (NMDOT), Ted Buell (HDR-Tucson) and Randy Simpson (URS-Phoenix) provided comments on some sections (particularly Section 8.9).
- Finally, the technical reviews and recommendations provided by Jerry DiMaggio, Silas Nichols, Benjamin Rivers, Richard Cheney (retired) and Justin Henwood of the FHWA, Ryan Berg of RRBA, Robert Bachus of Geosyntec Consultants, Jim Scott of URS, and Barry Christopher of Christopher Consultants, Inc., are gratefully acknowledged.

SPECIAL ACKNOWLEDGEMENTS

A special acknowledgement is due of the efforts of Richard Cheney and Ronald Chassie for their work in the preparation of the previous versions of this manual. It is their work that made this course one of the most popular FHWA courses. Their work in developing this course over the past 25 years is acknowledged.

With respect to this manual, the authors wish to especially acknowledge the in-depth review performed by Jerry DiMaggio and time he spent in direct discussions with the authors and other reviewers. Such discussions led to clarification of some existing guidance in other FHWA manuals as well as the introduction of new guidance in some chapters of this manual.

SI CONVERSION FACTORS						
	APPROXIMA	ATE CONVERSION	S FROM SI UNITS			
Symbol	When You	Multiply By	To Find	Symbol		
C C	Know			·		
		LENGTH				
mm	millimeters	0.039	inches	in		
m	meters	3.28	feet	ft		
m	meters	1.09	yards	yd		
km	kilometers	0.621	miles	mi		
	•	AREA	-	•		
mm^2	square millimeters	0.0015	square inches	in ²		
m ²	square meters	10.758	square feet	ft ²		
m^2	square meters	1.188	square yards	yd ²		
ha	hectares	2.47	acres	ac		
km ²	square kilometers	0.386	square miles	mi ²		
	•	VOLUME	• •	•		
ml	milliliters	0.034	fluid ounces	floz		
1	liters	0.264	gallons	gal		
m ³	cubic meters	35.29	cubic feet	ft ³		
m ³	cubic meters	1.295	cubic yards	vd ³		
		MASS	<u>۲</u>			
g	grams	0.035	ounces	OZ		
kg	kilograms	2.205	pounds	lb		
tonnes	tonnes	1.103	US short tons	tons		
		TEMPERATURE				
°C	Celsius	1.8°C + 32	Fahrenheit	°F		
	•	WEIGHT DENSIT	Y			
kN/m ³	kilonewtons / cubic	6.36	Pound force / cubic foot	pcf		
	meter					
	FC	ORCE and PRESSURE or	STRESS			
Ν	newtons	0.225	pound force	lbf		
kN	kilonewtons	225	pound force	lbf		
kPa	kilopascals	0.145	pound force / square inch	psi		
kPa	kilopascals	20.88	pound force / square foot	psf		
]	PERMEABILITY (VELO	DCITY)			
cm/sec	centimeter/second	1.9685	feet/minute	ft/min		

[THIS PAGE INTENTIONALLY BLANK]

SOILS AND FOUNDATIONS VOLUME I

TABLE OF CONTENTS

LIST	OF FIG	URES .		ix
LIST	OF TA	BLES		xv
LIST	OF SYI	MBOLS		xviii
1.0	INTR	ODUCT	ION	1-1
	1.1	PURPO	SE AND SCOPE	1-1
	1.2	SOILS	AND FOUNDATIONS FOR HIGHWAY FACILITIES	1-5
	1.3	ORGAN	NIZATION OF MANUAL	1-10
	1.4 REFERENCES		ENCES	1-12
		1.4.1	Primary FHWA References	1-12
		1.4.2	Other Primary References	1-13
2.0	STRE	SS AND	STRAIN IN SOILS	
	2.1	BASIC	WEIGHT-VOLUME RELATIONSHIPS	
		2.1.1	Volume Ratios	
		2.1.2	Weight Ratios	
		2.1.3	Weight-Volume Ratios (Unit Weights) and Specific Gravity	
		2.1.4	Determination and Use of Basic Weight-Volume Relations	
		2.1.5	Size of Grains in the Solid Phase	
		2.1.6	Shape of Grains in Solid Phase	2-13
			2.1.6.1 Bulky Shape	2-13
		/	2.1.6.2 Platy Shape	2-15
		2.1.7	Effect of Water on Physical States of Soils	2-15
	2.2	PRINC	PLE OF EFFECITVE STRESS	2-19
	2.3	OVERE	BURDEN PRESSURE	2-19
	2.4	VERTI	CAL STRESS DISTRIBUTION IN SOIL DUE TO EXTERNA	4L
		LOADI	NGS	2-22
		2.4.1	Uniformly Loaded Continuous (Strip) and Square Footings	2-24
		2.4.2	Approximate (2:1) Stress Distribution Concept	2-26
	2.5	REPRE	SENTATION OF IMPOSED PRESSURES ON	
		THE po	DIAGRAM	2-26
	2.6	LOAD-	DEFORMATION PROCESS IN SOILS	2-30
		2.6.1	Time Dependent Load-Deformation (Consolidation) Process .	2-31
		2.6.2	Comparison of Drainage Rates between Coarse-Grained and F	ine-
		(Grained Soil	2-34
	2.7	LATER	AL STRESSES IN FOUNDATION SOILS	2-34
		2.7.1	Effect of Shear Strength of Soils on Lateral Pressures	2-36

	2.8	STRE	NGTH OF SOILS TO RESIST IMPOSED STRESSES	2-38
		2.8.1	Basic Concept of Shearing Resistance and Shearing Strength	2-38
	2.9	STRE	ENGTH OF SOILS RELATED TO LATERAL	
		EART	ΓΗ PRESSURES	2-42
		2.9.1	Distribution of Lateral Earth and Water Pressures	2-45
		2.9.2	Deformations Associated with Lateral Pressures	2-47
	2.10	UNSA	ATURATED SOIL MECHANICS	2-47
3.0	SUBS	SURFA	CE EXPLORATIONS	3-1
	3.01	Prima	ry References	3-3
	3.1	PREP	ARING FOR SUBSURFACE EXPLORATION	3-3
		3.1.1	Soil Formations and Landforms	3-6
			3.1.1.1 Residual Soils	3-7
			3.1.1.2 Transported Soils	3-9
			3.1.1.3 Area Concept of Explorations Based on Landforms	3-9
	3.2	FIELI	D RECONNAISSANCE	3-13
	3.3	SUBS	SURFACE EXPLORATION PROGRAM	3-15
	3.4	SAMI	PLING TECHNIQUES AND TOOLS	3-17
	3.5	BORI	NG METHODS	3-20
		3.5.1	Auger Borings	3-20
		3.5.2	Wash-type Borings	3-26
		3.5.3	Coring in Rocks	3-26
	3.6	SAM	PLING METHODS	3-28
		3.6.1	Disturbed Sampling of Soil	3-28
		3.6.2	Undisturbed Sampling of Soil	3-28
		3.6.3	Thin-Walled (Shelby) Tube Sampling	3-35
		3.6.4	Undisturbed Sampling of Rock (Rock Coring)	3-38
			3.6.4.1 Core Barrels	3-38
			3.6.4.2 Coring Bits	3-40
			3.6.4.3 Drilling Fluid	3-43
		3.6.5	Observations During Rock Core Drilling	3-43
			3.6.5.1 Drilling Rate/Time	3-43
			3.6.5.2 Core Photographs	3-43
			3.6.5.3 Rock Classification	3-44
			3.6.5.4 Recovery	3-44
			3.6.5.5 Rock Quality Designation (ROD).	
			3.6.5.6 Drilling Fluid Recovery	
			3.6.5.7 Core Handling and Labeling	
			3.6.5.8 Care and Preservation of Rock Samples	
		3.6.6	Geologic Mapping	3-50
	3.7	STAN	JDARD PENETRATION TEST (SPT)	
	2.1	3.7.1	Energy Efficiency of Hammers	
		3.7.2	Effect of Overburden Stress on N-values	
		3,73	Correlation of SPT N-Values with Basic Soil Characteristics	3-58
		5.1.5	3731 Applicability of SPTs in Gravelly Soils	3-58
		374	SPT Test Errors	3-59
		2.7.1		

	3.8	LOG OF BOREHOLE INFORMATION ("BORING LOGS")	3-62
		3.8.1 Boring Log Format	3-62
		3.8.2 Duties of the Logger	3-62
	3.9	CONE PENETRATION TESTING (CPT)	3-67
		3.9.1 Equipment Description and Operation	3-68
		3.9.2 The Standard Cone Penetration Test (CPT)	3-69
		3.9.3 The Piezo-cone Penetration Test (CPTu)	3-71
		3.9.4 The Seismic Piezocone Penetration Test (SCPTu)	3-71
		3.9.5 Test Procedures	3-71
		3.9.6 CPT Profiles	3-72
		3.9.7 CPT Profile Interpretation	3-72
	3.10	DILATOMETER TEST (DMT)	3-75
	3.11	PRESSUREMETER TEST (PMT)	3-76
	3.12	VANE SHEAR TEST (VST)	3-77
	3.13	GROUNDWATER MEASUREMENTS	3-78
		3.13.1 Information on Existing Wells	3-78
		3.13.2 Open Borings	3-79
		3.13.3 Observation Wells	3-79
		3.13.4 Water Level Measurements	3-81
		3.13.4.1 Chalked Tape	3-81
		3.13.4.2 Tape with a Float	3-82
		3.13.4.3 Electric Water-Level Indicator	3-82
		3.13.4.4 Data Loggers	3-82
	3.14	GUIDELINES FOR MINIMUM SUBSURFACE EXPLORATION	3-83
		3.14.1 Recommendations for Sampling Depth Intervals in Soils	3-87
		3.14.2 Recommendations for Sampling Depth Intervals in Rocks	3-89
		3.14.3 Recommendations for Water Level Monitoring in Borings	3-89
	3.15	GEOPHYSICAL TESTS	3-90
		3.15.1 Types of Geophysical Tests	3-90
		3.15.2 Advantages and Disadvantages of Geophysical Tests	3-94
		3.15.2.1 Advantages of Geophysical Tests	3-94
		3.15.2.2 Disadvantages of Geophysical Tests	3-95
		3.15.3 Examples of Uses of Geophysical Tests	3-95
4.0	ENG	INEERING DESCRIPTION, CLASSIFICATION AND	
	CHA	RACTERISTICS OF SOILS AND ROCKS	
	4.01	Primary References	
	4.1	SOIL DESCRIPTION	
		4.1.1 Consistency and Apparent Density	
		4.1.2 Water Content (Moisture)	
		4.1.3 Color	
		4.1.4 Type of Soil	
		4.1.4.1 Coarse-Grained Soils (Gravel and Sand)	
		4.1.4.2 Fine-Grained Soils	
		4.1.4.3 Highly Organic Soils	4-10
		4.1.4.4 Minor Soil Type(s)	4-11

		4.1.4.5 Inclusions	
		4.1.4.6 Other Descriptors	
		4.1.4.7 Layered Soils	
		4.1.4.8 Geological Name	
4.2	SOIL	CLASSIFICATION	
	4.2.1	Unified Soil Classification System (USCS)	
		4.2.1.1 Classification of Coarse-Grained Soils	
		4.2.1.2 Classification of Fine-Grained Soils	
	4.2.2	AASHTO Soil Classification System	
4.3	ENGI	NEERING CHARACTERISTICS OF SOILS	
	4.3.1	Engineering Characteristics of Coarse-Grained Soils (Sands	and
		Gravels)	
	4.3.2	Engineering Characteristics of Fine-Grained Soils	
		(Inorganic Clays)	
	4.3.3	Engineering Characteristics of Fine-Grained Soils	
		(Inorganic Silts)	
	4.3.4	Engineering Characteristics of Organic Soils	
4.4	PRAC	TICAL ASPECTS OF ENGINEERING CHARACTERISTI	CS OF
	COAF	RSE-GRAINED SOILS	
4.5	PRAC	TICAL ASPECTS OF ENGINEERING CHARACTERISTI	CS OF
	FINE-	GRAINED SOILS	
4.6	DESC	RIPTION OF ROCK	
	4.6.1	Rock Type	
	4.6.2	Color	
	4.6.3	Grain Size and Shape	
	4.6.4	Stratification/Foliation	
	4.6.5	Mineral Composition	
	4.6.6	Weathering and Alteration	
	4.6.7	Strength	
	4.6.8	Hardness	
	4.6.9	Rock Discontinuity	
	4.6.10	Fracture Description	
	4.6.11	Rock Mass Classification	
4.7	SUBS	URFACE PROFILE DEVELOPMENT	
	4.7.1	Use of Historical Data in Development of Subsurface Profil	e 4-48
LAB	ORATO	ORY TESTING FOR GEOTECHNICAL DESIGN AND	
CON	STRUC	TION	
5.01	Prima	ry References	
5.1	QUAI	LITY ASSURANCE FOR LABORATORY TESTING	5-2
	5.1.1	Sample Tracking	5-2
	5.1.2	Sample Storage	5-2
	5.1.3	Sample Handling	5-4
	5.1.4	Effects of Sample Disturbance	5-4
	5.1.5	Specimen Selection	5-4
5.2	LABC	DRATORY TESTING FOR SOILS	

5.0

 5.3.1 General	5-10 5-10 5-11 5-12
 5.3.2 Moisture Content	5-10 5-11 5-12
 5.3.3 Unit Weight 5.3.4 Particle Size Distribution	5-11
 5.3.4 Particle Size Distribution 5.3.4.1 Sand Equivalent 5.3.5 Atterberg Limits 	5-12
5.3.4.1 Sand Equivalent5.3.5 Atterberg Limits	
5.3.5 Atterberg Limits	
	5-16
5.3.5.1 Significance of the "A-line" and "U-line" on	
Plasticity Chart	5-19
5.3.6 Specific Gravity	
5.3.7 Organic Content	
5.3.8 Electro Chemical Classification Tests	5-21
5.3.9 Laboratory Classification	5-21
5.4 CONSOLIDATION TESTING	5-22
5.4.1 Process of Consolidation	5-22
5.4.2 Consolidation Testing	5-23
5.4.3 Procedures	5-24
5.4.4 Presentation and Understanding the Consolidation Test Results	5-26
5.4.5 Comments on the Consolidation Tests	5-31
5.4.6 Useful Correlations between Consolidation Parameters and Index	X
Values	5-33
5.4.6.1 Compression Index, C _c	
5.4.6.2 Recompression Index, Cr	5-35
5.4.6.3 Coefficient of Vertical Consolidation, cv	5-35
5.4.6.4 Coefficient of Secondary Compression, C_{α}	5-37
5.5 SHEAR STRENGTH OF SOILS	5-38
5.5.1 Concept of Frictional and Cohesive Strengths	5-38
5.5.1.1 Strength Due to Friction	5-38
5.5.1.2 Strength Due to Cohesion	
5.5.1.3 Simplified Expression for Shear Strength of Soils	5-42
5.5.2 Strength Testing of Soils in the Laboratory	5-42
5.5.2.1 Unconfined Compression (UC) Tests	
5.5.2.2 Triaxial Tests	5-45
5.5.2.3 Direct Shear Tests	5-49
5.5.3 Factors Affecting Strength Testing Results	5-51
5.5.4 Comparison of Laboratory and Field Strengths	
5.5.5 Selection of Design Shear Strength	5-53
5.5.6 Correlations of Shear Strength Parameters with Index Parameters	3.5-53
5.5.6.1 Undrained Shear Strength of Cohesive Soils	5-53
5.5.6.2 Drained and Effective Shear Strength of Cohesive Soils	5-55
5.5.6.3 Shear Strength of Cohesionless Soils	5-56
5.6 PERMEABILITY	5-58
5.6.1 General	5-58
5.62 Equipment	5-58
5.6.2 Equipment	
5.6.3 Procedures	5-61

	5.7	VOLUME CHANGE PHENOMENA DUE TO LOADING AND	
		MOISTURE	5-65
		5.7.1 Swell Potential of Clays	5-65
		5.7.1.1 Evaluation of Expansion (Swell) Potential	5-67
		5.7.2 Collapse Potential of Soils	5-68
		5.7.3 Expansion of Soils due to Frost Action	5-70
	5.8	COMPACTION CHARACTERISTICS OF SOIL	5-72
		5.8.1 Concept of Compaction	5-72
		5.8.2 Test Procedures	5-73
		5.8.3 Implication of Laboratory Tests on Field	
		Compaction Specifications	5-76
		5.8.4 Engineering Characteristics of Compacted Soils	5-81
		5.8.4.1 Effect of Increase in Moisture Content on Shear Strength	
		of Compacted Soils	5-83
	5.9	ELASTIC PROPERTIES OF SOILS	5-83
	5.10	COMMON SENSE GUIDELINES FOR LABORATORY TESTING OF	7
		SOILS	5-84
	5.11	LABORATORY TESTS FOR ROCK	5-87
		5.11.1 Introduction	5-87
		5.11.2 Point-Load Strength Test	5-89
		5.11.3 Unconfined Compressive Strength of Intact Rock Core	5-91
		5.11.4 Elastic Modulus of Intact Rock Core	5-91
		5.11.5 Laboratory Direct Shear Test	5-92
	5.12	ELASTIC PROPERTIES OF ROCKS	5-94
		5.12.1 Elastic Modulus of Rock Mass	5-95
	5.13	COMMON SENSE GUIDELINES FOR LABORATORY TESTING OF	7
		ROCKS	5-96
	5.14	PRACTICAL ASPECTS FOR LABORATORY TESTING	5-98
	5.15	VARIABILITY OF MEASURED PROPERTIES	5-99
6.0	SLO	PE STABILITY	6-1
	6.01	Primary Reference	6-1
	6.1	EFFECTS OF WATER ON SLOPE STABILITY	6-3
	6.2	DESIGN FACTOR OF SAFETY	6-5
	6.3	INFINITE SLOPE ANALYSIS	6-5
		6.3.1 Infinite Slopes in Dry Cohesionless Soils	6-5
		6.3.2 Infinite Slopes in c-φ Soils with Parallel Seepage	6-6
	6.4	CIRCULAR ARC FAILURE	6-9
		6.4.1 Simple Rule of Thumb for Factor of Safety	6-10
		6.4.2 Stability Analysis Methods (General)	6-11
		6.4.3 Ordinary Method of Slices – Step-By-Step	
		Computation Procedure	6-13
		6.4.4 Recommended Stability Methods	6-20
		6.4.5 Remarks on Safety Factor	6-22
	6.5	CRITICAL FAILURE SURFACE	6-22
	6.6	DESIGN (STABILITY) CHARTS	6-24

		6.6.1	Historical Background	6-25
		6.6.2	Taylor's Stability Charts	6-25
			6.6.2.1 Determination of the Factor of Safety for a Slope	6-30
		6.6.3	Janbu's Stability Charts	6-33
	6.7	SLIDI	NG BLOCK FAILURE	6-43
		6.7.1	Sliding Block – Hand Method of Analysis	6-44
			6.7.1.1 Computation of Forces - Simple Sliding Block Analysis	6-45
		6.7.2	Computation of Forces - Complicated Sliding Block Analysis	6-47
	6.8	SLOP	E STABLITY ANALYSIS USING COMPUTER PROGRAMS	6-48
	6.9	IMPR	OVING THE STABILITY OF EMBANKMENTS	6-50
		6.9.1 E	Embankment Stability Design Solutions	6-50
		6.9.2 I	Design Approach for Reinforced Soil Slopes	6-50
			6.9.2.1 Preliminary Feasibility Design of RSS	6-53
	6.10	IMPR	OVING THE STABILITY OF CUT SLOPES	6-57
		6.10.1	Deep Seated Failure	6-57
		6.10.2	Shallow Surface Failures	6-58
		6.10.3	Factor of Safety - Cut Slopes	6-59
7.0	APPF	ROACH	ROADWAY DEFORMATIONS	7-1
	7.1	TYPIC	CAL APPROACH ROADWAY DEFORMATION PROBLEMS	7-1
	7.2	INTEF	RNAL DERFROMTION WITHIN EMBANKMENTS	7-6
		7.2.1	General Considerations for Select Structural Backfill	7-6
		7.2.2	General Considerations for Drainage Aggregate	7-6
		7.2.3	Use of Geosynthetics to Control Internal Deformations	7-10
	7.3	EXTE	RNAL DEFORMATION IN FOUNDATION SOILS BELOW	
		EMBA	ANKMENTS	7-10
		7.3.1	Procedure for Estimating Stress Distribution in Foundation Soils	
			under Fills	7-11
	7.4	COMF	PUTATION OF IMMEDIATE SETTLEMENT	7-15
		7.4.1	Modified Hough's Method for Estimating Immediate Settlements	s. 7-16
			7.4.1.1 Comments on the Computed Settlement of Embankments	. 7-19
	7.5	COMF	PUTATION OF CONSOLIDATION (LONG-TERM)	
		SETTI	LEMENTS	7-19
		7.5.1	Correction of Laboratory One-Dimensional Consolidation Curve	s 7-21
		7.5.2	Computation of Primary Consolidation Settlements	7-24
			7.5.2.1 Normally Consolidated Soils	7-24
			7.5.2.2 Overconsolidated (Preconsolidated) Soils	7-26
			7.5.2.3 Underconsolidated Soils	7-27
		7.5.3	Consolidation Rates (Time Rate of Consolidation Settlement)	7-28
			7.5.3.1 Percent Consolidation	7-30
			7.5.3.2 Step-by-step Procedure to Determine Amount and Time	
			for Consolidation	7-33
		7.5.4	Secondary Compression of Cohesive Soils	7-38
	7.6	LATE	RAL SQUEEZE OF FOUNDATION SOILS	7-40
		7.6.1	Threshold Condition for Lateral Squeeze	7-41
		7.6.2	Calculation of the Safety Factor against Lateral Squeeze	7-42

	7.6.3	Estimation of Horizontal Movement of Abutments	
7.7	DESIG	GN SOLUTIONS - DEFORMATION PROBLEMS	
	7.7.1	Reducing the Amount of Settlement	
		7.7.1.1 Category 1 - Increasing the Resistance	
		7.7.1.2 Category 2 - Reducing the Load	
	7.7.2	Reducing Settlement Time	
		7.7.2.1 Surcharge Treatment	
		7.7.2.2 Vertical Drains	
	7.7.3	Design Solutions to Prevent Abutment Tilting	7-47
7.8	PRAC	TICAL ASPECTS OF EMBANKMENT SETTLEMENT	
7.9	CONS	TRUCTION MONITORING AND QUALITY ASSURANCE	7-48
	7.9.1	Embankment Construction Monitoring by Instrumentation	
		7.9.1.1 Inspector's Visual Observation	
		7.9.1.2 Types of Instrumentation	
		7.9.1.3 Typical Locations for Instruments	

LIST OF FIGURES

<u>Figure</u>	<u>Caption</u> Page	<u>e</u>
1-1	Aerial view of a pair of 3-span Interstate 10 (I-10) bridges over local roadway in Tucson. Arizona	1
1-2	Example of 3-span roadway bridges over another roadway	2
1-3	The "BIG I" stack interchange at the intersection of I-40 and I-25 in Albuquerque, New Mexico (Photo: Courtesy of Bob Meyers, NMDOT) (Note: A stack interchange is a free-flowing junction between two or more	-
1-4	A major multi-span bridge structure over water (George P. Coleman Bridge	2
1-5	Example of a roadway bounded by cut slopes and wet lands in an	י ג
1-6	Combinations of sources of information required to solve geotechnical engineering issues	5
1-7	Geotechnical activity flow chart for a typical project using design-bid-build procurement process	8
2-1	A unit of soil mass and its idealization	2
2-2	Example of laboratory sieves for mechanical analysis for grain size distributions	1
2-3	Sample grain size distribution curves	2
2-4	Terminology used to describe shape of coarse-grained soils (Mitchell, 1976). 2-14	4
2-5	Conceptual changes in soil phases as a function of water content	б
2-6	Plasticity chart and significance of Atterberg Limits	8
2-7	Example calculation of a p_0 -diagram	1
2-8	Schematic of vertical stress distribution under embankment loading. Graphic generated by FoSSA (2003) program	2
2-9	Vertical stress contours (isobars) by Boussinesq's theory for continuous and square footings (modified after Sowers, 1979; AASHTO, 2002)	5
2-10	Distribution of vertical stress by the 2:1 method (after Perloff and Baron, 1976)	7
2-11	Combined plot of overburden pressures (total and effective) and pressure due to imposed loads	8
2-12	Example calculation of p _f with stress increments from strip load on p ₀ -diagram	9
2-13	Spring-piston analogy for the consolidation process of fine-grained soils 2-32	2
2-14	Comparison of excess pore water pressure dissipation in coarse-grained and fine-grained soils	4
2-15	Schematic of effect of lateral stresses	5
2-16	Schematic of lateral stress increases beneath an embankment. Graphic generated by FoSSA (2003)	7
2-17	Basic concept of shearing resistance and strength (after Murthy, 1989)	9
2-18	Graphical representation of shearing strength	1

2-19	Stress states on a soil element subjected only to body stresses: (a) In-situ geostatic effective vertical and horizontal stresses. (b) Insertion of	
	hypothetical infinitely rigid, infinitely thin frictionless wall and removal of	
	soil to left of wall, (c) Active condition of wall movement away from	
	retained soil, (d) Passive condition of wall movement into retained soil2-4	13
2-20	Development of Rankine active and passive failure zones for a smooth	
/	retaining wall	15
2-21	Failure surface, pressure distribution and forces	
	(a) active case, (b) passive case	16
2-22	General distribution of combined active earth pressure and water pressure 2-4	16
3-1	Recommended process for developing subsurface model for engineering	
	design (FHWA, 2002a)	-2
3-2	Typical weathering profile for metamorphic and igneous rocks (Deere and	
	Patton, 1971)	-8
3-3	Typical field reconnaissance form	14
3-4	Common in-situ tests for geotechnical site characterization of soils (FHWA, 2002b)	18
3-5	(a) Large diameter auger. (b) Small diameter continuous flight auger	21
3-6	(a) Solid stem auger and hollow stem auger (FHWA, 2002b), (b) Hollow	
00	stem auger components (ASTM D 4700), (c) Sizes of hollow stem auger	
	flights (FHWA, 2002b), (d) Outer and inner assembly of hollow stem auger	
	(FHWA, 2002b)	25
3-7	(a) Schematic of drilling rig for rotary wash methods (after Hyorsley, 1948).	
	(b) Typical drilling configuration. (c) Settling basin (mud tank)	27
3-8	Split barrel sampler	28
3-9	Schematic of thin-walled (Shelby) tube (after ASTM D 4700) and photo of	
	tube with end caps (FHWA, 2002b)	31
3-10	Stationary piston sampler schematic (after ASTM D 4700) and photo	
	(FHWA 2002b)	33
3-11	Denison sampler (FHWA, 1997)	33
3-12	Pitcher sampler (FHWA, 1997, 2002b)	34
3-13	Shelby tube sealing methods: (a) Microcrystalline Wax, (b) O-Ring packer.	
	(FHWA, 2002b)	38
3-14	(a) Single, (b) and (c) Double tube rock core barrels (FHWA, 1997)	39
3-15	Double tube core barrel. (a) Outer barrel assembly (b) Inner barrel assembly	
	(FHWA, 2002b)	10
3-16	Coring bits: Diamond (top left), Carbide (top right), and Sawtooth	
	(bottom center) (FHWA, 2001)	11
3-17	Modified core recovery as an index of rock mass quality (FHWA, 1997) 3-4	15
3-18	Length measurements for core RQD determination (FHWA, 1997)	16
3-19	Core box for storage of recovered rock and labeling	19
3-20	Sequence of driving split-barrel sampler during the Standard Penetration	
	Test (modified after FHWA, 2002b)	52
3-21	(a) Stainless steel and brass liners, (b) Sample catchers (FHWA, 2002b) 3-5	53
3-22	SPT hammer types, (a) Donut, (b) Safety, and (c) Automatic (FHWA, 2006). 3-5	54

3-23	SPT N-values from (a) Uncorrected data, and (b) Corrected to 60%	
	efficiency (Data modified after Robertson, et al. 1983)	3-56
3-24	Variation of overburden correction factor, C_N , as a function of vertical	2 57
2.05	Example subsymbols and example $(0, 25 \text{ ft denth})$	2 62
2-25h	Example subsurface exploration log (0 - 55 it deput)	2 61
2 26	Example subsurface exploration log (55 - 00 it deput)	2 60
3-20 2 27	Cons ponetrometer terminology (from Bohortson and Companella, 1080)	2 60
3 28	Cone and piezocone penetrometers (Note the Quarter for Scale)	5-09
3-28	(FHWA, 2002b)	3-70
3-29	Cone penetration testing from cone truck	3-71
3-30	Piezo-cone results for Apple Freeway Bridge	3-73
3-31	A commonly used simplified soil classification chart for standard electronic	
	friction cone (after Robertson, et al., 1986)	3-74
3-32	Dilatometer test equipment and procedure (FHWA, 2002b)	3-75
3-33	Pressuremeter test schematic (FHWA, 2002b)	3-76
3-34	Vane shear test equipment and procedure (after FHWA, 2002b)	3-77
3-35	Representative details of observation well installations. (a) Drilled-in place	
	stand-pipe piezometer, (b) Driven well point (FHWA, 1997)	. 3-80
4-1	Flow chart to determine the group symbol and group name for coarse-	
	grained soils (ASTM D 2488)	4-17
4-2	Evaluation of type of gradation for coarse-grained soils	4-20
4-3	Plasticity chart for Unified Soil Classification System (ASTM D 2488)	4-22
4-4a	Flow chart to determine the group symbol and group name for fine-grained soils (ASTM D 2488)	4-23
4-4b	Flow chart to determine the group symbol and group name for organic soils	4.04
4 5	(ASTM D 2488)	. 4-24
4-5	Range of liquid limit and plasticity index for soils in groups A-2, A-4, A-5,	1 20
16	A-o and A-/ per AASHIO M 145 (or ASIM D 3282)	. 4-28
4-0	Comparison of the USCS with the AASHTO Soil Classification System	4 20
4-7	(after Utan DO1 – Pavement Design and Management Manual, 2005)	. 4-29
	Classification Systems (Holtz and Kovacs, 1981)	4-30
4-8	Example boring location plan (FHWA, 2002a)	4-47
4-9	Example interpreted subsurface profile (FHWA, 2002a)	4-48
5-1	Sample laboratory test request form (Note: Only some tests are included in	
0 1	this sample form)	5-3
5-2	Example grain size distribution based on sieve analysis (Jumikis, 1962)	5-14
5-3	Grain size distribution curve based on data in Figure 5-2	5-14
5-4	Some of the equipment used for Atterberg Limits testing of soil	5-17
5-5	Location of clay minerals on the Casagrande Plasticity Chart and Activity	
	Index values (after Skempton, 1953, Mitchell, 1976, Holtz and	
	Kovacs, 1981)	5-18
5-6	Schematic of a consolidation test	5-24

5-7	(a) Components of consolidation test equipment, (b) Weighted lever arm –	
	incremental load consolidation apparatus, (c) Automatic load frame and	
	computerized consolidation apparatus	
	(Photo courtesy of GeoComp Corporation)	. 5-25
5-8	Consolidation test relationships (after NAVFAC, 1986a)	. 5-27
5-9	Empirical correlation between Compression Index and natural (in-situ) water	•
	content (from Terzaghi, et al., 1996)	. 5-34
5-10	Approximate correlations between c _v and LL (NAVFAC, 1986a)	. 5-36
5-11	Correlation between $C_{\alpha e}$ and natural water content (NAVFAC, 1986a)	. 5-37
5-12	Potential contributions of various bonding mechanisms to cohesive strength	
	(Ingles, 1962)	. 5-41
5-13	Schematic of an unconfined compression test	. 5-44
5-14	Schematic of a triaxial compression test (Lambe and Whitman, 1979)	. 5-45
5-15	(a) Failure of a loose sand specimen in a triaxial cell; and (b) Load frame,	
	pressure panel, and computerized data acquisition system (Photograph	
	courtesy of GeoComp Corporation)	. 5-46
5-16	Typical stress-strain curves from CU test	. 5-48
5-17	Schematic of the Direct Shear Test	. 5-49
5-18	Direct shear testing box (Photograph courtesy of GeoComp Corporation)	. 5-50
5-19	Soil sample mounted in direct shear testing apparatus (Photograph courtesy	
	of GeoComp Corporation)	. 5-50
5-20	Relationship between the ratio of undrained shear strength to effective	
	overburden pressure and plasticity index for normally-consolidated and	
	overconsolidated clays (after Holtz and Kovacs, 1981)	. 5-54
5-21	Relationships between ϕ and PI (after Terzaghi, <i>et al.</i> , 1996)	. 5-56
5-22	Correlation between relative density, material classification and angle of	
	internal friction for coarse-grained soils (NAVFAC, 1986a)	. 5-57
5-23	Correlation between relative density and SPT resistance	
	(NAVFAC, 1986a)	. 5-57
5-24	Rigid wall permeameter (Photograph courtesy of GeoComp Corporation)	. 5-59
5-25	Flexible wall permeameter (Photograph courtesy of GeoComp Corporation).	. 5-60
5-26	The permeability of sands and gravels (after NAVFAC, 1986a)	. 5-64
5-27	Classification of swell potential for soils (after Seed, et al., 1962)	. 5-66
5-28	Chart for evaluation of collapsible soils (after Holtz and Hilf, 1961)	. 5-68
5-29	Approximate frost depth map for United States (Bowels, 1996)	. 5-71
5-30	Hammer and mold for laboratory compaction test (tape measure is for scale	
	purpose only	. 5-73
5-31	Compaction curves (after Holtz and Kovacs, 1981)	. 5-74
5-32	Compactors recommended for various types of soil and rock	
	(Schroeder, 1980)	. 5-77
5-33	Relative density, relative compaction and void ratio concepts	. 5-78
5-34	Example evaluation of economical field compaction conditions	
	(after Bowles, 1979)	. 5-81
5-35	Point load strength test equipment (Wyllie, 1999)	. 5-89
5-36	(a) Unconfined compression test on intact rock core, (b) Use of strain gage	

	on intact rock core sample for measurement of stress-strain characteristics	z 0 2
	(Geomechanical Laboratory, University of Arizona)	. 5-92
5-37	Laboratory direct shear testing equipment for rock (Wyllie, 1999)	. 5-93
6-1	Embankment failures: (a) Infinite slope failure in embankment fill,	
	(b) Circular arc failure in embankment fill and foundation soil,	
	(c) Sliding block failure in embankment fill and foundation soil, and	
	(d) Lateral squeeze of foundation soil	6-2
6-2	Effect of water content on cohesive strength of clay	6-4
6-3	Infinite slope failure in dry sand	6-6
6-4	Infinite slope failure in a c- ϕ soil with parallel seepage	6-7
6-5	Typical circular arc failure mechanism	6-9
6-6	Example proposed embankment	. 6-10
6-7	Geometry of Ordinary Method of Slices	. 6-12
6-8	Example of dividing the failure mass in slices	. 6-13
6-9	Forces on a slice without water effect	. 6-15
6-10	Forces on a slice with water effect	. 6-15
6-11a	Tabular form for computing weights of slices	. 6-18
6-11b	Tabular form for calculating factor of safety by Ordinary Method of Slices	. 6-19
6-12	Typical static forces acting on a slice of sliding mass without seepage	. 6-20
6-13	Location of critical circle by plotting contours of minimum safety factors	
	for various trial circles	. 6-23
6-14	Taylor's chart for soils with friction angle (after Taylor, 1948)	. 6-27
6-15	Taylor's chart for $\phi'=0$ conditions for slope angles (β) less than 54° (after Taylor, 1948)	6 28
6 16	1001, 1940	6 24
6 17	Stability charts for $\psi = 0$ solis (Jalibu, 1908)	. 0-34
0-1/	shorts for the 0 and the 0 and the 1068	6.26
c 10	charts for $\phi=0$ and $\phi > 0$ solis (Janbu, 1968)	. 0-30
0-18	Reduction factors to account for surcharge (upper) and submergence and/or	
	seepage (lower) to be used with stability charts for $\phi=0$ and $\phi > 0$ solis	
C 10	(Janbu, 1908)	. 0-3/
6-19	Stability charts for $\phi > 0$ (Janbu, 1968)	. 0-39
6-20	Data for Example 6-2	. 0-41
6-21	Sliding block failure mechanism	. 0-43
6-22	Geometry and force components for sliding block analysis	. 6-44
0-25	Deduction of grade line to improve along stability	. 0-40
0-24	Lise of counterweight how to improve slope stability	. 0-32
6 26	Use of char key to improve slope stability	6 52
0-20 6 27	Eailure modes for Deinforced Soil Slopes	. 0-32 6 52
6 28	Chart solution for determining the rainforcement strength requirements	. 0-33
0-28	(Schwartmann, at al. 1987). The Tensor Corneration	6 55
6_20	Deep seated slope failure (left) and bench slope design (right) to provent	. 0-33
0-27	slope failure	6-57
6-30	Typical cut slope failure mechanism in clay soils	6-58
0-30	rypical cut slope famile meenamsin in clay solis	.0-30

7-1	(a) Elements of a bridge approach system, (b) Plan view of an approach system (modified after NCHRP, 1997) 7-2
7-2	Types of abutments (modified after NCHRP 1990) 7-3
7-3	Problems leading to the existence of a hump (modified after NCHRP 1997) 7-4
7-4	Suggested approach embankment details
7-5	Structural backfill placement limits for porous drainage aggregate
7-6	Pressure coefficients beneath the end of a fill (NYSDOT, 1970)
7-7	Bearing capacity index (C') values used in Modified Hough method for
	computing immediate settlements of embankments (AASHTO, 2004 with
	2006 Interims; modified after Hough, 1959)
7-8	Effect of sample disturbance on the shape of the one-dimensional
	consolidation curve (Reese, <i>et al.</i> , 2006)
7-9	Construction of field virgin consolidation relationships (adapted from
	USACE, 1994)
7-10	Typical consolidation curve for normally consolidated soil – (a) Void ratio
	versus vertical effective stress and (b) Vertical strain versus vertical
	effective stress
7-11	Typical consolidation curve for overconsolidated soil – (a) Void ratio versus
	vertical effective stress and (b) Vertical strain versus vertical effective stress. 7-26
7-12	Typical consolidation curve for under-consolidated soil – (a) Void ratio
	versus vertical effective stress and (b) Vertical strain versus vertical
	effective stress7-27
7-13	Diagram illustrating consolidation of a layer of clay between two pervious
	layers (modified after Terzaghi, et al., 1996)7-28
7-14	Typical settlement-time curve for clay under an embankment loading7-32
7-15	Logarithm-of-time method for determination of c _v
7-16	Square-root-of-time method for determination of c _v
7-17	Example time plot from one-dimensional consolidometer test for
	determination of secondary compression (USACE, 1994)7-39
7-18	Schematic of lateral squeeze phenomenon
7-19	Examples of abutment tilting due to lateral squeeze (FHWA, 2006a)
7-20	Definitions for calculating safety factor against later squeeze (after Silvestri, 1983)
7-21	Determination of surcharge time required to achieve desired settlement
7-22	Use of vertical drains to accelerate settlement
7-23	Typical locations for various types of monitoring instruments for an
	embankment constructed over soft ground
	-

LIST OF TABLES

<u>No.</u>	Caption	<u>Page</u>
1-1	Geotechnical involvement in project phases	1-9
2-1	Summary of index properties and their application	2-8
2-2	Weight-volume relations (after Das, 1990)	2-8
2-3	U.S. standard sieve sizes and corresponding opening dimension	. 2-10
2-4	Concept of soil phase, soil strength and soil deformation based on Liquidity	
	Index	. 2-17
3-1	Sources of historical site data (after FHWA, 2002a)	3-4
3-2	Common landforms of transported soils and their engineering significance	. 3-10
3-3	Reference publications on in-situ testing (FHWA, 2002b)	. 3-19
3-4a	Soil and soft rock boring methods (FHWA, 2002a)	. 3-22
3-4b	Rock core drilling methods (FHWA, 2002a)	. 3-23
3-4c	Other exploratory techniques (FHWA, 2002a)	. 3-24
3-5a	Common samplers to retrieve disturbed soil samples	
	(modified after NAVFAC, 1986a)	. 3-29
3-5b	Common samplers to retrieve disturbed soil samples	
	(modified after NAVFAC, 1986a)	. 3-30
3-6	Nominally undisturbed soil samplers (modified after NAVFAC, 1986a)	. 3-32
3-7	Dimensions of core sizes (FHWA, 1997)	. 3-41
3-8	Advantages and disadvantages of the Standard Penetration Test (SPT)	. 3-51
3-9	Soil properties correlated with Standard Penetration Test values	
	(after Peck. <i>et al.</i> , 1974)	. 3-58
3-10	Factors affecting the SPT and SPT results (after Kulhawy and Mayne, 1990)	. 3-61
3-11	Advantages and disadvantages of the Cone Penetration Test (CPT)	
	(FHWA, 2002b)	. 3-67
3-12	Classification of Sensitivity Values (Mitchell, 1976)	.3-78
3-13	Guidelines for minimum number of exploration points and depth of	
	exploration (modified after FHWA, 2002a)	. 3-84
3-14	Geophysical testing techniques (modified after FHWA, 2002a)	. 3-91
4-1	Evaluation of the apparent density of coarse-grained soils	
	(after Peck, et al., 1974)	4-5
4-2	Evaluation of the consistency of fine-grained soils (after Peck, et al., 1974).	4-5
4-3	Adjectives to describe water content of soils (ASTM D 2488)	4-6
4-4	Particle size definition for gravels and sands (after ASTM D 2488)	4-7
4-5	Adjectives for describing size distribution for sands and gravels (after ASTM	I
-	D 2488)	4-8
4-6	Field methods to describe plasticity (FHWA, 2002b)	.4-10
4-7	Descriptive terms for layered soils (NAVFAC. 1986a)	. 4-13
4-8	Basic USCS soil designations based on percents passing No. 200 (0.075mm)	
-	Sieve (after ASTM D 2487; Holtz and Kovacs, 1981)	. 4-14

4-9	Soil classification chart (laboratory method) (after ASTM D 2487)	. 4-15
4-10	Gradation based on C _u and C _c parameters	. 4-19
4-11	Soil plasticity descriptors (based on Figures 4-3, 4-4a and 4-4b)	. 4-25
4-12	Examples of description of fine-grained soils (based on Figures 4-3, 4-4a and	l
	4-4b)	. 4-25
4-13	AASHTO soil classification system based on AASHTO M 145 (or	
	ASTM D 3282)	. 4-27
4-14	Example gradation limits of well-graded granular material (see Curve A in	
	Figure 4-2)	. 4-33
4-15	Example gradation limits of drainage materials (see Curve C in Figure 4-2)	. 4-33
4-16	Rock groups and types (FHWA, 1997)	. 4-35
4-17	Terms to describe grain size (typically for sedimentary rocks)	. 4-36
4-18	Terms to describe grain shape (for sedimentary rocks)	. 4-36
4-19	Terms to describe stratum thickness	. 4-37
4-20	Terms to describe rock weathering and alteration (ISRM, 1981)	. 4-38
4-21	Terms to describe rock strength (ISRM, 1981)	. 4-38
4-22	Terms to describe rock hardness (FHWA, 2002b)	. 4-39
4-23	Terms to describe discontinuities (after ISRM, 1981)	. 4-40
4-24	Terms to classify discontinuities based on aperture size (ISRM, 1981)	. 4-40
4-25	Geomechanics classification of rock masses (AASHTO 2004	
	with 2006 Interims)	. 4-43
4-26	Geomechanics rating adjustment for joint orientations (after AASHTO 2004	
	with 2006 Interims)	. 4-44
4-27	Geomechanics rock mass classes determined from total ratings (AASHTO	
	2004 with 2006 Interims)	. 4-44
5 1	Commente a formed to be active to the end of the FUNDA 2002-)	5 (
5-1 5-2	Mothe de fan in deu testing of goile (after FHWA, 2002a)	3-0
5-2 5-2	Methods for index testing of soils (after FHWA, 2002a))-/
5-5 5-1	Turical neutial sizes uniformity coefficients used ratios and unit weights	3-8
3-4	(from Kulhawa and Mayne, 1990)	5 12
5 5	Correlations for C (modified after Holtz and Koyacs, 1081)	5 22
5-5 5-6	Typical values of coefficient of vertical consolidation c_{c} (after Carter and	. 5-55
5-0	Reptley 1991)	5-36
5_7	Typical values of C_{-}/C_{-} (Terzaghi <i>et al.</i> 1996)	5_37
5-8	Summary of issues relevant to shear strength evaluation in support of the	. 5-57
5-0	design of typical geotechnical features (after FHWA 2002a)	5_39
5-9	Recommended maximum hydraulic gradient for permeability testing	5-61
5-10	Typical permeability values in soils (after Carter and Bentley 1991)	5-63
5-11	Typical permeability values for highway materials (after Krebs and	. 5 05
5-11	Walker 1971)	5-63
5-12	Qualitative assessment of collapse potential (after ASTM D 5333)	5-69
5-13	Characteristics of laboratory compaction tests	5-73
5-14	Some values of D _c as a function of RC based on Modified and Standard	. 5 1 5
~ 1 1	Proctor Compaction Test	5-79
5-15	Average engineering properties of compacted inorganic soils	

	(after USBR, 1960)
5-16	Elastic constants of various soils (after AASHTO 2004 with 2006 Interims) 5-85
5-17	Rate of increase of soil modulus with depth n_h (tsf/ft) for sand
	(AASHTO 2004 with 2006 Interims)
5-18	Common sense guidelines for laboratory testing of soils
5-19	Common rock tests performed in the laboratory
5-20	Summary information on rock laboratory test methods (FHWA, 2002a) 5-88
5-21	Summary of elastic moduli for intact rock (AASHTO 2004 with
	2006 Interims)
5-22	Summary of Poisson's Ratio for intact rock (AASHTO 2004 with
	2006 Interims)
5-23	Estimation of E _m based on RQD (AASHTO 2004 with 2006 Interims)5-96
5-24	Common sense guidelines for laboratory testing of rocks
5-25	Values of coefficient of variation, V, for geotechnical properties and in-situ
	tests (after Duncan, 2000)
6-1	Slope stability guidelines for design
6-2	Practical design solutions to mitigate embankment stability problems
6-3	Typical design solutions to mitigate cut slope stability problems
7-1	General considerations for specification of select structural backfill7-9
7-2	Suggested gradation for drainage aggregate7-9
7-3	Reconstruction of virgin field consolidation (modified from USACE, 1994)7-23
7-4	Average degree of consolidation, U, versus time factor, T_v , for uniform
	initial increase in pore water pressure7-32
7-5	Summary of abutment movements (Nicu, et al., 1971)7-43

LIST OF SYMBOLS

Chapter 1

AASHTO	American Association of State Highway and Transportation Officials
AC	Asphaltic concrete
CMAR	Construction manager at risk
D-B	Design-build
FHWA	Federal Highway Administration
MSE	Mechanically stabilized earth
NHI	National Highway Institute
NMDOT	New Mexico Department of Transportation
PCC	Portland cement concrete
RCC	Reinforced cement concrete
RSS	Reinforced soil slope(s)
USDA	United States Department of Agriculture
USGS	Unites States Geological Survey

Chapter 2

A	Overall contact area
AASHTO	American Association of State Highway and Transportation Officials
В	Width
c	Cohesion
c'	Effective cohesion
D _r	Relative density
D _s , DOSI	Depth of significant influence
e	Void ratio
e _{max}	Maximum void ratio
e_{min}	Minimum void ratio
Fa	Tangential force
F _r	Shearing resistance
G	Specific gravity
Gs	Specific gravity of the solid phase
h	Embankment height
h _w	Depth to water table
K	Value of proportionality constant; coefficient of lateral earth pressure
Ka	Coefficient of active earth pressure
Ko	Coefficient of lateral earth pressure "at rest"
K _p	Coefficient of passive earth pressure
K_w	Coefficient of lateral earth pressure for water
L	Length
LI	Liquidity index
LL	Liquid limit
n	Porosity
Р	Load applied
pa	Active lateral pressure

p _f	Final stress = effective overburden pressure + pressure increment due to
-	external loads
\mathbf{p}_{h}	Lateral stress
PI	Plasticity index
PL	Plastic limit
P _n	Normal force
po	Effective overburden pressure
p _p	Passive lateral pressure
p_t	Total overburden pressure
Q	Load
q , q ₀	Unit load of embankment
S	Degree of saturation
SI	Shrinking index
SL	Shrinkage limit
t	time
u	Porewater pressure
USCS	Unified Soil Classification System
V	Volume of the total soils mass
Va	Volume of air phase
Vs	Volume of solid phase
V_{v}	Volume of total voids
\mathbf{V}_{w}	Volume of water phase
W	Gravimetric water or moisture content
W	Weight of the total soil mass
\mathbf{W}_{a}	Weight of air phase
\mathbf{W}_{s}	Weight of solid phase
$W_{ m v}$	Weight of total voids
\mathbf{W}_{w}	Weight of water phase
Z	Depth
Z_{W}	Depth below water table
δ	Angle of interface friction
δ_a	active translation
δ_b	passive translation
Δp	Pressure due to external loads
Δu	Excess pore water pressure
γ	Total unit weight
γ'	Effective unit weight
$\gamma_{\rm b}$	Buoyant unit weight (same as effective unit weight)
Ύd	Dry unit weight
γ _s	Unit weight of the solid phase
Ysat	Saturated unit weight
$\gamma_{\rm T}$ or $\gamma_{\rm f}$	Total unit weight
γ _w	Unit weight of water
 ф	Angle of friction
ት ሰ'	Effective angle of internal friction
٣	

ν	Poisson's ratio
θ	Angle of obliquity
$\theta_{\rm m}$	Maximum angle of obliquity
σ	Total stress
σ'	Effective stress
σ_{n}	Normal stress
σ_n'	Effective normal stress
τ	Shearing strength
τ'	Effective shear stress (strength)
Chapter 3	
AASHTO	American Association of State Highway and Transportation Officials
AR	Area ratio
ASTM	American Society for Testing and Materials
BPT	Becker (Hammer) penetration test
CN	Overburden correction factor or stress normalization parameter
	Cone penetration test
CPTu PCPT	Piezocone penetration test
d	Displacement
	Displacement
D	Diameter of sampler cutting tin
D _e	Inside diameter of the sampling tube
D _i DMT	Elet plate dilatometer
	Plate diamotor of the compline type
	Department of Transportation
DOI	Department of Transportation
E _f	Energy efficiency
EK	Energy ratio
F	Force
FEMA	Federal Emergency Management Agency
FHWA	Federal Highway Administration
t _s	Sleeve friction
g	Gravitational constant
GPR	Ground penetrating radar
h	Drop height
i	Inclination
ICR	Inside clearance ratio
ID	Inside Diameter
ISRM	International Society of Rock Mechanics
KE	Kinetic energy
LPT	Large penetration test
m	Mass
Ν	SPT blows per foot
N1 ₆₀	Overburden-normalized energy-corrected blowcount
N_{60}	Energy-corrected SPT-N value adjusted to 60% efficiency
NAVFAC	Naval Facilities Engineering Command
NCR	No core recovery

N _{meas}	N-Value measured in the field
OD	Outside diameter
PE	Potential energy
PMT	Pressuremeter test
po	Vertical effective pressure at the depth where the SPT is performed
PVC	Polyvinyl chloride
q _c	Cone tip resistance
q_t	Tip resistance
R_{f}	Friction ratio
RQD	Rock quality designation
$\mathbf{S}_{\mathbf{t}}$	Sensitivity
SASW	Spectral analysis of surface waves
SBT	Soil behavioral type
SCPTu	Seismic cone piezocone penetration test
SPT	Standard Penetration Test
SWPPP	Storm Water Pollution Prevention Plan
ts	Shear wave time
u _m	Pore water pressure
USCS	Unified Soil Classification System
USEPA	United States Environmental Protection Agency
USGS	Unites States Geological Survey
V	Impact velocity
VST	Vane shear test
W	Work

Chapter 4

AASHTO	American Association of State Highway and Transportation Officials				
ASTM	American Society for Testing and Materials				
Cc	Coefficient of curvature				
Cu	Coefficient of uniformity				
D ₁₀	Diameter of soil particles of which 10% of the soil is finer				
D ₃₀	Diameter of soil particles of which 30% of the soil is finer				
D ₆₀	Diameter of soil particles of which 60% of the soil is finer				
DOT	Department of Transportation				
EGS	Effective grain size				
F	Percent passing No. 200 sieve				
FHWA	Federal Highway Administration				
GI	Group index				
GIS	Geographic information system				
GSD	Grain size distribution				
IGM	Intermediate geomaterial				
Is	Point load index				
ISRM	International Society of Rock Mechanics				
LI	Liquid index				
LL	Liquid limit				
Ν	SPT blows per foot				
N ₆₀	Energy-corrected SPT-N value adjusted to 60% efficiency				
----------------------	--	--	--	--	--
NAVFAC	Naval Facilities Engineering Command				
PI	Plasticity index				
PL	Plastic limit				
RMR	Rock mass rating				
RQD	Rock quality designation				
SPT	Standard penetration test				
U.S.	United States				
USCS	Unified Soil Classification System				
USDA	United States Department of Agriculture				
Chapter 5					
A	Activity index				
А	Area				
AASHTO	American Association of State Highway and Transportation Officials				
ASTM	American Society for Testing and Materials				
В	Bulk modulus				
с	Cohesion				
С	Permeability coefficient				
C_{α}	Coefficient of secondary compression				
c'	Effective stress cohesion intercept				
c' _{cu}	Effective stress cohesion from CU test				
CBR	California Bearing Ratio				
C _c	Compression index				
C _{ce}	Modified compression index				
CD	Consolidated drained triaxial test				
CF	Clay fraction				
c _h	Coefficient of horizontal consolidation				
co	Compacted cohesion				
СР	Collapse potential				
Cr	Recompression index				
C _{rε}	Modified recompression index				
c _{sat}	Saturated cohesion				
CU	Consolidated undrained triaxial test				
c _u	Apparent cohesion				
c _v	Coefficient of consolidation				
c _v	Coefficient of vertical consolidation				
C_{α}	Secondary compression index				
$C_{\alpha\epsilon}$	Modified secondary compression index				
D	Distance between contact points of platens				
D	Vane diameter				
D ₁₀	Diameter of soil particles of which 10% of the soil is finer				
D ₆₀	Diameter of soil particles of which 60% of the soil is finer				
De	Equivalent core diameter				
D _{max}	Maximum diameter of soil particle				
D_{min}	Minimum diameter soil particles				

D _r	Relative density					
ds	Equivalent diameter					
e	Void ratio					
e _{max}	Maximum void ratio					
e _{min}	Minimum void ratio					
Е	Young modulus					
Ei	Elastic modulus of intact rock					
Em	Elastic modulus of rock mass					
e _{max}	Maximum void ratio					
e _{min}	Minimum void ratio					
eo	Initial void ratio					
E or E _s	Elastic modulus					
FHWA	Federal Highway Administration					
g	Gravitational constant					
G	Shear modulus					
Gs	Specific gravity					
Н	Height of vane					
Н	Soil layer thickness					
H/D	Height to diameter ratio					
Ho	Initial height of specimen					
i _B	Angle of taper at the bottom of the vane					
IL	Incremental load					
Is	Point load strength index					
I _{s(50)}	Size-corrected point load strength index					
i _T	Angle of taper at the top of the vane					
k	Hydraulic conductivity					
k _{PLT}	Size correction factor					
LI	Liquid index					
LIR	Load increment ratio					
LL	Liquid limit					
LVDT	Linear variable differential transducer					
md	Man-days					
MPC	Modified Proctor compaction					
Ms	Mass of solid component of sample					
M _t	Total mass					
Ν	Normal stress					
Ν	SPT blows per foot					
N1 ₆₀	Overburden-normalized energy-corrected blowcount					
N ₆₀	Energy-corrected SPT-N value adjusted to 60% efficiency					
NAVFAC	Naval Facilities Engineering Command					
NC	Normally consolidated					
n _h	Rate of increase of soil modulus with depth					
OC	Over consolidated					
OCR	Overconsolidation ratio					
OMC	Optimum moisture content					
Р	Breaking load					

pc	Maximum past effective stress				
p _c	Preconsolidation pressure				
PI	Plasticity index Plastic limit				
PL	Plastic limit				
$\mathbf{p}_{\mathbf{o}}$	Effective overburden pressure				
p_t	Total vertical stress				
q_c	Cone tip resistance				
q_{u}	Unconfined compression stress				
RC	Relative compaction				
RMR	Rock mass rating				
RQD	Rock quality designation				
S	Degree of saturation				
S, S _t	Sensitivity				
S _{collapse}	Collapse settlement				
SL	Shrinkage limit				
SPC	Standard Proctor compaction				
SPT	Standard penetration test				
s _{r, VST}	Remolded undrained shear strength (obtained by using VST data)				
St, VST	Sensitivity (obtained by using VST data)				
Su	Undrained shear strength				
S _{u, VST}	Undrained shear strength (obtained by using VST data)				
s_u/p_o	Undrained strength ratio				
Т	Tangential (shear) force				
Т	Torque (related to VST)				
t	Vane edge thickness				
t ₁₀₀	Time corresponding to 100% of primary consolidation				
T_{max}	Maximum torque (related to VST)				
T _{net}	Difference between T _{max} and T _{rod}				
T_{rod}	Rod friction (related to VST)				
u	Pore water pressure				
UC	Unconfined compression test				
U.S.	United States				
USBR	United States Bureau of Reclamation				
USCS	Unified Soil Classification System				
UU	Unconsolidated undrained triaxial test				
V	Coefficient of variation				
V_s	Volume of soil solids				
VST	Vane shear test				
\mathbf{V}_{t}	Total volume				
W	Specimen width				
W	Water content				
Wn	Natural moisture content				
Wopt	Optimum moisture content				
$\mathbf{W}_{\mathbf{s}}$	Weight of solid component of soil				
\mathbf{W}_{t}	Total weight				
Z	Depth below ground surface				

Δe	Change in void ratio				
ΔH_c	Change in height upon wetting				
$\Delta \sigma$	Incremental stress				
3	Strain				
γ	Unit weight				
γ'	Effective unit weight				
γ_b	Buoyant unit weight (same as effective unit weight)				
$\gamma_{d field}$	Field dry unit weight				
$\gamma_{\rm d}$ or $\gamma_{\rm dry}$	Dry unit weight				
γ _{d-max}	Maximum dry unit weight				
γ_{s}	Unit weight of solid particles in the soil mass				
γ_{sat}	Saturated unit weight				
γ_t or γ_{tot}	Total unit weight				
γ_t	Moist unit weight of compacted soil				
$\gamma_{\rm w}$	Unit weight of water				
φ	Angle of internal friction				
φ'	Effective friction angle				
φ	Friction				
φ'	Peak effective stress friction angle				
φ' _{cu}	Effective friction angle from CU test				
φ'r	Residual effective stress friction angle				
μ	Coefficient of friction				
ν	Poisson ratio				
ρ	Density				
$\rho_d \text{ or } \rho_{dry}$	Dry mass density				
$\rho_t \text{ or } \rho_{tot}$	Total mass density				
ρ_t	Moist (total) mass density				
σ'	Effective normal stress				
σ_{c}	Uniaxial compressive strength				
σ_n	Normal stress				
σ'_p	Preconsolidation stress				
σ_{vo}	Total vertical stress				
τ	Shear stress				
%C	Percent collapse				

Chapter 6				
AASHTO	American Association of State Highway and Transportation Officials			
b	Unit width			
b	Width of slice			
с	Cohesion			
с	Cohesion component of shear strength			
с	Unit cohesion			
c'	Effective cohesion			
CD	Consolidated drained triaxial test			
Cd	Developed cohesion			
ČU	Consolidated undrained triaxial test			
d	Depth factor			
D	Depth ratio			
- F _c	Average factor of safety with respect to cohesion			
FHWA	Federal Highway Administration			
FS or FOS	Factor of safety			
F ₊	Average factor of safety with respect to friction angle			
-Ψ h	Depth less than or equal to the depth of saturation			
Н	Height			
Н	Height of soil layer in active wedge			
h	Slope depth			
Н	Slope height			
H'w	Height of water within the slope			
H _{Fill}	Fill height			
h;	Height of laver at center of slice			
H _t	Tension crack height			
hw	Depth from groundwater surface to the centroid point on the circle			
	Depth of water outside the slope			
H _{zone}	Height of zone			
I _N	Interslice normal (horizontal) force			
Is	Interslice shear (vertical) force			
Ка	Coefficient of active earth pressure			
K _n	Coefficient of passive earth pressure			
1	Arc length of slice base			
Ls	Radius of circle			
Lw	Level arm distance to the center of rotation			
Ň	Normal force component or total normal force			
N	Number of reinforcement layers			
N'	Effective normal force component			
N _{ef}	Critical stability number			
N _o	Stability number			
N _a	Stability number			
P _a	Active force (driving)			
- a Do	In-situ vertical effective overburden pressure			
ru P.	Passive force (resisting)			
• p	Surcharge load			
Ч	Surenui 5e Iouu			

R	Moment arm				
R _c	Coverage ratio of the reinforcement				
RSS	Reinforced soil slope Frictional force along failure plane				
S	Frictional force along failure plane				
S	Shear strength along failure plane Standard penetration test				
SPT	Standard penetration test				
S_v	Vertical spacing of reinforcement				
Т	Tangential force component				
Ta	Sum of available tensile force per width of reinforcement for all reinforcement layers				
tan ø	Coefficient of friction along failure surface				
T _{MAX}	Maximum design tension				
T _{S-MAX}	Maximum tensile force				
T _{zone}	Maximum reinforced tension required for each zone				
U	Pore water force				
u	Water pressure on slice base				
u	Water uplift pressure against failure surface				
UU	Unconsolidated undrained triaxial test				
W	Weight of slice				
Wi	Partial weight				
W _T	Total slice weight				
α	Angle between vertical and line drawn from circle center to midpoint of slice base				
$\alpha_{\rm w}$	Slope of water table from horizontal				
$\gamma_{\rm Fill}$	Fill soil unit weight				
μ' _w	Seepage correction factor				
μ_q	Surcharge correction factor				
μ_t	Tension crack correction factor				
$\mu_{\rm w}$	Submergence correction factor				
σ	The total normal stress against the failure surface slice base due to the weight of soil and water above the failure surface				
ΣW_i	Total weight of slice				
β	Angle of slope				
β	Inclination of the slope				
φ	Angle of internal friction				
φ'	Effective angle of internal friction				
φ _d	Developed angle of internal friction				
γ	Unit weight of soil				
γ	Unit weight of soil in the active wedge				
γ _i	Unit weight of layer i				
γ	Effective unit weight				
γ	Moist unit weight				
v m V	Saturated unit weight				
I sat	Total soil unit weight				
Ϋ́t	I Utal SOIL UIIIT WEIGHT				
$\gamma_{ m w}$	Unit weight of water				

σ'_n	Effective stress between soil grains
τ	Frictional shearing resistance
τ	Total shear strength
τ_d	Developed shear strength

Chapter 7

AASHTO	American Association of State Highway and Transportation Officials				
C′	Bearing capacity index				
C_c	Compression index				
$C_{c\epsilon}$	Modified compression index				
Cr	Mean slope of the rebound laboratory curve				
$C_{r\epsilon}$	Modified recompression index				
Cv	Coefficient of consolidation				
C_{α}	Coefficient of secondary consolidation (determined from lab consolidation test)				
$C_{\alpha\epsilon}$	Modified secondary compression index				
Ds	Depth of soft soil beneath the toe of the end slope of the embankment				
e	Void ratio				
eo	Initial void ratio at p_0				
FHWA	Federal Highway Administration				
FS _{SQ}	Safety factor against failure by squeezing				
Н	Height of the fill				
Н	Thickness of soil layer considered				
H _d	Distance to the drainage boundary				
$h_{\rm f}$	Fill height				
H _o	Layer thickness				
ID	Inner Diameter				
N1 ₆₀	Number of blows per foot corrected for overburden and hammer efficiency				
NCHRP	National Cooperative of Highway Research Program				
OCR	Over consolidation ratio				
pc	Maximum past effective stress				
pc	Maximum past vertical pressure (preconsolidation)				
$p_{\rm f}$	Final effective vertical stress at the center of layer n				
$p_{\rm f}$	Final pressure applied to the foundation subsoil				
$p_{\rm f}$	Final stress				
$p_{\rm f}$	Total embanklment pressure				
PI	Plasticity index				
po	Effective overburden pressure				
po	Existing effective overburden pressure				
po	Initial effective vertical stress at the center of layer n				
RSS	Reinforced soil slope				
S	Degree of saturation				
S	Settlement				
S _c	Settlement due to primary consolidation				
SPT N	Number of blows per foot (blow/0.3m)				
SPT	Standard penetration test				

S _s Settlement due to secondary compression					
S _t Settlement at time t	Settlement at time t				
s _u Undrained shear strength of soft soil beneath em	Undrained shear strength of soft soil beneath embankment				
Sultimate Settlement at end of primary consolidation	Settlement at end of primary consolidation				
t Time					
t _{1 lab} Time when secondary compression begins					
t ₁ Time when approximately 90% of primary comp	ression has occurred				
t ₁₀₀ Time for 100% of primary consolidation					
t _{2 lab} Arbitrary time on the curve					
t ₂ The service life of the structure or any time of in	terest				
t ₉₀ Time for 90% of primary consolidation					
T_v Time factor					
U Average degree of consolidation					
u _s Hydrostatic pore water pressure at any depth					
u _s Initial hydrostatic pore water pressure					
USACE United States Army Corps of Engineers					
u _{sb} Hydrostatic pore water pressure at bottom of laye	Hydrostatic pore water pressure at bottom of layer				
u _{st} Hydrostatic pore water pressure at top of layer	Hydrostatic pore water pressure at top of layer				
ut Total pore water pressure at any depth after time	t				
Z _I Zone of influence					
Δe Change in void ratio					
ΔH Settlement					
Δp Distributed embankment pressure					
Δp Load increment					
Δp Stress increase					
Δp_o Effective vertical stress increment					
Δp_t Applied vertical stress increment					
Δu Excess pore water pressure at any depth after time	ne t				
Δu_i Initial excess pore water pressure					
ε_v Vertical strain					
γ Unit weight of fill					
γ' Effective unit weight					
$\gamma_{\rm b}$ Buoyant unit weight (same as effective unit weight)	(ht)				
$\gamma_{\rm f}$ Fill unit weight	- ·				
A Angle of slope					

[THIS PAGE INTENTIONALLY BLANK]

CHAPTER 1.0 INTRODUCTION

1.1 PURPOSE AND SCOPE

The Soils and Foundations course is sponsored by the National Highway Institute (NHI) to provide practical knowledge in geotechnical and foundation engineering for both civil engineering generalists and geotechnical and foundation specialists. The course is developed around the design and construction aspects of a highway project that includes bridges, earthworks and earth retaining structures. Bridges can range from single span bridges to multi-span bridges as part of a stack interchange. Bridges may be constructed over land, in which case they are known as viaducts, or over water. Examples of transportation facilities that include bridge structures are shown in Figures 1-1 to 1-4. Not all highway projects include bridge structures. Figure 1-5 shows an example of a highway corridor without bridges and in an environmentally sensitive area.



Figure 1-1. Aerial view of a pair of 3-span Interstate 10 (I-10) bridges over a local roadway in Tucson, Arizona.

FHWA NHI-06-088 Soils and Foundations – Volume I

1 - 1 Engineering-pdh.com | ged-114 |



Figure 1-2. Example of 3-span roadway bridges over another roadway.



Figure 1-3. The "BIG I" stack interchange at the intersection of I-40 and I-25 in Albuquerque, New Mexico (Photo: Courtesy of Bob Meyers, NMDOT) (Note: A stack interchange is a free-flowing junction between two or more roadways that allows turning in all directions).



Figure 1-4. A major multi-span bridge structure over water (George P. Coleman Bridge over the York River in Yorktown, Virginia).



Figure 1-5. Example of a roadway bounded by cut slopes and wetlands in an environmentally sensitive area.

FHWA NHI-06-088 Soils and Foundations – Volume I

1 - 3 Engineering-pdh.com | geo-114 |

Highway projects can involve a full range of geotechnical engineering assessments and alternatives depending on the complexity of the project. For example, the foundations for the bridge piers and abutments may be shallow foundations, or deep foundations such as driven piles and/or drilled shafts. The approach embankments may be unreinforced slopes or reinforced soil slopes (RSS). Cut slopes may be in rocks and/or soils. Retaining walls may be used at abutments and/or along approaches and may consist of cantilevered walls or mechanically stabilized earth (MSE) walls. The ground under the bridge may be soft and require improvement. Similarly, the transportation corridor may traverse wetlands and special ground improvement measures may be required. Pavements seen in Figures 1-1 to 1-3 and 1-5 may be constructed of asphaltic concrete (AC), Portland cement concrete (PCC) or reinforced cement concrete (RCC) on a variety of subgrade materials¹.

Recognizing the need for consistent guidance for practitioners involved in the planning, design and construction of transportation facilities that include bridges and associated structures, the Federal Highway Administration (FHWA) developed the first version of this manual in 1982. Subsequently, the manual was revised in 1993 and in 2000. The present reference manual, which is the fourth edition, represents a significant update and supersedes earlier editions of the manual. In particular, this manual has been updated to reflect the current standard of geotechnical practice in the planning, design and construction of transportation facilities. As part of this effort, this edition provides guidance consistent with that found in the latest FHWA manuals and courses.

This edition of the manual, like the earlier editions, is geared towards the practicing engineer who routinely deals with soils and foundations problems on highway projects but who may not have a thorough theoretical background of soil mechanics or foundation engineering. The overall goals of this manual are: (i) to explain geotechnical engineering principles, and (ii) to provide sound methods and recommendations related to safe, cost-effective design and construction of geotechnical features. The reader is encouraged to develop an appreciation for the design and construction of geotechnical features in all phases of a project that may influence or could be influenced by his/her work (cost, quality, time, and performance). Coordination among generalists and specialists in all project phases is stressed.

The manual contains an appendix (Appendix A) wherein the geotechnical engineering input to a bridge project is traced from conception (scoping) to completion (post construction) in a serialized illustrative problem that incorporates many of the technical concepts presented in the course. The bridge project used in Appendix A is based on an actual project in the State of New York.

¹ Pavement structures are not addressed in this manual.

1.2 SOILS AND FOUNDATIONS FOR HIGHWAY FACILITIES

Civilization's earliest attempts at construction probably involved soil; however, the understanding of the role of soil as a foundation or building material developed by trial and error. Since the early 20th century, an improved understanding of soil behavior has been achieved by applying the principles of physics, solid mechanics, fluid mechanics, strength of materials, and structural engineering to define soil behavior. The body of knowledge developed by analyzing soil behavior on a theoretically sound basis is called "soil mechanics" and its application to solution of actual problems is called "geotechnical engineering." Soil is a complex three-phase medium that contains various amounts of water and/or air surrounding the solid particles. It is not a solid mass, i.e., a continuum, as many of the theories of solid mechanics require. Therefore, an entirely theoretical solution of the most commonly encountered soil problems is not practical. The most practical solution to solitor to solution of the sources of information as illustrated in Figure 1-6.



Figure 1-6. Combinations of sources of information required to solve geotechnical engineering issues.

1. <u>Experience</u> obtained from previous projects can be developed into the empirical or "rule of thumb" procedures followed by some engineers/specialists today. Often some geotechnical designers rely almost exclusively on experience. The weakness of using this approach exclusively is that experience does not always recognize the factors that cause differences in the engineering properties of soils. What works well at one location may not succeed with the same type of soil at another location because of a change in conditions, such as water content. The current state of the practice

FHWA NHI-06-088 Soils and Foundations – Volume I requires the geotechnical specialist to rely on testing and theory in addition to experience or rules of thumb.

- 2. <u>Testing</u> of representative samples of soil in the field and laboratory is required to obtain information on the engineering properties and the characteristics of soils. The results of subsequent engineering analyses will be only as good as the soils data used as input.
- 3. <u>Theory</u> based on principles from various fields of engineering and science tempered by assumptions to fit reality is used to explain or predict the behavior of soils under various conditions.

The engineering analysis of soils is often more complex than the analysis of other construction materials because soil is not a continuum. Therefore, soil typically does not strictly meet the assumptions of the theories of solid mechanics and strength of materials. By contrast, steel and concrete are relatively uniform solids that have predictable properties. For example, the strength of steel is predictable within the elastic range of loading. Even though the strength of steel and concrete may be "ordered," that strength will be essentially constant under a wide range of climatic conditions. Structures can then be built of these materials with a high degree of confidence regarding the material strength.

The engineering properties of the soils, on the other hand, can vary widely over time and space so that their physical properties cannot be defined accurately at all locations for all conditions. Since soils are composed of a mixture of three dissimilar materials - soil solids, liquid fluids (usually water), and gaseous fluids (usually air) - their properties are influenced by the interaction of these three phases in the soil mass. Some of the factors that influence the behavior of soil are:

- 1. size, shape, and distribution of soil particles,
- 2. mineralogy,
- 3. degree of packing of soil particles,
- 4. amount of water in the soil,
- 5. climatic conditions, and
- 6. degree of confinement (i.e., depth).

In short, engineers should understand that the engineering properties of soils can be significantly influenced by many factors.

The success or failure of a geotechnical feature is often decided in the early stages of a project. Geotechnical engineering is a specialized field. Therefore, to assure success of a

project, the input of a qualified and experienced geotechnical specialist should begin at project inception and continue until completion of construction. Geotechnical designs are based upon soil properties that are generally defined from a subsurface exploration and laboratory testing of a very minute physical sampling of the soils. The volume of site soils excavated and exposed during construction is many orders of magnitude greater than that from the subsurface explorations. Thus, a great deal of geotechnical information can and should be gathered during the construction phase of a project to validate or revise the geotechnical design parameters. **A geotechnical design should not be considered complete until construction has been successfully completed.** A geotechnical specialist should also be involved during post-construction activities such as instrumentation monitoring, participating in resolution of contractor disputes and claims activities, and documenting lessons learnt on the project.

Based on the above considerations, early interactions at a project's scoping phase among the geotechnical specialist, other engineers/specialists, the project manager and the contractor will prevent the design of a project element, or even worse the construction of an element, such as alignment or grade, that may require costly foundation treatment later. It is imperative that good communication and interaction exist among the geotechnical specialist, structural specialist, construction specialist, project manager and contractor throughout the design and the construction process. Such interactions and involvement are required to insure a cost-effective design and to minimize change orders and contract disputes resulting from design deficiencies and/or misunderstandings during construction. The importance of communication and interaction is stressed throughout this manual and cannot be overemphasized.

The flow chart in Figure 1-7 and the six phases identified in Table 1-1 describe the details of geotechnical involvement in a typical project using the design-bid-build (D-B-B) procurement process where the geotechnical specialist interacts with the owner to provide information to the contractor. There are several other procurement processes such as the design-build (D-B) process and the Construction Manager at Risk (CMAR) process. In each such alternative process, the geotechnical specialist is concurrently dealing with both the owners and the contractors, with the geotechnical specialist's direct client being the contractor. Even though the geotechnical involvement is somewhat different in each of these types of procurement processes, it is important to realize that all the items listed in Figure 1-7 as well as in Table 1-1 must be addressed to achieve a successful project.





FHWA NHI-06-088 Soils and Foundations – Volume I

1 - 8 engineering-pdh.com | geo-114 |

Phase	Function				
PHASE 1	1. Study project information, scope and existing data. (a) USGS topographic				
Planning	Conduct site inspection with project manager. (a) inspect nearby structures for				
	settlement, scour, etc. (b) assess site conditions.				
	3. Prepare terrain reconnaissance report for planning engineer. Include: (a) anticipated soil, rock and water conditions. (b) major problems or costs that will hinder or preclude construction of the facility. (c) right-of-way required for possible special geotechnical treatment. (d) beneficial shifts in alignment.				
PHASE 2	1. Assess facility locations with regard to major soil issues.				
Design	2. Provide input for specific uses, e.g., soil/rock scour.				
Alternatives	3. Implement subsurface exploration and laboratory testing programs after design approval.				
PHASE 3 Prepare	 Review and interpret subsurface information from field and laboratory work. Provide preliminary input to bridge/roadway engineer. 				
Detail Plans	3. Submit report to bridge and roadway engineer summarizing the investigations				
	along with recommendations. Include: (a) coordination with roadway				
	provisions and specifications. (c) subsurface profile. (d) special				
PHASE 4	1. Review final plans				
Final Design	2. Make appropriate adjustments to geotechnical information if necessary				
PHASE 5	1. Provide geotechnical support to the resident engineer during construction.				
Construction	Examples are as follows:				
	(A) <i>Driven Piles</i> : (a) submit wave equation analysis to bridge engineer. (b) hammer approval. (c) stress analysis. (d) required blow count. (e) special				
	effects, etc. (B) Drilled Shafts: (a) shaft excavation information e.g. need for casing or				
	slurry. (b) steel placement tolerances. (c) tube placement for integrity testing.				
	(d) concreting requirements. (e) post-installation integrity tests, etc.				
	(C) Spread footings: (a) evaluation criteria of stiffness of soils at base of footing excavation etc.				
	(D) <i>Retaining Walls</i> : (a) construction process based on whether wall is top-down				
	or bottom-up construction. (b) backfill compaction requirements, etc.				
	(E) Slopes/Embankments: (a) backfill compaction requirements. (b) final grading				
	of a slope, etc.				
	2. Attend preconstruction meeting with resident engineer and foundation inspector.				
	Explain various important geotechnical issues: (a) general geologic profile. (b)				
	resistance values taking into account strain compatibility for drilled shafts (e)				
	possible geotechnical problems.				
	3. Troubleshoot soils-related problems as required.				
	4. Assist with structural foundation load tests as required.				
PHASE 6	1. Review actual pile results versus predicted. Include: (a) blow count for driven				
Post	piles. (b) installation methods for drilled shafts. (c) length. (d) field problems.				
Construction	(e) load test capacity.				
	2. Participate in contractor disputes and claims activities.				

Table 1-1Geotechnical involvement in project phases

1.3 ORGANIZATION OF MANUAL

The organization of this manual follows a project-oriented approach whereby a typical bridge project is traced from scoping stage through design computation of settlement, allowable footing pressure, selection of earth retaining structure, to the construction of approach embankments, pile driving or shaft drilling operations, etc. Recommendations are presented on how to layout borings efficiently, how to minimize approach embankment settlement and eliminate the bump at the end of-the bridge, how to design the most cost-effective deep foundation, and how to transmit design information properly to contractors directly through plans, specifications, and special provisions and/or indirectly through contact with the project engineer.

The concepts presented in various chapters are concise and specifically directed at a particular operation in the geotechnical design and construction process. Basic example problems are included in several sections to illustrate how concepts are used and for hands-on knowledge. Continuity between chapters is achieved by sequencing the information in the normal progression of a geotechnical project. In addition, the manual contains an appendix (Appendix A) with the solution to geotechnical issues, in a serialized format, for a highway project involving a bridge and approach embankment over soft ground. In each phase of the fictitious project the geotechnical concepts are developed into specific designs or recommendations for that segment of the problem.

The organization of the manual and a summary of the material presented in each chapter follow.

- Chapter 1 this chapter (Introduction) presents the purpose and scope of NHI's Soils and Foundation course and provides introductory material about geotechnical activities related to the design and construction aspects of a highway project.
- Chapter 2 (Stress and Strain in Soils) presents basic phase (weight-volume) relationships, effective stress principles, computation of overburden pressures, estimating vertical and horizontal stresses in soils due to external (superimposed) loads on geomaterials.
- Chapter 3 (Subsurface Explorations) presents basic information on subsurface exploration procedures including terrain reconnaissance, subsurface investigation methods, standard penetration test procedures, undisturbed soil sampling, and guidelines for the geotechnical investigation of both roadway and structure sites.

- Chapter 4 (Engineering Description, Classification and Characteristics of Soils and Rocks) discusses the basic engineering characteristics of the main soil and rock groups, and presents procedures for describing and classifying soils and rocks, and for developing a subsurface profile.
- Chapter 5 (Laboratory Testing for Geotechnical Design and Construction) presents several commonly used laboratory tests for soils and rocks including soil classification, basic consolidation and strength testing concepts. This chapter also includes guidelines for laboratory testing on a typical highway project, and a procedure for summarizing and choosing design values from laboratory tests.
- Chapter 6 (Slope Stability) presents the general procedures for the stability analysis of embankments and cut slopes. Basic methods of analysis are shown and explained with emphasis on practical application to highway embankments. Stability charts are presented for a rapid preliminary evaluation of slope stability. Remedial methods are discussed for stability problems.
- Chapter 7 (Approach Roadway Deformations) distinguishes between internal and external settlement within and below embankment fills. Recommendations are provided for select fill and compaction control for soils placed near abutments. Immediate (i.e., short-term) and consolidation (i.e., long-term) settlement, and lateral squeeze are discussed and methods of analysis are presented.
- Chapter 8 (Shallow Foundations) presents the FHWA-recommended foundation design procedure for shallow foundations in soils and rocks. The analysis for both bearing capacity and settlement are discussed and the application of results is presented. Economic considerations of shallow versus deep foundations are discussed.
- Chapter 9 (Deep Foundations) discusses basic concepts in the selection and design of both driven piles and drilled shafts in soils and rocks. Analyses for skin friction and end bearing are addressed for cohesive soil, cohesionless soils and rocks. Foundation installation effects on design are discussed as well as group effects, negative skin friction and deep foundation settlement. The components of pile driving equipment are presented. The use of driving formulae and the wave equation analysis in construction is introduced monitoring. Generic information is presented on the use of load testing. Construction considerations for drilled shafts are also presented.

1 - 11 engineering-pdh.com | geo-114 |

- Chapter 10 (Earth Retaining Structures) presents the basic lateral earth pressure theories, briefly introduces various wall types, presents a wall classification system, and presents the external stability analysis for a typical fill wall.
- Chapter 11 (Geotechnical Reports) presents outlines for various types of geotechnical reports, discussions on subsurface profiles, guidelines on the use of disclaimers, and suggestions for how to incorporate geotechnical information into contract documents.

1.4 **REFERENCES**

A detailed list of references is provided in Chapter 12. However, certain primary references were used to develop materials for many sections in this document. In addition, FHWA has either developed or is in the process of developing detailed guidance in the topic areas covered in this document. Most of those documents are reference manuals for geotechnical courses developed for the National Highway Institute. Both the FHWA and other primary references are listed below. The reader is directed to the web site for the FHWA National Geotechnical Team (NGT), <u>http://www.fhwa.dot.gov/engineering/geotech/index.cfm</u>, to obtain information on all geotechnical publications and software that have been developed by FHWA. The NAVFAC manuals and many other public domain manuals can be downloaded from <u>http://www.geotechlinks.com</u>.

1.4.1 Primary FHWA References

- FHWA (1988). Checklist and Guidelines for Review of Geotechnical Reports and Preliminary Plans and Specifications. Report No. FHWA ED-88-053, Federal Highway Administration, U.S. Department of Transportation. Revised 2003.
- FHWA (1999). Drilled Shafts: Construction Procedures and Design Methods. Report No. FHWA-IF-99-025, Authors: O'Neill, M. W. and Reese, L. C. Federal Highway Administration, U.S. Department of Transportation.
- FHWA (2001a). Soil Slopes and Embankment Design Reference Manual. Report No. FHWA-NHI-01-026. Authors: Collin, J.G., Hung, J.C., Lee, W.S., and Munfakh, G., Federal Highway Administration, U.S. Department of Transportation.
- FHWA (2002a). Geotechnical Engineering Circular 5 (GEC5) Evaluation of Soil and Rock Properties. Report No FHWA-IF-02-034. Authors: Sabatini, P.J, Bachus, R.C,

Mayne, P.W., Schneider, J.A., Zettler, T.E., Federal Highway Administration, U.S. Department of Transportation.

- FHWA (2002b). Subsurface Investigations (Geotechnical Site Characterization). Report No. FHWA NHI-01-031, Authors: Mayne, P. W., Christopher, B. R., and DeJong, J., Federal Highway Administration, U.S. Department of Transportation.
- FHWA (2002c). Geotechnical Engineering Circular 6 (GEC6), Shallow Foundations. Report No. FHWA-SA-02-054, Author: Kimmerling, R.E. 2002, Federal Highway Administration, U.S. Department of Transportation.
- FHWA (2006a). Design and Construction of Driven Pile Foundations Vol. I and II, Report No. FHWA-NHI-05-042 and FHWA-NHI-05-043, Authors: Hannigan, P.J., G.G. Goble, G. Thendean, G.E. Likins and F. Rausche., Federal Highway Administration, U.S. Department of Transportation.
- Geotechnical Engineering Notebook. FHWA Geotechnical Guidelines GT1 –GT16. http://www.fhwa.dot.gov/engineering/geotech/index.cfm.

1.4.2 Other Primary References

- AASHTO (1988). Manual on Foundations Investigations, Standard Specifications for Highway Bridges, American Association of State Highway and Transportation Officials, Washington, D.C.
- AASHTO (2002). *Standard Specifications for Highway Bridges*. 17th Edition, American Association of State Highway and Transportation Officials, Washington, D.C.
- AASHTO (2004 with 2006 Interims). AASHTO LRFD Bridge Design Specifications, 3rd Edition, American Association of State Highway and Transportation Officials, Washington, D.C.
- AASHTO (2006). Standard Specifications for Transportation Materials and Methods of Sampling and Testing, Parts I and II. American Association of State Highway and Transportation Officials, Washington, D.C.
- ASTM (2006). Annual Book of ASTM Standards Sections 4.02, 4.08, 4.09 and 4.13. ASTM International, West Conshohocken, PA.

FHWA NHI-06-088 Soils and Foundations – Volume I

1 - 13 engineering-pdh.com | ged-114 |

- Holtz, R. D. and Kovacs, W. D. (1981). *An Introduction to Geotechnical Engineering*, Prentice Hall, Englewood Cliffs, NJ.
- Lambe, T. W., and Whitman, R. V. (1979). *Soil Mechanics: SI Version*, John Wiley & Sons, Inc., New York, NY.
- NAVFAC (1986a). *Design Manual 7.01 Soil Mechanics*, Department of the Navy, Naval Facilities Engineering Command, Alexandria, VA. (can be downloaded from <u>http://www.geotechlinks.com</u>).
- NAVFAC (1986b). *Design Manual 7.02 Foundations & Earth Structures*, Department of the Navy, Naval Facilities Engineering Command, Alexandria, VA. (can be downloaded from <u>http://www.geotechlinks.com</u>).

CHAPTER 2.0 STRESS AND STRAIN IN SOILS

Soil mass is generally a three phase system that consists of solid particles, liquid and gas. The liquid and gas phases occupy the voids between the solid particles as shown in Figure 2-1a. For practical purposes, the liquid may be considered to be water (although in some cases the water may contain some dissolved salts or pollutants) and the gas as air. Soil behavior is controlled by the interaction of these three phases. Due to the three phase composition of soils, complex states of stresses and strains may exist in a soil mass. Proper quantification of these states of stress, and their corresponding strains, is a key factor in the design and construction of transportation facilities.

The first step in quantification of the stresses and strains in soils is to characterize the distribution of the three phases of the soil mass and determine their inter-relationships. The inter-relationships of the weights and volumes of the different phases are important since they not only help define the physical make-up of a soil but also help determine the in-situ geostatic stresses, i.e., the states of stress in the soil mass due only to the soil's self-weight. The volumes and weights of the different phases of matter in a soil mass shown in Figure 2-1a can be represented by the block diagram shown in Figure 2-1b. Such a diagram is also known as a phase diagram. A block of unit cross sectional area is considered. The symbols for the volumes and weights of the different phases are shown on the left and right sides of the block, respectively. The symbols for the volumes and weights of the three phases are defined as follows:

$\mathbf{V}_{\mathrm{a}}, \mathbf{W}_{\mathrm{a}}$:	volume, weight of air phase. For practical purposes, $W_a = 0$.
V_w, W_w :	volume, weight of water phase.
$\mathbf{V}_{\mathrm{v}}, \mathbf{W}_{\mathrm{v}}$:	volume, weight of total voids. For practical purposes, $W_v = W_w$ as $W_a = 0$.
$\mathbf{V}_{\mathbf{s}}, \mathbf{W}_{\mathbf{s}}$:	volume, weight of solid phase.
V, W :	volume, weight of the total soil mass.

Although $W_a = 0$ so that $W_v = W_w$, V_a is generally > 0 and must always be taken into account. Since the relationship between V_a and V_w usually changes with groundwater conditions as well as under imposed loads, it is convenient to designate all the volume not occupied by the solid phase as void space, V_v . Thus, $V_v = V_a + V_w$. Use of the terms illustrated in Figure 2-1b, allows a number of basic phase relationships to be defined and/or derived as discussed next.



(a)



Figure 2-1. A unit of soil mass and its idealization.

FHWA NHI-06-088 Soils and Foundations – Volume I 2 – Stress and Strain in Soils December 2006

2.1 **BASIC WEIGHT-VOLUME RELATIONSHIPS**

Various volume change phenomena encountered in geotechnical engineering, e.g., compression, consolidation, collapse, compaction, expansion, etc. can be described by expressing the various volumes illustrated in Figure 2-1b as a function of each other. Similarly, the in-situ stress in a soil mass is a function of depth and the weights of the different soil elements within that depth. This in-situ stress, also known as overburden stress (see Section 2.3), can be computed by expressing the various weights illustrated in Figure 2-1b as a function of each other. This section describes the basic inter-relationships among the various quantities shown in Figure 2-1b.

2.1.1 Volume Ratios

A parameter used to express of the volume of the voids in a given soil mass can be obtained from the ratio of the volume of voids, V_v , to the total volume, V. This ratio is referred to as porosity, n, and is expressed as a percentage as follows:

$$n = \frac{V_v}{V} x100$$
 2-1

Obviously, the porosity can never be greater than 100%. As a soil mass is compressed, the volume of voids, V_v , and the total volume, V, decrease. Thus, the value of the porosity changes. Since both the numerator and denominator in Equation 2-1 change at the same time, it is difficult to quantify soil compression, e.g., settlement or consolidation, as a function of porosity. Therefore, in soil mechanics the volume of voids, V_v, is expressed in relation to a quantity, such as the volume of solids, V_s, that remains unchanging during consolidation or compression. This is done by the introduction of a quantity known as void ratio, e, which is expressed in decimal form as follows:

$$e = \frac{V_v}{V_s}$$
 2-2

Unlike the porosity, the void ratio can have values greater than 1. That would mean that the soil has more void volume than solids volume, which would suggest that the soil is "loose" or "soft." Therefore, in general, the smaller the value of the void ratio, the denser the soil. As a practicality, for a given type of coarse-grained soil, such as sand, there is a minimum and maximum void ratio. These values can be used to evaluate the relative density, D_r (%), of that soil at any intermediate void ratio as follows:

2 - 3

$$D_r = \frac{(e_{max} - e)}{(e_{max} - e_{min})} x100$$
 2-2a

At $e = e_{max}$ the soil is as loose as it can get and the relative density equals zero. At $e = e_{min}$ the soil is as dense as it can get and the relative density equals 100%. Relative density and void ratio are particularly useful index properties since they are general indicators of the relative strength and compressibility of the soil sample, i.e., high relative densities and low void ratios generally indicate strong or incompressible soils; low relative densities and high void ratios may indicate weak or compressible soils.

While the expressions for porosity and void ratio indicate the relative volume of voids, they do not indicate how much of the void space, V_v , is occupied by air or water. In the case of a saturated soil, all the voids (i.e., soil pore spaces) are filled with water, $V_v = V_w$. While this condition is true for many soils below the ground water table or below standing bodies of water such as rivers, lakes, or oceans, and for some fine-grained soils above the ground water table due to capillary action, the condition of most soils above the ground water table is better represented by consideration of all three phases where voids are occupied by both air and water. To express the amount of void space occupied by water as a percentage of the total volume of voids, the term **degree of saturation**, **S**, is used as follows:

$$S = \frac{V_w}{V_v} \times 100$$
 2-3

Obviously, the degree of saturation can never be greater than 100%. When S = 100%, all the void space is filled with water and the soil is considered to be **saturated**. When S = 0%, there is no water in the voids and the soil is considered to be **dry**.

2.1.2 Weight Ratios

While the expressions of the distribution of voids in terms of volumes are convenient for theoretical expressions, it is difficult to measure these volumes accurately on a routine basis. Therefore, in soil mechanics it is convenient to express the void space in gravimetric, i.e., weight, terms. Since, for practical purposes, the weight of air, W_a , is zero, a measure of the void space in a soil mass occupied by water can be obtained through an index property known as the *gravimetric* water or moisture content, w, expressed as a percentage as follows:

$$w = \frac{W_w}{W_s} \times 100$$
 2-4

The word "gravimetric" denotes the use of weight as the basis of the ratio to compute water content as opposed to volume, which is often used in hydrology and the environmental sciences to express water content. Since water content is understood to be a weight ratio in geotechnical engineering practice, the word "gravimetric" is generally omitted. Obviously, the water content can be greater than 100%. This occurs when the weight of the water in the soil mass is greater than the weight of the solids. In such cases the void ratio of the soil is generally greater than 1 since there must be enough void volume available for the water so that its weight is greater than the weight of the solids. However, even if the water content is a weight ratio while saturation is a volume ratio.

For a given amount of soil, the total weight of soil, W, is equal to $W_s + W_w$, since the weight of air, W_a , is practically zero. The water content, w, can be easily measured by oven-drying a given quantity of soil to a high enough temperature so that the amount of water evaporates and only the solids remain. By measuring the weight of a soil sample before and after it ahs been oven dried, both W and W_s , can be determined. The water content, w, can be determined as follows since $W_a = 0$:

$$w = \frac{W - W_s}{W_s} = \frac{W_w}{W_s} \times 100$$
 2-4a

Most soil moisture is released at a temperature between 220 and 230°F (105 and 110°C). Therefore, to compare reported water contents on an equal basis between various soils and projects, this range of temperature is considered to be a standard range.

2.1.3 Weight-Volume Ratios (Unit Weights) and Specific Gravity

The simplest relationship between the weight and volume of a soil mass (refer to Figure 2-1b) is known as the **total unit weight**, γ_t , and is expressed as follows:

$$\gamma_{t} = \frac{W}{V} = \frac{W_{w} + W_{s}}{V}$$
 2-5

The total unit weight of a soil mass is a useful quantity for computations of vertical in-situ stresses. For a constant volume of soil, the total unit weight can vary since it does not

FHWA NHI-06-088 Soils and Foundations – Volume I account for the distribution of the three phases in the soil mass. Therefore the value of the total unit weight for a given soil can vary from its maximum value when all of the voids are filled with water (S=100%) to its minimum value when there is no water in the voids (S=0%). The former value is called the **saturated unit weight**, γ_{sat} ; the latter value is referred to as the **dry unit weight**, γ_d . In terms of the basic quantities shown in Figure 2-1b and with reference to Equation 2-5, when $W_w = 0$ the **dry unit weight**, γ_d , can be expressed as follows:

$$\gamma_{\rm d} = \frac{\rm W_s}{\rm V}$$
 2-6

For computations involving soils below the water table, the buoyant unit weight is frequently used where:

$$\gamma_{b} = \gamma_{sat} - \gamma_{w} \qquad 2-7$$

where, γ_w equals the unit weight of water and is defined as follows:

$$\gamma_{\rm w} = \frac{W_{\rm w}}{V_{\rm w}}$$
 2-8

In the geotechnical literature, the buoyant unit weight, γ_b , is also known as the effective unit weight, γ' , or submerged unit weight, γ_{sub} . Unless there is a high concentration of dissolved salts, e.g., in sea water, the unit weight of water, γ_w , can be reasonably assumed to be 62.4 lb/ft³ (9.81 kN/m³).

To compare the properties of various soils, it is often instructive and preferable to index the various weights and volumes to unchanging quantities, which are the volume of solids, V_s , and the weight of solids, W_s . A ratio of W_s to V_s , is known as the unit weight of the solid phase, γ_s , and is expressed as follows:

$$\gamma_{\rm s} = \frac{\rm W_{\rm s}}{\rm V_{\rm s}}$$
 2-9

The unit weight of the solid phase, γ_s , should not be confused with the dry unit weight of the soil mass, γ_d , which is defined in Equation 2-6 as the total unit weight of the soil mass when there is no water in the voids, i.e., at S = 0%. The distinction between γ_s and γ_d is very subtle,

but it is very important and should not be overlooked. For example, for a solid piece of rock (i.e., no voids) the total unit weight is γ_s while the total unit weight of a soil whose voids are dry is γ_d . In geotechnical engineering, γ_d is more commonly of interest than γ_s .

Since the value of γ_w is reasonably well known, the unit weight of solids, γ_s , can be expressed in terms of γ_w . The concept of **Specific Gravity**, **G**, is used to achieve this goal. In physics textbooks, **G** is defined as the ratio between the mass density of a substance and the mass density of some reference substance. Since unit weight is equal to mass density times the gravitational constant, **G** can also be expressed as the ratio between the unit weight of a substance and the unit weight of some reference substance. In the case of soils, the most convenient reference substance is water since it is one of the three phases of the soil and its unit weight is reasonably constant. Using this logic, the **specific gravity of the soil solids**, **G**_s, can be expressed as follows:

$$G_{s} = \frac{\gamma_{s}}{\gamma_{w}}$$
 2-10

The **bulk specific gravity of a soil** is equal to γ_t / γ_w . The "bulk specific gravity" is not the same as G_s and is not very useful in practice since the γ_t of a soil can change easily with changes in void ratio and/or degree of saturation. Therefore, the bulk specific gravity is almost never used in geotechnical engineering computations.

The value of G_s can be determined in the laboratory, but it can usually be estimated with sufficient accuracy for various types of soil solids. For routine computations, the value of G_s for sands composed primarily of quartz particles may be taken as 2.65. Tests on a large number of clay soils indicate that the value of G_s for clays usually ranges from 2.5 to 2.9 with an average value of 2.7.

2.1.4 Determination and Use of Basic Weight-Volume Relations

The five relationships, n, e, w, γ_t and G_s , represent the basic weight-volume properties of soils and are used in the classification of soils and for the development of other soil properties. These properties and how they are obtained and applied in geotechnical engineering are summarized in Table 2-1. A summary of commonly used weight-volume (unit weight) relations that incorporate these terms is presented in Table 2-2.

Property	Symbol	Units ¹	How Obtained (AASHTO/ASTM)	Comments and Direct Applications
Porosity	n	Dim	From weight-volume relations	Defines relative volume of voids to total volume of soil
Void Ratio	e	Dim	From weight-volume relations	Volume change computations
Moisture Content	w	Dim	By measurement (T 265/ D 4959)	Classification and in weight- volume relations
Total unit weight ²	γ _t	FL ⁻³	By measurement or from weight-volume relations	Classification and for pressure computations
Specific Gravity	Gs	Dim	By measurement (T 100/D 854)	Volume computations
NOTES:				

Table 2-1Summary of index properties and their application

1 F=Force or weight; L = Length; Dim = Dimensionless. Although by definition, moisture content is a dimensionless decimal (ratio of weight of water to weight of solids) and used as such in most geotechnical computations, it is commonly reported in percent by multiplying the decimal by 100.
2 Total unit weight for the same soil can yory from "acturated" (S=1000() to "dry" (S=00())

2 Total unit weight for the same soil can vary from "saturated" (S=100%) to "dry" (S=0%).

Table 2-2

Weight-volume	relations	(after D	as. 1990)
vv eight=volume	i ciations		as, 1770)

Unit-Weight Relationship	Dry Unit Weight (No Water)	Saturated Unit Weight (No Air)
$\gamma_t = \frac{(1+w)G_s\gamma_w}{1+e}$	$\gamma_{d} = \frac{\gamma_{t}}{1 + w}$	$\gamma_{\text{sat}} = \frac{(G_{\text{s}} + e)\gamma_{\text{w}}}{1 + e}$
$\gamma_{t} = \frac{(G_{s} + Se)\gamma_{w}}{1 + e}$	$\gamma_{d} = \frac{G_{s} \gamma_{w}}{1 + e}$	$\gamma_{\text{sat}} = [(1 - n)G_{\text{s}} + n]\gamma_{\text{w}}$ $\begin{pmatrix} 1 + w \end{pmatrix}$
$\gamma_t = \frac{(1+w)G_s\gamma_w}{m}$	$\gamma_d = G_s \gamma_w (1 - n)$	$\gamma_{\rm sat} = \left(\frac{1}{1 + wG_{\rm s}}\right)G_{\rm s}\gamma_{\rm w}$
$1 + \frac{wG_s}{S}$ $\gamma_t = G_s \gamma_w (1 - n)(1 + w)$	$\gamma_{\rm d} = \frac{G_{\rm s} \gamma_{\rm w}}{1 + \frac{{\rm w}G_{\rm s}}{{\rm s}}}$	$\gamma_{sat} = \left(\frac{e}{w}\right) \left(\frac{1+w}{1+e}\right) \gamma_{w}$
	$\gamma_{\rm d} = \frac{{\rm eS}\gamma_{\rm w}}{(1+{\rm e}){\rm w}}$	$\gamma_{sat} = \gamma_d + n \gamma_w$ $\gamma_{sat} = \gamma_d + \left(\frac{e}{1+e}\right) \gamma_w$
	$\gamma_d = \gamma_{sat} - n \gamma_w$	(1+e)
	$\gamma_{\rm d} = \gamma_{\rm sat} - \left(\frac{\rm e}{1+\rm e}\right) \gamma_{\rm w}$	
In above relations, γ_w refers to the	he unit weight of water, 62.4 pcf (:	=9.81 kN/m ³).

FHWA NHI-06-088 Soils and Foundations – Volume I

2.1.5 Size of Grains in the Solid Phase

As indicated in Figure 2-1a, the solid phase is composed of soil grains. One of the major factors that affect the behavior of the soil mass is the size of the grains. The size of the grains may range from the coarsest (e.g., boulders, which can be 12- or more inches [300 mm] in diameter) to the finest (e.g., colloids, which can be smaller than 0.0002–inches [0.005 mm]). Since soil particles come in a variety of different shapes, the size of the grains is defined in terms of an effective grain diameter. The distribution of grain sizes in a soil mass is determined by shaking air-dried material through a stack of sieves having decreasing opening sizes. Table 2-3 shows U.S. standard sieve sizes and associated opening sizes. Sieves with opening size 0.25 in (6.35 mm) or less are identified by a sieve number which corresponds to the approximate number of square openings per linear inch of the sieve (ASTM E 11).

To determine the grain size distribution, the soil is sieved through a stack of sieves with each successive screen in the stack from top to bottom having a smaller (approximately half of the upper sieve) opening to capture progressively smaller particles. Figure 2-2 shows a selection of some sieves and starting from right to left soil particles retained on each sieve, except for the powdery particles shown on the far left, which are those that passed through the last sieve on the stack. The amount retained on each sieve is collected, dried and weighed to determine the amount of material passing that sieve size as a percentage of the total sample being sieved. Since electro-static forces impede the passage of finer-grained particles through sieves, testing of such particles is accomplished by suspending the chemically dispersed particles in a water column and measuring the change in specific gravity of the liquid as the particles fall from suspension. The change in specific gravity is related to the fall velocities of specific particle sizes in the liquid. This part of the test is commonly referred to as a hydrometer analysis. Because of the strong influence of electro-chemical forces on their behavior, colloidal sized particles may remain in suspension indefinitely (particles with sizes from 10⁻³ mm to 10⁻⁶ mm are termed "colloidal.") Sample grain size distribution curves are shown in Figure 2-3. The nomenclature associated with various grain sizes (cobble, gravel, sand, silt or clay) is also shown in Figure 2-3. Particles having sizes larger than the No. 200 sieve (0.075 mm) are termed "coarse-grained" while those with sizes finer than the No. 200 sieve are termed "fine-grained."

The results of the sieve and hydrometer tests are represented graphically on a grain size distribution curve or gradation curve. As shown in Figure 2-3, an arithmetic scale is used on the ordinate (Y-axis) to plot the percent finer by weight and a logarithmic scale is used on the abscissa (X-axis) for plotting particle (grain) size, which is typically expressed in millimeters.

U.S.	Sieve	Sieve	Comment		
Standard	Opening	Opening	(Based on the Unified Soil Classification System		
Sieve No. ¹	(in)	(mm)	(USCS) discussed in Chapter 4)		
3	0.2500	6.35			
4	0.1870	4.75	• Breakpoint between fine gravels and coarse sands		
			• Soil passing this sieve is used for compaction test		
6	0.1320	3.35			
8	0.0937	2.36			
10	0.0787	2.00	Breakpoint between coarse and medium sands		
12	0.0661	1.70			
16	0.0469	1.18			
20	0.0331	0.850			
30	0.0234	0.600			
40	0.0165	0.425	• Breakpoint between medium and fine sands		
40 0.0165		0.425	• Soil passing this sieve is used for Atterberg limits		
50	0.0117	0.300			
60	0.0098	0.250			
70	0.0083	0.212			
100	0.0059	0.150			
140	0.0041	0.106			
200	0.0029	0.075	• Breakpoint between fine sand and silt or clay		
270	0.0021	0.053			
400	0.0015	0.038			

Table 2-3U.S. standard sieve sizes and corresponding opening dimension

Note:

1. The sieve opening sizes for various sieve numbers listed above are based on Table 1 from ASTM E 11. Sieves with opening size greater than No. 3 are identified by their opening size. Some of these sieves are as follows:

4.0 in	(101.6 mm)	1-1/2 in	(38.1 mm)	½ in	(12.7 mm)
3.0 in	(76.1 mm)*	1-1/4 in	(32.0 mm)	3/8 in	(9.5 mm)
2-1/2 in	(64.0 mm)	1.0 in	(25.4 mm)	5/16 in	(8.0 mm)
2.0 in	(50.8 mm)	3⁄4 in	(19.0 mm)**		
1-3/4 in	(45.3 mm)	5/8 in	(16.0 mm)		

* The 3 in (76.1 mm) sieve size differentiates between cobbles and coarse gravels. **The ³/₄ in (19 mm) sieve differentiates between coarse and fine gravels.



Figure 2-2. Example of laboratory sieves for mechanical analysis for grain size distributions. Shown (right to left) are sieve nos. 3/8-in (9.5-mm), No. 10 (2.0-mm), No. 40 (0.425 mm) and No. 200 (0.075 mm). Example soil particle sizes shown at the bottom of the photo include (right to left): medium gravel, fine gravel, medium-coarse sand, silt, and clay (kaolin) (FHWA, 2002b).

FHWA NHI-06-088 Soils and Foundations – Volume I

2 - 11 engineering-pdh.com | geo-114 | 2 – Stress and Strain in Soils December 2006



Figure 2-3. Sample grain size distribution curves.

The logarithmic scale permits a wide range of particle sizes to be shown on a single plot. More importantly it extends the scale, thus giving all the grains sizes an approximately equal amount of separation on the X-axis. For example, a grain-size range of 4.75 mm (No.4 sieve) to 0.075 mm (No. 200 sieve) when plotted on an arithmetic scale, will have the 0.075 mm (No. 200 sieve), 0.105 mm (No. 140 sieve), and 0.150 mm (No. 100) particle size plot very close to each other. The logarithmic scale permits separation of grain sizes that makes it easier to compare the grain size distribution of various soils.

The shape of the grain size distribution curve is somewhat indicative of the particle size distribution as shown in Figure 2-3. For example,

- A smooth curve covering a wide range of sizes represents a *well-graded* or *non-uniform* soil.
- A vertical or near vertical slope over a relatively narrow range of particle sizes indicates that the soil consists predominantly of the particle sizes within that range of particle sizes. A soil consisting of particles having only a few sizes is called a *poorly-graded* or *uniform* soil.
- A curve that contains a horizontal or nearly horizontal portion indicates that the soil is deficient in the grain sizes in the region of the horizontal slope. Such a soil is called a *gap-graded* soil.

Well-graded soils are generally produced by bulk transport processes (e.g., glacial till). Poorly graded soils are usually sorted by the transporting medium e.g., beach sands by water; loess by wind. Gap-graded soils are also generally sorted by water, but certain sizes were not transported.

2.1.6 Shape of Grains in Solid Phase

The shape of individual grains in a soil mass plays an important role in the engineering characteristics (strength and stability) of the soil. Two general shapes are normally recognized, bulky and platy.

2.1.6.1 Bulky Shape

Cobbles, gravel, sand and some silt particles cover a large range of sizes as shown in Figure 2-2; however, they are all bulky in shape. The term bulky is confined to particles that are relatively large in all three dimensions, as contrasted to platy particles, in which one dimension is small as compared to the other two, see Figure 2-4. The bulky shape has five subdivisions listed in descending order of desirability for construction

• *Angular* particles are those that have been freshly broken up and are characterized by jagged projections, sharp ridges, and flat surfaces. Angular gravels and sands are generally the best materials for construction because of their interlocking characteristics. Such particles are seldom found in nature, however, because physical and chemical weathering processes usually wear off the sharp ridges in a relatively short period time. Angular material is usually produced artificially, by crushing.
- *Subangular* particles are those that have been weathered to the extent that the sharper points and ridges have been worn off.
- *Subrounded* particles are those that have been weathered to a further degree than subangular particles. They are still somewhat irregular in shape but have no sharp corners and few flat areas. Materials with this shape are frequently found in stream beds. If composed of hard, durable particles, subrounded material is adequate for most construction needs.
- *Rounded* particles are those on which all projections have been removed, with few irregularities in shape remaining. The particles resemble spheres and are of varying sizes. Rounded particles are usually found in or near stream beds or beaches.
- *Well rounded* particles are rounded particles in which the few remaining irregularities have been removed. Like rounded particles, well rounded particles are also usually found in or near stream beds or beaches.



Figure 2-4. Terminology used to describe shape of coarse-grained soils (Mitchell, 1976).

FHWA NHI-06-088 Soils and Foundations – Volume I 2 – Stress and Strain in Soils December 2006

2.1.6.2 Platy Shape

Platy, or flaky, particles are those that have flat, plate like grains. Clay and some silts are common examples. Because of their shape, flaky particles have a greater surface area than bulky particles, assuming that the weights and volumes of the two are the same. For example, 1 gram of bentonite (commercial name for montmorillonite clay) has a surface area of approximately 950 yd² (800 m²) compared to a surface area of approximately 0.035 yd² (0.03 m^2) of 1 gram of sand. Because of their mineralogical composition and greater specific surface area, most flaky particles also have a greater affinity for water than bulky particles. Due to the high affinity of such soils for water, the physical states of such fine-grained soils change with the amount of water in these soils. The effect of water on the physical states of fine grained soils is discussed next.

2.1.7 Effect of Water on Physical States of Soils

For practical purposes, the two most dominant phases are the solid phase and the water phase. It is intuitive that as the water content increases, the contacts between the particles comprising the solid phase will be "lubricated." If the solid phase is comprised of coarse particles, e.g. coarse sand or gravels, then water will start flowing between the particles of the solid phase. If the solid phase is comprised of fine-grained particles, e.g., clay or silt, then water cannot flow as freely as in the coarse-grained solid phase because pore spaces are smaller and solids react with water. However, as the water content increases even the finegrained solid phase will conduct water and under certain conditions the solid phase itself will start deforming like a viscous fluid, e.g., like a milk shake or a lava flow. The mechanical transformation of the fine-grained soils from a solid phase into a viscous phase is a very important concept in geotechnical engineering since it is directly related to the load carrying capacity of soils. It is obvious that the load carrying capacity of a solid is greater than that of water. Since water is contained in the void space, the effect of water on the physical states of fine-grained soils is important. Some of the basic index properties related to the effect of water are described next.

The physical and mechanical behavior of fine-grained-soils is linked to four distinct states: solid, semi-solid, plastic and viscous liquid in order of increasing water content. Consider a soil initially in a viscous liquid state that is allowed to dry uniformly. This state is shown as Point A in Figure 2-5, which shows a plot of total volume versus water content. As the soil dries, its water content reduces and consequently so does its total volume as the solid particles move closer to each other. As the water content reduces, the soil can no longer flow like a viscous liquid. Let us identify this state by Point B in Figure 2-5. The water content at Point B is known as the "Liquid Limit" in geotechnical engineering and is denoted by LL.

As the water content continues to reduce due to drying, there is a range of water content at which the soil can be molded into any desired shape without rupture. In this range of water content, the soil is considered to be "plastic."



Figure 2-5. Conceptual changes in soil phases as a function of water content.

If the soil is allowed to dry beyond the plastic state, the soil cannot be molded into any shape without showing cracks, i.e., signs of rupture. The soil is then in a semi-solid state. The water content at which cracks start appearing when the soil is molded is known as the "Plastic Limit." This moisture content is shown at Point C in Figure 2-5 and is denoted by PL. The difference in water content between the Liquid Limit and Plastic Limit, is known as the **Plasticity Index**, PI, and is expressed as follows:

$$PI = LL - PL$$
 2-11

Since PI is the difference between the LL and PL, it denotes the range in water content over which the soil acts as a plastic material as shown in Figure 2-5.

As the soil continues to dry, it will be reduced to its basic solid phase. The water content at which the soil changes from a semi-solid state to a solid state is called the **Shrinkage Limit**, SL. No significant change in volume will occur with additional drying below the shrinkage limit. The shrinkage limit is useful for the determination of the swelling and shrinkage characteristics of soils.

The liquid limit, plastic limit and shrinkage limit are called Atterberg limits after A. Atterberg (1911), the Swedish soil scientist who first proposed them for agricultural applications.

For foundation design, engineers are most interested in the load carrying capacity, i.e., strength, of the soil and its associated deformation. The soil has virtually no strength at the LL, while at water contents lower than the PL (and certainly below the SL) the soil may have considerable strength. Correspondingly, soil strength increases and soil deformation decreases as the water content of the soil reduces from the LL to the SL. Since the Atterberg limits are determined for a soil that is remolded, a connection needs to be made between these limits and the in-situ moisture content, w, of the soil for the limits to be useful in practical applications in foundation design. One way to quantify this connection is through the **Liquidity Index**, LI, that is given by:

$$LI = \frac{W - PL}{PI}$$
 2-12

The liquidity index is the ratio of the difference between the soil's in-situ water content and plastic limit to the soil's plasticity index. The various phases shown in Figure 2-5 and anticipated deformation behavior can now be conveniently expressed in terms of LI as shown in Table 2-4.

Liquidity		Soil Strength
Index, LI	Son Phase	(Soil Deformation)
$LI \ge 1$	Liquid	Low strength
		(Soil deforms like a viscous fluid)
0 < LI < 1	Plastic	Intermediate strength
		• at $w \approx LL$, the soil is considered soft and very compressible
		• at $w \approx PL$, the soil is considered stiff
		(Soil deforms like a plastic material)
$LI \leq 0$	Semi-solid to Solid	High strength
		(Soil deforms as a brittle material, i.e., sudden, fracture of
		material)

 Table 2-4

 Concept of soil phase, soil strength and soil deformation based on Liquidity Index

Another valuable tool in assessing the characteristics of a fine-grained soil is to compare the LL and PI of various soils. Each fine-grained soil has a relatively unique value of LL and PI. A plot of PI versus LL is known as the **Plasticity Chart** (see Figure 2-6). Arthur Casagrande, who developed the concept of the Plasticity Chart, had noted the following during the First Pan American Conference on Soil Mechanics and Foundation Engineering (Casagrande, 1959).

I consider it essential that an experienced soils engineer should be able to judge the position of soils, from his territory, on a plasticity chart merely on the basis of his visual and manual examination of the soils. And more than that, the plasticity chart should be for him like a map of the world. At least for certain areas of the chart, that are significant for his activities, he should be well familiar. The position of soils within these areas should quickly convey to him a picture of the significant engineering properties that he should expect.



Figure 2-6. Plasticity chart and significance of Atterberg Limits (NAVFAC, 1986a).

Casagrande proposed the inclusion of the A-line on the plasticity chart as a boundary between clay (above the A-line) and silt (below the A-line) to help assess the engineering characteristics of fine-grained soils. Once PI and LL are determined for a fine-grained soil at a specific site, a point can be plotted on the plasticity chart that will allow the engineer to develop a feel for the general engineering characteristics of that particular soil. The plasticity

FHWA NHI-06-088 Soils and Foundations – Volume I chart also permits the engineer to compare different soils across the project site and even between different project sites. (The symbols for soil groups such as CL and CH are discussed later in this manual.) The plasticity chart, including the laboratory determination of the various limits (LL, PL and SL), are discussed further in Chapters 4 and 5. Additional useful terms such as "Activity Ratio" that relate the PI to clay fraction are also introduced in Chapter 5.

2.2 PRINCIPLE OF EFFECTIVE STRESS

The contacts between soil grains are effective in resisting applied stresses in a soil mass. Under an applied load, the total stress in a saturated soil sample is composed of the intergranular stress and the pore water pressure. When pore water drains from a soil, the contact between the soil grains increases, which increases the level of intergranular stress. This intergranular contact stress is called the **effective stress**. **The effective stress**, p_o , **within a soil mass is the difference between the total stress**, p_t , and pore water pressure, **u**. The **principle of effective stress** is a fundamental aspect of geotechnical engineering and is written as follows:

$$p_o = p_t - u \qquad 2-13$$

In general, soil deposits below the ground water table will be considered saturated and the ambient pore water pressure at any depth may be computed by multiplying the unit weight of water, γ_w , by the height of water above that depth. The total stress at that depth may be found by multiplying the total unit weight of the soil by the depth. The effective stress is the total stress minus the pore water pressure. This concept is used to construct the profile of pressure in the ground as a function of depth and is discussed next.

2.3 OVERBURDEN PRESSURE

Soils existing at a distance below ground are affected by the weight of the soil above that depth. The influence of this weight, known generally as **overburden**, causes a state of stress to exist, which is unique at that depth, for that soil. This state of stress is commonly referred to as the **overburden** or **in-situ** or **geostatic state of stress**. When a soil sample is removed from the ground, as during the field exploration phase of a project, that in-situ state of stress is relieved as all confinement of the sample has been removed. In laboratory testing, it is important to reestablish the in-situ stress conditions and to study changes in soil properties when additional stresses representing the expected design loading are applied. The stresses

to be used during laboratory testing of soil samples are estimated from either the total or effective overburden pressure. The engineer's first task is determining the total and effective overburden pressure variation with depth. This relatively simple task involves estimating the average total unit weight for each soil layer in the soil profile, and determining the depth of the water table. Unit weight may be reasonably well estimated from tests on undisturbed samples or from standard penetration N-values and visual soil identification. The water table depth, which is typically recorded on boring logs, can be used to compute the hydrostatic pore water pressure at any depth. The **total overburden pressure**, p_t , is found by multiplying the total unit weight of each soil layer by the corresponding layer thickness and continuously summing the results with depth. The **effective overburden pressure**, p_o , at any depth is determined by accumulating the weights of all layers above that depth with consideration of the water level conditions at the site as follows:

Soils above the water table

• Multiply the total unit weight by the thickness of each respective soil layer above the desired depth, i.e., $p_o = p_t$.

Soils below the ground water table

- Compute pore water pressure u as $z_w \gamma_w$ where z_w is the depth below ground water table and γ_w is the unit weight of water
- To obtain effective overburden pressure, po, subtract pore water pressure, u, from pt
- For soils below the ground water table, pt is generally assumed to be equal to psat

Alternatively, the following approach can be used:

• Reduce the total unit weights of soils below the ground water table by the unit weight of water (62.4 pcf (9.8 kN/m³)), i.e., use effective unit weights, γ' , and multiply by the thickness of each respective soil layer between the water table and the desired depth below the ground water table, i.e., $p_o = (\gamma_t - \gamma_w)$ (depth), or γ' (depth).

In the geotechnical literature, the effective unit weight, γ' , is also known as the buoyant unit weight or submerged unit weight and symbols, γ_b or γ_{sub} , respectively are used.

An example is solved in Figure 2-7.



Figure 2-7. Example calculation of a p₀-diagram.

2.4 VERTICAL STRESS DISTRIBUTION IN SOIL DUE TO EXTERNAL LOADINGS

When a load is applied to the soil surface, it increases the vertical and lateral stresses within the soil mass. The increased stresses are greatest directly under the loaded area and dissipate within the soil mass as a function of distance away from the loaded area. This is commonly called spatial attenuation of applied loads. A schematic of the vertical stress distribution with depth along the centerline under an embankment of height, h, constructed with a soil having total unit weight, γ_t , is shown in Figure 2-8.



Figure 2-8. Schematic of vertical stress distribution under embankment loading. Graphic generated by FoSSA (2003) program.

(Note: Version 1.0 of FoSSA program is licensed to FHWA. See Appendix E for a brief overview of the FoSSA program).

FHWA NHI-06-088 Soils and Foundations – Volume I Estimation of vertical stresses at any point in a soil mass due to external loadings are of great significance in the prediction of volume change of soils (e.g., settlement) under buildings, bridges, embankments and many other structures. The computation of the total vertical stress change induced by an external loading will depend on the configuration of the external loads. Common examples of the external loads are as follows:

- Uniform strip loads such as the load on a long wall footing of sufficient width,
- Uniformly loaded square, rectangular or circular footings such as column footings of buildings, pier footings, footings for water tanks, mats, etc., and
- Triangular and/or trapezoidal strip loads such as the loads of long earth embankments.

The theory of elasticity is often used to compute the stresses induced within a soil mass by external loadings. The most widely used elastic formulae were first developed by Boussinesq (1885) for point loads acting at the surface of a semi-infinite elastic half-space. These formulae, often known as **Boussinesq solutions**, can be integrated to give stresses below external loadings acting on a finite area. The basic assumptions in these formulae are (a) the stress is proportional to strain, (b) the soil is homogeneous (i.e., the properties are constant throughout the soil mass), and (c) the soil is isotropic (i.e., the properties are the same in all directions through a point). Westergaard (1938) modified the Boussinesq solutions by assuming that the semi-infinite elastic half-space is interspersed with infinitely thin but perfectly rigid layers that allow vertical movement but no lateral movement. In reality, a soil mass never fulfills the assumptions of either of these idealized solutions. Nevertheless, these elastic solutions, with appropriate modifications and judgment, have been found to yield acceptable approximate estimates of stresses in the soil mass and are widely used in geotechnical engineering practice. The Boussinesq solutions are generally used in most situations, even those where layered soils are encountered provided the thickness of the layers is on the order of a few feet or more. On the other hand, the Westergaard solutions are usually used for varved clays where the predominant soil mass is clay interspersed with thin layers of sand whose thickness is on the order of inches.

The derivations of the equations for various common loadings cited above are tedious. They are omitted in this manual so that the reader can concentrate on the use of published solutions, generally in the form of charts. The following sections contain the chart solutions for some of the loadings most commonly encountered in practice. Caution in the use of these charts is advised since they all pertain to **stress increments** at very well-defined points within the soil mass due to the applied pressures indicated. **The total stress acting at a point of interest is equal to the stress increment at that point due to the newly applied**

load plus existing stresses at that point due to the geostatic stress and stresses due to other external loads applied previously.

2.4.1 Uniformly Loaded Continuous (Strip) and Square Footings

A loaded area is considered to be infinitely long when its length, L, to width, B, ratio is greater than or equal to 10, i.e., $L/B \ge 10$. The load on such an area is commonly known as a strip load. Figure 2-9 presents vertical pressure isobars under strip and square footings based on Boussinesq's theory. An **isobar** is a line that connects all points of equal stress increment below the ground surface. In other words, an isobar is a stress increment contour.

Each isobar represents a fraction of the stress applied at the surface and delineates the zone of influence of the footing such that the area contained within two adjacent isobars experiences stresses greater than the lower isobar and less than the upper isobar. Since these isobars form closed figures that resemble the form of a bulb, they are also termed **bulbs of pressure** or simply the **pressure bulbs**. The pressure bulb concept gives the user a feel for the spread of the stresses through a soil mass.

According to linear elastic theory, the size of the pressure bulb is proportional to the size of the loaded area. This is a key concept in geotechnical engineering that is used to evaluate the **depth of significant influence, DOSI**, denoted by D_S of an applied surface load. The depth D_S is a finite depth below which there are no significant strains in the soil mass due to the loads imposed at the surface. Typically, strains are not significant once the stresses have attenuated to a value of 10 to 15% of those at the surface. For example, Figure 2-9a shows that for "infinitely long" strip footings, $D_S = 4$ to 6B, while for square footings, Figure 2-9b shows that $D_S = 1.5$ to 2B. The depths corresponding to this 10 to 15% criterion can be used to determine the minimum depth of field exploration for proposed strip or square footings to ensure that the anticipated significant depth is explored.

It may be seen from Figure 2-9 that the effect of the vertical stresses extends laterally beyond the width of the loaded area, B. This observation is very useful in assessing the influence of one loaded area on the other. Alternatively, this observation can be used to determine an adequate spacing between adjacent loaded areas. It also indicates that the effect of construction activities may be felt beyond a specific site. Such effects should be evaluated before construction so that mitigation measures can be taken to avoid legal implications.



Figure 2-9. Vertical stress contours (isobars) based on Boussinesq's theory for continuous and square footings (modified after Sowers, 1979; AASHTO, 2002).

2.4.2 Approximate (2:1) Stress Distribution Concept

As an approximation to the exact solution given by the Boussinesq charts, the total load at the surface of the soil mass may be distributed over an area of the same shape as the loaded area on the surface, but with dimensions that increase with depth at a rate of one horizontal unit for every two vertical units. This is illustrated in Figure 2-10, which shows a rectangular area of dimensions B x L at the surface. At a depth, z, the total load is assumed to be uniformly distributed over an area (B+z) by (L+z). Since the stress is distributed at the rate of 2:1 (vertical:horizontal), this approximation method it is commonly known as the "**2:1** stress distribution" method.

The relationship between the approximate distribution of stress determined by this method and the exact distribution is illustrated in Figure 2-10. In this figure, the vertical stress distribution at a depth B below a uniformly loaded square area of width B is shown along a horizontal line that passes beneath the center of the area and extends beyond the edges of the loaded area. Also shown is the approximate uniform distribution at depth B determined by the 2:1 stress distribution method described above. The discrepancy between the two methods decreases as the ratio of the depth considered to the size of the loaded area increases (Perloff and Baron, 1976).

2.5 REPRESENTATION OF IMPOSED PRESSURES ON THE po DIAGRAM

The pressure distributions computed by using the charts in Section 2.4, can be shown superimposed on the p_0 diagram as shown in Figure 2-7. As discussed in the previous sections, an applied pressure at the surface causes stress increments within the soil mass that decrease with depth due to spatial attenuation. This is shown in Figure 2-11 where Δp is plotted with respect to the p_0 line that represents the existing geostatic stress distribution. As can been seen in Figure 2-11, Δp approaches the p_0 line, which indicates that at a sufficient depth the effect of the externally imposed loads reduces significantly. In other words, this means that most of the strain due to the increased stress from the applied load will be experienced at relatively shallow depths below the load. As noted earlier, this depth is known as the **depth of significant influence (DOSI)**, D_S. Also, as indicated previously, D_S depends on the load and load configuration as demonstrated by the pressure distribution charts in Section 2.4. Figure 2-11 also shows that that the **final stress**, p_f , in the soil mass at **any depth is equal to p_0 + \Delta p**.



Figure 2-10. Distribution of vertical stress by the 2:1 method (after Perloff and Baron, 1976).

A chart such as that shown in Figure 2-11 is even more useful when the soil stratigraphy is plotted on it. Then the stress levels in various layers will be clearly identified, which can help the engineer determine depth of borings to collect subsurface information within DOSI as well as perform proper analysis.

Example 2-2 illustrates these concepts by providing calculations of p_f with depth due to stress increments from a strip load and presenting the results of the calculations on a p_o -diagram.



Figure 2-11. Combined plot of overburden pressures (total and effective) and pressure due to imposed loads.

Example 2-2: For the Example 2-1 shown in Figure 2-7, assume that a 5 ft wide strip footing with a loading intensity of 1,000 psf is located on the ground surface. Compute the stress increments, Δp , under the centerline of the footing and plot them on the p_0 diagram shown in Figure 2-7 down to a depth of 20 ft.



Solution:

For the strip footing, use the left chart in Figure 2-9. As per the terminology of the chart in Figure 2-9, B = 5 ft and $q_0 = 1,000$ psf. Compile a table of stresses for various depths and plot as follows:

Depth	7/D	Isobar	Stress, ∆p	n nef	n – n – An nof
z, ft		Value, x	$= x(q_o), psf$	p ₀ , psi	$p_f - p_o + \Delta p psi$
2.5	0.5	0.80	800	(110)(2.5)=275	1,075
5.0	1.0	0.55	550	(110)(5.0)=550	1,100
7.5	1.5	0.40	400	(110)(7.5)=825	1,225
10.0	2.0	0.32	320	(110)(10.0)=1,100	1,420
12.5	2.5	0.25	250	1,100+(12.5-10.0)(110-62.4)=1,219	1,469
15.0	3.0	0.20	200	1,100+(15.0-10.0)(110-62.4)=1,338	1,538
17.5	3.5	0.18	180	1,100+(17.5-10.0)(110-62.4)=1,457	1,637
20.0	4.0	0.16	160	1,100+(20.0-10.0)(110-62.4)=1,576	1,736





FHWA NHI-06-088 Soils and Foundations – Volume I

2.6 LOAD-DEFORMATION PROCESS IN SOILS

When subjected to static and/or dynamic loads, soils deform mainly because of a change in void volume rather than through deformation of the soil solids. When the void volume decreases the soil is said to compress, consolidate, collapse or compact. There is an important distinction between these four mechanisms although conceptually they appear to be the same since each pertains to a reduction in volume.

- *Compression*: Compression is defined as a relatively rapid decrease in void volume that <u>partially saturated</u> (unsaturated) soils undergo as air is expelled from the voids during loading.
- *Consolidation:* Consolidation is generally defined as a time-dependent decrease in void volume that <u>saturated and near-saturated soils</u> undergo as water is expelled from the voids during loading. The conceptual process of consolidation is discussed in Section 2.6.1.
- *Collapse:* Collapse is primarily related to soil structure and its response to an increase in water content that results in a rapid decrease in void volume. Collapse-susceptible soils characteristically have dry densities less than approximately 100 pcf (16 kN/m³) that suggest high void ratios. Their structure is like a honeycomb with fine-grained "bridges" connecting coarser-grained particles. When dry, these soils are able to sustain externally applied loads with very little deformation. However, upon being wetted they tend to undergo a rapid decrease in void volume as the fine-grained "bridges" lose strength and the entire structure collapses. The magnitude of the potential collapse increases with increasing load. One of the important things to note is that full saturation (S=100%) is not required for these types of soils to collapse. Often collapse occurs at a degree of saturation of 50 to 70%. Collapse-susceptible soils are very common in the southwest and midwest of the United States and in many other parts of the world.
- *Compaction*: Compaction is the name given to the compression that takes place generally under an impact-type loading (e.g., modified and standard Proctor), a static loading (e.g., rubber-tired or steel drum rollers) or kneading-type loading (e.g., sheepsfoot roller). Most commonly, the compaction processes are deliberate and intended to achieve a dense packing of soil particles. Regardless of the type of loading, the moisture content of the soil being compacted is far enough below the saturation moisture content that the compaction mechanism is considered to be related to compression (i.e., expulsion of air) rather than consolidation (i.e., expulsion

of water) from the voids. Typically, the desired moisture content in the case of compaction is slightly above or below the PL. If the moisture content of the soil being compacted gets to be too close to the saturation moisture content then "pumping" will occur, i.e. water in addition to air will be forced out of the soil.

These distinctions in load-deformation processes should be kept in mind during the discussions that follow in subsequent sections of this chapter.

Finally, in contrast to the above processes that involve void volume decrease, there are conditions under which soils may actually increase in volume. When the void volume increases under static and/or dynamic load, the soil is said to **dilate**. **Dilation** can occur in either saturated or partially saturated soils. It is a function of the initial void ratio, confinement stress, and the magnitude and direction of the loading/unloading imposed on the soil. **Expansion**, on the other hand, is generally considered to be due to the presence of expansive clay minerals, such as montmorillonite (commercially known as "bentonite"), in the soil and the response of these minerals to the introduction of water into the void spaces. The physico-chemical properties of expansive clay minerals cause inter-particle repulsions to take place in the presence of water so that even under considerable externally applied loads these soils will undergo an increase in void volume that leads to swelling. A variation of the expansion is **heave** which can occur due to various factors such as frost action or reduction in overburden pressure due to excavation.

2.6.1 Time Dependent Load-Deformation (Consolidation) Process

Deformation of a saturated soil is more complicated than that of a dry soil since water, which fills the voids, must be squeezed out of the soil before readjustment of the soil grains can occur. The more permeable a soil is, the faster the deformation under load will occur. However, when the load on a saturated soil is quickly increased, the increase is initially carried by the pore water resulting in the buildup of an **excess pore water pressure**, Δu . **Excess pore water pressure is water pressure greater than the hydrostatic pressure**. As drainage of the water takes place more and more load is gradually transferred from the pore water to the soil grains until the excess pore water pressure has dissipated completely and the soil grains readjust to a denser configuration under the applied load. This time dependent process is called **consolidation** and results in a decreased void ratio and greater unit weight relative to conditions before the load was applied. To illustrate this concept, one-dimensional (vertical) drainage of the water will be considered here. The process is analogous to loading a spring-supported piston in a cylinder filled with water. The spring-piston analogy is shown schematically in Figure 2-13 and is briefly discussed below.





FHWA NHI-06-088 Soils and Foundations – Volume I 2 – Stress and Strain in Soils December 2006 In the spring-piston model, the spring represents the solid phase of the soil and the water below the piston is the pore water under saturated condition in the soil mass. Before a new load, W, is applied to the piston, the system is assumed to be in equilibrium, i.e., the drainage valve is open and there is no <u>excess</u> pore water pressure, $\Delta u = 0$. The spring alone is carrying any previously applied loads, such as the weight of the piston itself. The drainage valve is closed just before the new load is applied. If the valve is completely shut-off and the piston is leak-proof, then, there is no chance for water to escape. Such a condition represents a clay-water system in which the clay is very impermeable so that there is significant resistance to drainage of water in any direction. When the new load, W, is placed on the piston (this is called the initial or "time = 0" condition), the total applied pressure immediately below the piston, p_t , which equals the load, W, divided by the area of the piston, is immediately transferred to the water. Since the drainage valve is closed and water is virtually incompressible, the water pressure increases to a value equal to the total applied pressure, i.e., the excess water pressure $\Delta u = p_t$.

At "time = 0," the spring does not carry any of the applied load W. The excess water pressure is analogous to the pore water pressure that would be developed in a clay-water system under externally applied loads, e.g., loads due to construction of an embankment on soft saturated clay. If the valve is now opened, the water will drain to relieve the excess pressure in it. With the escape of the water, a part of the pressure carried by the water is transferred to the spring where it induces a stress increase analogous to an effective increase in the inter-particle stresses, p_o in a soil mass. The transfer of pressure from the water to the spring occurs over a period of time as shown on the bottom part of Figure 2-13, however, at any time during the process, the increased stress in the spring, p_o, plus the excess pressure in the water, Δu , must equal the applied pressure, pt. This transfer of pressure from the water to the spring goes on until the flow stops. At that time all of the applied pressure, pt, will be carried by the spring, p_0 , and none by the water, i.e., $\Delta u = 0$, and the system will have come into equilibrium under the applied load. The time required to attain equilibrium depends on the avenue provided to the water to escape, i.e., the longest drainage path the water has to take to leave the system. In Figure 2-13 the longest drainage path is the length of the cylinder. Obviously, the system would drain quicker if there were another standpipe-type drain at the bottom of the cylinder.

Regardless of the number of avenues provided for drainage, the rate of excess water pressure drop generally decreases with time as shown in the lower half of Figure 2-13. After the spring water system attains an equilibrium condition under the imposed load, the compression of the piston is analogous to the settlement of the clay-water system under an externally applied load. This process is called **consolidation**.

2.6.2 Comparison of Drainage Rates between Coarse-Grained and Fine-Grained Soils

Figure 2-14 shows a comparison of excess pore water pressure dissipation in coarse-grained and fine-grained soils. The relatively large pore spaces in coarse-grained soils permit the water to drain quicker in comparison to fine-grained soils. This leads to a quick transfer of applied loads to the soil solids with an associated decrease in void space. This quick load transfer results in a displacement that is commonly termed "rapid" in contrast to the "long-term" displacement that is associated with the consolidation process in fine-grained soils.



Figure 2-14. Comparison of excess pore water pressure dissipation in coarse-grained and fine-grained soils.

2.7 LATERAL STRESSES IN FOUNDATION SOILS

In most cases, the vertical stress at any depth in a soil mass due to its self weight is the summation of the simple products of the unit weight of each soil layer and its corresponding thickness down to the depth of interest. This vertical stress was denoted by p_t and the effective component of this pressure was denoted by p_o . Due a variety of factors, including depositional patterns, the lateral stress, p_h , in a soil mass is usually not the same as the vertical stress, p_o . Since the vertical stress is known with reasonable certainty for practical purposes, the lateral stress can be assumed to be a certain percentage of the vertical stress and can be expressed as follows:

$$p_{\rm h} = K p_{\rm o} \qquad 2-14$$

For an elastic solid, the value of the proportionality constant, K, can be expressed in terms of Poisson's ratio, v, as follows:

FHWA NHI-06-088 Soils and Foundations – Volume I

2 - 34 Engineering-pdh.com | ged-114 | 2 – Stress and Strain in Soils December 2006

$$K = \frac{v}{1 - v}$$
 2-15

Poisson's ratio, v, is defined as a ratio of lateral to vertical strains. The value of Poisson's ratio is a function of the type of material, e.g., v is practically zero for cork (hence its suitability as a bottle stopper), for concrete v is between 0.1 and 0.2, and for steel v is between 0.27 and 0.30. A theoretical upper limit of Poisson's ratio is 0.5 (rubber comes close to this limiting value). In the case of soils, v will have a different value depending upon the type of soil and its moisture condition. For example, for free-draining soils a reasonable value of v would be in the range of 0.25 to 0.35, while for very soft saturated clays under rapid loading conditions the value of v would be close to 0.5. Thus, for free-draining soils, the value of K based on elasticity theory will range from 33% to 54% corresponding to v=0.25 and v=0.35, respectively, while for soft clays the value of K ≈ 1 since v ≈ 0.5 .

Even though a soil mass is not an elastic body, the point to be noted here is that at any point within the soil mass both vertical and horizontal (or lateral) stresses exist. When external forces are imposed on a soil mass, they will result in an increase in vertical stresses as discussed in Sections 2.5 and 2.6. Equation 2-14 indicates that an increase in vertical stresses will in turn lead to an increase in lateral stresses. While the increase in vertical stresses is important in assessing vertical settlements, change in lateral stresses may affect the load acting, for example, against piles supporting a bridge abutment, see Figure 2-15. In this figure, it can be seen that the increase in vertical stress imposed by the embankment leads to an increase in the lateral stress in the ground that causes lateral deformation ("squeeze") of the soft soil. As the soft soil spreads laterally it will have an effect on foundations. Therefore, it is important to evaluate the increase in lateral stresses due to vertical loadings.





FHWA NHI-06-088 Soils and Foundations – Volume I

2 - 35 ENGINEERING-PDH.COM | GEO-114 | 2 – Stress and Strain in Soils December 2006 A two-dimensional (2-D) representation of the lateral stresses transverse to an embankment centerline is shown in Figure 2-16. This schematic was developed with a soft layer of soil under the embankment. It can be seen that significant lateral stresses are generated in the soil below the embankment load. Note that the vertical stresses due to the embankment can cause zones of tensile stresses to develop near the toes of the embankment as shown by the hatched zones in Figure 2-16. This means that tensile cracks are likely to develop near the toes of the embankments for this particular case. This knowledge can help the geotechnical specialist to select proper ground improvement measures rationally and to develop and implement an instrumentation program. The key point to understand based on the schematics shown in Figures 2-15 and 2-16 is that lateral deformations can be three-dimensional and can affect a number of facilities such as buried utilities, embankment slopes and bridge foundations. Lateral deformations can also affect off-site structures very easily leading to potential legal actions. The three-dimensional (3-D) lateral deformations coupled with vertical deformations due to vertical stresses can create a complex state of deformation that needs to be carefully considered in the design of geotechnical features.

Similar to the estimation of vertical stresses, the theory of linear elasticity yields equations for lateral stress distribution. However, in these equations Poisson's ratio is assumed to be a constant. Hence, the use of chart solutions in these cases is not as simple as for the vertical stress case since complicated equations have to be evaluated (Poulos and Davis, 1974). One can prepare spreadsheet solutions based on the equations or use commercially available computer programs that have already programmed the equations. Program FoSSA (2003) by ADAMA Engineering (Version 1.0 was licensed to FHWA) is an example of a program capable of computing the vertical and lateral stresses due to surface loading, including embankment and multiple footings. Figures 2-10 and 2-16 were generated using the FoSSA program.

2.7.1 Effect of Shear Strength of Soils on Lateral Pressures

Up to now the stresses in soils have been explained by using unit weights and the theory of elasticity. Elastic theory, when suitably modified to reflect observed phenomena in soils, provides a tool to obtain a reasonable first approximation to a solution for many problems in geotechnical engineering. However, elastic theory does not recognize the role of shear strength of soil in the development of lateral pressures. For example, soils have an ability to stand vertically or at a certain slope. The reason for this observed ability is that soil has shear strength and to some degree can support itself. This shear strength may come from friction and/or cohesion between the soil particles. It is intuitive that these components of shear strength should also somehow affect the lateral pressures in soils computed by use of the theory of elasticity. The shear strength of soils and its representation for analytical purposes

is discussed in the Section 2.8 followed in Section 2.9 by a demonstration of how the shear strength parameters can be used to express lateral pressures. Readers are referred to Lambe and Whitman (1979) or Holtz and Kovacs (1981) for detailed discussions.



Figure 2-16. Schematic of vertical stress distribution under embankment loading. Graphic generated by FoSSA (2003) program.

(Note: Version 1.0 of FoSSA program is licensed to FHWA. See Appendix E for a brief overview of the FoSSA program).

2.8 STRENGTH OF SOILS TO RESIST IMPOSED STRESSES

If the imposed stress in a soil mass is increased until the deformations (movements) become unacceptably large, a "failure" is considered to have taken place. In this case, the strength of the soil is considered to be insufficient to withstand the applied stress.

The strength of geologic materials is a variable property that is dependent on many factors, including material properties, magnitude and direction of the applied forces and their rate of application, drainage conditions of the mass, and the magnitude of confining pressure. Unlike steel whose strength is usually discussed in terms of either tension or compression and concrete whose strength is generally discussed in terms of compressive strength only, the strength of soil is generally discussed in terms of shear strength. Typical geotechnical failures occur when the shear stresses induced by applied loads exceed the soil's shear strength somewhere within the soil mass.

2.8.1 Basic Concept of Shearing Resistance and Shearing Strength

The basic concept of shearing resistance and shearing strength can be understood by first studying the principle of friction between solid bodies. Consider a prismatic block B resting on a plane surface XY as shown in Figure 2-17. The block B is subjected to two forces:

- A normal force, P_n , that acts perpendicular to the plane XY, and
- A tangential force, F_a , that acts parallel to the plane XY.

Assume that the normal force, P_n , is constant and that the tangential force, F_a , is gradually increased. At small values of F_a , the block B will not move since the applied force, F_a , will be balanced by an equal and opposite force, F_r , on the plane of contact XY. The resisting force, F_r , is developed as a result of surface roughness on the bottom of the block B and the plane surface XY. The angle, θ , formed by the resultant R of the two forces F_r and P_n with the normal to the plane XY is known as the **angle of obliquity**.

If the applied horizontal force, F_a , is gradually increased, the resisting force, F_r , will likewise increase, always being equal in magnitude and opposite in direction to the applied force. When the force F_a reaches a value that increases the angle of obliquity to a certain maximum value θ_m , the block B will start sliding along the plane. Recall that during this entire process the normal force, P_n , remains constant. The following terminology can now be developed:



Figure 2-17. Basic concept of shearing resistance and strength (after Murthy, 1989).

- If the block B and the plane surface XY are made of the same material, the angle θ_m is equal to ϕ , which is termed the **angle of friction** of the material. The value tan ϕ is called the **coefficient of friction**.
- If the block B and the plane surface XY are made of dissimilar materials, the angle θ_m is equal to δ , which is termed the **angle of interface friction** between the bottom of the block and the plane surface XY. The value tan δ is called the **coefficient of interface friction**.
- The applied horizontal force, F_a, on the block B is a shearing force and the developed force is called **frictional resistance** or **shearing resistance**. The maximum frictional or

FHWA NHI-06-088 Soils and Foundations – Volume I shearing resistance that the materials are capable of developing on the interface is $(F_a)_{max}$.

If the same experiment is conducted with a greater normal force, P_n , the maximum frictional or shearing resistance $(F_a)_{max}$, will be correspondingly greater. A series of such experiments would show that for the case where the block and surface are made of the same material, the maximum frictional or shearing resistance is approximately proportional to the normal load P_n as follows:

$$(F_a)_{max} = P_n \tan \phi$$
 2-16

If A is the overall contact area of the block B on the plane surface XY, the relationship in Equation 2-16 may be written as follows to obtain stresses on surface XY:

$$\frac{\left(F_{a}\right)_{max}}{A} = \left(\frac{P_{n}}{A}\right) \tan\phi \qquad 2-17$$

or

$$\tau = \sigma_n \tan \phi \qquad \qquad 2-18$$

The term σ_n is called the **normal stress** and the term τ is called the **shear strength**. A graphical representation of Equation 2-18 is shown in Figure 2-18a. In reality, the relationship is curved, but since most geotechnical problems involve a relatively narrow range of pressures, the relationship is assumed to be linear as represented by Equation 2-18 over that range.

The concept of frictional resistance explained above applies to soils that possess only the frictional component of shear strength, i.e., generally coarse-grained granular soils. But soils that are not purely frictional exhibit an additional strength component due to some kind of internal electro-chemical bonding between the particles. This bonding between the particles is typically found in fine-grained soils and is termed **cohesion**, **c**. Simplistically, the shear strength, τ , of such soils is expressed by two additive components as follows and can be graphically represented as shown in Figure 2-18(b):

$$\tau = c + \sigma_n \tan \phi \qquad 2-19$$

Again, in reality, the relationship is curved. But, as noted above, since most geotechnical problems involve a relatively narrow range of pressures, the relationship is assumed to be linear as represented by Equation 2-19 over that range.

FHWA NHI-06-088 Soils and Foundations – Volume I

2 - 40 Engineering-pdh.com | ged-114 | 2 – Stress and Strain in Soils December 2006









Equation 2-19 was first proposed by French engineer Coulomb and is used to express shear strength of soils. When plotted on arithmetic axes the resulting straight line is conventionally known as the Mohr-Coulomb (M-C) failure envelope. "Mohr" is included in "Mohr-Coulomb" because Equation 2-19 can also be derived based on concept of Mohr's circle. The development of the Mohr-Coulomb failure envelope based on the application of Mohr's circle is presented in Appendix B.

As indicated previously, the deformation of soils occurs under effective stresses. In terms of effective stresses, Equation 2-19 can be re-written as follows:

$$\tau' = c' + (\sigma_n - u) \tan \phi' = c' + \sigma' \tan \phi'$$
 2-20

where c' = effective cohesion, σ' is the effective normal stress and ϕ' is the effective friction angle. Further discussion on the cohesion and friction angle is presented in Chapter 4.

In geotechnical engineering, the normal stresses are commonly expressed using the overburden pressure concept introduced in Section 2.3. In terms of overburden pressure, the term σ_n in above equations is the same as p_t and the term σ' is the same as p_o . Thus, Equations 2-19 and 2-20 can be expressed in terms of overburden stresses as follows:

$$\tau = c + p_t \tan \phi \qquad 2-21$$

$$\tau' = c' + (p_t - u) \tan \phi' = c' + p_o \tan \phi'$$
 2-22

Since this manual relates to geotechnical engineering, Equations 2-21 and 2-22 will be used to express the M-C failure envelope. The physical meaning of the M-C failure envelope shown in Figure 2-18(a) and Figure 2-18(b) may be explained as follows:

- Every point on the M-C failure envelope represents a combination of normal and shear stress that results in failure of the soil, i.e., the Mohr failure envelope essentially defines the strength of the soil. In other words, any point along the M-C envelope defines the limiting state of stress for equilibrium.
- If the state of stress is represented by a point below the M-C failure envelope then the soil will be stable for that state of stress.
- States of stress beyond the M-C failure envelope cannot exist since failure would have occurred before that point could be reached.

2.9 STRENGTH OF SOILS RELATED TO LATERAL EARTH PRESSURES

The concept of shear strength described in the previous section can now be used to understand the phenomenon of lateral earth pressure in a soil mass, which is related to problems of slope stability and earth retention. From a theoretical viewpoint, problems in these three areas (earth pressures, slope stability, and retaining structures) fall into a class of problems involving plasticity theory and are best solved by some form of equilibrium solution. Many geotechnical engineering text books (e.g., Lambe and Whitman, 1979; Holtz and Kovacs, 1981) deal with these solutions extensively. From a practical viewpoint, values of earth pressure are needed either directly or indirectly to determine:

- a) If an unrestrained slope is stable and
- b) If not, what kind of retaining structure will be required to stabilize the slope.

The simplest consideration of earth pressure theory starts with the assessment of the vertical geostatic effective stress, p_o , at some depth in the ground (effective overburden pressure) as considered in Section 2.3. The lateral geostatic effective stress, p_h , at this depth is given in general terms by Equation 2-14 where, for an ideally elastic solid, the value of the lateral earth pressure coefficient, K, is given by Equation 2-15. However, the behavior of real soils under loads is not always ideally elastic. To simplify the discussion of this topic, consider only dry coarse-grained cohesionless soils. The geostatic effective stress condition on a soil element at any depth, z, is shown in Figure 2-19a. Since the ground is "at-rest" without any external disturbance, this condition is commonly referred to as the "**at-rest**" condition with zero deformation. The coefficient of lateral earth pressure for this condition is labeled K_o .



Figure 2-19. Stress states on a soil element subjected only to body stresses: (a) In-situ geostatic effective vertical and horizontal stresses, (b) Insertion of hypothetical infinitely rigid, infinitely thin frictionless wall and removal of soil to left of wall, (c) Active condition of wall movement away from retained soil, (d) Passive condition of wall movement into retained soil.

To relate to the lateral earth pressures acting on retaining structures, assume that a hypothetical, infinitely thin, infinitely rigid "wall" is inserted into the soil without changing the "at rest" stress condition in the soil. For the sake of discussion, assume that the hypothetical wall maintains the "at rest" stress condition in the soil to the right of the wall when the soil to the left of the wall is removed. This condition is shown in Figure 2-19b. Now suppose that the "at rest" condition is removed by allowing the hypothetical vertical wall to move slightly to the left, i.e., away from the soil element as shown in Figure 2-19c. In this condition, the vertical stress would remain unchanged. However, since the soil is cohesionless and cannot stand vertically on its own, it actively follows the wall. In this event, the horizontal stress decreases, which implies that the lateral earth pressure coefficient is less than K_o since the vertical stress remains unchanged. When this occurs the soil is said to be in the "**active**" state. The lateral earth pressure coefficient at this condition is called the "**coefficient of active earth pressure,"** K_a , and its value at failure is expressed in terms of effective friction angle, ϕ' , as follows:

$$K_{a} = \frac{1 - \sin \phi'}{1 + \sin \phi'}$$
 2-23

Returning to the condition shown in Figure 2-19b, now suppose that the "at rest" condition is removed by moving the hypothetical vertical wall to the right, i.e., into the soil element as shown in Figure 2-19d. Again, the vertical stress would remain unchanged. However, the soil behind the wall passively resists the tendency for it to move, i.e., the horizontal stress would increase, which implies that the lateral earth pressure coefficient would become greater than K_0 since the vertical stress remains unchanged. When this occurs the soil is said to be in the "**passive**" state. The lateral earth pressure coefficient at this condition is called the "**coefficient of passive earth pressure,"** K_p , and its value at failure is expressed in terms of effective friction angle, ϕ' , as follows:

$$K_{p} = \frac{1 + \sin \phi'}{1 - \sin \phi'}$$
 2-24

When failure occurs during either of the two processes described above, "**Rankine**" failure **zones** form within the soil mass. The details of how the failure zones develop are described in most geotechnical engineering textbooks and will not be treated here. The so-called "Rankine" failure zones and their angles from the horizontal are shown in Figure 2-20.



Figure 2-20. Development of Rankine active and passive failure zones for a smooth retaining wall.

2.9.1 Distribution of Lateral Earth and Water Pressures

The earth pressure coefficients, K_a and K_p , can be substituted into Equation 2-14 to obtain equations for active and passive lateral earth pressures, respectively as follows:

$$p_a = K_a p_o \qquad 2-25a$$

$$\mathbf{p}_{\mathrm{p}} = \mathbf{K}_{\mathrm{p}} \, \mathbf{p}_{\mathrm{o}} \qquad \qquad 2-25\mathbf{b}$$

It can be seen from Equations 2-25a and 2-25b that the lateral pressures p_a and p_p are a certain fraction of the vertical <u>effective</u> overburden pressure p_o . Thus, active and passive lateral earth pressures are effective pressures and their distribution will be same as that for p_o . The overburden pressure increases in proportion to the unit weight and is typically triangular for a given geomaterial. The general distribution of the active and passive pressures along with the configuration of active and passive failure surfaces is shown in Figure 2-21a and 2-21b, respectively.

In cases where ground water exists, the lateral pressure due to the water at any depth below the ground water level is equal to the hydrostatic pressure at that point since the friction angle of water is zero and use of either Equation 2-23 or 2-24 leads to a coefficient of lateral pressure for water, K_w equal to 1.0. The computation of the vertical water pressure was demonstrated previously in Example 2-1. Since $K_w=1$, the same computation applies for the lateral pressure as well. The lateral earth pressure is computed by using the vertical <u>effective</u> overburden pressure p_o at any depth and applying Equations 2-25a and 2-25b. The lateral earth pressure is added to the hydrostatic water pressure to obtain the total lateral pressure acting on the wall at any point below the ground water level. For a typical soil friction angle of 30 degrees, $K_a = 1/3$. Since $K_w = 1$, it can be seen that the **lateral pressure due to water** **is approximately 3 times that due the active lateral earth pressure**. A general case for the distribution of combined active lateral earth pressure and lateral water pressure is shown in Figure 2-22. As will be discussed in Chapter 10 (Earth Retaining Structures), this disparity in lateral pressures has serious consequences when the stability of walls is considered and is the reason why drainage behind walls is so important.



 $\begin{array}{ll} \mbox{Active pressure at depth } z \mbox{:} & p_a = K_a \, \gamma \, z \\ \mbox{Active force within depth } z \mbox{:} & P_a = K_a \, \gamma \, z^2 / 2 \\ \end{array}$

 $\begin{array}{ll} Passive \mbox{ pressure at depth } z: & p_p = K_p \, \gamma \ z \\ Passive \mbox{ force within depth } z: & P_p = K_p \, \gamma \ z^2 / 2 \end{array}$

Figure 2-21. Failure surfaces, pressure distribution and forces (a) active case, (b) passive case.



Figure 2-22. General distribution of combined active earth pressure and water pressure.

FHWA NHI-06-088 Soils and Foundations – Volume I

2 - 46 Engineering-pdh.com | geo-114 | 2 – Stress and Strain in Soils December 2006

2.9.2 Deformations Associated with Lateral Pressures

The active and passive pressures are predicated on the development of a certain amount of lateral deformation in the soil. The magnitudes of these lateral deformations and their effect on the development of earth pressures at failure are discussed in Chapter 10 (Earth Retaining Structures).

2.10 UNSATURATED SOIL MECHANICS

As discussed in this Chapter, soil is three phase system that consists of solid particles, liquid and gas. Classical soil mechanics concentrates primarily on the behavior of saturated or dry soils, i.e., a two phase system. For soils in a saturated state, the principle of effective stress is invoked to quantify stress and strain in the soil mass. For soils in a dry state, pore water pressure does not exist and the total stress and effective stress are the same. In reality, all the pore space in soil within the depth of significant influence of geotechnical features is rarely occupied by liquid or gas alone. This is particularly true for soils above the ground water table and soils that are mechanically compacted as in the case of earthworks. In such soils the degree of saturation is generally intermediate between 0% (dry soil) and 100% (saturated soil). Under these conditions, negative pore pressures, i.e., suction, may exist within the soil mass depending upon the type of soil and its grain size distribution. An example of the presence of negative pore pressures is the capillary rise often encountered above the water table. Such negative pore pressures affect all aspects of soil behavior ranging from volume change and shear strength to seepage. Consequently, unsaturated soil behavior impacts a broad array of engineering issues ranging from foundation design and performance to flow through earth embankments and the engineering of facilities on or in expansive, collapsible and compacted soils (ASCE 1993, 1997).

To date the tendency in engineering practice has often been to apply a total stress approach where the effects of negative pore pressures are not properly simulated. In the last couple of decades significant progress has been made to model such negative pore pressures and that field of study is often called "unsaturated soil mechanics." Discussion of the engineering behavior of unsaturated soils is beyond the scope of this manual. At this stage, it is important simply to realize that advanced studies beyond those discussed in this manual may be required on projects where unsaturated state can significantly affect the engineering behavior of soils. The interested readers are directed to the work by Fredlund and Rahardjo (1993), who provide a comprehensive treatment of unsaturated soils. [THIS PAGE INTENTIONALLY BLANK]