

# FLUID POWER FUNDAMENTALS VOL 3 OF 3

Main Category:	Mechanical Engineering
Sub Category:	Hydraulics/Pneumatics
Course #:	MEC-120
Course Content:	76 pgs
PDH/CE Hours:	5

# **OFFICIAL COURSE/EXAM**

(SEE INSTRUCTIONS ON NEXT PAGE)

<u>WWW.ENGINEERING-PDH.COM</u>
TOLL FREE (US & CA): 1-833-ENGR-PDH (1-833-364-7734)
SUPPORT@ENGINEERING-PDH.COM

# **MEC-120 EXAM PREVIEW**

#### - TAKE EXAM! -

# **Instructions:**

- At your convenience and own pace, review the course material below. When ready, click "Take Exam!" above to complete the live graded exam. (Note it may take a few seconds for the link to pull up the exam.) You will be able to re-take the exam as many times as needed to pass.
- Upon a satisfactory completion of the course exam, which is a score of 70% or better, you will be provided with your course completion certificate. Be sure to download and print your certificates to keep for your records.

# Exam Preview:

- 1. In an air-pressurized reservoir, what component is used to separate the air and fluid chambers?
  - a. Air separator
  - b. Filter
  - c. Piston
  - d. Strainer
- 2. Chemical air dries are installed in air systems to absorb moisture that may collect from air entering the system?
  - a. True
  - b. False
- 3. Direct-contact gas-to-fluid accumulators generally are used in very large installations where it would be very expensive to require a piston or bladder-type accumulator.
  - a. True
  - b. False
- 4. Into what two classes are filter elements generally divided?
  - a. Material and strength
  - b. Surface and depth
  - c. Temperature and size
  - d. Length and width
- 5. The piston type of cylinder is normally used for applications that require both push and pull functions. Thus, the piston type serves many more requirements than the ram type, and therefore is the most common type used in fluid power systems.
  - a. True
  - b. False

- 6. What type of turbine is turned by reactive force?
  - a. Impulse
  - b. Compulsion
  - c. Reaction
  - d. Response
- 7. Which of the following scientists proposed the hypothesis that is accepted as the kinetic theory of gases?
  - a. Bernoulli
  - b. Boyle
  - c. Charles
  - d. Newton
- 8. Gases can be readily compressed and are assumed to be perfectly inelastic. This combination of properties gives a gas the ability to resist a force and return promptly to its original condition when the force is removed.
  - a. True
  - b. False
- 9. As in hydraulic systems, fluid contamination is also a leading cause of malfunctions in pneumatic systems. The only applies however to solid particles of foreign matter that find a way to enter the system, moisture is typically not a problem in pneumatic systems.
  - a. True
  - b. False
- 10. In an open-center system, the pump circulates the fluid from the reservoir, through the selector valves, and back to the reservoir.
  - a. True
  - b. False

# **CHAPTER 9**

# RESERVOIRS, STRAINERS, FILTERS, AND ACCUMULATORS

Fluid power systems must have a sufficient and continuous supply of uncontaminated fluid to operate efficiently. This chapter covers hydraulic reservoirs, various types of strainers and filters, and accumulators installed in fluid power systems.

#### LEARNING OBJECTIVES

When you have completed this chapter, you will be able to do the following:

- 1. Recognize the functions and operating requirements of hydraulic reservoirs.
- 2. Identify the types, characteristics, and construction features of hydraulic reservoirs.
- 3. Identify the types, operating principles, and applications of accumulators.
- 4. Recognize the types, functions, and construction features of filters and strainers.
- 5. Recognize the operating characteristics of filters and strainers.
- 6. Recognize the effects of foreign matter on filtration in a hydraulic power system.
- 7. Recognize the functions and construction features of dehydrators.
- 8. Recognize the operating characteristics of dehydrators.

#### RESERVOIRS

A hydraulic system must have a reserve of fluid in addition to that contained in the pumps, actuators, pipes, and other components of the system. This reserve fluid must be readily available to make up losses of fluid from the system, to make up for compression of the fluid under pressure, and to compensate for the loss of volume as the fluid cools. This extra fluid is contained in a tank usually called a reservoir. A reservoir may sometimes be referred to as a sump tank, a service tank, an operating tank, a supply tank, or a base tank.

In addition to providing storage for the reserve fluid needed for the system, the reservoir acts as a radiator for dissipating heat from the fluid and as a settling tank where heavy particles of contamination may settle out of the fluid and remain harmlessly on the bottom until removed by cleaning or flushing of the reservoir. Also, the reservoir allows entrained air to separate from the fluid.

Most reservoirs have a capped opening for filling, an air vent, an oil level indicator or dip stick, a return line connection, a pump inlet or suction line connection, a drain line connection, and a drain plug (*Figure 9-1*). The inside of the reservoir generally will have baffles to prevent excessive sloshing of the fluid and to put a partition between the fluid return line and the pump suction or inlet line. The partition forces the returning fluid to travel farther around the tank before being drawn back into the active system through the pump inlet line. This process aids in settling the contamination and separating the air from the fluid.

Large reservoirs are desirable for cooling. A large reservoir also reduces recirculation, which helps settle contamination and separate air. The ideal reservoir should be two to three times the pump output per minute. However, due to space limitations in mobile and aerospace systems, the benefits of a large reservoir may have to be sacrificed. But, they must be large enough to accommodate thermal expansion of the fluid and changes in fluid level due to system operation. Reservoirs are of two general types—nonpressurized and pressurized.




Figure 9-1 — Typical hydraulic reservoir.

# **Nonpressurized Reservoirs**

Nonpressurized reservoirs are used in several transport, patrol, and utility aircraft. These aircraft are not designed for violent maneuvers; in some cases, they do not fly at high altitudes. Those aircraft that incorporate nonpressurized reservoirs and fly at high altitudes have the reservoirs installed within a pressurized area. High altitude in this situation means an altitude where atmospheric pressure is inadequate to maintain sufficient flow of fluid to the hydraulic pumps. Most nonpressurized reservoirs are constructed in a cylindrical shape. The outer housing is manufactured from a strong corrosion-resistant metal.

Filter elements are normally installed internally within the reservoir to clean returning system hydraulic fluid. In some of the older aircraft, a filter bypass valve is incorporated to allow fluid to bypass the filter in the event the filter becomes clogged. Reservoirs serviced by pouring fluid directly into the reservoir have a filler strainer (finger strainer) assembly incorporated within the filler well to strain out impurities as the fluid enters the reservoir.

Generally, reservoirs described in the above paragraph use a visual gauge to indicate the fluid quantity. Gauges incorporated on or in the reservoir may be a glass tube, a direct reading gauge, or a float-type rod, which is visible through a transparent dome. In some cases, the fluid quantity may also be read in the cockpit through the use of quantity transmitters.

A typical nonpressurized reservoir is shown in *Figure 9-2*. This reservoir consists of a welded




Figure 9-2 — Nonpressurized aircraft reservoir.

body and cover assembly clamped together. Gaskets are incorporated to seal against leakage between assemblies.

#### **Pressurized Reservoirs**

A pressurized reservoir is required in hydraulic systems where atmospheric pressure is insufficient to maintain a net positive suction head (NPSH) to the pump. There are two common types of pressurized reservoirs—fluid-pressurized and air-pressurized.

#### Fluid-Pressurized Reservoir

Some aircraft hydraulic systems use fluid pressure for pressurizing the reservoir. The reservoir shown in *Figure 9-3* is of this type. This reservoir is divided into two chambers by a floating piston. The piston is forced downward in the reservoir by a compression spring within the pressurizing cylinder and by system pressure entering the pressurizing port of the cylinder.




Figure 9-3 — Typical fluid-pressurized reservoir.

The pressurizing port is connected directly to the pressure line. When the system is pressurized, pressure enters the pressure port, thus pressurizing the reservoir. Pressure from the reservoir pressurizes the pump suction line and the reservoir return line to the same pressure.

The reservoir shown in *Figure 9-3* has five ports—pump suction, return, pressurizing, overboard drain, and bleed. Fluid is supplied to the pump through the pump suction port. Fluid returns to the reservoir from the system through the return port. Pressure from the pump enters the pressurizing cylinder in the top of the reservoir through the pressurizing port. The overboard drain port is used to drain the reservoir during maintenance, and the bleed port is used as an aid when the reservoir is being serviced.

#### **Air-Pressurized Reservoirs**

Air-pressurized reservoirs are currently used in many high-performance naval aircraft. *Figure 9-4* shows a hydraulic power system with an air-pressurized reservoir incorporated. This system is similar to the one found on many aircraft; however, for clarification in the discussion of the operation of the system, *Figure 9-4* does not show all of the components between the reservoir and the pump.

The reservoir is cylindrical in shape and has a piston installed internally to separate the air and fluid chambers. The piston rod end protrudes through the reservoir end cap and indicates the fluid quantity. The quantity indication may be seen by inspecting the distance the piston rod protrudes from the reservoir end cap. The reservoir has threaded openings for the connection of fittings and components. The schematic shown in *Figure 9-4* shows several components installed in lines leading to and from the reservoir; however, this—arrangement may not be the case in the actual installation. The air relief valve, bleeder valve, etc., may be installed directly on the reservoir. Because the reservoir is pressurized, it can normally be installed at any attitude and still maintain a positive flow of fluid to the pump.




Figure 9-4 — Air-pressurized reservoir.

#### **ACCUMULATORS**

An accumulator is a pressure storage reservoir in which hydraulic fluid is stored under pressure from an external source. The storage of fluid under pressure serves several purposes in hydraulic systems.

In some hydraulic systems it is necessary to maintain the system pressure within a specific pressure range for long periods of time. It is very difficult to maintain a closed system without some leakage, either external or internal. Even a small leak can cause a decrease in pressure. By using an accumulator, leakage can be compensated for and the system pressure can be maintained within an acceptable range for long periods of time. Accumulators also compensate for thermal expansion and contraction of the liquid due to variations in temperature.

A liquid, flowing at a high velocity in a pipe will create a backward surge when stopped suddenly by the closing of a valve. This sudden stoppage causes instantaneous pressures two to three times the operating pressure of the system. These pressures, or shocks, produce objectionable noise and vibrations, which can cause considerable damage to piping, fittings, and components. The incorporation of an accumulator enables such shocks and surges to be absorbed or cushioned by the entrapped gas, thereby reducing their effects. The accumulator also dampens pressure surges caused by pulsating delivery from the pump.

There are times when hydraulic systems require large volumes of liquid for short periods of time. This necessity is due to either the operation of large cylinders or the necessity of operating two or more circuits simultaneously. It is not economical to install a pump of such large capacity in the system for

only intermittent usage, particularly if there is sufficient time during the working cycle for an accumulator to store up enough liquid to aid the pump during these peak demands.

The energy stored in accumulators may also be used to actuate hydraulically operated units if normal hydraulic system failure occurs. Four types of accumulators used in Navy hydraulic systems are as follows:

- 1. Piston type.
- 2. Bag or bladder type.
- 3. Direct-contact gas-to-fluid.
- 4. Diaphragm.

# **Piston-Type Accumulators**

Piston-type accumulators consist of a cylindrical body called a barrel, closures on each end called heads, and an internal piston. The piston may be fitted with a tailrod, which extends through one end of the cylinder (Figure 9-5), or it may not have a tailrod at all (Figure 9-6). In the latter case, it is referred to as a floating piston. Hydraulic fluid is pumped into one end of the cylinder, and the piston is forced toward the opposite end of the cylinder against a captive charge of air or an inert gas, such as nitrogen. Sometimes the amount of air charge is limited to the volume within the accumulator; other installations may use separate air flasks, which are piped to the air side of the accumulator. Piston accumulators may be mounted in any position.




Figure 9-5 — Cross-section view of a piston-type accumulator with a tailrod.




Figure 9-6 — Floating piston-type accumulator.

The gas portion of the accumulator may be located on either side of the piston. For example, in submarine hydraulic systems with tailrod pistons, the gas is usually on the bottom and the fluid on top; in surface ships with floating pistons, the gas is usually on the top. The orientation of the accumulator and the type of accumulator are based upon such criteria as available space, maintenance accessibility, size, need for external monitoring of the piston's location (tailrod indication), contamination tolerance, seal life, and safety. The purpose of the piston seals is to keep the fluid and the gas separate.

Usually, tailrod accumulators use two piston seals, one for the air side and one for the oil side, with the space between them vented to the atmosphere through a hole drilled the length of the tailrod. When the piston seals fail in this type of accumulator, air or oil leakage is apparent. However, seal failure in floating piston or nonvented tailrod accumulators will not be as obvious. Therefore, more frequent attention to venting or draining the air side is necessary. An indication of worn and leaking seals can be detected by the presence of significant amounts of oil in the air side.

# **Bladder-Type Accumulators**

Bladder- or bag-type accumulators consist of a shell or case with a flexible bladder inside the shell (Figure 9-7). The bladder is larger in diameter at the top (near the air valve) and gradually tapers to a smaller diameter at the bottom. The synthetic rubber is thinner at the top of the bladder than at the bottom. The operation of the accumulator is based on Barlow's formula for hoop stress, which states: "The stress in a circle is directly proportional to its diameter and wall thickness." This means that for a certain thickness, a large-diameter circle will stretch faster than a small-diameter circle: or for a certain diameter. a thin wall hoop will stretch faster than a thick wall hoop. Thus, the bladder will stretch around the top at its largest diameter and thinnest wall thickness, and then will gradually stretch downward and push itself outward against the walls of the shell. As a result, the




Figure 9-7 — Bladder-type accumulator.

bladder is capable of squeezing out all the liquid from the accumulator. Consequently, the bladder accumulator has a very high volumetric efficiency. In other words, this type of accumulator is capable of supplying a large percentage of the stored fluid to do work.

The bladder is precharged with air or inert gas to a specified pressure. Fluid is then forced into the area around the bladder, further compressing the gas in the bladder. This type of accumulator has the advantage that as long as the bladder is intact, there is no exposure of fluid to the gas charge and therefore less danger of an explosion.

#### **Direct-Contact Gas-to-Fluid Accumulators**

Direct-contact gas-to-fluid accumulators generally are used in very large installations where it would be very expensive to require a pistonor bladder-type accumulator. This type of accumulator consists of a fully enclosed cylinder, mounted in a vertical position, containing a liquid port on the bottom and a pneumatic charging port at the top (*Figure 9-8*). This type of accumulator is used in some airplane elevator hydraulic systems where several thousand gallons of fluid are needed to supplement the output of the hydraulic pumps for raising the elevator platform. The direct contact between the air or gas and the hydraulic fluid tends to entrain excessive amounts of gas in the fluid. For this reason,

direct contact accumulators are generally not used for pressures over 1,200 per square inch (psi). The use of this type of accumulator with flammable fluid is dangerous because there is a possibility of explosion if any oxygen is present in the gas, and pressure surges generate excessive heat. For this reason, safety fluids are used in this type of installation.

# **Diaphragm Accumulators**

The diaphragm-type accumulator is constructed in two halves that are either screwed or bolted together. A synthetic rubber diaphragm is installed between both halves, making two chambers. Two threaded openings exist in the assembled component. The opening at the top, as shown in Figure 9-9, contains a screen disc that prevents the diaphragm from extruding through the threaded opening when system pressure is depleted, thus rupturing the diaphragm. On some designs the screen is replaced by a button-type protector fastened to the center of the diaphragm. An air valve for pressurizing the accumulator is located in the gas chamber end of the sphere, and the liquid port to the hydraulic system is located on the opposite end of the sphere. This accumulator operates in a manner similar to that of the bladder-type accumulator.

#### **FILTRATION**

You have learned that maintaining hydraulic fluids within allowable limits is crucial to the care and protection of hydraulic equipment. While every effort must be made to prevent contaminants from entering the system, contaminants that do find their way into the system must be removed. Filtration devices are installed at key points in fluid power systems to remove the contaminants that enter the system, along with those that are generated during normal operations.

Filtration devices for hydraulic systems differ somewhat from those of pneumatic systems. Therefore, they will be discussed separately. The filtering devices used in




Figure 9-8 — Direct-contact gas-to-fluid accumulator.




Figure 9-9 — Diaphragm accumulator.

hydraulic systems are commonly referred to as strainers and filters. Because they share a common function, the terms strainer and filter are often used interchangeably. As a general rule, devices used to remove large particles of foreign matter from hydraulic fluids are referred to as strainers, while those used to remove the smallest particles are referred to as filters.

#### **STRAINERS**

Strainers are used primarily to catch only very large particles and will be found in applications where this type of protection is required. Most hydraulic systems have a strainer in the reservoir at the inlet to the suction line of the pump. A strainer is used in lieu of a filter to reduce its chance of being

clogged and starving the pump. However, because this strainer is located in the reservoir, its maintenance is frequently neglected. When heavy dirt and sludge accumulate on the suction strainer, the pump soon begins to cavitate. Pump failure follows quickly.

#### **FILTERS**

The most common device installed in hydraulic systems to prevent foreign particles and contamination from remaining in the system is filters. They may be located in the reservoir, in the return line, in the pressure line, or in any other location in the system where the designer of the system decides they are needed to safeguard the system against impurities.

Filters are classified as full flow and proportional or partial flow. In the full-flow type of filter, all the fluid that enters the unit passes through the filtering element, while in the proportional-flow type, only a portion of the fluid passes through the element.

#### **Full-Flow Filter**

The full-flow filter provides a positive filtering action; however, it offers resistance to flow, particularly when the element becomes dirty. Hydraulic fluid enters the filter through the inlet port in the body and flows around the filter element inside the filter bowl. Filtering takes place as the fluid passes through the filtering element and into the hollow core, leaving the dirt and impurities on the outside of the filter element. The filtered fluid then flows from the hollow core through the outlet port and into the system (*Figure 9-10*).

Some full-flow filters are equipped with a contamination indicator (Figure 9-11). These indicators, also known as differential pressure indicators, are available in three types—gauge indicators, mechanical pop-up indicators, and electrical with mechanical pop-up indicators. As contaminating particles collect on the filter element, the differential pressure across the element increases. In some installations using gauges as indicators, the differential pressure must be obtained by subtracting the readings of two gauges located somewhere along the filter inlet and outlet piping. For pop-up indicators, when the increase in pressure reaches a specific value, an indicator (usually




Figure 9-10 — Full-flow hydraulic filter.




Figure 9-11 — Full-flow bypass-type hydraulic filter.

in the filter head) pops out, signifying that the filter must be cleaned or replaced. To eliminate the possibility of false indications resulting from cold weather, a low-temperature lockout feature is installed in most pop-up types of contamination indicators. The pressure differential may be much higher with a cold fluid because of increased viscosity.

Filter elements used in filters that have a contamination indicator are not normally removed or replaced until the indicator is actuated. This procedure decreases the possibility of system contamination from outside sources due to unnecessary handling.

The use of the nonbypassing type of filter eliminates the possibility of contaminated fluid bypassing the filter element and contaminating the entire system. This type of filter will minimize the necessity for flushing the entire system and lessen the possibility of failure of pumps and other components in the system.

A bypass relief valve is installed in some filters. The bypass relief valve allows the fluid to bypass the filter element and pass directly through the outlet port in the event that the filter element becomes clogged. These filters may or may not be equipped with the contamination indicator. *Figure 9-11* shows a full-flow bypass-type hydraulic filter with a contamination indicator.

A filter bypass indicator provides a positive indication, when activated, that fluid is bypassing the filter element by flowing through the bypass relief valve. This indicator should not be confused with the pop-up differential pressure indicator previously discussed, which simply monitors the pressure across the element. With the bypass indicator, a similar pop-up button is often used to signal that maintenance is needed. However, the bypass indicators further signal that, as a result of the high differential pressures across the element, an internal bypass relief valve has lifted and some of the fluid is bypassing the element.

Identification of the type of installed indicator can be obtained from filter manifold drawings or related equipment manuals. Both a fluid bypass indicator and a differential pressure indicator or gauge may be installed on the same filter assembly.

As with differential pressure indicators, bypass relief indicators can be activated by pressure surges. On some relief indicators, the pop-up button, or whatever signal device is used, will return to a normal position when the surge passes and pressure is reduced. Other relief indicators may continue to indicate a bypass condition until they are manually reset. Before taking corrective action based on indicator readings, verify the bypass condition at normal operating temperature and flow conditions by attempting to reset the indicator.

# **Proportional-Flow Filter**

This type of filter operates on the venturi principle. As the fluid passes through the venturi throat, a drop in pressure is created at the narrowest point (*Figure 9-12*). A portion of the fluid flowing toward and away from the throat of the venturi flows




Figure 9-12 — Proportional-flow filter.

through the passages into the body of the filter. A fluid passage connects the hollow core of the filter with the throat of the venturi. Thus, the low-pressure area at the throat of the venturi causes the fluid under pressure in the body of the filter to flow through the filter element, through the hollow core, into the low-pressure area, and then return to the system. Although only a portion of the fluid is filtered during each cycle, constant recirculation through the system will eventually cause all the fluid to pass through the filter element.

# **Filter Rating**

Filters have three ratings—absolute, mean, and nominal. The absolute filtration rating is the diameter in microns of the largest spherical particle that will pass through the filter under a certain test condition. This rating is an indication of the largest opening in the filter element. The mean filtration rating is the measurement of the average size of the openings in the filter element. The nominal filtration rating is usually interpreted to mean the size of the smallest particles, of which 90 percent will be trapped in the filter at each pass through the filter.

#### **Filter Elements**

Filter elements generally may be divided into two classes—surface and depth. Surface filters are made of closely woven fabric or treated paper with a uniform pore size. Fluid flows through the pores of the filter material, and contaminants are stopped on the filter's surface. This type of element is designed to prevent the passage of a high percentage of solids of a specific size. Depth filters, on the other hand, are composed of layers of fabric or fibers that provide many tortuous paths for the fluid to flow through. The pores or passages must be larger than the rated size of the filter if particles are to be retained in the depth of the media rather than on the surface. Consequently, there is a statistical probability that a rather large particle may pass through a depth-type filter.

Filter elements may be of the 5-micron, woven mesh, micronic, porous metal, or magnetic type. The micronic and 5-micron elements have noncleanable filter media and are disposed of when they are removed. Porous metal, woven mesh, and magnetic filter elements are usually designed to be cleaned and reused.

#### 5-Micron Noncleanable Filter Elements

The most common 5-micron filter medium is composed of organic and inorganic fibers integrally bonded by epoxy resin and faced with a metallic mesh upstream and downstream for protection and added mechanical strength. Filters of this type are not to be cleaned under any circumstances and will be marked Disposable or Noncleanable.

Another 5-micron filter medium uses layers of very fine stainless-steel fibers drawn into a random but controlled matrix. Filter elements of this material may be either cleanable or noncleanable, depending upon their construction.

#### **Woven Wire-Mesh Filter Elements**

Filters of this type are made of stainless steel and are generally rated as 15 or 25 microns (absolute). *Figure 9-13* shows a magnified cross section of a woven wire-mesh filter element. This type of filter is reusable.




Figure 9-13 — Cross-section of a stainlesssteel hydraulic filter element.

#### **Micronic Hydraulic Filter Element**

The term micronic is derived from the word micron. It could be used to describe any filter element; however, through usage, this term has become associated with a specific filter with a filtering element made of a specially treated cellulose paper (*Figure 9-14*). The filter shown in *Figure 9-10* is a typical micronic hydraulic filter. The micronic filter element is designed to remove 99 percent of all particles 10 to 20 microns in diameter or larger. The replaceable element is made of specially treated convolutions (wrinkles) to increase its dirt-holding capacity. The element is noncleanable and should be replaced with a new filter element during maintenance inspections.

# Micronic Filter

Figure 9-14 — Micronic filter element.

#### **Magnetic Filters**

Some hydraulic systems have magnetic filters installed at strategic points. Filters of this type are designed primarily to trap any ferrous particles that may be in the system.

#### PNEUMATIC GASES

Clean, dry gas is required for the efficient operation of pneumatic systems. Due to the normal conditions of the atmosphere, free air seldom satisfies these requirements adequately. The atmosphere contains both dust and impurities in various amounts and a substantial amount of moisture in vapor form.

Solids, such as, dust, rust, or pipe scale in pneumatic systems may lead to excessive wear and failure of components and in some cases, may prevent the pneumatic devices from operating. Moisture is also very harmful to the system. It washes lubrication from moving parts, thereby aiding corrosion and causing excessive wear of components. Moisture will also settle in low spots in the system and freeze during cold weather, causing a stoppage of the system or ruptured lines.

An ideal filter would remove all dirt and moisture from a pneumatic system without causing a pressure drop in the process. Obviously, such a condition can only be approached; it cannot be attained.

#### **Removal of Solids**

The removal of solids from the gas of pneumatic systems is generally done by screening (filtering), centrifugal force, or a combination of the two. In some cases, the removal of moisture is done in conjunction with the removal of solids.

Some types of air filters are similar in design and operation to the hydraulic filters discussed earlier. Some materials used in the construction of elements for air filters are woven screen wire, steel wool, fiberglass, and felt fabrics. Elements made of these materials are often used in the unit that filters the air as it enters the compressor.

Porous metal and ceramic elements are commonly used in filters that are installed in the compressed air supply lines. These filters also use a controlled air path to provide some filtration. Internal design causes the air to flow in a circular path within the bowl (*Figure 9-15*). Heavy particles and water droplets are thrown out of the airstream and drop to the bottom of the bowl. The air then flows through the filter element, which filters out most of the smaller particles. This type of filter is designed with a drain valve at the bottom of the bowl.

An air filter that uses moving mechanical devices as an element is illustrated in *Figure 9-16*. As compressed air passes through the filter, the force revolves a number of multiblade rotors at high speed. Moisture and dirt are caught on the blades of the rotors. The whirling blades hurl the impurities by centrifugal force to the outer rims of the rotors and to the inner walls of the filter housing. Here, contaminating matter is out of the airstream and falls to the bottom of the bowl, where it must be drained at periodic intervals.




Figure 9-16 — Air filter using rotating blades as element.




Figure 9-15 — Air filter.

#### **Removal of Moisture**

The removal of moisture from compressed air is important for a compressed air system. If air at atmospheric pressure, even at a very low relative humidity, is compressed to 3,000 or 4,500 pounds psi, it becomes saturated with water vapor. Some moisture is removed by the intercoolers and aftercoolers. Also, air flasks, receivers, and banks are provided with low point drains to allow periodic draining of any collected moisture. However, many uses of air require air with an even smaller moisture content than can be obtained through these methods. Moisture in air lines can create problems that are potentially hazardous, such as the freezing of valves and controls. Freezing can occur, for example, if air at an extremely high pressure is throttled to a very low pressure at a high flow rate. The venturi effect of the throttled

air produces very low temperatures, which will cause any moisture in the air to freeze into ice. Ice makes the valve (especially an automatic valve) either very difficult or impossible to operate. Also, droplets of water can cause serious water hammer in an air system that has high pressure and a high flow rate, and can cause corrosion, rust, and dilution of lubricants within the system. For these reasons, air driers (dehydrator, air purifier, and desiccator are all terms used by different manufacturers to identify these components) are used to dry the compressed air. Some water removal devices are similar in design and operation to the filters, shown *in Figures 9-16 and 9-17*. Two basic types of air dehydrators are the refrigerated and the desiccant types.

#### **Refrigerated-Type Dehydrators**

In refrigerated-type dehydrators, compressed air is passed over a set of refrigerated cooling coils. Oil and moisture vapors condense from the air and can be collected and removed via a low point drain.

#### **Desiccant-Type Dehydrators**

A desiccant is a chemical substance with a high capacity to absorb water or moisture. It also has the capacity to give off that moisture so that the desiccant can be reused.

Some compressed air system dehydrators use a pair of desiccant towers (flasks full of desiccant). One is kept in service dehydrating the compressed air, while the other one is being reactivated. A desiccant tower is normally reactivated by passing dry, heated air through it in the direction opposite the normal dehydration airflow.

#### **Chemical Air Drier**

Chemical air driers are installed in air systems to absorb moisture that may collect from air entering the system. The main parts of the air drier, shown in *Figure 9-17*, are the housing, the desiccant cartridge, the filter (porous bronze), and the spring. To ensure proper filtering, the air must pass through the air drier in the proper direction. The correct direction of flow is indicated by an arrow and the word flow printed on the side of the cartridge.




Figure 9-17 — Chemical drier.

# **CHAPTER 10**

# **ACTUATORS**

One of the outstanding features of fluid power systems is that force, generated by the power supply, controlled and directed by suitable valving, and transported by lines, can be converted with ease to almost any kind of mechanical motion desired at the very place it is needed. Either linear (straight line) or rotary motion can be obtained by using a suitable actuating device.

An actuator is a device that converts fluid power into mechanical force and motion. Cylinders, motors, and turbines are the most common types of actuating devices used in fluid power systems.

This chapter describes various types of actuating cylinders and their applications, different types of fluid motors, and turbines used in fluid power systems.

#### LEARNING OBJECTIVES

When you have completed this chapter, you will be able to do the following:

- 1. Recognize the types of fluid power actuating devices.
- 2. Identify the construction features and uses of the various types of actuating cylinders.
- 3. Identify the operating characteristics of various types of actuating cylinders.
- 4. Recognize the different types of fluid power motors.
- 5. Identify functions and operating characteristics of various types of turbines.
- 6. Identify the construction features of various types of turbines.

#### **CYLINDERS**

An actuating cylinder is a device that converts fluid power to linear, force, and motion. Since linear motion is a back-and-forth motion along a straight line, this type of actuator is sometimes referred to as a reciprocating, or linear, motor. The cylinder consists of a ram or piston operating within a cylindrical bore. Actuating cylinders may be installed so that the cylinder is anchored to a stationary structure and the ram or piston is attached to the mechanism to be operated. The piston or ram could also be anchored to the stationary structure and the cylinder attached to the mechanism to be operated.

Actuating cylinders for pneumatic and hydraulic systems are similar in design and operation. Some of the variations of ram- and piston-type actuating cylinders are described in the following paragraphs.

# **Ram-Type Cylinders**

The terms ram and piston are often used interchangeably. However, a ram-type cylinder is usually considered one in which the cross-sectional area of the piston rod is more than one-half the cross-sectional area of the movable element. In most actuating cylinders of this type, the rod and the movable element have equal areas. This type of movable element is frequently referred to as a plunger.

The ram-type actuator is used primarily to push rather than to pull. Some applications require simply a flat surface on the external part of the ram for pushing or lifting the unit to be operated. Other applications require some mechanical means of attachment, such as a clevis or eyebolt. The design

of ram-type cylinders varies in many other respects to satisfy the requirements of different applications.

#### **Single-Acting Ram**

The single-acting ram (*Figure 10-1*) applies force in only one direction. Fluid directed into the cylinder displaces the ram and forces it outward. Since there is no provision for retracting the ram by the use of fluid power, the retracting force can be gravity or some mechanical means, such as a spring. This type of actuating cylinder is often used in the hydraulic jack.




Figure 10-1 — Single-acting ram.

#### **Double-Acting Ram**

A double-acting ram type of cylinder is illustrated in *Figure 10-2*. In this cylinder, both strokes of the ram are produced by pressurized fluid. There are two fluid ports—one at or near each end of the cylinder. To extend the ram and apply force, fluid under pressure is directed to the closed end of the cylinder through one port.




Figure 10-2 — Double-acting ram.

#### **Telescoping Rams**

Figure 10-3 shows a telescoping ram-type actuating cylinder. A series of rams are nested in the telescoping assembly. With the exception of the smallest ram, each ram is hollow and serves as the cylinder housing for the next smaller ram. The ram assembly is contained in the main cylinder assembly, which also provides the fluid ports. Although the assembly requires a small space with all the rams retracted, the telescoping action of the assembly provides a relatively long stroke when the rams are extended.

An excellent example of the application of this type of cylinder is in the dump truck. It is used to lift the forward end of the truck bed and dump the load. During the lifting operation, the greatest force is required for the initial lifting of the load.




Figure 10-3 — Telescoping ram-type actuating cylinder.

As the load is lifted and begins to dump, the required force becomes less and less until the load is completely dumped. During the raise cycle, pressurized fluid enters the cylinder through port A (*Figure 10-3*) and acts on the bottom surface of all three rams. Ram 1 has a larger surface area and, therefore, provides the greater force for the initial load. As ram 1 reaches the end of its stroke and the required force is decreased, ram 2 moves, providing the smaller force needed to continue raising the load. When ram 2 completes its stroke, a still smaller force is required. Ram 3 then moves outward to finish raising and dumping the load.

Some telescoping ram-type cylinders are of the single-acting type. Like the single-acting ram discussed previously, these telescoping ram-type cylinders are retracted by gravity or mechanical force. Some hydraulic jacks are equipped with telescoping rams. Such jacks are used to lift vehicles with low clearances to the required height.

Other types of telescoping cylinders, like the one illustrated in *Figure 10-3*, are of the double-acting type. In this type, fluid pressure is used for both the extension and retraction strokes. A four-way directional control valve is commonly used to control the operation of the double-acting type. Note the small passages in the walls of rams 1 and 2. They provide a path for fluid to flow to and from the chambers above the lips of rams 2 and 3. During the extension stroke, return fluid flows through these passages and out of the cylinder through port B. It then flows through the directional control valve to the return line or reservoir.

To retract the rams, fluid under pressure is directed into the cylinder through port B and acts against the top surface areas of all three ram lips. This pressure forces the rams to the retracted position. The displaced fluid from the opposite side of the rams flows out of the cylinder through port A, through the directional control valve to the return line or reservoir.

#### **Dual Rams**

A dual ram assembly consists of a single ram with a cylinder at either end (*Figure 10-4*). Fluid can be directed to either cylinder, forcing the ram to move in the opposite direction. The ram is connected through mechanical linkage to the unit to be operated. A four-way directional control valve is commonly used to operate the dual ram. When the control valve is positioned to direct fluid under pressure to one of the cylinders (let's say the left one), the ram is forced to the right. This action

displaces the fluid in the opposite cylinder. The displaced fluid flows back through the directional control valve to the return line or reservoir in hydraulic systems or to the atmosphere in pneumatic systems.

Dual ram actuating assemblies are used in steering systems of most ships. In some systems, one assembly is used to actuate the rudder in either direction; while in other systems, two assemblies are used for the same purpose.




Figure 10-4 — Dual ram actuating assembly.

# **Piston-Type Cylinders**

The piston type of cylinder is normally used for applications that require both push and pull functions. Thus, the piston type serves many more requirements than the ram type, and therefore is the most common type used in fluid power systems.

The essential parts of a piston-type cylinder are a cylindrical barrel, a piston and rod, end caps, and suitable seals. The end caps are attached to the ends of the barrel. These end caps usually contain the fluid ports. The end cap on the rod end contains a hole for the piston rod to pass through. Suitable seals are used between the hole and the piston rod to keep fluid from leaking out and to keep dirt and other contaminants from entering the barrel. The opposite end cap of most cylinders is provided with a fitting for securing the actuating cylinder to some structure. This end cap is referred to as the anchor end cap.

The piston rod may extend through either or both ends of the cylinder. The extended end of the rod is normally threaded so that some type of mechanical connector, such as an eyebolt or a clevis, and a locknut can be attached. This threaded connection of the rod and mechanical connector provides for adjustment between the rod and the unit to be actuated. After the correct adjustment is made, the locknut is tightened against the connector to prevent the connector from turning. The other end of the eyebolt or clevis is connected to the unit to be actuated, either directly or through additional mechanical linkage.

In order to satisfy the many requirements of fluid power systems, piston-type cylinders are available in various designs.

#### **Single-Acting Actuating Cylinder**

The single-acting, piston-type cylinder uses fluid pressure to apply force in only one direction. In some designs of this type, the force of gravity moves the piston in the opposite direction. However, most cylinders of this type apply force in both directions. Fluid pressure provides the force in one direction, and spring tension provides the force in the opposite direction. In some single-acting cylinders, compressed air or nitrogen is used instead of a spring for movement in the direction opposite that which is achieved with fluid pressure.

Figure 10-5 shows a single-acting, spring-loaded, piston-type actuating cylinder. In this cylinder the spring is located on the rod side of the piston. In some spring-loaded cylinders, the spring is located on the blank side, and the fluid port is located on the rod side of the cylinder.

A three-way directional control valve is normally used to control the operation of the single-acting piston-type cylinder. To extend the piston rod, fluid under pressure is directed through the port into the cylinder (Figure 10-5). This pressure acts on the surface area of the blank side of the piston and forces the piston to the right. This action moves the rod to the right, through the end of the cylinder, thus moving the actuated unit in one direction. During this action, the spring is compressed between the rod side of the piston and the end of the cylinder. The length of the stroke depends upon the physical limits within the cylinder and the required movement of the actuated unit.




Figure 10-5 — Single-acting actuating cylinder.

To retract the piston rod, the directional control valve is moved to the opposite working position, which releases the pressure in the cylinder. The spring tension forces the piston to the left, retracting the piston rod and moving the actuated unit in the opposite direction. The fluid is free to flow from the cylinder through the port, back through the control valve to the return line in hydraulic systems or to the atmosphere in pneumatic systems.

The end of the cylinder opposite the fluid port is vented to the atmosphere. This vent prevents air from being trapped in this area. Any trapped air would compress during the extension stroke, creating excess pressure on the rod side of the piston. The trapped air can cause sluggish movement of the piston and could eventually cause a complete lock, preventing the fluid pressure from moving the piston.

Seals prevent leakage between the cylinder wall and the piston. Hydraulic components use seals or gaskets to prevent leakage between static parts (nonmoving), such as a valve body and a hydraulic line fitting. Seals also prevent leakage between dynamic (moving) parts, such as the piston and cylinder wall. The most common seal is an O-ring. Some static seals and all dynamic seals require a backup ring or rings.

#### **Double-Acting Cylinder**

Most piston-type actuating cylinders are double-acting, which means that fluid under pressure can be applied to either side of the piston to apply force and provide movement.

One design of the double-acting piston-type actuating cylinder is shown in *view A* of *Figure 10-6*. This cylinder contains one piston and piston rod assembly. The stroke of the piston and piston rod assembly in either direction is produced by fluid pressure. The two fluid ports—one near each end of the cylinder—alternate as inlet and outlet ports, depending on the direction of flow from the directional control valve.

This actuator (*Figure 10-6, view A*) is referred to as an unbalanced actuating cylinder because of the difference in the effective working areas on the two sides of the pistor Therefore, this type of cylinder is normally installed so the blank side the piston carries the greater load; that is, the cylinder carries the greater load during the piston rod extension stroke.

A four-way directional control valve normally used to control the operation of this type of cylinder. The valve can be positioned to direct fluunder pressure to either end of the cylinder and allow the displaced fluuto flow from the opposite end of the cylinder through the control valve to the return line in hydraulic systems to the atmosphere in pneumatic systems.

The piston of the cylinder shown in view A of Figure 10-6 is equipped with an O-ring seal and backup rings to prevent internal leakage of fluid




Figure 10-6 — Double-acting cylinder.

from one side of the piston to the other. Suitable seals and backup rings are also used between the hole in the end cap and the piston rod to prevent external leakage. In addition, some cylinders of this type have a felt wiper ring attached to the inside of the end cap and fitted around the piston rod to guard against the entrance of dirt and other foreign matter into the cylinder. The actuating cylinder shown in *view B* of *Figure 10-6* is a double-acting-balanced type. The piston rod extends through the piston and out through both ends of the cylinder. One or both ends of the piston rod may be attached to a mechanism to be actuated. In either case, the cylinder provides equal areas on each side of the piston so that the amount of fluid and force required to move the piston a certain distance in one direction is exactly the same as the amount required to move it an equal distance in the opposite direction.

Actuators are designed for a particular type of installation. For example, internal locking cylinders are used on some bomb bay door installations, while cushioned types are used where it is necessary to slow the extension or retraction of landing gears.

# **Tandem Cylinders**

A tandem actuating cylinder consists of two or more cylinders arranged one behind the other but designed as a single unit (*Figure 10-7*). This type of actuating cylinder is used in applications that require two or more independent systems; for example, power-operated flight control systems in naval aircraft.




Figure 10-7 — Tandem actuating cylinder.

The flow of fluid to and from the two chambers of the tandem actuating cylinder is provided from two independent hydraulic systems and is controlled by two sliding spool directional control valves. In some applications, the control valves and the actuating cylinder are two separate units. In some units, the pistons (lands) of the two sliding spools are machined on one common shaft. In other applications, the valves and the actuator are directly connected in one compact unit. Although the two control valves are hydraulically independent, they are interconnected mechanically. In other units, the two sliding spools are connected through mechanical linkages with a synchronizing rod. In either case, the movement of the two sliding spools is synchronized, thus equalizing the flow of fluid to and from the two chambers of the actuating cylinder.

Since the two control valves operate independently of each other as far as hydraulic pressure is concerned, failure of either hydraulic system does not render the actuator inoperative. Failure of one system does reduce the output force by one-half; however, this force is sufficient to permit operation of the actuator.

#### RACK-AND-PINION PISTON-TYPE ROTARY ACTUATORS

The rack-andpinion-type actuators, also referred to as limited rotation cylinders, of the single or multiple. bidirectional piston are used for turning. positioning, steering, opening and closing. swinging, or any other mechanical function involving restricted rotation. Figure 10-8 shows a rack-and-pinion double-piston rotary actuator.

The actuator consists of a body and two reciprocating pistons with an integral rack for rotating the shaft mounted in roller or journal bearings.




Figure 10-8 — Rack-and-pinion double-piston rotary actuator.

The shaft and bearings are located in a central position and are enclosed with a bearing cap. The pistons—one on each side of the rack—are enclosed in cylinders machined or sleeved into the body. The body is enclosed with end caps and static seals to prevent external leakage of pressurized fluid.

Only a few of the many applications of actuating cylinders were discussed in the preceding paragraphs. *Figure 10-9* shows additional types of force and motion applications.




Figure 10-9 — Applications of actuating cylinders.

In addition to its versatility, the cylinder-type actuator is probably the most trouble-free component of fluid power systems. However, it is very important that the cylinder, mechanical linkage, and actuating unit are correctly aligned. Any misalignment will cause excessive wear of the piston, piston rod, and seals. Also, proper adjustment between the piston rod and the actuating unit must be maintained.

#### **MOTORS**

A fluid power motor is a device that converts fluid power energy to rotary motion and force. The function of a motor is opposite that of a pump. However, the design and operation of fluid power motors are very similar to pumps. Therefore, a thorough knowledge of pumps will help you understand the operation of fluid power motors. Motors have many uses in fluid power systems. In hydraulic power drives, pumps and motors are combined with suitable lines and valves to form hydraulic transmissions. The pump, commonly referred to as the A-end, is driven by some outside source, such as an electric motor. The pump delivers fluid to the motor. The motor, referred to as the B-end, is actuated by this flow, and through mechanical linkage conveys rotary motion and force to the work. This type of power drive is used to operate (train and elevate) many of the Navy's guns and rocket launchers. Hydraulic motors are commonly used to operate the wing flaps, radomes, and radar equipment in aircraft. Air motors are used to drive pneumatic tools. Air motors are also used in missiles to convert the kinetic energy of compressed gas into electrical power, or to drive the pump of a hydraulic system.

Fluid motors may be either fixed or variable displacement. Fixed-displacement motors provide constant torque and variable speed. The speed is varied by controlling the amount of input flow. Variable-displacement motors are constructed so that the working relationship of the internal parts can be varied to change displacement. The majority of the motors used in fluid power systems are the fixed-displacement type.

Although most fluid power motors are capable of providing rotary motion in either direction, some applications require rotation in only one direction. In these applications, one port of the motor is connected to the system pressure line and the other port to the return line or exhausted to the atmosphere. The flow of fluid to the motor is controlled by a flow control valve, a two-way directional control valve, or by starting and stopping the power supply. The speed of the motor may be controlled by varying the rate of fluid flow to it.

In most fluid power systems, the motor is required to provide actuation power in either direction. In these applications the ports are referred to as working ports, alternating as inlet and outlet ports. The flow to the motor is usually controlled by either a four-way directional control valve or a variable-displacement pump.

Fluid motors are usually classified according to the type of internal element, which is directly actuated by the flow. The most common types of elements are the gear, vane, and piston. All three of these types are adaptable for hydraulic systems, while only the vane-type is used in pneumatic systems.

# **Gear-Type Motors**

The spur, helical, and herringbone design gears are used in gear-type motors.

The operation of a gear-type motor is shown in *Figure 10-10*. Both gears are driven gears; however, only one is connected to the output shaft. As fluid under pressure enters the chamber, it takes the path of least resistance and flows around the inside surface of the housing, forcing the gears to rotate as indicated.




Figure 10-10 — Gear-type rotary pump.

The flow continues through the outlet port to the return. This rotary motion of the gears is transmitted through the attached shaft to the work unit.

#### Vane-Type Motors

A typical vane-type air motor is shown in *Figure 10-11*. This particular motor provides rotation in only one direction. The rotating element is a slotted rotor which is mounted on a drive shaft. Each slot of the rotor is fitted with a freely sliding rectangular vane. The rotor and vanes are enclosed in the housing, the inner surface of which is offset from the drive shaft axis. When the rotor is in motion, the vanes tend to slide outward due to centrifugal force. The distance the vanes slide is limited by the shape of the rotor housing.

This motor operates on the principle of differential areas. When compressed air is directed into the inlet port, its pressure is exerted equally in all directions. Since area A




Figure 10-11 — Vane-type air motor.

(*Figure 10-11*) is greater than area B, the rotor will turn counterclockwise. Each vane, in turn, assumes the No. 1 and No. 2 positions and the rotor turns continuously. The potential energy of the compressed air is thus converted into kinetic energy in the form of rotary motion and force. The air at reduced pressure is exhausted to the atmosphere. The shaft of the motor is connected to the unit to be actuated.

Many vane-type motors are capable of providing rotation in either direction. A motor of this design is shown in *Figure 10-12*. This motor operates on the same principle as the vane motor shown in *Figure 10-11*. The two ports may be alternately used as inlet and outlet, thus providing rotation in either direction. Notice the springs in the slots of the rotor. Their purpose is to hold the vanes against the housing during the initial starting of the motor, since centrifugal force does not exist until the rotor begins to rotate.

# **Piston-Type Motors**

Piston-type motors are the most commonly used motors in hydraulic systems. They are basically the same as hydraulic pumps except they are used to convert hydraulic energy into mechanical (rotary) energy.

The most commonly used hydraulic motor is the fixed-displacement piston type. Some equipment uses a variable-displacement




Figure 10-12 — Vane-type motor.

piston motor where very wide speed ranges are desired. Although some piston-type motors are controlled by directional control valves, they are often used in combination with variable displacement pumps. This pump-motor combination is used to provide a transfer of power between a driving element and a driven element. Some applications for which hydraulic transmissions may be used are speed reducers, variable speed drives, constant speed or constant torque drives, and torque converters. Some advantages of hydraulic transmission of power over mechanical transmission of power are as follows:

- Quick, easy speed adjustment over a wide range while the power source is operating at a constant (most efficient) speed; rapid, smooth acceleration or deceleration
- Control over maximum torque and power
- Cushioning effect to reduce shock loads
- Smoother reversal of motion

#### **Radial-Piston Motor**

The radial-piston motor operates in reverse of the radial-piston pump. In the radial-piston pump, as the cylinder block rotates, the pistons press against the rotor and are forced in and out of the cylinders, thereby receiving fluid and pushing it out into the system. In the radial-piston motor, fluid is forced into the cylinders and drives the pistons outward. The pistons pushing against the rotor cause the cylinder block to rotate.

The operation of a radial-piston motor is shown in *Figure 10-13*. This motor is shown with three pistons for simplicity. Normally, it contains seven or nine pistons. When liquid is forced into the cylinder bore containing piston 1, the piston moves outward since the liquid cannot be compressed causing the cylinder to rotate in a clockwise direction. As the force acting on piston 1 causes the cylinder block to rotate, piston 2 starts to rotate and approach the position of piston 3 (note that the distance between the cylinder block and the reaction ring of the rotor gets progressively shorter on the top and right half of the rotor).

As piston 2 rotates, it is forced inward and, in turn, forces the fluid out of the cylinder. Since there is little or no pressure on this side of the pintle valve, the piston is easily moved in by its contact with the reaction ring of the rotor. The fluid is easily forced out of the cylinder and




Figure 10-13 — Operation of a radial-piston motor.

back to the reservoir or to the inlet side of the pump. As the piston moves past the midpoint or past the shortest distance between the cylinder block and the rotor, it enters the pressure side of the pintle valve and fluid is forced into the cylinder. Piston 3 then becomes the pushing piston and in turn rotates the cylinder block. This action continues as long as fluid under pressure enters the cylinders.

The direction of rotation of the motor (*Figure 10-13*) is changed by reversing the flow of fluid to it. By admitting fluid under pressure on the top side of the pintle valve, it forces piston 3 out of the cylinder block, causing the cylinder to rotate in the counterclockwise direction.

#### **Axial-Piston Motor**

The variable-stroke axial-piston pump usually has either seven or nine single-acting pistons which are evenly spaced around a cylinder barrel. An uneven number of pistons are always used in order to avoid pulsations in the discharge flow. Notice that the term "cylinder barrel," as used here, actually refers to a cylinder block which holds all the cylinders. The piston rods make a ball-and-socket connection with a socket ring. The socket ring rides on a thrust bearing carried by a casting called the tilting box or tilting block.

When the tilting box is at a right angle to the shaft, and the pump is rotating, the pistons do not reciprocate; therefore, no pumping takes place. When the box is tilted away from a right angle, however, the pistons reciprocate and the liquid is pumped.

The variable-stroke axial-piston pump (*Figure 10-14*) is often used as a part of a variable speed gear such as electrohydraulic anchor windlasses, cranes, winches, and the power-transmitting unit in electrohydraulic steering engines. In those cases, the tilting box is so arranged that it may be tilted in either direction. Thus it may be used to transmit power hydraulically to pistons or rams, or it may be used to drive a hydraulic motor. In the latter use, the pump is driven by a constant-speed electric motor and is called the A-end of the variable speed gear. The hydraulic motor is called the B-end.

The B-end unit of the hydraulic speed gear is exactly the same as the A-end of the variable-stroke pump mentioned previously. However, it generally does not have a variable-stroke feature. The tilting box is installed at a permanently fixed angle. Thus, the B-end becomes a fixed-stroke axial-piston pump. *Figure 10-14* illustrates an axial-piston hydraulic gear with the A-end and B-end as a single unit. It is used in turrets for train and elevation driving units. For electrohydraulic winches and cranes, the A-end and B-end are in separate housings connected by hydraulic piping.




Figure 10-14 — Axial-piston pump.

Hydraulic fluid introduced under pressure to a cylinder causes the piston to be pushed out. In being pushed out, the piston, through its connecting rod, will seek the point of greatest distance between the cylinder barrel and the socket ring. The resultant pressure of the piston against the socket ring will cause the cylinder barrel and the socket ring to rotate. This action occurs during the half revolution

while the piston is passing the intake port of the motor, which is connected to the pressure port of the pump. After the piston of the motor has taken all the hydraulic fluid it can from the pump, the piston passes the valve plate land and starts to discharge oil through the outlet ports of the motor to the suction inlet of the pump, and thence to suction pistons of the pump. The pump is constantly putting pressure on one side of the motor while it is constantly receiving hydraulic fluid from the other side. The fluid is merely circulated from pump to motor and back again.

#### **TURBINES**

Turbines are used in pneumatic systems to convert kinetic energy of gases to mechanical energy. Turbines are used to drive electric generators, convert mechanical energy into electrical energy, and drive pumps to supply fluid flow in hydraulic systems.

The basic parts of a turbine are the rotor, which has blades projecting radially from its periphery; and nozzles, through which the gas is expanded and directed. The conversion of kinetic energy to mechanical energy occurs on the blades.

The basic distinction between types of turbines is the manner in which the gas causes the turbine rotor to move. When the rotor is moved by a direct push or impulse from the gas impinging upon the blades, the turbine is said to be an impulse turbine. When the rotor is moved by force of reaction, the turbine is said to be a reaction turbine.

Although the distinction between impulse turbines and reaction turbines is a useful one, it should not be considered as an absolute distinction in real turbines. An impulse turbine uses both the impulse of the gas jet and, to a lesser extent, the reactive force that results when the curved blades cause the gas to change direction. A reaction turbine is moved primarily by reactive force, but some motion of the rotor is caused by the impact of the gas against the blades.

# **Impulse Turbine**

The impulse turbine consists essentially of a rotor mounted on a shaft that is free to rotate in a set of bearings. The outer rim of the rotor carries a set of curved blades, and the whole assembly is enclosed in an airtight case. Nozzles direct the rapidly moving fluid against the blades and turn the rotor.

The steam in an impulse turbine (1) passes through stationary nozzles, which (2) converts some of the thermal energy contained in the steam (indicated by its pressure and temperature) into kinetic energy (velocity), and (3) directs the steam flow into the blades of the turbine wheel (*Figure 10-15*). The blades and moving wheel (4) then convert the kinetic energy of the steam into mechanical energy in the form of the actual movement of the turbine wheel and shaft or rotor. Let us see why an impulse turbine uses a certain amount of reactive force as opposed to operating purely on the principle of impulse.




Figure 10-15 — Impulse turbine.

#### **Reaction Turbine**

The reaction turbine, as the name implies, is turned by reactive force rather than by a direct push or impulse. In reaction turbines, there are no nozzles as such. Instead, the blades that project radially from the periphery of the rotor are formed and mounted so that the spaces between the blades have, in cross section, the shape of nozzles. Since these blades are mounted on the revolving rotor, they are called moving blades.

In a reaction turbine, steam passes through a row of fixed blades that act as nozzles and expand the steam (decrease pressure). This action increases the steam's velocity and directs it into the moving blades, which are almost identical in shape to the fixed blades (*Figure 10-16*). Until the steam flows into the moving blades, it is only an impulse turbine. However, the moving blades act as nozzles. More thermal energy of the steam will be converted into kinetic energy, and the steam will counteract or kick back onto the moving blades, giving them—and the wheel to which they are attached—more energy. This conversion is the reason there is a drop (*Figure 10-16*) in both pressure and velocity across the moving blades of the reaction turbine as opposed to a drop in velocity alone in the impulse turbine. The additional pressure drop across the moving blades provides additional energy (reaction principle) that can be put to work. Consider the principles of both the impulse turbine and the reaction turbine we have described. By changing the direction of the steam flow in the impulse turbine blades, an additional amount of energy is gained (reaction principle).

# **CHAPTER 11**

# **PNEUMATICS**

The word pneumatics is a derivative of the Greek word pneuma, which means air, wind, or breath. It can be defined as that branch of engineering science that pertains to gaseous pressure and flow. As used in this manual, pneumatics is the portion of fluid power in which compressed air, or other gas, is used to transmit and control power to actuating mechanisms.

This chapter discusses the basic principles of pneumatics. It discusses the characteristics of gases and compares them with those of liquids. It explains factors which affect the properties of gases, identifies and explains the gas laws, and identifies gases commonly used in pneumatics and their pressure ranges. It also discusses hazards of pneumatic gases, methods of controlling contamination, and safety precautions associated with compressed gases.

#### **LEARNING OBJECTIVES**

When you have completed this chapter, you will be able to do the following:

- 1. Recognize the pressure characteristics of gases and liquids.
- 2. Recognize the common temperature scales.
- 3. Recognize various theories, laws, and properties of gases.
- 4. Recognize characteristics of gases used in pneumatic systems.
- 5. Recognize the color codes of compressed gas cylinders.
- 6. Identify safety precautions for handling compressed gas.

# **CHARACTERISTICS OF GASES**

Gas is one of the three states of matter. It has characteristics similar to those of liquids in that it has no definite shape but conforms to the shape of its container and readily transmits pressure.

Gases differ from liquids in that they have no definite volume. That is, regardless of the size or shape of the containing vessel, a gas will completely fill it. Gases are highly compressible, while liquids are only slightly so. Also, gases are lighter than equal volumes of liquids, making gases less dense than liquids.

# **Density**

Density, as defined in chapter 2, is the weight per unit volume of a substance. Since gases do not have a specific volume, the gas depends on the size of the container holding it to calculate the volume. The number of molecules and the weight of the molecules from the periodic table are calculated for the weight of the gas. To calculate the density of the gas, the weight of the gas is divided by the volume of the gas. The formula for density will be discussed later in the chapter.

# **Temperature and Pressure Relationship**

Early experiments were conducted concerning the behavior of air and similar gases. These experiments were conducted by scientists such as Boyle and Charles. Italian scientist, Amedeo Avogadro, discovered a relationship between pressure, temperature, volume, and the amount of gas in a specified container.

The results of their experiments indicated that the gases' behavior follows the law known as the ideal-gas law. It states as follows: For a given weight of any gas, the product of the absolute pressure and the volume occupied, divided by the absolute temperature, is constant. In the equation form, it is expressed as follows:

**Equation 11-1**: 
$$\frac{P_{1}v_{1}}{T_{1}} = \frac{P_{2}v_{2}}{T_{2}} = \frac{P^{V}}{T} = R$$
 (a constant),

also,

Equation 11-2: PV = nRT,

Where:

P = absolute pressure

V = total volume

n = amount of gas (number of molecules)

T = absolute temperature

R = gas constant

The specific volume (v) is expressed in cubic feet per pound.

For any weight of a gas this equation maybe modified as follows:

W = weight of the gas in pounds,

V = volume of W pounds of the gas in cubic feet.

The volume of 1 pound would then be V/W. If we substitute V/W for v in equation 11-2, it then becomes

Equation 11-3: 
$$P\frac{V}{W} = RT$$
 or  $PV = WRT$ .

Solving equation 11-4 for pressure,

Equation 11-4: 
$$P = \frac{WRT}{V}$$

In equation 11-4,  $\frac{W}{V}$  represents density. (Notice that this equation is the reverse of the specific volume.) We can now say that pressure is equal to the density of the gas times the gas constant times the absolute temperature of the gas. The gas constant varies for different gases. From this equation we can show how density varies with changes in pressure and temperature. Decreasing the volume, with the weight of the gas and the temperature held constant, causes the pressure to increase.

#### NOTE

During the compression of the gas, the temperature will actually increase; however, the explanation for this is beyond the scope of this text.

Also, since density equals

 $\frac{W}{}$ 

 $\overline{V}$ ,

a decrease in volume with the weight held constant will cause density to increase.

# **Temperature**

As indicated previously, temperature is a dominant factor affecting the physical properties of gases. It is of particular concern in calculating changes in the states of gases.

Three temperature scales are used extensively in gas calculations. They are the Celsius (C), the Fahrenheit (F), and the Kelvin (K) scales. The Celsius (or centigrade) scale is constructed by identifying the freezing and boiling points of water, under standard conditions, as fixed points of 0 and 100 degrees, respectively, with 100 equal divisions between. The Fahrenheit scale identifies 32 degrees as the freezing point of water and 212 degrees as the boiling point, and has 180 equal divisions between. The Kelvin scale has its zero point equal to -273 °C, or -460 °F.

Absolute zero, one of the fundamental constants of physics, is commonly used in the study of gases. It is usually expressed in terms of the Celsius scale. If the heat energy of a gas sample could be progressively reduced, some temperature should be reached at which the motion of the molecules would cease entirely. If accurately determined, this temperature could then be taken as a natural reference, or as a true absolute zero value.

Experiments with hydrogen indicated that if a gas were cooled to -273.16 °C (-273 °C for most calculations), all molecular motion would cease and no additional heat could be extracted. Since this is the coldest temperature to which an ideal gas can be cooled, it is considered to be absolute zero. Absolute zero may be expressed as 0 °K, -273 °C, or -459.69 °F (-460 °F for most calculations).

When you work with temperatures, always be sure which system of measurement is being used and how to convert from one to another. The conversion formulas are shown in *Figure 11-1*. For purposes of calculations, the Rankine (R) scale illustrated in *Figure 11-1* is commonly used to convert Fahrenheit to absolute temperature. For Fahrenheit readings above zero, 460 degrees is added. Thus, 72 °F equals 460 degrees plus 72 degrees, or 532 degrees absolute (532 °R). If the Fahrenheit reading is below zero, it is subtracted from 460 degrees. Thus, -40 °F equals 460 degrees minus 40 degrees, or 420 degrees absolute (420 °R).




Figure 11-1 — Comparison of Kelvin, Celsius, Fahrenheit, and Rankine temperature.

The Kelvin and Celsius scales are used internationally in scientific measurements; therefore, some technical manuals may use these scales in directions and operating instructions. The Fahrenheit scale is commonly used in the United States; therefore, it is used in most areas of this manual.

#### **Pressure**

We defined pressure in chapter 2 as force per unit area. Remember, liquids exert pressure on all surfaces with which they come in contact. Gases, because of their ability to completely fill containers, exert pressure on all sides of a container.

In practice, we may be interested in either of two pressure readings. We may desire either the gauge pressure or the absolute pressure.

Absolute pressure is measured relative to the absolute zero pressure - the pressure that would occur at absolute vacuum. All calculation involving the gas laws requires pressure (and temperature) to be in absolute units. Gauge Pressure is often called the gauge pressure (a gauge is often used to measure the pressure difference between a system and the surrounding atmosphere). Therefore Gauge Pressure is measured from atmospheric, and absolute is measured from 0 (as all absolute scales are measured from). They both use the same scale for measuring. Standard atmosphere at sea level is 14.7 pounds per square inch of pressure absolute and 0 pressure gauge. If you have 100 pounds per square inch (psi) gauge pressure, you have 14.7 + 100 psi absolute. Atmospheric Pressure is pressure in the surrounding air at - or "close" to - the surface of the earth. The atmospheric pressure varies with temperature and altitude above sea level.

#### **COMPRESSIBILITY AND EXPANSION OF GASES**

Gases can be readily compressed and are assumed to be perfectly elastic. This combination of properties gives a gas the ability to yield to a force and return promptly to its original condition when the force is removed. These are the properties of air that are used in pneumatic tires, tennis balls, and other deformable objects whose shapes are maintained by compressed air.

#### KINETIC THEORY OF GASES

In an attempt to explain the compressibility of gases, Bernoulli proposed the hypothesis that is accepted as the kinetic theory of gases. According to this theory, the pressure exerted by a gas on the walls of a closed container is caused by continual bombardment of the walls by molecules of the gas.

Consider the container shown in *Figure 11-2* as containing a gas. At any given time, some molecules are moving in one direction, some are traveling in other directions; some are traveling fast, some slow, and some may even be in a state of rest. The average effect of the molecules bombarding each container wall corresponds to the pressure of the gas.

As more gas is pumped into the container, more molecules are available to bombard the walls; thus the pressure in the container increases.

The gas pressure in a container can also be increased by increasing the speed with which the




Figure 11-2 — Molecular bombardment creating pressure.

molecules hit the walls. If the temperature of the gas is raised, the molecules move faster, causing an increase in pressure. This pressure increase can be shown by considering the automobile tire. When you take a long drive on a hot day, the pressure in the tires increases and a tire which appeared to be somewhat "soft" in the cool morning temperature may appear normal at a higher midday temperature.

#### **BOYLE'S LAW**

When the automobile tire is initially inflated, air that normally occupies a specific volume is compressed into a smaller volume inside the tire. This increases the pressure on the inside of the tire.

Charles Boyle, an English scientist, was among the first to experiment with the pressure-volume relationship of gas. During an experiment, when he compressed a volume of air he found that the volume decreased as the pressure increased, and by doubling the force exerted on the air he could decrease the volume of the air by half (Figure 11-3). Recall from the example of the automobile tire that changes in temperature of a gas also change the pressure and volume. Therefore, the experiment must be performed at a constant temperature. The relationship between pressure and volume is known as Boyle's law. It states: When the temperature of a gas is kept constant. the volume of an enclosed gas varies inversely with its pressure.

In equation form, this relationship may be expressed as

Equation 11-5:  $V_1P_1 = V_2P_2$ 

Where:




Figure 11-3 — Gas compressed to half its original size by a doubled force.

 $V_1$  and  $P_1$  are the initial volume and pressure, and  $V_2$  and  $P_2$  are the final volume and pressure ( $P_1$  and  $P_2$  are absolute pressures).

Example of Boyle's law: 4 cubic feet of nitrogen are under a pressure of 100 psi (gauge). The nitrogen is allowed to expand to a volume of 6 cubic feet. What is the new gauge pressure? Remember to convert gauge pressure to absolute pressure by adding 14.7.

Using equation 11-6,  $V_1P_1 = V_2P_2$ , where  $V_1$  is 4 ft 3,  $V_2$  is 6 ft, and  $P_1$  is 100 psig:

Solution:

$$V_1P_1=V_2P_2$$

$$P_2 = \frac{V_1 P_1}{V_2}$$

Substituting:

$$P_2 = \frac{4(100 + 14.7)}{6}$$

Converting absolute pressure to gauge pressure:

76.47 -14.761.77 psig

#### **CHARLES'S LAW**

Boyle's law assumes conditions of constant temperature. In actual situations this constant temperature is rarely the case. Temperature changes continually and affects the volume of a given mass of gas.

Jacques Charles, a French physicist, provided much of the foundation for the modern kinetic theory of gases. Through experiments, he found that all gases expand and contract proportionally to the change in the absolute temperature, providing the pressure remains constant. The relationship between volume and temperature is known as Charles's law. It states: The volume of a gas is proportional to its absolute temperature, if constant pressure is maintained. In equation form, this relationship may be expressed as

Equation 11-6: 
$$\frac{V_1}{V_2} = \frac{T_1}{T_2}$$

Where  $V_1$  and  $V_2$  are the original and final volumes, and  $T_1$  and  $T_2$  are the original and final absolute temperatures.

Since an increase in the temperature of a gas causes it to expand if the pressure is kept constant, it is reasonable to expect that if a given sample is heated within a closed container and its volume remains constant, the pressure of the gas will increase. Experiments have proven this expectation to be true. In equation form, this becomes

Equation 11-7: 
$$P_1T_1 = P_2T_2$$

or

$$\frac{P_1}{P_2} = \frac{T_1}{T_2}$$

This equation states that for a constant volume, the absolute pressure of a gas varies directly with the absolute temperature.

Example: A cylinder of gas under a pressure of 1,800 psig at 70 °F is left out in the sun in the tropics and heats up to a temperature of 130 °F. What is the new pressure within the cylinder? (Remember that both pressure and temperature must be converted to absolute pressure and absolute temperature.)

Using equation 11-8,  $P_1T_1 = P_2T_2$ , when  $P_1$  is 1,800 psig,  $T_1$  is 70 °F, and  $T_2$  is 130 °F:

Solution:

$$P_1T_1 = P_2T_2; P_2 = \frac{P_1 T_2}{T_1}$$

Substituting:

$$P_2 = \frac{(1,800 + 14.7 \, x \, (130^\circ + 460^\circ))}{70^\circ + 460^\circ}$$

$$=\frac{1,814.7 \times 590}{530}$$

$$P_2 = 2,020$$
 psia

Converting absolute pressure to gauge pressure:

 $\frac{2020.0}{-14.7}$  psig

#### **GENERAL GAS LAW**

We have learned that Boyle's law pertains to situations in which the temperature remains constant (*Figure 11-4*), and that Charles's law pertains to situations in which pressure remains constant (*Figure 11-4*). It is usually not possible to control pressure or temperature in tanks or bottles of gas subject to the weather and shipboard demands. Boyle's and Charles's laws are combined to form the general gas law. This law states: The product of the initial pressure, initial volume, and new temperature (absolute scale) of an enclosed gas is equal to the product of the new pressure, new volume, and initial temperature. It is a mathematical statement that allows many gas problems to be solved by using the principles of Boyle's law and/or Charles's law. The equation is expressed as

Equation 11-8:  $P_1V_1T_2 = P_2V_2T_1$ 

or

$$\frac{P_1 V_1}{T_1} = \frac{P_2 V_2}{T_2}$$

(*P* and *T* represent absolute pressure and absolute temperature, respectively.)

You can see by examining *Figure 11-4* that the three equations are special cases of the general equation. Thus, if the temperature remains constant, *T*1 equals *T*2 and both can be eliminated from the general formula, which then reduces to the form shown *Figure 11-4*, *view A*. When the volume remains constant, *V*1 equals *V*2, thereby reducing the general equation to the form given shown *Figure 11-4*, *view B*. Similarly, *P*1 is equated to *P*2 for constant pressure, and the equation then takes the form given shown *Figure 11-4*, *view C*.




Figure 11-4 — The general gas law.

The general gas law applies with exactness only to "ideal" gases in which the molecules are assumed to be perfectly elastic. However, it describes the behavior of actual gases with sufficient accuracy for most practical purposes.

Two examples of the general equation follow:

1. Two cubic feet of a gas at 75 psig and 80 °F are compressed to a volume of 1 cubic foot and then heated to a temperature of 300 °F. What is the new gauge pressure?

Using equation 11-9,  $P_1V_1T_2 = P_2V_2T_1$ , where  $V_1$  is 2 ft<sup>3</sup>,  $P_1$  is 75 psig,  $T_1$  is 80 °F,  $V_2$  is 1 ft<sup>3</sup>, and  $T_2$  is 300 °F:

Solution:

$$P_1V_1T_2 = P_2V_2T_1$$

or

$$P_2 = \frac{P_1 \, V_1 \, T_2}{V_2 \, T_1}$$

Substituting:

$$P2 = \frac{(75 + 14.7)(2)(300 + 460)}{(1)(80 + 460)}$$

$$=\frac{(89.7)(2)(760)}{(1)(540)}$$

$$=\frac{(179.4)(760)}{(540)}$$

$$P_2 = 252.5$$
 psia

Converting absolute pressure to gauge pressure:

$$\frac{252.5}{-14.7}$$
 psig

2. Four cubic feet of a gas at 75 psig and 80 °F are compressed to 237.8 psig and heated to a temperature of 300 °F. What is the volume of the gas resulting from these changes? Using equation 11-9,  $P_1V_1T_2 = P_2V_2T_1$ , where  $V_1$  is 4 ft<sup>3</sup>,  $P_2$  is 75 psig,  $T_1$  is 800,  $P_1$  is 237.8 psig, and  $T_2$  is 300 °F:

Solution:

$$P_1V_1T_2 = P_2V_2T_1$$

or

$$V_2 = \frac{P_1 \ V_1 \ T_2}{P_2 \ T_1}$$

Substituting:

$$V_2 = \frac{(75 + 14.7)(4)(300 + 460)}{(237.8 + 14.7)(80 + 460)}$$

$$=\frac{(89.7)(4)(760)}{(252.5)(540)}$$

 $V_2 = 2$  cubic feet

#### **PNEUMATIC GASES**

Many factors are considered in determining whether to use hydraulics or pneumatics as a power source in a fluid power system. Once it is determined that pneumatics will be used as the source of power, some of the same factors are considered in selecting the pneumatic gas.

#### **Qualities**

The ideal fluid medium for a pneumatic system is a readily available gas that is nonpoisonous (nontoxic), chemically stable, free from any acids that cause corrosion of system components, and nonflammable. It also will not support combustion of other elements.

Gases that have these desired qualities may not have the required lubricating power. Therefore, lubrication of the components of some pneumatic systems must be arranged by other means. For example, some air compressors are provided with a lubricating system, some components are lubricated upon installation, or, in some cases, lubrication is introduced into the air supply line.

Two gases meeting these qualities and most commonly used in pneumatic systems are compressed air and nitrogen.

# **Compressed Air**

Compressed air is a mixture of all gases contained in the atmosphere. In this manual, compressed air is referred to as a gas when it is used as a fluid medium.

The unlimited supply of air and the ease of compression make compressed air the most widely used fluid for pneumatic systems. Although moisture and solid particles must be removed from the air, it does not require the extensive distillation or separation process required in the production of other gases.

Compressed air has most of the desired properties and characteristics of a gas for pneumatic systems. It is nonpoisonous and nonflammable but does contain oxygen, which supports combustion. One of the most undesirable qualities of compressed air as a fluid medium for pneumatic systems is moisture content. The atmosphere contains varying amounts of moisture in vapor form. Changes in the temperature of compressed air will cause condensation of moisture in the pneumatic system. This condensed moisture can be very harmful to the system, as it increases corrosion, dilutes lubricants, and may freeze in lines and components during cold weather. Moisture separators and air driers (dehydrators) are installed in the compressed air lines to minimize or eliminate moisture in systems where moisture would deteriorate system performance.

The supply of compressed air at the required volume and pressure is provided by an air compressor. In most systems, the compressor is part of the system with distribution lines leading from the compressor to the devices to be operated. In these systems, a receiver is installed in-line between the compressor and the device to be operated to help eliminate pulsations in the compressor

discharge line, to act as a storage tank during intervals when the demand for air exceeds the compressor's capacity, and to enable the compressor to shut down during periods of light load. Other systems receive their supply from cylinders, which must be filled at a centrally located air compressor and then connected to the system.

Compressed air systems are categorized by their operating pressures as follows: high-pressure (HP) air, medium-pressure (MP) air, and low-pressure (LP) air.

## **High-Pressure (HP) Air Systems**

HP air systems provide compressed air at a nominal operating pressure of 3,000 psi or 5,000 psi and are installed whenever pressure in excess of 1,000 psi is required. HP compressed air plants support functions that require high pressures and high flow rates of compressed air by the addition of HP storage flasks to the system. An example of such a system is one that provides air for starting diesel and gas turbine engines. Reduction in pressure, if required, is done by using specially designed pressure-reducing stations.

## Medium-Pressure (MP) Air Systems

MP air systems provide compressed air at a nominal operating pressure of 151 psi to 1,000 psi. These pressures are provided either by an MP air compressor or by the HP air system supplying air through an air bank and pressure-reducing stations.

## Low-Pressure (LP) Air Systems

LP air systems provide compressed air at a nominal operating pressure of 150 psi and below. The LP air system is supplied with LP air by LP air compressors or by the HP air system supplying air through an air bank and pressure-reducing stations. LP air is the most extensive and varied air system used in the Navy.

In addition to being used for various pneumatic applications, LP and HP compressed air are used in the production of nitrogen.

# Nitrogen

For all practical purposes, nitrogen is considered to be an inert gas. It is nonflammable, does not form explosive mixtures with air or oxygen, and does not cause rust or decay. Due to these qualities, its use is preferred over compressed air in many pneumatic systems, especially aircraft and missile systems, and wherever an inert gas blanket is required.

Nitrogen is obtained by the fractional distillation of air. Oxygen/nitrogen-producing plants expand compressed air until its temperature decreases to -196 °C (-320 °F), the boiling point of nitrogen at atmospheric pressure. The liquid nitrogen is then directed to a storage tank. A liquid nitrogen pump pumps the low-pressure liquid nitrogen from the storage tank and discharges it as a high-pressure (5,000 psi) liquid to the vaporizer where it is converted to a gas at 5,000 psi. Oxygen/nitrogen-producing plants are located at many naval installations and on submarine tenders and aircraft carriers.

# **CONTAMINATION CONTROL**

As in hydraulic systems, fluid contamination is also a leading cause of malfunctions in pneumatic systems. In addition to the solid particles of foreign matter that find a way to enter the system, there is also the problem of moisture. Most systems are equipped with one or more devices to remove this contamination. These include filters, water separators, air dehydrators, and chemical driers. In addition, most systems contain drain valves at critical low points in the system. These valves are

opened periodically to allow the escaping gas to purge a large percentage of the contaminants, both solids and moisture, from the system. In some systems these valves are opened and closed automatically, while in others they must be operated manually.

Complete purging is done by removing lines from various components throughout the system and then attempting to pressurize the system, causing a high rate of airflow through the system. The airflow will cause the foreign matter to be dislodged and blown from the system.

#### **NOTE**

If an excessive amount of foreign matter, particularly oil, is blown from any one system, the lines and components should be removed and cleaned or replaced.

In addition to monitoring the devices installed to remove contamination, it is your responsibility as a maintenance person or supervisor to control the contamination. You can control contamination by using the following maintenance practices:

- 1. Keep all tools and the work area in a clean, dirt-free condition.
- 2. Cap or plug all lines and fittings immediately after disconnecting them.
- 3. Replace all packing and gaskets during assembly procedures.
- 4. Connect all parts with care to avoid stripping metal slivers from threaded areas. Install and torque all fittings and lines according to applicable technical instructions.
- 5. Complete preventive maintenance as specified by maintenance requirements cards (MRCs).

Also, you must take care to ensure that the proper cylinders are connected to systems being supplied from cylinders.

Cylinders for compressed air are painted black. Cylinders containing oil-pumped air have two green stripes painted around the top of the cylinder, while cylinders containing water-pumped air have one green stripe. Oil-pumped air indicates that the air or nitrogen is compressed by an oil-lubricated compressor. Air or nitrogen compressed by a water-lubricated (or non-lubricated) compressor is referred to as water pumped. Oil-pumped nitrogen can be very dangerous in certain situations. For example, nitrogen is commonly used to purge oxygen systems. Oxygen will not burn, but it supports and accelerates combustion and will cause oil to burn easily and with great intensity. Therefore, oil-pumped nitrogen must never be used to purge oxygen systems. When the small amount of oil remaining in the nitrogen comes in contact with the oxygen, an explosion may result. In all situations, use only the gas specified by the manufacturer or recommended by the Navy. Nitrogen cylinders are painted gray. One black stripe identifies cylinders for oil-pumped nitrogen, and two black stripes identify cylinders for water-pumped nitrogen. In addition to these color codes, the exact identification of the contents is printed in two locations diametrically opposite one another along the longitudinal axis of the cylinder. For compressed air and nitrogen cylinders, the lettering is white.

## POTENTIAL HAZARDS

All compressed gases are hazardous. Compressed air and nitrogen are neither poisonous nor flammable, but should not be handled carelessly. Some pneumatic systems operate at pressures exceeding 3,000 psi. Lines and fittings have exploded, injuring personnel and property. Literally thousands of careless workers have blown dust or harmful particles into their eyes by the careless handling of compressed air outlets.

Nitrogen gas will not support life, and when it is released in a confined space, it will cause asphyxia (the loss of consciousness as a result of too little oxygen and too much carbon dioxide in the blood). Although compressed air and nitrogen seem so safe in comparison with other gases, do not let overconfidence lead to personal injury.

#### SAFETY PRECAUTIONS

To minimize personal injury and equipment damage when using compressed gases, observe all practical operating safety precautions, including the following:

- 1. Do not use compressed air to clean parts of your body or clothing, or to perform general space cleanup in lieu of vacuuming or sweeping.
- 2. Never attempt to stop or repair a leak while the leaking portion is still under pressure. Always isolate, repressurize, and danger tag out the portion of the system to be repaired. For pressures of 1,000 psi or greater, double valve protection is required to prevent injury if one of the valves should fail.
- 3. Avoid the application of heat to the air piping system or components, and avoid striking a sharp or heavy blow on any pressurized part of the piping system.
- 4. Avoid rapid operation of manual valves. The heat of compression caused by a sudden high-pressure flow into an empty line or vessel can cause an explosion if oil is present. Valves should be slowly cracked open until airflow is noted and should be kept in this position until pressures on both sides of the valve have equalized. The rate of pressure rise should be kept under 200 psi per second, if possible. Valves may then be opened fully.
- 5. Do not discharge large quantities of nitrogen into closed compartments unless adequate ventilation is provided.
- 6. Do not subject compressed gas cylinders to temperatures greater than 130 °F.

Remember, any pressurized system can be hazardous to your health if it is not maintained and operated carefully and safely.

## **CHAPTER 12**

## **BASIC DIAGRAMS AND SYSTEMS**

In the preceding chapters, you learned about hydraulic and pneumatic fluids and components of fluid power systems. While having knowledge of system components is essential, it is difficult to understand the interrelationships of these components by simply watching the system operate. The knowledge of system interrelation is required to effectively troubleshoot and maintain a fluid power system. Diagrams provided in applicable technical publications or drawings are a valuable aid in understanding the operation of the system and in diagnosing the causes of malfunctions.

This chapter explains the different types of diagrams used to illustrate fluid power circuits, including some of the symbols that depict fluid power components. Included in this chapter are descriptions and illustrations denoting the differences between open-center and closed-center fluid power systems. The last part of the chapter describes and illustrates some applications of basic fluid power systems.

### **LEARNING OBJECTIVES**

When you have completed this chapter, you will be able to do the following:

- 1. Recognize the importance of diagrams and symbols.
- 2. Identify symbols used in diagrams.
- 3. Identify the types of diagrams.
- 4. Recognize Navy applications and component functions of hydraulic power drive systems.
- 5. Recognize the construction features of hydraulic power drive systems.
- 6. Recognize the operating characteristics of hydraulic power drive systems.

#### **DIAGRAMS**

As mentioned in this chapter's introduction, to troubleshoot fluid power systems intelligently, a mechanic or technician must be familiar with the system on which he or she is working. The mechanic must know the function of each component in the system and have a mental picture of its location in relation to other components. The mental picture can be attained by studying the diagrams of the system.

A diagram may be defined as a graphic representation of an assembly or system that indicates the various parts and expresses the methods or principles of operations. The ability to read diagrams is a basic requirement for understanding the operation of fluid power systems. Understanding the diagrams of a system requires having knowledge of the symbols used in the schematic diagrams.

The standards and procedures prescribed for military drawings and blueprints are stated in military standards (MIL-STDs), military handbooks (MIL-HDBKs), American National Standards Institute (ANSI) standards, American Society of Mechanical Engineers (ASME), and the Institute of Electrical and Electronics Engineers (IEEE). The Acquisition Streamlining and Standardization Information System (ASSIST) Web site lists these standards. A list containing common standards, listed by number and title, that concern engineering drawings and blueprints are illustrated in *Table 12-1*.

Table 12-1 — Common Standards

Number	Title	
ASME Y14.100-2013	Engineering Drawing Practices	
ANSI Y14.5M-2009	Dimensioning and Tolerancing	
ANSI Y14.6-2001	Screw Thread Representation	
ASME B46.1-2009	Surface Texture (Surface Roughness, Waviness, and Lay)	
ASME Y14.38-2007	Abbreviations and Acronyms for Use on Drawings and Related Documents	
IEEE-315-1975	Graphic Symbols for Electrical and Electronic Diagrams (Including Reference Designation Letters)	
ANSI Y32.9	Electrical Wiring Symbols for Architectural and Electrical Layout Drawings	
ANSI Y32.16-1965	Electrical and Electronic Reference Designations	
ASTM F1000-13	Standard Practice for Piping Systems Drawing Symbols	
MIL-HDBK-21	Welded-Joint Designs, Armored-Tank Type	
MIL-STD-22D	Welded Joint Designs	
MIL-STD-25B	Ship Structural Symbols for Use on Ship Drawings	

### **Symbols**

The American Society for Testing and Materials (ASTM) Standard F1000-13 lists mechanical symbols used on piping prints other than those for aeronautical, aerospacecraft, and spacecraft. Many of these symbols are also listed in the Organizational, Intermediate and Depot Maintenance Aviation Hydraulics Manual, Naval Air Systems Command (NAVAIR) 01-1A-17. A few of the common plumbing and piping symbols from the ASTM Standard F1000-13 and the Symbols, Piping Systems, Naval Sea Systems Command (NAVSEA) Standard Drawing 803-5001049 are illustrated in *Figure* 12-1.

Notice that the symbols may show the type of connections (screwed, flanged, welded, and so forth) including fittings, valves, gauges, and items of the equipment. When an item is not covered in the standards, the responsible activity designs a suitable symbol and provides an explanation in a note.

When a print shows more than one piping system of the same kind, additional letters are added to the symbols to differentiate between the systems. Notice the letters on the drinking water supply and drinking water return lines in *Figure 12-1*.

Some rules applicable to graphical symbols for fluid diagrams are as follows:

- Symbols show connections, flow paths, and the function of the component represented only.
   They do not indicate conditions occurring during transition from one flow path to another, nor do they indicate component construction or values, such as pressure or flow rate
- Symbols do not indicate the location of ports, direction of shifting of spools, or position of control elements on actual components
- Symbols may be rotated or reversed without altering their meaning except in cases of lines to reservoirs and vented manifolds
- Symbols may be drawn in any size
- Each symbol is drawn to show the normal or neutral condition of each component unless multiple circuit diagrams are furnished showing various phases of circuit operation

For more detailed information concerning the symbols used in fluid power diagrams, consult the above-mentioned military standards.

<u>Plumbing</u>		Piping		
Corner Bath	0	Soil and Waste —	_	_
Recessed Bath		Soil and Waste, Underground		-
Roll Rim Bath		Vent		
Sitz Bath	$\overline{}$	Cold Water		
Floor Bath	<u>-</u>	Hot Water		
Bidet	<u></u>	Hot Water Return		
Shower Stall	<u>되</u>	Gas	_	-
Shower Head —		Acid Waste	-	
Overhead Gang Shower(Plan)	~	Drinking Water Supply —		
Pedestal Lavatory	21	Drinking Water Return —		<u> </u>
Wall Lavatory	1	Vacuum Cleaning		-V <i>-</i>
w	/L	Compressed Air	A_	_
Medical Lavatory Medical Lavatory	_	<u>Pipe Fittings</u>		Soldered
Pontal Lavatory		Joint		$\leftarrow$
Dental Lavatory	AL LAV	Elbow - 90	- f ,	7
Plain Kitchen Sink	•	Elbow - 45	- <b>f</b>	f
Kitchen Sink, R & L Drain Board	Ē	Elbow - Turned Up	- O <del>L</del>	<b>⊙</b> ⊢
Combination Sink and Dishwasher	□○	Elbow - Turned Down	- 0-	O)-
Combination Sink & Laundry Tray		Elbow Long Radius	- <del>/</del>	0,
	G T	Side Outlet Elbow-	LR	46
Wash Sink (Wall Type) نو	SS	Outlet Down	¥'.	`¥
Wash Sink		Side outlet Elbow -	- 4	7
Laundry Tray		Outlet Up Base Elbow		<u> </u>
	_	Double Branch Elbow	<u> </u>	"
Water Closet (Low Tank)	_	Single Sweep Tee		
Water Closet (No Tank)	R		2	
Urinal (Pedestal Type) — (		Reducing Elbow		
Urinal (Wall Type)	7	Tee	· + <del>†</del> +	<del>, †</del>
Urinal (Corner Type)		Tee - Outlet UP		<del>&gt;</del> <b>⊙</b> ←
Urinal (Stall Type)	$\frown$	Tee - Outlet Down	<del>-101-</del>	<del>))(</del>
Drinking Fountain (Pedestal Type)	<u></u>	Side Outlet Tee - Outlet Up	4	*
	DF	Side Outlet Tee -	. •	↓ ↓
31 a/	DF	Outlet Down		<del>)</del>
Drinking Fountain (Trough Type)	DF	Cross	- +‡+	**
	HW T	Reducer	- <del>- &gt;-</del>	<del>-&gt;&gt;</del>
Water Heater	WH	Lateral	- <b>*</b>	tx
Meter ———————————————————————————————————	D⊣ w	Expansion Joint Flanged	+ - <del>- = -</del>	<b>↑</b>
Hose Bibb		Valves	Screwed	Soldered
	T	Gate Valve	>>	<b>→</b>
Vacuum Outlet	G V	Globe Valve ————————————————————————————————————		→-
		Angle Glove Valve ——————		
		Angle Gate Valve	- ፟ቑ	
Carrana Brain		Check Valve		→
_	₽\₽ Э	Angle Check Valve	- 4	7
	٧	Safety Valve		- ->≪-
	$\cup$	Motor Operated Gate Valve		

Figure 12-1 — Common plumbing and piping symbols.

## **Color Coding for Safety**

Color warnings mark physical hazards, indicate the location of safety equipment, and identify fire and other protective equipment.

The MIL-STD-101 establishes the color code used to identify piping carrying hazardous fluids. It applies to all piping installations in naval industrial plants and shore stations where color coding is used.

Five classes of materials have been selected to represent the general hazards for all dangerous materials, while a sixth class has been reserved for fire protection materials. A standard color represents each of these classes, as shown in *Table 12-2*. In some instances, piping systems that do not require warning colors may be painted to match surroundings; in other instances, such systems may be painted aluminum or black or remain unpainted.

Table 12-2 — Warning Colors

Class	Standard Color	Identification Marking	Class of Material
A	Yellow	FLAM	FLAMMABLE MATERIALS. All materials known ordinarily as flammables or combustibles. Of the chromatic colors, yellow has the highest coefficient of reflection under white light and can be recognized under the poorest conditions of illumination.
В	Brown	TOXIC	TOXIC AND POISONOUS MATERIALS. All materials extremely hazardous to life or health under normal conditions as toxics or poisons.
С	Blue	AAHM	ANESTHETICS AND HARMFUL MATERIALS. All materials productive of anesthetic vapors and all liquid chemicals and compounds hazardous to life and property but not normally productive of dangerous quantities of fumes or vapors.
D	Green	OXYM	<b>OXIDIZING MATERIALS</b> . All materials which readily furnish oxygen for combustion, and fire producers which react explosively or with the evolution of heat in contact with many other materials.
E	Gray	PHDAN	PHYSICALLY DANGEROUS MATERIALS. All materials not dangerous in themselves, but which are asphyxiating in confined areas or which are generally handled in a dangerous physical state of pressure or temperature.
F	Red	FPM	<b>FIRE PROTECTION MATERIALS</b> . Materials provided in piping systems or in compressed gas cylinders for use in fire protection.

### **TYPES OF DIAGRAMS**

There are many types of diagrams. Those that are most pertinent to fluid power systems are discussed in this section.

## **Pictorial Diagrams**

Pictorial diagrams (*Figure 12-2*) show the general location and actual appearance of each component, all interconnecting piping, and the general piping arrangement. This type of diagram is sometimes referred to as an installation diagram. Diagrams of this type are invaluable to maintenance personnel in identifying and locating components of a system.




Figure 12-2 — Hydraulic system pictorial diagram.

# **Cutaway Diagrams**

Cutaway diagrams (*Figure 12-3*) show the internal working parts of all fluid power components in a system. The diagrams include controls and actuating mechanisms and all interconnecting piping. Cutaway diagrams do not normally use symbols.





Figure 12-3 — Cutaway diagram—pneumatic.

## **Graphic Diagrams**

The primary purpose of a graphic (schematic) diagram is to enable the maintenance person to trace the flow of fluid from component to component within the system. This type of diagram uses standard symbols to show each component and includes all interconnecting piping. Additionally, the diagram contains a component list, pipe size, data on the sequence of operation, and other pertinent information. The graphic diagram (*Figure 12-4*) does not indicate the physical location of the various components, but it does show the relationship of each component to the other components within the system.



- 1. Rotary actuator
- 2. 11/4-inch shutoff valve
- 3. 0-5000 psi pressure snubber
- 4. 0-3000 psi pressure gauge
- 5. Manual 1-inch rotary Selector valve
- 6. Pressure control valve
- 7. Manifold block
- 8. 7-250 psi pressure switch
- 9. 1/4-inch solenoid-operated 4-way valve

- 10. 3/4-inch pilot-operated 4-way valve
- 11. None
- 12. Electric motor (see note)
- 13. 0-300 psi pressure gauge
- Servo-operated variabledisplacement
- 15. pump
- 16. 10-micron filter 1/2-inch manual rotary selector valve
- 17. Pressure control valve
- 18. 1/2-inch manual rotary selector valve

- 19. Common check valve with hand pump
- 20. 1/2-inch shutoff valve
- 21. 3/8-inch manual rotary selector valve
- 22. Hand pump
- 23. 10-micron filter
- 24. Shutoff valve
- 25. Lvr/lvp selector cylinder
- 26. Relief valves

Figure 12-4 — Typical schematic diagram.

#### FLUID POWER SYSTEMS

One type of system that is sometimes used in hydraulically operated equipment is the open-center system. An open-center system is one having fluid flow, but no pressure in the system when the actuating mechanisms are idle.

Another fluid power system used in hydraulically operated equipment is the closed-center system. In a closed-center system, the fluid in the system remains pressurized from the pump (or regulator) to the directional control valve while the pump is operating. In this type of system, any number of subsystems may be incorporated, with a separate directional control valve for each subsystem. The directional control valves are arranged in parallel so that system pressure acts equally on all control valves.

# **Open-Center System**

In an open-center system, the pump circulates the fluid from the reservoir, through the selector valves, and back to the reservoir (Figure 12-5, view A). The open-center system may employ any number of subsystems, with a selector valve for each subsystem. Unlike the closed-center system, the selector valves of the open-center system are always connected in series with each other. In this arrangement. the system pressure line goes through each selector valve. Fluid is always allowed free passage through each selector valve and back to the reservoir until one of the selector valves is positioned to operate a mechanism.

When one of the selector valves is positioned to operate an actuating device, fluid is directed from the pump through one of the working lines to the actuator (*Figure 12-5, view B*). With the selector valve in this position, the flow




Figure 12-5 — Basic open-center hydraulic system.

of fluid through the valve to the reservoir is blocked. The pressure builds up in the system to overcome the resistance and moves the piston of the actuating cylinder. The fluid from the opposite end of the actuator returns to the selector valve and flows back to the reservoir. Operation of the system following actuation of the component depends on the type of selector valve being used.

Several types of selector valves are used in conjunction with the open-center system. One type is both manually engaged and manually disengaged. First, the valve is manually moved to an operating position. Then, the actuating mechanism reaches the end of its operating cycle, and the pump output continues until the system relief valve relieves the pressure. The relief valve unseats and allows the fluid to flow back to the reservoir. The system pressure remains at the relief valve set pressure until the selector valve is manually returned to the neutral position. This action reopens the open-center flow and allows the system pressure to drop to line resistance pressure. The manually engaged and pressure disengaged type of selector valve is similar to the valve previously discussed. When the

actuating mechanism reaches the end of its cycle, the pressure continues to rise to a predetermined pressure. The valve automatically returns to the neutral position and to open-center flow.

## **Closed-Center System**

In the closed-center system, the fluid is under pressure whenever the power pump is operating. *Figure 12-6* shows a complex closed-center system. The power pump may be one used with a separate pressure regulator control. The power pump may also be used with an integral pressure control valve that eliminates the need for a pressure regulator. This system differs from the opencenter system in that the selector or directional control valves are arranged in parallel and not in series. The means of controlling pump pressure will vary in the closed-center system. If a constant delivery pump is used, the system pressure will be regulated by a pressure regulator. A relief valve acts as a backup safety device in case the regulator fails. If a variable displacement pump is used, system pressure is controlled by the pump's integral pressure mechanism compensator. The compensator automatically varies the volume output. When pressure approaches normal system pressure, the compensator begins to reduce the flow output of the pump. The pump is fully compensated (near zero flow) when normal system pressure is attained. When the pump is in this fully compensated condition, its internal bypass mechanism provides fluid circulation through the pump for cooling and lubrication. A relief valve is installed in the system as a safety backup.

An advantage of the open-center system over the closed-center system is that the continuous pressurization of the system is eliminated. Since the pressure is built up gradually after the selector valve is moved to an operating position, there is very little shock from pressure surges. This action provides a smoother operation of the actuating mechanisms. However, the operation is slower than the closed-center system, in which the pressure is available the moment the selector valve is positioned. Since most aircraft applications require instantaneous operation, closed-center systems are the most widely used.




Figure 12-6 — Closed-center hydraulic system schematic.

#### HYDRAULIC POWER DRIVE SYSTEM

The hydraulic power drive has been used in the Navy for many years. Proof of its effectiveness is that it has been used to train and elevate nearly all caliber guns, from the 40 mm gun mount to the 16-inch turret. In addition to gun mounts and turrets, hydraulic power drives are used to position rocket launchers and missile launchers, and to drive and control such equipment as windlasses, capstans, and winches.

In its simplest form, the hydraulic power drive consists of the following:

- The prime mover, which is the outside source of power used to drive the hydraulic pump
- A variable-displacement hydraulic pump
- A hydraulic motor
- A means of introducing a signal to the hydraulic pump to control its output
- Mechanical shafting and gearing that transmits the output of the hydraulic motor to the equipment being operated

Hydraulic power drives differ in some respects, such as size, method of control, and so forth. However, the fundamental operating principles are similar. The following paragraphs discuss the fundamental operating principles of a hydraulic power drive that is representative of those used to operate the 5-inch/54- caliber gun mount.

Figure 12-7 shows the basic components of the train power drive. The electric motor is constructed with drive shafts at both ends. The forward shaft drives the A-end pump through reduction gears, and the after shaft drives the auxiliary pumps through the auxiliary reduction gears. The reduction gears are installed because the pumps are designed to operate at a speed much slower than that of the motor

The replenishing pump is a spur gear pump. Its purpose is to replenish fluid to the active system of the power drive. It receives its supply of fluid from the reservoir and discharges it to the Bend valve plate. This discharge of fluid from the pump is held at a constant pressure by the action of a pressure relief valve. (Because the capacity of the pump exceeds replenishing demands, the relief valve is continuously allowing some of the fluid to flow back to the reservoir.)

The sump pump and oscillator unit has a twofold




Figure 12-7 — Train power drive components.

purpose. It pumps leakage, which collects in the sump of the indicator regulator, to the expansion tank. Additionally, it transmits a pulsating effect to the fluid in the response pressure system.

Oscillations in the hydraulic response system help eliminate static friction of valves, allowing hydraulic control to respond faster.

The control pressure pump supplies high-pressure fluid for the hydraulic control system, brake pistons, lock piston, and the hand-controlled clutch operating piston. The control pressure pump is a fixed-displacement, axial piston type. An adjustable relief valve is used to limit the operating pressure

at the outlet of the pump.

#### Control

For the purpose of this text, control constitutes the relationship between the stroke control shaft and the tilting box. The stroke control shaft is one of the piston rods of a double-acting piston-type actuating cylinder. This actuating cylinder and its direct means of control are referred to as the main cylinder assembly (*Figure 12-8*). It is the link between the hydraulic followup system and the power drive itself.

In hand control, the tilting box is mechanically positioned by gearing from the handwheel through the A-end control unit. In local and automatic control, the tilting box is positioned by the stroke control shaft. As shown in *Figure 12-8*, the extended end of the control shaft is connected to the tilting box. Movement of the shaft will pivot the tilting box one way or the other, which, in turn, controls the output of the A-end of the transmission. The other end of the shaft is attached to the main piston. A shorter shaft is




Figure 12-8 — Main cylinder assembly.

attached to the opposite side of the piston. This shaft is also smaller in diameter. Thus, the working area of the left side of the piston is twice that of the area of the right side, as it appears in *Figure 12-8*.

Intermediate high-pressure (IHP) fluid is transmitted to the left side of the piston, while the high-pressure control (HPC) system fluid is transmitted to the right side. The HPC is held constant at 1,000 pounds per square inch (psi). Since the area of the piston upon which HPC acts is exactly one-half the area upon which IHP acts, the main piston is maintained in a fixed position when IHP is one-half HPC (500 psi). Whenever IHP varies from its normal value of 500 psi, the main piston will move, thus moving the tilting box.

# Operation

Assume that a right train order signal is received. This signal will cause the pilot valve to be pulled upward. The fluid in the upper chamber of the amplifier piston can now flow through the lower land chamber of the fine pilot to exhaust. The fluid will cause the amplifier piston to move upward, and the fluid in the right-hand chamber of the main control valve can flow into the lower chamber of the amplifier valve.

The main control valve will now move to the right, IHP will drop below 500 psi, and the stroke piston will move to the left. Movement of the stroke piston will cause tilt to be put on the tilt plate, and the Aend will cause the mount to train right.

Figure 12-9 is a simplified block diagram showing the main element of the hydraulic power drive system under automatic control for clockwise and counterclockwise rotation.

There are two principal problems in positioning a gun to fire. One is to get an accurate gun-order signal. This problem is solved by the director-computer combination. The other problem is to transmit the director signal promptly to the gun so that the position and movements of the gun will be synchronized with the signals from the director.

The problem of transforming gun-order signals to mount movements is solved by the power drive and its control—the indicator regulator. The indicator regulator controls the power drive, which controls the movement of the gun.




Figure 12-9 — Operation of the hydraulic power drive.

The indicator regulator receives an initial electrical gun-order from the director-computer, compares it to the existing mount position, and sends an error signal to the hydraulic control mechanism in the regulator. The hydraulic control mechanism controls the flow to the stroke control shaft, which positions the tilting box in the A-end of the transmission. Its tilt controls the volume and direction of fluid pumped to the B-end and, therefore, the speed and direction of the drive shaft of the B-end. Through mechanical linkage, the B-end output shaft moves the gun in the direction determined by the signal. At the same time, B-end response is transmitted to the indicator regulator and is continuously combined with incoming gun-order signals to give the error between the two. This error is modified hydraulically, according to the system of mechanical linkages and valves in the regulator. When the gun is lagging behind the signal, its movement is accelerated; and when it begins to catch up, its movement is slowed down so that it will not overrun excessively.

# LANDING GEAR EMERGENCY SYSTEM

If the landing gear fails to extend to the down and locked position, each naval aircraft has an emergency method to extend the landing gear. Emergency extension systems may vary from one aircraft to another. The methods used may be the auxiliary/emergency hydraulic system, the air or nitrogen system, or the mechanical free-fall system. An aircraft may contain a combination of these systems. For example, the main landing gear and the nose gear emergency extension may be operated by the auxiliary/hydraulic system method.

The nitrogen storage bottle system is a one-shot system powered by nitrogen pressure stored in compressed nitrogen bottles (*Figure 12-10*). When the EMER LG PULL handle is disengaged from the LDG GEAR handle and moved aft to EMER DOWN, a crank linked to the handle is raised. The

raised crank pulls an actuating cable that operates a lever, opening the spring-loaded emergency release valve. When the release valve opens, nitrogen pressure goes from the CYL port to shuttle valves on the nose gear, main gear, main gear door, and tail skid actuating cylinders. Pressure also goes to the landing gear and tail skid dump valves.

Pneumatic pressure actuates the dump valves to the emergency position. The valves are held in position by a spring-loaded detent. In this position, the uplines between the dump valves and the respective selector valves are blocked off. All landing gear and tail skid system uplines are ported to the combined system reservoir through the respective dump valves. (With the selector valves bypassed, a malfunction in either selector valve cannot prevent emergency extension.) Hydraulic fluid on the up side of each actuating cylinder flows back to the reservoir and allows pneumatic pressure to enter the down side and extend the gear and the tail skid.

Pneumatic pressure applied to each shuttle valve shifts a spool over to block off the hydraulic port. Pressure enters the down port and extends the actuating cylinder, displacing hydraulic fluid on the up side back to the reservoir through the landing gear or tail skid dump valve. (The main gear doors and the main gear shock struts begin to lower at the same time since the hydraulic door timer check valves are bypassed during pneumatic operation; however, the doors open fast enough to clear the shock struts since the door cylinders have approximately one-half the stroke of the gear actuating cylinders.)

Once the emergency extension system has been used, the system must be reset before the gear and tail skid can be extended again by either normal or emergency means. With the aircraft on jacks, the EMER LG PULL handle is moved from EMER DOWN and is engaged with the LDG GEAR handle. This seats the emergency release valve and opens the pneumatic extension lines to the atmosphere through the OVBD port of the release valve. Most of the pressurized nitrogen in the lines then flows back through the emergency release valve and is discharged overboard. The reset buttons on the dump valves are then manually pressed, resetting the dump valves to their normal position. In the normal position, the selector valves are connected to the landing gear and tail skid lines.




Figure 12-10 — Emergency landing gear extension system.

### JET BLAST DEFLECTORS

Jet blast deflectors (JBDs) onboard aircraft carriers are raised and lowered by hydraulic cylinders through mechanical linkage. Two hydraulic cylinders are attached to each JBD panel shaft by crank assemblies (Figure 12-11). The shaft is rotated by the push and pull operation of the hydraulic cylinders. Shaft rotation extends or retracts the linkage to raise or lower the JBD panels. This operation is designed so that in the event of a failure of one of the hydraulic cylinders, the other one will raise or lower the panels.

Hydraulic fluid from the catapult hydraulic supply system is supplied to the JBD hydraulic system through an isolation valve and a filter to the fourway control valve (stack valve) assembly (Figure 12-12).

The four-way control valve assembly consists of the following:

- Pilot-operated pilot valve—small valve that controls a limited flow of fluid and is often used in critical applications such as emergency or safety controls
- Solenoid-operated pilot valve electromechanically operated valve controlled by an electrical current (110 volts) through a solenoid
- Sequence valve—used to control the sequence of two or more hydraulic actuators




Figure 12-11 — Operating gear assembly (panels raised).




Figure 12-12 — Four-way control valve (stack valve).

All three valves are secured together to conserve space and simplify connection to a subplate or manifold as shown in *Figure 12-12*. One stack valve controls fluid flow for a pair of panel assemblies. Three stack valves are required for Mk 7 Mod 0/2 and two stack valves for Mk 7 Mod 1 JBDs. Hydraulic fluid at 2,500 psi from the associated catapult is supplied to the stack valve, with all fluid return lines going to that catapult gravity tank.

With hydraulic fluid at normal operating pressure and neither solenoid B (raise) nor solenoid A (lower) energized, fluid flows through the sequence valve and pilot valve to both sides of the slide in the main valve. This pressure to both sides of the slide keeps it centered and blocks fluid flow into and out of both ends of the hydraulic cylinders.



Electrical shock can cause injury or death. Verify that power is off by using an electrical power indicator device such as a voltmeter prior to performing any work.

#### **JBD Raising Operation**

When a raise switch is actuated (*Figure 12-13*), solenoid B in the pilot valve energizes, shifting the spool and directing pressure to a pilot port at the main valve slide. The slide shifts and directs fluid to port A of both hydraulic cylinders. The hydraulic cylinder pistons extend, pushing the crank assembly of the operating gear aft and rotating the shaft. Rotation of the shaft extends the operating gear linkage and raises the associated panel assemblies. During the raise cycle, fluid in the cylinder lower port B vents to the gravity tank through the main valve. If the raise switch is released during the raise cycle, solenoid B de-energizes, a spring returns the solenoid spool to the centered position, and panel movement will stop.

#### NOTE

Switches on the control panel, auxiliary panel, and portable panel assembly (chest pack) are momentary-contact "dead man" switches. They must be pressed until the panels are fully raised or fully lowered.




Figure 12-13 — Hydraulic fluid flow (rising).

## **JBD Lowering Operation**

When a lower switch is actuated (*Figure 12-14*), solenoid A in the pilot valve energizes, shifting the spool and directing pressure to a pilot port at the main valve slide. The slide shifts in the opposite direction (from rising) and directs fluid to port B of both hydraulic cylinders. The pistons retract, pulling the crank assembly of the operating gear forward and rotating the shaft. The rotation of the shaft retracts the operating gear linkage and lowers the panels. During the lower cycle, fluid in the raise port A vents to the gravity tank through the main valve. If the lower switch is released during the lower cycle, solenoid A de-energizes, a spring returns the solenoid spool to the centered position, and panel movement will stop.

#### NOTE

Momentary contact switches light up in the down and up positions. With the JBD panels down, the DOWN light switches are GREEN. When the panels are raised, the green lights go out, and when fully raised the UP light switches turn AMBER. When the panels are lowered, the UP light switches' amber lights go out, and when fully down the DOWN light switches turn green.




Figure 12-14 — Hydraulic fluid flow (lowering).

# **APPENDIX I**

# **GLOSSARY**

**ABSOLUTE TEMPERATURE**—The temperature measured using absolute zero (-273.16 degrees Celsius or -459.69 degrees Fahrenheit) as a reference.

**ACCELERATION**—The increase in the rate or speed of an object.

**ACCUMULATOR**—A device for storing liquid under pressure. It usually consists of a chamber separated into a gas compartment and a liquid compartment by a piston or diaphragm. An accumulator also serves to smooth out pressure surges in a hydraulic system.

**ACTUATOR**—A device that converts fluid power into mechanical force and motion.

**ADDITIVE**—A chemical compound or compounds added to a fluid to change its properties.

**AIR, COMPRESSED**—Air at any pressure greater than atmospheric pressure.

**AMBIENT**—Surrounding, such as ambient air, meaning surrounding air.

**BAROMETER**—An instrument that measures atmospheric pressure.

**BAROMETER, ANEROID**—Uses the change in shape of an evacuated metal cell (aneroid) to measure variations in atmospheric pressure.

**BERNOULLI'S PRINCIPLE**—If a fluid flowing through a tube reaches a constriction, or narrowing of the tube, the velocity of the fluid flowing through the constriction increases and the pressure decreases.

**BOYLE'S LAW**—The absolute pressure of a fixed mass of gas varies inversely with the volume, provided the temperature remains constant.

**CAVITATION**—A localized gaseous condition within a liquid stream that occurs where the pressure is reduced to the vapor pressure.

**CELSIUS**—The temperature scale using the freezing point of water as zero and the boiling point as 100, with 100 equal divisions between, called degrees. This scale was formerly known as the centigrade scale.

**CENTIGRADE**—(See Celsius.)

**CENTRIFUGAL FORCE**—A force exerted on a rotating object in a direction outward from the center of rotation.

**CHARLES' LAW**—If the pressure is constant, the volume of dry gas varies directly with the absolute temperature.

**CHEMICAL CHANGE**—A change that alters the composition of the molecules of a substance.

**CIRCUIT**—An arrangement of interconnected component parts.

**CLOSED-CENTER SYSTEM**—A type of fluid power system in which fluid is pressurized any time a power pump is operated.

**COMPRESSIBILITY**—The change in volume of a unit volume of a fluid when it is subjected to a unit change of pressure.

**COMPRESSOR**—A device that converts mechanical force and motion into pneumatic fluid power.

**COMPUTER**—A device capable of accepting information, applying prescribed processes to the information, and supplying the results of these processes.

**CONDENSATION**—The change from a gaseous (or vapor) state to a liquid state.

**CONTAMINATION**—Any foreign material or substance whose presence in a fluid is capable of adversely affecting system performance or reliability.

**CONTINUITY EQUATION**—The mass rate of fluid flow into any fixed space is equal to the mass flow rate out. Therefore, the mass flow rate of fluid past all cross sections of a conduit is equal.

**CONTROL**—A device used to regulate the function of a component or system.

**CONTROL**, **CYLINDER**—A control in which a fluid cylinder is the actuating device.

**CONTROL**, **ELECTRIC**—A control actuated electrically.

**CONTROL**, **HYDRAULIC**—A control actuated by a liquid.

**CONTROL**, **MANUAL**—A control actuated by the operator.

**CONTROL, MECHANICAL**—A control actuated by linkages, gears, screws, cams, or other mechanical elements.

**CONTROL**, **PNEUMATIC**—A control actuated by air or other gas pressure.

**CONTROL**, **SERVO**—A control actuated by a feedback system that compares the output with the reference signal and makes corrections to reduce the difference.

**CONTROLS, PUMP**—Controls applied to positive-displacement variable delivery pumps to adjust their volumetric output or direction of flow.

**CONVERGENT**—That which inclines and approaches nearer together, as the inner walls of a tube that is constricted.

**COOLER**—A heat exchanger, which removes heat from a fluid.

**COOLER, AFTERCOOLER**—A device that cools a gas after it has been compressed.

**COOLER, INTERCOOLER**—A device that cools a gas between the compressive steps of a multiple stage compressor.

**COOLER, PRECOOLER**—A device that cools a gas before it is compressed.

**CORROSION**—The slow destruction of materials by chemical agents and electromechanical reactions.

**CYCLE**—A single complete operation consisting of progressive phases starting and ending at the neutral position.

**CYLINDER**—A device that converts fluid power into linear mechanical force and motion. It usually consists of a movable element, such as a piston and piston rod, plunger, or ram, operating within a cylindrical bore.

**CYLINDER, CUSHIONED**—A cylinder with a piston-assembly deceleration device at one or both ends of the stroke.

**CYLINDER, DOUBLE-ACTING**—A cylinder in which fluid force can be applied to the movable element in either direction.

**CYLINDER, DOUBLE-ROD**—A cylinder with a single piston and a piston rod extending from each end.

**CYLINDER**, **DUAL-STROKE**—A cylinder combination that provides two working strokes.

**CYLINDER, PISTON**—A cylinder in which the movable element has a greater cross-sectional area than the piston rod.

**CYLINDER, PLUNGER**—A cylinder in which the movable element has the same cross-sectional area as the piston rod.

**CYLINDER, SINGLE-ACTING**—A cylinder in which the fluid force can be applied to the movable element in only one direction.

**CYLINDER**, **SINGLE-ROD**—A cylinder with a piston rod extending from one end.

**CYLINDER, SPRING-RETURN**—A cylinder in which a spring returns the piston assembly.

**CYLINDER, TANDEM**—Two or more cylinders with interconnected piston assemblies.

**CYLINDER, TELESCOPING**—A cylinder with nested multiple tubular rod segments, which provide a long working stroke in a short retracted envelope.

**DENSITY**—The weight per unit volume of a substance.

**DIAGRAM, COMBINATION**—A drawing using a combination of graphical, cutaway, and pictorial symbols.

**DIAGRAM, CUTAWAY**—A drawing showing principal internal parts of all components, controls, and actuating mechanisms, all interconnecting lines, and functions of individual components.

**DIAGRAM, GRAPHICAL**—A drawing or drawings showing each piece of apparatus, including all interconnecting lines, by approved standard symbols.

**DIAGRAM, PICTORIAL**—A drawing showing each component in its actual shape according to the manufacturer's installation.

DIAGRAM, SCHEMATIC—See DIAGRAM, GRAPHICAL.

**DIAPHRAGM**—A dividing membrane or thin partition.

**DIFFUSER**—A duct of varying cross section designed to convert a high-speed gas flow into low-speed flow at an increased pressure.

**DISPLACEMENT**—The volume of fluid that can pass through a pump, motor, or cylinder in a single revolution or stroke.

**DIVERGENT**—Moving away from each other, as the inner wall of a tube that flares outward.

**EDUCTOR**—A jet-type pump with no moving parts that is designed to pump large volumes of water.

**EFFICIENCY**—The ratio of the output power to the input power, generally expressed as a percentage.

**ENERGY**—The ability or capacity to do work.

**EQUILIBRIUM**—A state of balance between opposing forces or actions.

**FAHRENHEIT**—The temperature scale using the freezing point of water as 32 and the boiling point as 212, with 180 equal divisions between, called degrees.

**FEEDBACK**—A transfer of energy from the output of a device to its input.

**FILTER**—A device whose primary function is the retention by a porous media of insoluble contaminants from a fluid.

**FILTER ELEMENT**—The porous device that performs the actual process of filtration.

**FILTER MEDIA**—The porous materials that perform the actual process of filtration.

**FILTER MEDIA, SURFACE**—Porous materials that primarily retain contaminants on the influent face.

**FIRE POINT**—The temperature at which a substance gives off vapor in a sufficient quantity to ignite and continue to burn when exposed to a spark or flame.

**FLASHPOINT**—The temperature to which a liquid must be heated under specified test conditions to give off sufficient vapor to form a mixture with air that can be ignited momentarily by a specified flame.

**FLOW, LAMINAR**—A flow situation in which fluid moves in parallel layers (also referred to as streamline flow).

**FLOW. METERED**—Flow at a controlled rate.

**FLOW, TURBULENT**—A flow situation in which the fluid particles move in a random manner.

**FLOW RATE**—The volume, mass, or weight of a fluid passing through any conductor per unit of time.

**FLOWMETER**—An instrument used to measure quantity or the flow rate of a fluid motion.

**FLUID**—A liquid or a gas.

**FLUID FLOW**—The stream or movement of a fluid, or the rate of its movement.

**FLUID FRICTION**—Friction due to the viscosity of fluids.

**FLUID**, **FIRE-RESISTANT**—A fluid, difficult to ignite, which shows little tendency to propagate flame.

**FLUID**, **HYDRAULIC**—A fluid suitable for use in a hydraulic system.

**FLUID**, **PETROLEUM**—A fluid composed of petroleum oil. It may contain additives.

**FLUID, PHOSPHATE ESTER BASE**—A fluid that contains a phosphate ester as one of the major components.

**FLUID, SILICONE**—A fluid composed of silicones. It may contain additives.

**FLUID, WATER-GLYCOL**—A fluid whose major constituents are water and one or more glycols or polyglycols.

**FLUID STABILITY**—Resistance of a fluid to permanent change in properties.

**FLUID POWER**—Energy transmitted and controlled through the use of fluids under pressure.

**FLUID POWER SYSTEM**—A system that transmits and controls power through use of a pressurized fluid within an enclosed circuit.

**FOAMING**—An emulsion of gas bubbles in a fluid. Foaming in a hydraulic system results from compressed gases in the hydraulic fluid.

**FOOT-POUND**—The amount of work accomplished when a force of 1 pound produces a displacement of 1 foot.

**FORCE**—The action of one body on another tending to change the state of motion of the body acted upon.

**FREE FLOW**—Flow that encounters negligible resistance.

**FRICTION**—The action of one body or substance rubbing against another, such as fluid flowing against the walls of pipe; the resistance to motion caused by this rubbing.

**FRICTION PRESSURE DROP**—The decrease in the pressure of a fluid flowing through a passage attributable to the friction between the fluid and the passage walls.

**GAS**—The form of matter that has neither a definite shape nor a definite volume.

**GASKET**—A class of seals that provides a seal between two stationary parts.

**GAUGE**—An instrument or device for measuring, indicating, or comparing a physical characteristic.

**GAUGE PRESSURE**—Pressure above atmospheric pressure.

**GAUGE SNUBBER**—A device installed in the line to the pressure gauge used to dampen pressure surges and thus provide a steady reading and protection for the gauge.

**GAUGE**, **BELLOWS**—A gauge in which the sensing element is a convoluted closed cylinder. A pressure differential between the outside and the inside causes the cylinder to expand or contract axially.

**GAUGE**, **BOURDON TUBE**—A pressure gauge in which the sensing element is a curved tube that tends to straighten out when subjected to internal fluid pressure.

**GAUGE**, **DIAPHRAGM**—A gauge in which the sensing element is relatively thin and its inner portion is free to deflect with respect to its periphery.

**GAUGE**, **PRESSURE**—A gauge that indicates the pressure in the system to which it is connected.

**GAUGE, VACUUM**—A pressure gauge for pressures less than atmospheric.

**GRAVITY**—The force that tends to draw all bodies toward the center of the earth. The weight of a body is the resultant of gravitational force acting on the body.

**HEAD**—The height of a column or body of fluid above a given point expressed in linear units. Head is often used to indicate gauge pressure. Pressure is equal to the height times the density of the fluid.

**HEAD, FRICTION**—The head required to overcome the friction at the interior surface of a conductor and between fluid particles in motion. It varies with flow, size, type, and condition of conductors and fittings, and fluid characteristics.

**HEAD, STATIC**—The height of a column or body of fluid above a given point.

**HEAD, VELOCITY**—The equivalent head through which the liquid would have to fall to attain a given velocity. Mathematically it is equal to the square of the velocity (in feet) divided by 64.4 feet per second squared.

**HEAT EXCHANGER**—A device that transfers heat through a conducting wall from one fluid to another.

**HYDRAULICS**—Engineering science pertaining to liquid pressure and flow.

**HYDRAULIC POWER DRIVE SYSTEM**—Typically consists of an outside power source, hydraulic pump, hydraulic motor, control signal, and mechanical shafting and gearing.

**HYDROMETER**—An instrument for determining the specific gravities of liquids.

**HYDROPNEUMATICS**—Pertaining to the combination of hydraulic and pneumatic fluid power.

**HYDROSTATICS**—Engineering science pertaining to the energy of liquids at rest.

**IMPACT PRESSURE**—The pressure of a moving fluid brought to rest that is in excess of the pressure the fluid has when it does not flow; that is, total pressure less static pressure. Impact pressure is equal to dynamic pressure in incompressible flow; but in compressible flow, impact pressure includes the pressure change owing to the compressibility effect.

**IMPINGEMENT**—The striking or dashing upon with a clash or sharp collision, as air impinging upon the rotor of a turbine or motor.

**IMPULSE TURBINE**—A turbine driven by a fluid at high velocity under relatively low pressure.

**INERTIA**—The tendency of a body at rest to remain at rest, and a body in motion to continue to move at a constant speed along a straight line, unless the body is acted upon in either case by an unbalanced force.

**INHIBITOR**—Any substance that slows or prevents chemical reactions such as corrosion or oxidation.

**INVERSE PROPORTION**—The relation that exists between two quantities when an increase in one of them produces a corresponding decrease in the other.

**KELVIN SCALE**—The temperature scale using absolute zero as the zero point and divisions that are the same size as centigrade degrees.

**KINETIC ENERGY**—The energy that a substance has while it is in motion.

**KINETIC THEORY**—A theory of matter that assumes that the molecules of matter are in constant motion.

**LINE**—A tube, pipe, or hose that is used as a conductor of fluid.

**LIQUID**—A form of matter that has a definite volume but takes the shape of its container.

**LOAD**—The power that is being delivered by any power-producing device. Also, the equipment that uses the power from the power-producing device.

**LUBRICATOR**—A device that adds controlled or metered amounts of lubricant into a fluid power system.

**MANIFOLD**—A type of fluid conductor that provides multiple connections ports.

**MANOMETER**—A differential pressure gauge in which pressure is indicated by the height of a liquid column of known density. Pressure is equal to the difference in vertical height between two connected columns multiplied by the density of the manometer liquid. Some forms of manometers are U-tube, inclined tube, well, and bell types.

**MATTER**—Any substance that occupies space and has weight.

**MECHANICAL ADVANTAGE**—The ratio of the resisting weight to the acting force. The ratio of the distance through which the force is exerted divided by the distance the weight is raised.

**METER-IN**—To regulate the amount of fluid into a system or an actuator.

**METER-OUT**—To regulate the flow of fluid from a system or actuator.

MICRON—A millionth of a meter or about 0.00004 inch.

**MOLECULE**—A small natural particle of matter composed of two or more atoms.

**MOTOR**—A device that converts fluid power into mechanical force and motion. It usually provides rotary mechanical motion.

**MOTOR, FIXED-DISPLACEMENT**—A motor in which the displacement per unit of output motion cannot be varied.

**MOTOR**, **LINEAR**—(See Cylinder.)

**MOTOR, ROTARY**—A motor capable of continuous rotary motion.

**MOTOR, ROTARY LIMITED**—A rotary motor having limited motion.

**MOTOR, VARIABLE-DISPLACEMENT**— A motor in which the displacement per unit of output motion can be varied.

**NEOPRENE**—A synthetic rubber highly resistant to oil, light, heat, and oxidation.

**NEUTRALIZATION NUMBER**—A measure of the total acidity or basicity of an oil; this includes organic or inorganic acids or bases or a combination of them.

**OPEN-CENTER SYSTEM**—A type of fluid power system that circulates fluid from a reservoir, through selector valves, and then back to a reservoir.

**OXIDATION**—The process by which oxygen unites with some other substance, causing rust or corrosion.

**PACKING**—A class of seal that is used to provide a seal between two parts of a unit that move in relation to each other.

**PASCAL'S LAW**—A pressure applied to a confined fluid at rest is transmitted with equal intensity throughout the fluid.

**PERIPHERY**—The outside surface, especially that of a rounded object or body.

**PIPE**—A type of fluid line whose dimensions are designated by nominal (approximate) inside diameter and wall thickness.

**PNEUMATICS**—Engineering science pertaining to gaseous pressure and flow.

**PORT**—An internal or external terminus of a passage in a component.

**POTENTIAL ENERGY**—The energy a substance has because of its position, its condition, or its chemical composition.

**POUR POINT**—The lowest temperature at which a liquid will flow under specified conditions.

**POWER UNIT**—A combination of pump, pump drive, reservoir, controls, and conditioning components that may be required for the unit's application.

**POWER**—The rate of doing work or the rate of expanding energy.

**PRESSURE**—The amount of force distributed over each unit of area, usually expressed in pounds per square inch.

**PRESSURE**, **ABSOLUTE**—The sum of atmospheric and gauge pressures.

**PRESSURE**, **ATMOSPHERIC**—Pressure exerted by the atmosphere at any specific location.

**PRESSURE**, **BACK**—The pressure encountered on the return side of a system.

**PRESSURE**, **DIFFERENTIAL**—The difference in pressure between any two points of a system or a component.

**PRESSURE**, **HEAD**—The pressure due to the height of a column or body of fluid. It is usually expressed in feet.

**PRESSURE, OPERATING**—The pressure at which a system operates.

**PRESSURE**, **PRECHARGE**—The pressure of compressed gas in an accumulator prior to the admission of a liquid.

**PRESSURE**, **PROOF**—The nondestructive test pressure in excess of the maximum rated operating pressure.

**PRESSURE, STATIC**—The pressure in a fluid at rest.

PRESSURE SWITCH—An electrical switch operated by the increase or decrease of fluid pressure.

**PRIME MOVER**—The source of mechanical power used to drive the pump or compressor.

**PUMP**—A device that converts mechanical force and motion into hydraulic fluid power.

**RANKINE SCALE**—A thermometer scale based on absolute zero of the Fahrenheit scale, in which the freezing point of water is approximately 492 degrees Rankine (°R).

**RATIO**—The value obtained by dividing one number by another, indicating their relative proportions.

**RECEIVER**—A container in which gas is stored under pressure as a supply source for pneumatic power.

**RECIPROCATING**—Moving back and forth, as in a piston reciprocating in a cylinder.

**RESERVOIR**—A container for storage of liquid in a fluid power system.

**RESPONSE TIME**—The time lag between a signal input and the resulting change of output.

**RESTRICTOR**—A device that reduces the cross-sectional flow area.

**RESTRICTOR, ORIFICE**—A restrictor, the length of which is relatively small with respect to its cross-sectional area. The orifice may be fixed or variable. Variable types are non-compensated, pressure compensated, or pressure and temperature compensated.

**RETURN LINE**—A line used for returning fluid back into the reservoir or atmosphere.

**SEPARATOR**—A device whose primary function is to isolate undesirable fluids and or contaminants by physical properties other than size.

**SERVO**—A device used to convert a small movement into a greater movement of force.

**SOLID**—The form of matter that has a definite shape and a definite volume.

**SPECIFIC GRAVITY**—The ratio of the weight of a given volume of a substance to the weight of an equal volume of some standard substance.

**STEADY FLOW**—A flow in which the velocity, pressure, and temperature at any point in the fluid do not vary with time.

**STRAINER**—A coarse filter.

**STUFFING BOX**—A cavity and closure with manual adjustment for a sealing device.

**SUPPLY LINE**—A line that conveys fluid from the reservoir to the pump.

**SURGE**—A momentary rise of pressure in a circuit.

**SYNCHRONIZE**—To make two or more events or operations occur at the proper time with respect to each other.

**SYNTHETIC MATERIAL**—A complex chemical compound that is artificially formed by the combining of two or more simpler compounds or elements.

**TANK**—A container for the storage of fluid in a fluid power system.

**THEORY**—A scientific explanation, tested by observations and experiments.

**THERMAL EXPANSION**—The increase in volume of a substance due to temperature change.

**TORQUE**—A force or combination of forces that produces or tends to produce a twisting or rotary motion.

**TOXICITY**—The quality, state, or degree of being toxic or poisonous. Some liquids contain chemicals that are a serious hazard.

**TUBING**—A type of fluid line whose dimensions are designated by actual measured outside diameter and by actual measured wall thickness.

**TURBINE**—A rotary motor actuated by the reaction, impulse, or both, of a flow of pressurized fluid.

**VALVE**—A device that controls fluid flow direction, pressure, or flow rate.

**VELOCITY**—The rate of motion in a particular direction. The velocity of fluids is usually expressed in feet per second.

**VENTURI**—A tube having a narrowing throat or constriction to increase the velocity of fluid flowing through it. The flow through the venturi causes a pressure drop in the smallest section, the amount being a function of the velocity of flow.

**VISCOSITY**—A measure of the internal friction or resistance of a fluid to flow.

**VISCOSITY INDEX**—A measure of the viscosity-temperature characteristics of a fluid as referred to that of two arbitrary reference fluids.

**VISCOSITY, SAYBOLT UNIVERSAL SECONDS (SUS)**—The time in seconds for 60 milliliters of oil to flow through a standard orifice at a given temperature.

**VISCOSITY, KINEMATIC**—The absolute viscosity divided by the density of the fluid. It is usually expressed in centistokes.

**VOLUME OF FLOW**—The quantity of fluid that passes a certain point in a unit of time. The volume of flow is usually expressed in gallons per minute for liquids and cubic feet per minute for gases.

**WORK**—The transference of energy from one body or system to another. That which is accomplished by a force acting through a distance.

# **APPENDIX II**

# REFERENCES

#### NOTE

Although the following references were current when this NRTC was published, their continued currency cannot be assured. When consulting these references, keep in mind that they may have been revised to reflect new technology or revised methods, practices, or procedures; therefore, you need to ensure that you are studying the latest references.

If you find an incorrect or obsolete reference, please use the Rate Training Manual User Update Form provided at the end of each chapter to contact the SWOS Rate Training Manager.

### Chapter 1

*Airman*, NAVEDTRA 14014A, Center for Naval Aviation Technical Training (CNATT), Pensacola, FL, December 2012.

Construction Mechanic Basic, NAVEDTRA 14264A, Center for Seabees and Facilities Engineering (CSFE), Port Hueneme, CA, October 2010.

*Machinist's Mate (Surface)*, NAVEDTRA 14150A, Surface Warfare Officers School (SWOS), Newport, RI, September 2013.

### Chapter 2

*Airman*, NAVEDTRA 14014A, Center for Naval Aviation Technical Training (CNATT), Pensacola, FL, December 2012.

Aviation Structural Mechanic, NAVEDTRA 14315A, Center for Naval Aviation Technical Training (CNATT), Pensacola, FL, March 2011.

Construction Mechanic Basic, NAVEDTRA 14264A, Center for Seabees and Facilities Engineering (CSFE), Port Hueneme, CA, October 2010.

"Hydraulic Equipment (Power Transmission and Control)," *Naval Ships' Technical Manual (NSTM)*, Chapter 556, Naval Sea Systems Command (NAVSEA), Washington, DC, December 2012.

## **Chapter 3**

"Afloat Hazardous Material Control and Management Guidelines Hazardous Material Users Guide (HMUG)," *Naval Ships' Technical Manual (NSTM)*, Chapter 670, Volume 2, Naval Sea Systems Command, Washington, DC, June 2012.

*Aviation Hydraulics Manual*, NAVAIR 01-1A-17, Commander, Naval Air Systems Command, Patuxent River, MD, August 2008.

*Environmental Readiness Program*, OPNAVINST 5090.1(series), Chief of Naval Operations, Washington, DC, 10 January 2014.

"Gaskets and Packing," *Naval Ships' Technical Manual (NSTM)*, Chapter 078, Volume 2, Naval Sea Systems Command (NAVSEA), Washington, DC, September 1998.

"Hydraulic Equipment (Power Transmission and Control)," *Naval Ships' Technical Manual (NSTM*), Chapter 556, Naval Sea Systems Command (NAVSEA), Washington, DC, December 2012.

Navy Safety and Occupational Health (SOH) Program Manual for Forces Afloat, OPNAVINST 5100.19(series), Volume 1, Chief of Naval Operations, Washington, DC, May 2007.

#### **Chapter 4**

*Engineman*, NAVEDTRA 14075A, Surface Warfare Officers School (SWOS), Newport, RI, September 2013.

*Machinist's Mate (Surface)*, NAVEDTRA 14150A, Surface Warfare Officers School (SWOS), Newport, RI, September 2013.

"Pumps," *Naval Ships' Technical Manual (NSTM)*, Chapter 503, Naval Sea Systems Command (NAVSEA), Washington, DC, January 2009.

#### **Chapter 5**

Aviation Hydraulics Manual, NAVAIR 01-1A-17, Naval Air Systems Command, Patuxent River, MD, August 2008.

Aviation Structural Mechanic, NAVEDTRA 14315A, Center for Naval Aviation Technical Training (CNATT), Pensacola, FL, March 2011.

Hull Maintenance Technician, NAVEDTRA 14119, Surface Warfare Officers School (SWOS), Newport, RI, June 1995.

"Piping Systems," *Naval Ships' Technical Manual (NSTM)*, Chapter 505, Naval Sea Systems Command (NAVSEA), Washington, DC, April 2013.

#### **Chapter 6**

*Machinist's Mate (Surface)*, NAVEDTRA 14150A, Surface Warfare Officers School (SWOS), Newport, RI, September 2013.

"Piping Systems," *Naval Ships' Technical Manual (NSTM*), Chapter 505, Naval Sea Systems Command (NAVSEA), Washington, DC, April 2013.

"Pressure, Temperature and other Mechanical and Electromechanical Measuring Instruments," *Naval Ships' Technical Manual (NSTM)*, Chapter 504, Naval Sea Systems Command (NAVSEA), Washington, DC, September 2012.

## Chapter 7

Construction Mechanic Basic, NAVEDTRA 14264A, Center for Seabees and Facility Engineering (CSFE), Port Hueneme, CA, October 2010.

"Gaskets and Packing," *Naval Ships' Technical Manual (NSTM*), Chapter 078, Volume 2, Naval Sea Systems Command (NAVSEA), Washington, DC, September 1998.

"Hydraulic Equipment (Power and Transmission Control)," *Naval Ships' Technical Manual (NSTM*), Chapter 556, Naval Sea Systems Command (NAVSEA), Washington, DC, December 2012.

*Machinist's Mate (Surface)*, NAVEDTRA 14150A, Surface Warfare Officers School (SWOS), Newport, RI, September 2013.

#### **Chapter 8**

Aviation Structural Mechanic, NAVEDTRA 14315A, Center for Naval Aviation Technical Training (CNATT), Pensacola, FL, March 2011.

*Machinist's Mate (Surface)*, NAVEDTRA 14150A, Surface Warfare Officers School (SWOS), Newport, RI, September 2013.

"Pressure, Temperature and other Mechanical and Electromechanical Measuring Instruments," *Naval Ships' Technical Manual (NSTM)*, Chapter 504, Naval Sea Systems Command (NAVSEA), Washington, DC, September 2012.

#### **Chapter 9**

Aviation Hydraulics Manual, NAVAIR 01-1A-17, Commander, Naval Air Systems Command (NAVAIR), Patuxent River, MD, August 2008.

Aviation Structural Mechanic, NAVEDTRA 14315A, Center for Naval Aviation Technical Training (CNATT), Pensacola, FL, March 2011.

"Hydraulic Equipment (Power Transmission and Control)," *Naval Ships' Technical Manual (NSTM)*, Chapter 556, Naval Sea Systems Command (NAVSEA), Washington, DC, December 2012.

#### Chapter 10

*Airman*, NAVEDTRA 14014A, Center for Naval Aviation Technical Training (CNATT), Pensacola, FL, December 2012.

Construction Mechanic Basic, NAVEDTRA 14264A, Center for Seabees and Facility Engineering (CSFE), Port Hueneme, CA, October 2010.

"Hydraulic Equipment (Power Transmission and Control)," *Naval Ships' Technical Manual (NSTM)*, Chapter 556, Naval Sea Systems Command, (NAVSEA), Washington, DC, December 2012.

#### **Chapter 11**

Aviation Structural Mechanic, NAVEDTRA 14315A, Center for Naval Aviation Technical Training (CNATT), Pensacola, FL, March 2011.

*Machinist's Mate* (*Surface*), NAVEDTRA 14150A, Surface Warfare Officers School (SWOS), September 2013.

"Pressure, Temperature and other Mechanical and Electromechanical Measuring Instruments," *Naval Ships' Technical Manual (NSTM)*, Chapter 504, Naval Sea Systems Command (NAVSEA), Washington, DC, September 2012.

#### Chapter 12

"Afloat Hazardous Material Control and Management Guidelines Hazardous Materials Users Guide (HMUG)," *Naval Ships' Technical Manual (NSTM)*, Chapter 670, Volume 2, Naval Sea Systems Command (NAVSEA), Washington, DC, June 2012.

Aviation Structural Mechanic, NAVEDTRA 14315A, Center for Naval Aviation Technical Training (CNATT), Pensacola, FL, March 2011.

Engineering Drawing and Related Documentation Practices, ASME Y14.100, The American Society of Mechanical Engineers (ASME), 22 Law Drive, P O, Box 2900, Fairfield, NJ 07007-2900.

"Hydraulic Equipment (Power Transmission and Control)," *Naval Ships' Technical Manual (NSTM)*, Chapter 556, Naval Sea Systems Command (NAVSEA), Washington, DC, December 2012.

Navy Blueprint Reading and Sketching, NAVEDTRA 14040, Surface Warfare Officers School (SWOS), Newport, RI, October 2003.

Navy Safety and Occupational Health (SOH) Program Manual for Forces Afloat, OPNAVINST 5100.19(series), Volume 1, Chief of Naval Operations, Washington, DC, May 2007.

"Propulsion Reduction Gears, Couplings, Clutches, and Associated Components," Naval Ships' Technical Manual (NSTM), Chapter 241, Naval Sea Systems Command (NAVSEA), Washington, DC, March 2012.

Ships' Maintenance and Material Management (3-M) Manual, NAVSEAINST 4790.8C, Naval Sea Systems Command (NAVSEA), Washington, DC, 14 March 2013.

Ships' Maintenance and Material Management (3-M) System Policy, Chief of Naval Operations, Washington, DC, 31 October 2007.

# **APPENDIX III**

# **GRAPHIC SYMBOLS FOR FLUID POWER DIAGRAMS**

Fluid Connectors	Lines, Joining		
Line, Working (Main)	<del></del>		
Line, Pilot (for Control)	or		
Line, Exhaust and Liquid Drain			
Flow, Direction of (Hydraulic)	l		
Line Flevible	Energy Storage & Fluid Storage		
Line, Flexible	Reservoir Vented		
<b>Quick Disconnect Without Checks</b>			
Connected	Pressurized		
Disconnected			
$\longrightarrow \vdash \longleftarrow$	Above Fluid Level		
Line, with			
Fixed Restriction  ———————————————————————————————————	Accumulator		
Lines, Crossing	'		
$\rightarrow$ or $\times$	Accumulator, Spring Loaded		

Figure AllI-1 — Fluid power graphic symbols.




Figure AllI-1 — Fluid power graphic symbols (continued).




Figure AllI-1 — Fluid power graphic symbols (continued).




Figure AllI-1 — Fluid power graphic symbols (continued).






Figure AllI-1 — Fluid power graphic symbols (continued).

# Servovalve, Variable Position (Indicated by Parallel lines)




**Four Way Valves** 


**Two Position** 




**Three Position** 




**Actuated Left** 



**Actuated Right** 



#### Typical Flow Paths for Center Condition of Three Position Valves



**Flow Control Valves** 

Adjustable, Non Compensated (Flow Control in Each Direction)



Adjustable, Temperature & Pressure Compensated




Figure AllI-1 — Fluid power graphic symbols (continued).